

# LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
R2	DASHBOARD/LEFT REAR CONNECTION
R3	DASHBOARD/DRIVER'S DOOR CONNECTION
R4	DASHBOARD/PASSENGER'S DOOR CONNECTION
R13	LEFT REAR/LEFT-HAND REAR DOOR CONNECTION
R20	ENGINE/IGNITION
R24	ENGINE/INJECTION CONNECTION
R37	ENGINE/INJECTION CONNECTION
R67	FRONT OF ENGINE/ENGINE CONNECTION
R99	DASHBOARD/HEATING CONNECTION
R106	FRONT OF ENGINE/BUMPER CONNECTION
R107	DASHBOARD/FRONT OF ENGINE CONNECTION
R243	RIGHT-HAND REAR DOOR/REAR LEFT-HAND WIRING CONNECTION
R244	LEFT-HAND REAR/LUGGAGE COMPARTMENT LID CONNECTION
R301	DASHBOARD/COURTESY LIGHT CONNECTION
R319	REAR/REAR BUMPER CONNECTION
R339	ROOF / SUNROOF
R348	REAR / DISCHARGE LAMP
R359	RIGHT-HAND REAR LIGHT /TOWING CONNECTION
R360	LEFT-HAND REAR LIGHT /TOWING CONNECTION
R374	REAR LEFT-HAND WIRING / FRONT WIRING HARNESS CONNECTION
R376	FRONT RIGHT-HAND SEAT CONNECTION
R377	FRONT LEFT-HAND SEAT CONNECTION
R423	REAR LEFT-HAND WIRING / DASHBOARD WIRING CONNECTION 2
R444	PASSENGER COMPARTMENT HEATING WIRING 1 / FRONT WIRING CONNECTION
R655	STEERING COLUMN SWITCH/CRUISE CONTROL CONNECTION
R999	CONNECTION USED FOR TEST