

# LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
101	CIGARETTE LIGHTER
103	ALTERNATOR
104	STARTING SWITCH
105	MAIN ELECTROMAGNETIC HORN
107	BATTERY
119	AUTOMATIC TRANSMISSION COMPUTER
120	INJECTION COMPUTER
129	GEAR SELECTOR CONTROL
130	REAR RIGHT-HAND ELECTRIC WINDOW CONTROL
131	REAR LEFT-HAND ELECTRIC WINDOW CONTROL
133	PASSENGER'S SIDE ELECTRIC WINDOW CONTROL
138	REAR RIGHT DOOR ELECTRIC LOCKING
139	REAR LEFT DOOR ELECTRIC LOCKING
140	DRIVER'S DOOR ELECTRIC LOCKING
141	CENTRAL LOCKING FOR PASSENGER DOOR
146	PINKING SENSOR 1
147	MANIFOLD PRESSURE SENSOR
149	TDC SENSOR
150	RIGHT REAR WHEEL SENSOR
151	LEFT REAR WHEEL SENSOR
152	RIGHT FRONT WHEEL SENSOR
153	LEFT FRONT WHEEL SENSOR
156	HANDBRAKE SWITCH
160	BRAKE SWITCH
163	STARTER
164	COLD AIR BLOWER
166	RIGHT-HAND REGISTRATION PLATE LIGHTING
167	LEFT-HAND REGISTRATION PLATE LIGHTING
168	GLOVE COMPARTMENT LIGHT
171	AIR CONDITIONING CLUTCH
172	RIGHT REAR LIGHT
173	LEFT REAR LIGHT
176	RIGHT FRONT FOGLIGHT
177	LEFT FRONT FOGLIGHT
188	COOLING FAN UNIT
189	RIGHT REAR SPEAKER
190	LEFT REAR SPEAKER
193	INJECTOR 1
194	INJECTOR 2
195	INJECTOR 3
196	INJECTOR 4
200	REAR SCREEN DE-ICING
201	REAR RIGHT-HAND WINDOW MOTOR
202	REAR LEFT-HAND WINDOW MOTOR
204	PASSENGER ELECTRIC WINDOW MOTOR
205	PRESSURE SWITCH
207	BRAKE FLUID MIN LEVEL SENSOR
212	WINDSCREEN WIPER MOTOR
213	FRONT COURTESY LIGHT
219	HEADLIGHT WASHER PUMP
221	WINDSCREEN WASHER PUMP
225	DIAGNOSTIC SOCKET
226	RIGHT-HAND HEADLIGHT

# LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
227	LEFT-HAND HEADLIGHT
229	HORN RELAY
234	FAN ASSEMBLY RELAY
235	HEATED REAR SCREEN RELAY
239	DRIVER'S ELECTRIC REAR-VIEW MIRROR
240	PASSENGER ELECTRIC REAR-VIEW MIRROR
242	DOWNSTREAM OXYGEN SENSOR
243	OIL LEVEL SENSOR
244	WATER INJECTION TEMPERATURE SENSOR
247	INSTRUMENT PANEL
260	PASSENGER COMPARTMENT FUSE BOX AND RELAY
261	RADIO
272	INJECTION AIR TEMPERATURE SENSOR
283	ADDITIONAL FUEL PUMP
300	REAR CROSSMEMBER COURTESY LIGHT
303	AUTOMATIC TRANSMISSION SELECTOR LIGHT
304	SUNROOF
317	SUNROOF CONTROL
319	AIR CONDITIONING CONTROL PANEL
325	RADIO SATELLITE CONTROL
331	CRUISE CONTROL SWITCH
365	RIGHT-HAND TWEETER SPEAKER
366	LEFT-HAND FRONT TWEETER SPEAKER
369	TURBO BEARING COOLANT PUMP
371	PETROL VAPOUR ABSORBER
408	EVAPORATOR SENSOR
414	WATER IN DIESEL SENSOR
419	AIR CONDITIONING CONTROL UNIT
436	TURBO PRESSURE SOLENOID VALVE
438	BONNET SWITCH
449	DIESEL FUEL HEATER RESISTOR
475	RECYCLING MOTOR
485	MULTIFUNCTION SWITCH
509	LEFT-HAND LUGGAGE COMPARTMENT LIGHT
523	DRIVER'S DOOR LIGHT
524	FRONT PASSENGER DOOR LIGHT
537	LEFT HEADLIGHT CORRECTOR MOTOR
538	RIGHT HEADLIGHT CORRECTOR MOTOR
541	COURTESY MIRROR LIGHT
560	TAILGATE OPENING CONTROL
588	DRIVER'S COURTESY MIRROR LIGHT
597	ENGINE AND RELAY FUSE BOX
602	REVERSING LIGHTS RELAY
615	DRIVER'S HEATED SEAT CONTROL
616	PASSENGER'S HEATED SEAT CONTROL
639	RAISED BRAKE LIGHT
645	PASSENGER COMPARTMENT COMPUTER
653	CLOCK/EXTERNAL TEMPERATURE/CARPHONE DISPLAY ASSEMBLY
662	NAVIGATION COMPUTER
675	CLUTCH PEDAL SWITCH
689	CRUISE CONTROL AND AIR BAG SWITCH
703	ELECTRIC WINDOW RELAY
710	UNIT FUSE

# LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
713	CARAVAN CONNECTION
750	CHILD SAFETY RELAY
754	HYDRAULIC ELECTRIC INTERFACE
756	AIR BAG/PRETENSIONER COMPUTER
777	POWER SUPPLY FUSE BOARD
783	POWER RELAY UNIT 2
789	HANDS-FREE MOBILE PHONE MICROPHONE
799	INJECTION AIR FLOW METER
833	FUEL PUMP AND SENDER UNIT
844	FUEL FILLER FLAP LOCKING MOTOR
861	PASSENGER AIR BAG
877	RH MIXER MOTOR
878	LH MIXER MOTOR
887	UPSTREAM OXYGEN SENSOR
899	DRIVER'S AIR BAG
921	ACCELERATOR POTENTIOMETER
953	WHEEL SPEED COMPUTER
979	OIL VAPOUR RECIRCULATION HOSE REHEATER
989	DISCHARGE BULB COMPUTER
1013	VARIABLE CAMSHAFT
1014	ENGINE COOLING LOW SPEED FAN RESISTANCE
1023	AIR CONDITIONING FAN OUTPUT MODULE
1067	ADDITIONAL HEATING RELAY 1
1068	ADDITIONAL HEATING RELAY 2
1071	TURBOCHARGING PRESSURE SENSOR
1076	MOTORISED THROTTLE BODY
1077	CYLINDER 1 PENCIL COIL
1078	CYLINDER 2 PENCIL COIL
1079	CYLINDER 3 PENCIL COIL
1080	CYLINDER 4 PENCIL COIL 4
1081	CRUISE CONTROL LIMITER START STOP CONTROL
1082	KEYLESS VEHICLE CARD READER
1083	KEYLESS VEHICLE FRONT RIGHT HANDLE PRESENCE DETECTOR
1084	KEYLESS VEHICLE FRONT LEFT HANDLE PRESENCE DETECTOR
1085	KEYLESS VEHICLE REAR RIGHT HANDLE PRESENCE DETECTOR
1086	KEYLESS VEHICLE REAR LEFT HANDLE PRESENCE DETECTOR
1087	KEYLESS VEHICLE ENGINE STOP/START CONTROL BUTTON
1088	STEERING COLUMN ELECTRIC LOCK
1094	ANTI-LOCK BRAKING SYSTEM AND/OR ELECTRONIC STABILITY PROGRAM COMPUTER
1106	ESP ON/OFF BUTTON
1107	CLUSTER SENSOR (YAW AND ACCELERATION SPEED)
1109	MANUAL GEARBOX NEUTRAL SENSOR/REVERSING LIGHTS
1112	AIR TOXICITY SENSOR
1113	ADDITIONAL PASSENGER COMPARTMENT HEATING
1115	WEIGHT DISTRIBUTION MOTOR
1122	DRIVER'S DOOR MULTIPLEX COMPUTER
1132	RIGHT-HAND REAR TWEETER SPEAKER
1133	LEFT-HAND REAR TWEETER SPEAKER
1140	GEARBOX OUTPUT SPEED SENSOR
1144	BATTERY DISCONNECTION MODULE
1156	PASSENGER COMPARTMENT FAN ASSEMBLY 1
1202	COOLANT GAS PRESSURE SENSOR
1208	RADIO AERIAL

# LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
1218	PARKING AID LEFT-HAND REAR OUTER DETECTION SENSOR
1219	PARKING AID REAR OUTER DETECTION SENSOR
1220	PARKING AID REAR INNER DETECTION SENSOR
1221	PARKING AID LEFT-HAND REAR INNER DETECTION SENSOR
1222	PARKING AID COMPUTER
1223	PARKING AID BUZZER
1232	ELECTRIC POWER ASSISTED STEERING SYSTEM
1249	DRIVER'S ADAPTIVE FRONT AIR BAG
1265	CAMSHAFT INLET SENSOR
1284	RIGHT-HAND BOOT LID LIGHT
1285	LEFT-HAND BOOT LID LIGHT
1322	TAILGATE LOCK
1337	SWITCHING PROTECTION UNIT
1340	INTERNAL REARVIEW MIRROR
1372	REAR HEIGHT SENSOR
1373	FRONT HEIGHT SENSOR
1374	DRIVER'S DOOR HANDS-FREE CARD DETECTION AERIAL
1375	PASSENGER FRONT DOOR HANDS-FREE CARD DETECTION AERIAL
1382	SECOND ROW ACCESSORIES INPUT
1385	STEERING WHEEL WARNING CONTROL
1390	HEADLIGHT ADJUSTMENT RHEOSTAT SWITCH
1391	CENTRAL LOCKING / HAZARD WARNING LIGHTS SWITCH
1396	FRONT INTERIOR HANDS-FREE CARD DETECTION AERIAL
1397	REAR INTERIOR HANDS-FREE CARD DETECTION AERIAL
1398	CENTRAL INTERIOR HANDS-FREE CARD DETECTION AERIAL
1415	RAIN / LIGHT SENSOR
1423	LEFT-HAND COURTESY LIGHT SWITCH
1424	RIGHT-HAND COURTESY LIGHT SWITCH
1440	PARKING AID SWITCH
1515	FUEL FLAP CONTROL
1519	UNDER STEERING WHEEL CONTROLS
1531	PASSENGER COMPARTMENT FUSE AND RELAY BOX 2
1551	GPS NAVIGATION AERIAL
1559	REVERSE GEAR BUZZER INHIBITION SWITCH
1584	REAR HANDS-FREE CARD DETECTION AERIAL 2
1597	DRIVER'S SIDE FRONT SPEAKER
1598	PASSENGER SIDE FRONT SPEAKER
1601	SEAT BELT WARNING MODULE
1603	VARIABLE CAMSHAFT INLET
1615	INTERNAL COMBUSTION ENGINE RUNNING + RELAY
1616	INTERNAL COMBUSTION ENGINE RUNNING + RELAY 2
1618	TRANSPONDER RING
1623	LEFT-HAND SIDE CURTAIN AIRBAG
1624	RIGHT-HAND SIDE CURTAIN AIRBAG
1625	FRONT LEFT-HAND INERTIA REEL PRETENSIONER
1626	FRONT RIGHT-HAND INERTIA REEL PRETENSIONER
1639	AUXILIARY FUEL PUMP RELAY
1645	DRIVER'S SEAT BASE HEATING PANEL (SEAT)
1646	DRIVER'S SEATBACK HEATING PANEL (SEAT)
1647	PASSENGER SEAT BASE HEATING PANEL (SEAT)
1648	PASSENGER SEATBACK HEATING PANEL (SEAT)
1667	MULTIPLEX DOOR INFORMATION DISPLAY CONTROL
1714	MULTIPLEX LINE INTERFACE UNIT (MULTIPLEXING)

# LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
1724	GEARBOX PRIMARY SPEED SENSOR
1759	CLUTCH END OF TRAVEL SWITCH
1760	TIMED BATTERY CUT OFF +RELAY 1 (FUNCTION POWER CUT OFF DURING START PHASE)
1762	TIMED BATTERY NOT CUT OFF +RELAY (NO FUNCTION POWER CUT OFF DURING START PHASE)
1799	FRONT LEFT-HAND SEAT BELT SWITCH
1813	LEFT-HAND SIDE SATELLITE (AIR BAG)
1814	RIGHT-HAND SIDE SATELLITE (AIR BAG)
1822	FRONT LEFT-HAND PELVIC CHEST SIDE AIRBAG
1823	FRONT RIGHT-HAND PELVIC CHEST SIDE AIRBAG
1872	PASSENGER COMPARTMENT TEMPERATURE SENSOR
1873	NEGATIVE BATTERY TERMINAL
1877	MULTIMEDIA ACCESSORIES SOCKET
1886	HEATED REAR WINDOW ANTI-INTERFERENCE FILTER
1887	HEATED REAR WINDOW ANTI-INTERFERENCE FILTER 2
1907	AERIAL CONNECTION UNIT
1920	OPENING ELEMENT WARNING SOUND UNIT (WAC)
1921	AERIAL 2 AMPLIFIER
1930	LUGGAGE COMPARTMENT OPENING INTERNAL CONTROL
1959	MULTIMEDIA AUDIO SOCKET (C BOX)
1971	TRAILER SOCKET SWITCHING MODULE
2130	AIR CONDITIONING COMPRESSOR
2186	ANTI-THEFT TRACKER UNIT
2191	MINIMUM FUEL LEVEL SENSOR