

Alcyon

FIRE DETECTION AND PROTECTION SYSTEM Operating manual



PH377111

THIS PAGE INTENTIONNALLY LEFT BLANK

INDEX

GENERAL OPERATING PRINCIPLES	4
GENERAL INDICATION AND OPERATION	5
SUMMARY OF OPERATIONS.....	8
FREQUENTLY-USED GENERAL OPERATIONS.....	9
GENERAL SERVICING OPERATIONS.....	11
INDICATIONS AND OPERATIONS RELATED TO FIRE DETECTION ZONES.....	18
INDICATIONS AND COMMANDS RELATED TO THE TECHNICAL ALARM DETECTION ZONES.....	23
INDICATIONS AND COMMANDS ASSOCIATED WITH EVACUATION.....	24
INSTRUCTIONS FOR OPERATION	30

GENERAL OPERATING PRINCIPLES

Management by access level

As required by EN 54/2, the control panel mode of operation is based on access levels.

- Level 1
It enables the user to execute commands which do not change the status of the control panel (mute the buzzer, test internal buzzer and visible indications, scrolling...)
- Level 2
It enables the user to perform general operating functions (enable detection zones, disable detection zones, silence / resound sounders ...)
- Level 3
It is reserved for the installer / maintainer and enables to execute commands related to servicing operations (test ...).

Level 1 is included in level 2.

Level 2 is included in level 3.

If there is no operation for 30 seconds, the control panel automatically returns to access level 1.

When a correct code is entered, the panel beeps twice successively and the display indicates the current access level in the top right-hand corner.

If incorrect codes are entered 5 times successively in less than 5 minutes, the control panel beeps successively several times and prohibits access to levels 2 and 3 for 15 minutes.

In order to optimize the use, access level 2 is divided into two types:

- level 2 "operator", and
- level 2 "master",

There are also two types of access level 3

- level 3 "user",
- And level 3 "maintainer",

There are up to 16 codes for level 2 and 3 and a single code for level 3 "maintainer".

Level 2 can also be accessed with a button.

General information

Each action on a push button produces a brief acknowledgement beep.

A manipulation error produces a longer beep.

If access is requested for an unauthorized operation in the current access level, the display asks for the correct code

The control panel executes only those commands, which can be accessed from the current access level, to the display.

Information is latched with the exception of pre alarm and power supply faults that reset automatically when they are corrected.

In the case of an event during operations, the user exits the current menu and the event is directly displayed.

Audible signals

Steady: fire

Pulsed: pre alarm, fault including power supply fault, system fault,

Long beep: operation prohibited

Short beep: operation on buttons

General screen

Screen for standby condition

28/08/08	09:33:17	0-1
Return Validate		

Screen in case of disablement and test

28/08/08	09:43:57	0-1
3 Disable 1 Test		

Screen in case of fire

28/08 at 15:31 Fire detector	
Zone 1	Apparatus floor warehouse
Address 01101	Front door
1 Zone(s) in fire	
Scroll	Instruct

General principles applicable to signals

The information is provided with respect to the following hierarchy :

1 - Fire -> 2 - Fault -> 3 - Technical alarm

GENERAL INDICATION AND OPERATION

Organisation of general indication





Figure 1 [PE310711]


Organization of general operations

The buttons are divided into six groups:



[PE310811]

1. Three buttons which enable to access functions that can normally be directly accessed:
 - mute,
 - indicator test,
 - CODE.
2. Two buttons which enable to access other functions with the help of a menu given in the display:
 - RESET
 - SCROLL.
3. The button "MENU" helps to access the menu below. Each of these menus allows access to several sub-menus.




The same principles are applicable to the other command that can be selected:

Either by pressing the corresponding button on the numeric push keypad (e.g. 7 for overview) or, by moving the cursor with the navigation buttons and by validating the option with the content button 'validate'.

4. A numeric keypad (push buttons 0 to 9) enables to select one of the menus, to enter an access code or the value of data
5. Four push buttons ◀ ▶ ▲ ▼ for navigation enable to move the cursor (shadowed zone) in the display.
6. Four push buttons ▲ ▲ ▲ ▲ are located just below the display and enable the content menu given in the last line of the display.

If a function which is not yet available but displayed in a selected menu, the following screen is displayed:



SUMMARY OF OPERATIONS

Operations	Level 1	Level 2 operator	Level 2 master	Level 3 user	Level 3 maintainer
Frequently-used general operations					
Enter an access code					
Mute internal buzzer	Yes	Yes	Yes	Yes	Yes
Test internal buzzer and visible indication	Yes	Yes	Yes	Yes	Yes
Scroll	Yes	Yes	Yes	Yes	Yes
Reset		Yes	Yes	Yes	Yes
General servicing operations					
View stored information			Yes	Yes	Yes
Set printer			Yes	Yes	Yes
Modify an access code			Yes		Yes
Adjust date and time			Yes	Yes	Yes
Access data from the panel				Yes	Yes
Upgrade boot program				Yes	Yes
Upgrade loop processor				Yes	Yes
Perform a network monitoring				Yes	Yes
Perform a service PIN				Yes	Yes
Modify the language				Yes	Yes
Enable / disable a loop				Yes	Yes
Adjust the contrast of the display				Yes	Yes
Operations related to fire detection zones					
Status	Yes	Yes	Yes	Yes	Yes
Overview	Yes	Yes	Yes	Yes	Yes
Enable		Yes	Yes	Yes	Yes
Disable		Yes	Yes	Yes	Yes
Walk test				Yes	Yes
Simulation test					Yes
Operations related to technical alarm detection zones					
Status	Yes	Yes	Yes	Yes	Yes
Overview	Yes	Yes	Yes	Yes	Yes
Enable		Yes	Yes	Yes	Yes
Disable		Yes	Yes	Yes	Yes
Walk test				Yes	Yes
Simulation test					Yes
Operations related to the alarm zones					
Status	Yes	Yes	Yes	Yes	Yes
Overview	Yes	Yes	Yes	Yes	Yes
Enable		Yes	Yes	Yes	Yes
Disable		Yes	Yes	Yes	Yes
Test				Yes	Yes
Enablement of staff alarm		Yes	Yes	Yes	Yes
Disablement of staff alarm		Yes	Yes	Yes	Yes

FREQUENTLY-USED GENERAL OPERATIONS

To enter an access code

- Press the "Code" button

Access code 0-1

Enter your code

Return Correct Validate

- Type your code with the help of the numeric button pad
- Validate the code with the content button located below the **validate** menu (to the right in the last line of the display) or correct the value entered with the help of the content button located below the **correct** menu.

To mute the internal buzzer (Access levels 1, 2, 3) or (2, 3)

- Press the "MUTE" button

To test the internal buzzer and visible indications (access levels 1, 2, 3) or (2, 3)

- Press the "INDICATOR TEST" button

To view the general status of the panel (access levels 1, 2, 3)

- Press the "MENU" button
- Select sub-menu "7 ▶ **Overview**".

Menu 0-1

1>Fire detection 5>Fire protection
2>Evacuation 6>Technical alarm
3>Logging 7>Overview
4>Others

Return Validate

- Validate,

Report 0-1

Total number of zones 6
Number of zones in fire 2
Number of faults 3
Number of zones disabled 1
Number of zones in test 0


Return

To view information that is not displayed (access levels 1, 2, 3)

- Press the "Scroll" button (the cursor is positioned directly on the option "1 > Fire").

Menu		0-1
1>Fire	6>Fault	
2>Evacuation	7>Disabled	
3>Fire protection	8>Test	
4>Technical alarm	9>Activated input	
5>Pre-alarm		
Return	Validate	

If the sub-menu "1 > Fire" is selected and there is no "Fire", the following screen will be displayed:

Fire		0-1
<div> No fire! Press a push button..</div>		
Return		

If the menu "1 > Fire" is selected and there is a "Fire", the following screen will be displayed:

Last fire		1/ 1
08/08 at 15:31 Call point alarm		
zone	11	Warehouse
Address	02101	Entrance gate
1 Address (es) in fire in the zone		
Return	Address	Scroll Instruct

The same principles are applicable to the other information that can be selected:

Either by pressing the corresponding button on the numeric push keypad (e.g. 8 for scrolling through tests)

Or by moving the cursor with the navigation buttons and by validating the option with the content button 'validate'.

To reset the control panel (access levels 2, 3)

- Set the panel to access levels 2 or 3,
- Press the "RESET" button
- This command enables to reset fires, technical alarms, faults, evacuation and fire protection



If the reset is not performed, verify and restore the installation status with the appropriate technical service.

The disablement of a detection zone or technical alarm zone also leads to the reset of this zone only

GENERAL SERVICING OPERATIONS

To view stored information (access levels 2 master and 3)

- Go to access levels 2 master or 3,
- Press the "MENU" button
- Select "3 ▶ **Logging**".

Menu		0-1
1>Fire detection	5>Fire protection	
2>Evacuation	6>Technical alarm	
3> Logging	7>Overview	
4>Others		
Return	Validate	

- Validate,

Logging		0-2
1> Events and commands		
Return	Validate	

- Validate,

Events and commands		0-2
1> General	5>Disabled	
2>Fires	6>Test	
3>Technical alarm	7>Commands	
4>Fault		
Return	Validate	

- Select the type of information that you wish to access then validate.




Logged events can be printed.

To adjust the printer settings (access level 2 master and 3)

- Set the panel to access level 2 master or 3,
- Press the "MENU" button.
- Select sub-menu "4 ▶ **Others**" then validate,

Menu		0-1
1>Fire detection	5>Fire protection	
2>Evacuation	6>Technical alarm	
3>Logging	7>Overview	
4> Others		
Return	Validate	

- Select sub-menu "3 ▶ **Printer**".




- Validate,




The display "Speed" is not present at access level 2 master.

To change the direction of printing

- Press the button (▲) located below the sub-menu "**Up / down**",




- Press the button (▲) located below the sub-menu "**Return**", the direction of printing is reversed.



To set the printer online / off-line

- Press the button (▲) located below the sub-menu "**ES**",



- Press the button (▲) located below the sub-menu "Return ", the printer is off-line.


Printer		0-3
Printer enabled upward printing Speed 9600 bps		
Return	Up/down	On Speed

To modify the transmission speed (access level 3 only)

- Press the button (▲) located below the sub-menu "Speed ",

Printer		0-3
1>Speed 1200 bps 2>Speed 2400 bps 3>Speed 4800 bps 4>Speed 9600 bps		
Return	Validate	

- Select the desired speed (e.g. 4800 bauds),
- Validate,

Printer		0-3
<div style="border: 2px solid black; padding: 10px; text-align: center;">  Speed 4800 bps Press a push button.. </div>		
Return		

- Press the button (▲) located below the sub-menu "Return ", the printing speed is 4800 bauds.

To modify an access code (level 2 master or 3)

- Set the panel to access level 2 master or 3,
- Press the "MENU" button.
- Select sub-menu "4 ▶ Others " then validate,
- Select sub-menu "4 ▶ Access codes ".

Menu Others		0-3
1>Counters 2>Internal clock 3>Printer 4>Access codes 5>Date/Time 6>Maintenance 7>Loops 8>Contrast		
Return	Validate	

- Validate,

New Code		0-3
Enter the code to modified		
★		
Return	Correct	Validate

- Enter the new value and validate with the content button located below the validate menu or correct the value entered with the content button located below the correct menu.

To adjust the date and time (access level 2 master and 3)

- Set the panel to access level in-charge 2 or 3,
- Press the "MENU" button.
- Select sub-menu "4 ▶ **Others**" then validate,

Menu Others		0-3
1>Counters	5> Date/Time	
2>Internal clock	6>Maintenance	
3>Printer	7>Loops	
4>Access codes	8>Contrast	
Return	Validate	

- Select sub-menu "5 ▶ **Date/Time**" then validate,

Date/Time		0-3
Date:	14 / 08 / 02	
Time:	11 : 23 : 34	
Return	Correct	Validate

- Enter the date and time and then validate.



The data to be modified is displayed in flashing mode. To modify it, enter the new value with the help of the numeric keypad and validate it with the content menu push button "validate". If the value is not to be modified, press the content menu push button "validate" directly to move to the following data.

To access data on the panel (level 3 maintainer)

- ⇨ Set the control panel to access level 3 maintainer,
- ⇨ Press the "MENU" button.
- ⇨ Select sub-menu "4 ▶ **Others**" then validate,
- ⇨ Select sub-menu « 6 ▶ **Maintenance**" then validate,


Maintenance		0-3
1> Information	5>Service PIN	
2>Upgrade boot prog	6>Language	
3>Upgrade loop prog		
4>Network monitoring		
Return	Validate	

- ⇨ Select sub-menu "1 ▶ **Information**" then validate,

Information		0-3
UTI 1 V 4.2	28-09-08	
BOOT V 1.8		
Loop processor V1.0		
Sounder processor V1.3		
Return		


To boot the control panel (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu « 6 ▶ **Maintenance**" then validate,
- ⇒ Select sub-menu "2 ▶ **Upgrade boot prog**" then validate,



To load the direct acquisition unit (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu « 6 ▶ **Maintenance**" then validate,
- ⇒ Select sub-menu "3 ▶ **Upgrade loop prog**" then validate,



To access network monitoring (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu « 6 ▶ **Maintenance**" then validate,
- ⇒ Select sub-menu « 4 ▶ **Network monitoring**" then validate,

To perform the service PIN (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu "6 ▶ **Maintenance**" then validate,
- ⇒ Select sub-menu "5 ▶ **Service PIN**" then validate,

Servicing 0-3

1>Info
2>Load
3>Load
4>Cont

i PIN Service performed
Press a button.

Return **Validate**

Change the language (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu "6 ▶ **Maintenance**" then validate,
- ⇒ Select sub-menu "6 ▶ **Language**" then validate,

Language 0-3

1>French
2>English

Return **Validate**

To enable / disable the addressable lines (level 3 maintainer)

- Set the panel to access level 2 in-charge or 3,
- Press the "MENU" button.
- Select sub-menu "4 ▶ **Others**" then validate,
- Select sub-menu "7 ▶ **Loops**" then validate,

Loops 0-3

1>Enable
2>Disable

Return **Validate**

- Select the retained option and follow the procedure indicated in the display,

To adjust the contrast of the display (level 3 maintainer)

- ⇒ Set the control panel to access level 3 maintainer,
- ⇒ Press the "MENU" button.
- ⇒ Select sub-menu "4 ▶ **Others**" then validate,
- ⇒ Select sub-menu "8 ▶ **Contrast**".

Menu Others		0-3
1>Counters	5>Date/Time	
2>Internal clock	6>Maintenance	
3>Printer	7>Loops	
4>Access codes	8> Contrast	
Return	Validate	

- Validate,

Contrast		0-3
-	<input type="text"/>	+
26%		
Return	-	+ Validate

- Adjust the contrast with the help of the – and + (▲) buttons.

INDICATIONS AND OPERATIONS RELATED TO FIRE DETECTION ZONES

Note

Fire detection information are given :

- In the display of the control panel
- On zones LED modules (fire indication for zones)



- Each indicator is dedicated to a single zone
- Each new zone in alarm is indicated by flashing. The indication changes from flashing to steady following a mute operation

Figure 2 [PH377411]

Indications

With exception of fire, all other type of signals (prealarm, fault, disabled and test) are only given in the display

Fire indications

```
28/08 at 14:08 Call point alarm
zone      11      Warehouse
Address   02101 Entrance gate
28/08 at 14:13 Detector alarm
zone      4       Reception ground floor
Address   01004 Staircase

4 zone(s) in fire      Scroll      Instruct
```



The information (date, time, title of event, identification of the zone and first address on alarm in the zone) associated with the first zone of the fire alarm is given in lines 1, 2 and 3 of the display. The total number of zones on fire is given in the last line of the display.

Pre-alarm indications

```
28/08 at 14:08 Pre-alarm detector
zone      11      Warehouse
Address   02101 Entrance gate

1 zone(s) in pre-alarm
Scroll Instruct
```

Fault indication

 This information is not memorised

```
Fault      Communication fault
zone       1      Entrance of building A
Address    01101 Point 123
Fault      Line fault
Line N.1

2 faults Scroll
```

The total number of faults related to fire detection is given in the last line of the display.
The display indicates the origin of the fault in the first line:



- Sensor
- Communication
- Open line
- Line in short circuit...

Operations

To access the instruction related to a fire zones

- Press the button (▲) located below the sub-menu "Instruct"

```
28/08 at 14:08 Call point alarm
zone      11      Warehouse
Instruction call the fire brigade
28/08 at 14:13 Detector alarm
zone       4      Reception ground floor
Instruction call 1234

4 zone(s) on fire Scroll Instruct
```



The instruction replace the address indications

In case of fire, each detection zone can be associated with an instruction made up of 25 characters

To scroll through fires

- Press the button (▲) located below the sub-menu "Scroll"

```

===== First fire ===== 1 / 4 =====
28/08 at 14:08 Call point alarm
zone      11      Warehouse
Address   02101   Entrance gate
1 Address (es) on fire in the zone
Instruction call 1234

Return    Address    Scroll    Instruct
  
```

Scrolling is done in the chronological order (from the first to the last fire)



The order in which the fire alarms of the zone were activated with respect to the total number of alarm zones is given on the right hand side of the first line of the display (for example 1/4)

Scrolling can also be accessed from the Scroll push button

- Press the push button (▲) located below the sub-menu "Address" to scroll through all the addresses in fire in this zone (the text of the address is indicated at every instance).

```

===== Last fire ===== 1 / 1 =====
28/08 at 14:13 Detector alarm
zone      6      Entrance
3 Address (es) on fire in the zone
Address   03035   Door A
Address   03036   Door B
Address   03041   Door C

Return    Zone       Scroll
  
```

To go back to the screen for scrolling the zones press on the push button (▲) located below the sub-menu "Zone"

To view the status of the zone or an address (access levels 1, 2 and 3)

- Press the "MENU" button.

```

===== Menu ===== 0-1 =====
1>Fire detection      5>Fire protection
2>Evacuation          6>Technical alarm
3>Logging             7>Overview
4>Others

Return              Validate
  
```

- Validate (if the access is carried out at different access levels, other sub-menus are provided)

```

===== State Detection ===== 0-1 =====
1>State
2>Overview

10 zones              45 addresses
Return              Validate
  
```

- Validate,

```

===== State Detection ===== 0-1 =====
1>One zone
2>One address

10 zones
Return              Validate
  
```

- Select the option one zone OR one address, then follow the indicated procedure

To view the overall status of all the fire detection zones (access levels 1, 2 and 3)

- Press the "MENU" button.
- Validate,
- Select "2 ▶ **Overview**".

Fire Detection		0-1
1>State		
2> Overview		
Return	Validate	

- Validate,

Overview detection		0-1
Total number of zones		7
Number of zones in fire		2
Number of zones in pre-alarm		1
Number of zones in faults		0
Number of zones disabled		0
Number of zones in test		1
Return	Scroll	

To enable (access levels 2 and 3)

- Go to access levels 2 or 3,
- Press the "MENU" button.
- Validate,
- Select "3 ▶ **Enable**".

Enable detection		0-2
1>State	5>Test	
2>Overview	6>Simulation	
3> Enable		
4>Disable		
Return	Validate	

- Validate,

Enable detection		0-2
1> All zones		
2>A set of zones		
3>One zone		
4>One address		
Return	Validate	

- Select the proposed option, then follow the indicated procedure

To disable (access levels 2 and 3)

- Go to access levels 2 or 3,
- Press the "MENU" button.
- Validate,
- Select "4 ▶ **Disable**".

- Validate,

Disable detection		0-2
1>All zones 2>A set of zones 3>One zone 4>One address		
Return	Validate	

- Select the proposed option, then follow the indicated procedure

To perform a walk test (level 3)

- Go to access level 3,
- Press the "MENU" button
- Validate,
- Select "5 > Test".
- Validate,

Test detection		0-2
1>All zones 2>A set of zones 3>One zone		
Return	Validate	

- Follow the indicated procedure



During the walk test, the fire alarm of a detector remains in alarm for approximately 15 seconds then the zone is automatically reset. All the detectors of a same zone can be tested one after the other. The controls associated with a functional test zone are not operated.

To perform a simulation test (levels 3 maintainer)

- Go to access level 3 maintainer,
- Press the "MENU" button
- Validate,
- Select "6 > Simulation".
- Validate,

Simulation		0-3
Do you really want to Start the simulation		
Return	Validate	

- Follow the indicated procedure



It is possible to conduct simulation tests one zone at a time
 During the simulation test, the fire alarm of the zone is simulated at the level of the panel.
 The activation of simulation tests of a zone is logged as a specific event
 In case of simulation in a zone, all associated command are operated excepted ancillary output.

INDICATIONS AND COMMANDS RELATED TO THE TECHNICAL ALARM DETECTION ZONES

Indications

The indications associated with the technical alarm zones are equivalent to those given for the fire detection zones

Commands

The commands associated with the technical alarm zones are equivalent to those given for the fire detection zones. They can be accessed with the help of:

- The button menu
- Sub-menu "5 ▶ **Technical alarm**".

INDICATIONS AND COMMANDS ASSOCIATED WITH EVACUATION

Note

The indications related to evacuation are given:

- In the display of the control panel
- With the help of dedicated indicators

The commands related to evacuation are performed:

- With the help of proposed menus following an action on the button menu
- With the help of dedicated buttons



Figure 3 [PH377311]

Special signals and commands




Figure 4 [PE310911]

Signals given in the display

Fault		Communication fault	
zone	1	Building A	
Address	01101	Point 123	
1 faults		Scroll	

Commands performed with the push button menu

To view the status of an evacuation zone or an output (access levels 1, 2, 3)

- Press the "MENU" button

Menu		0-1
1>Fire detection	5>Fire protection	
2>Evacuation	6>Technical alarm	
3>Logging	7>Overview	
4>Others		
Return	Validate	

- Select 2 > "Evacuation" and validate

Evacuation		0-1
1>	State	
2>	Overview	
Return		Validate

- Validate,

Evacuation state		0-1
1>	One zone	
2>	One output	
Return		Validate

- Select the option one zone OR one address, then follow the indicated procedure

To view the overall status of all the evacuation zones (access levels 1, 2, 3)

- Press the "MENU" button
- Select "2 ▶ Evacuation" and validate,

Evacuation		0-1
1>	State	
2>	Overview	
Return		Validate

- Select "2 ▶ Overview" and validate,

Evacuation overview		0-1
Total number of evacuation zones	7	
Number of zones delaying	2	
Number of zones evacuating	0	
Number of zones in faults	0	
Number of zones disabled	0	
Number of zones in test mode	1	
Return	Scroll	

To enable the evacuation zones (level 2 or 3)

Aims:

- Enable the sounders in a zone, a group of zones or all the alarm zones.

Procedure:

- Go to access levels 2 or 3,
- Press the "MENU" button
- Select "2 ▶ Evacuation".
- Validate,
- Select "3 > **Enable**".

Evacuation		0-3
1>Status	5>Test	
2>Summary	6>Staff alarm on	
3> Enable	7>Staff alarm off	
4>Disable		
Return	Validate	

- Validate,

Enabled evacuation		0-3
1> All zones		
2>A set of zones		
3>One zone		
Return	Validate	

- Follow the given procedure

To disable the evacuation zones (level 3)

Aims:

- Disable the sounders in a zone, a group of zones or all the alarm zones.

Procedure:

- Go to access level 3,
- Press the "MENU" button
- Select "2 > Evacuation".
- Validate,
- Select "4 > **Disable**".
- Validate,

Disable evacuation		0-3
1> All zones		
2>A set of zones		
3>One zone		
Return	Validate	

- Follow the given procedure

Testing (levels 2 (according to the site configuration) and 3)

Procedure:

- Go to access levels 2 or 3,
- Press the "MENU" button
- Select "2 ▶ Evacuation".
- Validate,
- Select "7> Test".
- Validate,

Test evacuation		0-3
1>All zones		
2>A set of zones		
3>One zone		
Return		Validate



When an evacuation zone which is in test receives a command from a detection zone under test, sirens are operated 5 seconds in the alert mode(if programmed) and then 5 seconds in the evacuate mode

To enable the staff alarm (level 2 or 3)

Procedure:

- Go to access levels 2 or 3,
- Press the "MENU" button
- Select "2 ▶ Evacuation".
- Validate,
- Select "6> **Staff alarm on**".

Evacuation		0-2
1>Status		
2>Summary		
3>Enable		
4>Disable		
5>Test		
6>Staff alarm on		
7>Staff alarm off		
Return		Validate

- Validate,

Staff alarm ON		0-2
1>All zones		
2>A set of zones		
3>One zone		
Return		Validate

To disable the staff alarm (level 2 or 3)

Procedure:

- Go to access levels 2 or 3,
- Press the "MENU" button
- Select "2 ▶ Evacuation".
- Validate,
- Select "7> **Staff alarm off**".

Evacuation		0-2
1>Status	5>Test	
2>Summary	6>Staff alarm on	
3>Enable	7>Staff alarm off	
4>Disable		
Return	Validate	

- Validate,

Staff alarm OFF	0-2
1> All zones	
2>A set of zones	
3>One zone	
Return	Validate

INSTRUCTIONS FOR OPERATION

IN CASE OF A FIRE ALARM

The general red FIRE indicator lights up steadily.
The display indicates the information.
The buzzer produces a continuous sound.

APPLY THE SECURITY INSTRUCTIONS OF THE ORGANIZATION.
STOP THE BUZZER BY PRESSING THE "mute" BUTTON.

IN CASE OF A FAULT

The yellow FAULT indicator lights up steadily.
A yellow indicator or the display enables to identify the main defects
The buzzer produces a pulsed sound.

STOP THE SOUNDER BY PRESSING THE "mute" BUTTON.
FIND OUT THE CAUSE of the fault.

Finally call the technical service for information or intervention at XXXXXXXXX.

RESET

THE RESET CONTROL IS OPERATED BY SKILLED PERSONNEL AT ACCESS LEVEL 2

TO ORDER OR STOP AN EVACUATION PROCESS

To extend the Staff alarm delay before the evacuation command (the "delay active" indicator is flashing slowly)

- ⇒ Press the "ACCEPT DELAY" button
The "delay active" indicator becomes steady

To start evacuation:

- ⇒ Set the panel to access level 2
- ⇒ Press the "EVACUATE" button
The "alarm" indicator becomes steady

To stop evacuation

- ⇒ Set the panel to access level 2
- ⇒ Press the "SILENCE / RESOUND" button.
The "alarm" indicator light turn off
The "sounders silence" indicator turn on steadily

The sounders can be restarted by pressing again the "silence / resound" button.

THIS PAGE INTENTIONNALLY LEFT BLANK

