



Notes:
A14_DAC is used as S meter input for Simple VFO Plus Code.
Pull-ups are present on SI5351 module so no need to install.
Only populate the headers you require, unless you intend to expand the system.
to use +13V8 external supply – fit regulator on Simple VFO Plus processor PCB.
+3V3 output from Teensy, so don't overload this supply line.

Copyright (C) K Wheatley 2020
This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2.
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2.
(<http://ohwr.org/cernohl>).
This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY,
INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE.
Please see the CERN OHL v.1.2 for applicable conditions.

Sheet: /
File: Simnple_VFO_Plus_Backplane.sch

Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad (5.1.4-0)		Id: 1/1