



### PREPARATORY FUNCTION

G00	RAPID POSITIONING
G01	LINEAR INTERPOLATION
G02	CW CIRCULAR INTERPOLATION
G03	CCW CIRCULAR INTERPOLATION
G20	DIMENSION IN INCH
G21	DIMENSION IN MM
G28	RETURN TO HOME
G40	NO CUTTER RADIUS COMPENSATION
G41	CUTTER RADIUS COMPENSATION-LEFT
G42	CUTTER RADIUS COMPENSATION-RIGHT
G54-G57	WORK ZERO (ZERO OFFSET)
G90	ABSOLUTE DIMENSION
G91	INCREMENTAL DIMENSION

### MISCELLANEOUS FUNCTION

M00	PROGRAM STOP
M01	OPTIONAL STOP
M02	PROGRAM END WITH OUT RESET
M03	SPINDLE ON CW
M04	SPINDLE ON CCW
M05	SPINDLE STOP
M06	TOOL CHANGE
M08	COOLANT ON
M09	COOLANT OFF
M30	PROGRAM END WITH RESET
M97	LOCAL SUBPROGRAM CALL
M99	SUBPROGRAM RETURN

N	SEQUENCE OR BLOCK NUMBER
T	TOOL SELECTION
S	SPINDLE SPEED IN RPM
F	FEED IN mm/min
R	RADIUS OF CIRCLE
P	PROGRAM LINE NUMBER (GO TO N....)
L	REPEATS SUBPROGRAM CALL



**G54-G57**

## PROGRAM

O00001	N1
G28	G91 G01 Z-0.25
T1 M06	G90 G01 G41 X3 Y25 F300 D01
G54 G40 G90 G21	
M03 S1500	G01 X3 Y42
M08	G01 X8 Y47
G00 X-20 Y25	G01 X37 Y47
G00 Z10	G02 X47 Y37 R10
G01 Z0 F100	G01 X47 Y3
M97 P1 L4	G01 X3 Y3
	G01 X3 Y25
G00 Z10	G01 G40 X-20 Y25
G28	M99
M09	
M05	
M30	

## **MACHINE ON**

- COMPRESSOR ON
- MAIN PANEL ON
- STABILIZER ON
- SELECT THREE PHASE (MENU-3)
- START BUTTON PRESS
- MACHINE MAIN POWER ON
- POWER ON

## **RUNING SET UP**

- ALARM
  - RESET (LOW AIR)
  - RESET (EMERGENCY)
  - RESET (SERVO)
- SETTING
  - PAGE DOWN
  - 51 SAFETY.. - ON
  - WRIT ENTER – Y
- ZERO RET
- ALL
- HAND JOG (2)