

# Maintenance Procedure


## No. MP880

Page 1 of 1

<b>TASK DESCRIPTION</b>
INSPECT OPERATION OF MAIN ENGINE INERTIAL FILTER BLOWER MOTOR
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b>
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 8
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b>
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

### PROCEDURE

1. Check operation of the blower and motor. If defective, refer to M.I. 3614 for service.



DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment