

**No. MP1015**

Page 1 of 1

<b>TASK DESCRIPTION</b>
CHECK FOR DAMAGED/WORN SEALS AROUND THE CARBODY SIDE DOORS AND REAR DOOR
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b>
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 10
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b>
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

## PROCEDURE

1. Open the carbody side and rear access doors. Verify the door seals are not worn or damaged. If the door seals are worn or damaged, the seals must be replaced.
2. Open interior doors (clean air compartment door and short hood door) and verify seals are not worn. Replace damaged or worn seals.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment