

**No. MP960**

Page 1 of 1

**PREPARATION:**

## PROCEDURE

1. Visually inspect the air reservoir's aftercooler heater circuit breaker for cracks in insulation or heat damage.
2. Operate the circuit breaker, ensuring proper switching.
3. Replace damaged or malfunctioning circuit breaker.

Manager, Rail Equipment