

Maintenance Procedure

No. MP1315

Page 1 of 1

TASK DESCRIPTION

REPLACE HEP AIR CLEANER ELEMENT

BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS

MP40PH-3C Head End Power Maintenance Manual

SPECIAL TOOLS REQUIRED:

RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.

SAFETY PRECAUTIONS:

CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.

PREPARATION:

PROCEDURE



CAUTION

Never service the air cleaner with the engine running since this will allow dirt to enter the engine. Check the inlet piping for leaks. Make all repairs to the inlet piping immediately, as dirt and debris could enter the engine causing damage to the turbocharger and engine components.

1. Remove air cleaner cover and element. Discard used element.
2. Cover air inlet opening with a clean cloth or towel to prevent dirt and debris from entering the engine.
3. Clean the inside of the air cleaner cover and body.
4. Remove cloth from air inlet opening and install a new element noting the arrows indicating the air flow on the side of the element.
5. Reinstall the cover.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment