

No. MP1380

Page 1 of 1

TASK DESCRIPTION HEP ENGINE STARTER INSPECTION
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS MP40PH-3C Head End Power MAINTENANCE MANUAL, CATERPILLAR MANUAL C27
SPECIAL TOOLS REQUIRED:
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.
SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
PREPARATION:

PROCEDURE

1. Check starter operation, including pinion engagement, air leaks, unusual noise, hose, or housing damage. If defective, repair or replace starter or hoses as needed.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	