

**No. MP1005**

Page 1 of 1

<b>TASK DESCRIPTION</b>
CHECK HOOD
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b>
MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 10
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b>
CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

## PROCEDURE

1. Check bolts and nuts fastening the various hood compartments to the locomotive frame.
2. Tighten loose bolts and nuts to 150 ft-lbs.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	