

No. MP555

Page 1 of 1

TASK DESCRIPTION

BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS

SPECIAL TOOLS REQUIRED:

SAFETY PRECAUTIONS:

PREPARATION:

Lube oil strainers should be removed and cleaned at each oil change. The lube oil strainer housing should be cleaned when strainers are removed for cleaning.

DATE OF FIRST ISSUE

AUTHORIZED BY:

August 2009

TITLE:

Manager, Rail Equipment