

No. MP620

Page 1 of 1

TASK DESCRIPTION CHECK AUTOMATIC/MANUAL DRAIN VALVE
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 6
SPECIAL TOOLS REQUIRED:
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.
SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
PREPARATION:

PROCEDURE

1. Check the drain valves to see if they are seating properly and that no air is leaking out.
2. Check that the drain valves are cycling periodically.
3. Turn valve to the manual open (center) position and then return to automatic.
4. Verify air flows out in the manual open position.
5. Verify only slight amount of water, if any, escapes.
6. If complete valve needs to be replaced, refer to MP40 P622 Replace Automatic/Manual Drain Valve.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	TITLE: Manager, Rail Equipment