

Maintenance Procedure  
**No. P825**

Page 1 of 1

<b>TASK DESCRIPTION</b> CLEAN AR15 TRACTION ALTERNATOR
<b>BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS</b> MPI Locomotive Maintenance Manual, Section 8 F59 Service Manual, Section 8A MI 3317-1E AR-Type Traction Alternator
<b>SPECIAL TOOLS REQUIRED:</b>
<b>RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.</b>
<b>SAFETY PRECAUTIONS:</b> CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
<b>PREPARATION:</b>

**PROCEDURE**

1. Use low pressure compressed air to blow out dust and dirt from the exterior and interior of the alternator. Avoid excessive air pressure which could damage the insulation.
2. Use clean, bound-edge, lintless wiping cloths to remove oil, grease, and accumulations of dirt.
3. Ensure the rectifier is as clean as possible.
4. Inspect and clean alternator pit drain aspirator.

DATE OF FIRST ISSUE	August 2010	AUTHORIZED BY:
REVISION        0		TITLE: Manager, Rail Equipment