


No. MP570

Page 1 of 1

TASK DESCRIPTION CHANGE OUT SOAK BACK OIL PUMP FILTER ELEMENT
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS MPI LOCOMOTIVE MAINTENANCE MANUAL, SECTION 5
SPECIAL TOOLS REQUIRED:
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.
SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
PREPARATION:

PROCEDURE

1. Remove the spin-on filter element from the housing.
2. Install new filter element in the container.
3. Check the O-ring seal, replace if damaged.

	<p style="text-align: center;">CAUTION</p> <p style="text-align: center;">Do not over tighten as the seal may be damaged</p>
---	---

DATE OF FIRST ISSUE	2007	AUTHORIZED BY:
REVISION 1	August 2009	