

No. MP1435

PREPARATION:

PROCEDURE

The event recorder contains configuration settings that can be check or changed using software. Some configuration settings are protected and can only be changed by authorized technicians. The WinDNLd program allows the user to change analog channel settings, frequency channel settings, the event recorder clock etc.

Modules for changing the event recorder configuration parameters are only available when the event recorder is on-line. The modules for changing the event recorder configuration parameters are all under the Configure menu within Tools.

Manager, Rail Equipment