


No. MP1385

Page 1 of 1

TASK DESCRIPTION HEP ENGINE EXHAUST SYSTEM MAINTENANCE
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS MP40PH-3C Head End Power MAINTENANCE MANUAL
SPECIAL TOOLS REQUIRED:
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.
SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
PREPARATION:

PROCEDURE

1. The exhaust system should be inspected regularly for exhaust leaks and torn or punctured insulation. Make repairs as necessary.

	<p style="text-align: center;">WARNING</p> <p>Shut down the HEP diesel engine and allow engine components to ambient temperature prior to making repairs to the exhaust system.</p> <p>If the insulation blanket covering the bottom of the muffler assembly is removed/replaced, temporary padding and warning signage should be installed on the bottom of the muffler assembly to prevent accidental head injury.</p>
---	---

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY:
REVISION 1	August 2009	