


No. MP1306

Page 1 of 1

TASK DESCRIPTION CHECK INTERLOCKS AND POWER CONTACTORS
BUILDER'S OR VENDOR'S MAINTENANCE INSTRUCTIONS MP40PH-3C Head End Power Maintenance Manual
SPECIAL TOOLS REQUIRED:
RELATED MAINTENANCE PROCEDURES MODIFICATIONS, POINTERS, ETC.
SAFETY PRECAUTIONS: CONTRACTOR TO ASSUME RESPONSIBILITY FOR SAFETY RULES AND COMPLIANCE.
PREPARATION:

PROCEDURE

	<p style="text-align: center;">WARNING</p> <p>Before inspecting or performing maintenance verify that all power to starter has been disconnected to prevent electrical shock. If the device has been in service, many parts may still be thermally hot.</p>
---	--

1. Inspect interlocks and power contacts. Arc chutes should be replaced when power contacts are replaced.
2. Refer locomotive maintenance manual chapter 13 for contact tip service limits and instructions for replacement of contactors.

DATE OF FIRST ISSUE	September 2007	AUTHORIZED BY: TITLE: Manager, Rail Equipment
REVISION 1	August 2009	