



Nios[®] II Software Developer Handbook

Updated for Intel[®] Quartus[®] Prime Design Suite: **19.2**



Subscribe

Send Feedback

NII-SDH | 2019.07.01

Latest document on the web: [PDF](#) | [HTML](#)



Contents

1. Nios® II Software Developer's Handbook Revision History.....	12
1.1. Overview of Nios® II Embedded Development Revision History.....	13
1.2. Getting Started with the Graphical User Interface Revision History.....	13
1.3. Getting Started from the Command Line Revision History.....	13
1.4. Nios II Software Build Tools Revision History.....	14
1.5. Overview of the Hardware Abstraction Layer Revision History.....	14
1.6. Developing Programs Using the Hardware Abstraction Layer Revision History.....	14
1.7. Developing Device Drivers for the Hardware Abstraction Layer Revision History.....	15
1.8. Exception Handling Revision History.....	15
1.9. Cache and Tightly-Coupled Memory Revision History.....	15
1.10. MicroC/OS-II Real-Time Operating System Revision History.....	15
1.11. Ethernet and the NicheStack TCP/IP Stack - Nios II Edition Revision History.....	16
1.12. Read-Only Zip File System Revision History.....	16
1.13. Publishing Component Information to Embedded Software Revision History.....	16
1.14. HAL API Reference Revision History.....	17
1.15. Nios II Software Build Tools Reference Revision History.....	17
2. Overview of Nios II Embedded Development.....	18
2.1. Installing Windows Subsystem for Linux (WSL) on Windows.....	18
2.2. Prerequisites for Understanding the Nios II Embedded Design Suite.....	19
2.3. Finding Nios II EDS Files.....	19
2.4. Nios II Software Development Environment.....	19
2.5. Nios II EDS Development Flows.....	20
2.5.1. Nios II SBT Development Flow.....	20
2.6. Nios II Programs.....	21
2.6.1. Makefiles and the SBT.....	21
2.6.2. Nios II Software Project Types.....	21
2.7. Intel FPGA Software Packages for Embedded Systems.....	22
2.8. Nios II Embedded Design Examples.....	23
2.8.1. Hardware Examples.....	23
2.8.2. Software Examples.....	23
2.9. Third-Party Embedded Tools Support.....	24
2.10. Additional Nios II Information.....	24
3. Getting Started with the Graphical User Interface.....	26
3.1. Installing Eclipse IDE into Nios II EDS.....	26
3.2. Getting Started with Nios II Software in Eclipse.....	27
3.2.1. The Nios II SBT for Eclipse Workbench.....	27
3.2.2. Creating a Project.....	28
3.2.3. Navigating the Project.....	30
3.2.4. Building the Project.....	30
3.2.5. Configuring the FPGA.....	31
3.2.6. Running the Project on Nios II Hardware.....	31
3.2.7. Debugging the Project on Nios II Hardware.....	32
3.2.8. Creating a Simple BSP.....	38
3.3. Makefiles and the Nios II SBT for Eclipse.....	38
3.3.1. Eclipse Source Management.....	39
3.3.2. User Source Management.....	40



3.3.3. BSP Source Management.....	41
3.4. Using the BSP Editor.....	41
3.4.1. Tcl Scripting and the Nios II BSP Editor.....	42
3.4.2. Starting the Nios II BSP Editor.....	42
3.4.3. The Nios II BSP Editor Screen Layout.....	42
3.4.4. The Command Area.....	42
3.4.5. The Console Area.....	47
3.4.6. Exporting a Tcl Script.....	47
3.4.7. Creating a New BSP.....	48
3.4.8. BSP Validation Errors.....	48
3.5. Run Configurations in the SBT for Eclipse.....	49
3.5.1. Opening the Run Configuration Dialog Box.....	49
3.5.2. The Project Tab.....	49
3.5.3. The Target Connection Tab.....	50
3.5.4. The Debugger Tab.....	50
3.6. Optimizing Project Build Time.....	50
3.7. Importing a Command-Line Project.....	50
3.7.1. Nios II Command-Line Projects.....	51
3.7.2. Importing through the Import Wizard.....	51
3.7.3. Road Map.....	51
3.7.4. Import a Command-Line C/C++ Application.....	52
3.7.5. Import a Supporting Project.....	52
3.7.6. User-Managed Source Files.....	53
3.8. Packaging a Library for Reuse.....	53
3.8.1. Creating the User Library.....	53
3.8.2. Using the Library.....	54
3.9. Creating a Software Package.....	54
3.10. Programming Flash in Intel FPGA Embedded Systems.....	57
3.10.1. Starting the Flash Programmer.....	57
3.10.2. Creating a Flash Programmer Settings File.....	58
3.10.3. The Flash Programmer Screen Layout.....	58
3.10.4. The Command Area.....	58
3.10.5. The Console Area.....	59
3.10.6. Saving a Flash Programmer Settings File.....	59
3.10.7. Flash Programmer Options.....	59
3.11. Creating Memory Initialization Files.....	60
3.11.1. Generate Memory Initialization Files.....	60
3.11.2. Generate Memory Initialization Files by the Legacy Method.....	61
3.11.3. Memory Initialization Files for User-Defined Memories.....	61
3.12. Running a Nios II System with ModelSim.....	63
3.12.1. Using ModelSim with an SOPC Builder-Generated System.....	63
3.12.2. Using ModelSim with a Platform Designer-Generated System.....	63
3.13. Eclipse Usage Notes.....	66
3.13.1. Configuring Application and Library Properties.....	66
3.13.2. Configuring BSP Properties.....	66
3.13.3. Exclude from Build Not Supported.....	67
3.13.4. Selecting the Correct Launch Configuration Type.....	67
3.13.5. Target Connection Options.....	67
3.13.6. Renaming Nios II Projects.....	67
3.13.7. Running Shell Scripts from the SBT for Eclipse.....	68
3.13.8. Must Use Nios II Build Configuration.....	68




3.13.9. CDT Limitations.....	69
3.13.10. Enhancements for Build Configurations in SBT and SBT for Eclipse.....	70
4. Getting Started from the Command Line.....	73
4.1. Advantages of Command-Line Software Development.....	73
4.2. Outline of the Nios II SBT Command-Line Interface.....	73
4.2.1. Utilities.....	74
4.2.2. Scripts.....	74
4.2.3. Tcl Commands.....	77
4.2.4. Tcl Scripts.....	77
4.2.5. The Nios II Command Shell.....	77
4.3. Getting Started in the SBT Command Line.....	78
4.3.1. Prerequisites.....	78
4.3.2. Creating Hello_World for an Intel FPGA Development Board.....	79
4.3.3. Running Hello_World on an Intel FPGA Development Board.....	79
4.3.4. Debugging hello_world.....	80
4.4. Software Build Tools Scripting Basics.....	81
4.4.1. Creating a BSP with a Script.....	82
4.4.2. Creating an Application Project with a Script.....	85
4.5. Running make.....	85
4.5.1. Creating Memory Initialization Files.....	86
5. Nios II Software Build Tools.....	87
5.1. Road Map for the SBT.....	88
5.1.1. What the Build Tools Create.....	88
5.1.2. Comparing the Command Line with Eclipse.....	88
5.2. Makefiles.....	88
5.2.1. Modifying Makefiles.....	89
5.2.2. Makefile Targets.....	89
5.3. Nios II Embedded Software Projects.....	90
5.3.1. Applications and Libraries.....	90
5.3.2. Board Support Packages.....	91
5.3.3. Software Build Process.....	93
5.4. Common BSP Tasks.....	94
5.4.1. Adding the Nios II SBT to Your Tool Flow.....	94
5.4.2. Linking and Locating.....	96
5.4.3. Other BSP Tasks.....	102
5.5. Details of BSP Creation.....	106
5.5.1. BSP Settings File Creation.....	108
5.5.2. Generated and Copied Files.....	108
5.5.3. HAL BSP Files and Folders.....	109
5.5.4. Linker Map Validation.....	113
5.6. Tcl Scripts for BSP Settings.....	113
5.6.1. Calling a Custom BSP Tcl Script.....	113
5.7. Revising Your BSP.....	116
5.7.1. Rebuilding Your BSP.....	116
5.7.2. Regenerating Your BSP.....	117
5.7.3. Updating Your BSP.....	119
5.7.4. Recreating Your BSP.....	120
5.8. Specifying BSP Defaults.....	122
5.8.1. Top Level Tcl Script for BSP Defaults.....	123



5.8.2. Specifying the Default stdio Device.....	124
5.8.3. Specifying the Default System Timer.....	124
5.8.4. Specifying the Default Memory Map.....	125
5.8.5. Specifying Default Bootloader Parameters.....	125
5.8.6. Using Individual Default Tcl Procedures.....	126
5.9. Device Drivers and Software Packages.....	127
5.10. Boot Configurations for Intel FPGA Embedded Software.....	127
5.10.1. Memory Types.....	127
5.10.2. Boot from Flash Configuration.....	128
5.10.3. Boot from Monitor Configuration.....	128
5.10.4. Run from Initialized Memory Configuration.....	128
5.10.5. Run-time Configurable Reset Configuration.....	129
5.11. Intel FPGA-Provided Embedded Development Tools.....	129
5.11.1. Nios II Software Build Tool GUIs.....	129
5.11.2. The Nios II Command Shell.....	132
5.11.3. The Nios II Command-Line Commands.....	132
5.12. Restrictions.....	151
6. Overview of the Hardware Abstraction Layer.....	152
6.1. Getting Started with the Hardware Abstraction Layer.....	152
6.2. HAL Architecture for Embedded Software Systems.....	153
6.2.1. Services.....	153
6.2.2. Layers of a HAL-Based System.....	153
6.2.3. Applications versus Drivers.....	154
6.2.4. Generic Device Models.....	154
6.2.5. C Standard Library—newlib.....	155
6.3. Embedded Hardware Supported by the HAL.....	155
6.3.1. Nios II Processor Core Support.....	155
6.3.2. Supported Peripherals.....	155
6.3.3. MPU Support.....	157
6.3.4. MMU Support.....	157
7. Developing Programs Using the Hardware Abstraction Layer.....	158
7.1. HAL BSP Settings.....	158
7.2. The Nios II Embedded Project Structure.....	159
7.3. The system.h System Description File.....	160
7.4. Data Widths and the HAL Type Definitions.....	161
7.5. UNIX-Style Interface.....	162
7.6. File System.....	162
7.7. Using Character-Mode Devices.....	164
7.7.1. Standard Input, Standard Output and Standard Error.....	164
7.7.2. General Access to Character Mode Devices.....	164
7.7.3. C++ Streams.....	165
7.7.4. /dev/null.....	165
7.7.5. Lightweight Character-Mode I/O.....	165
7.7.6. Intel FPGA Logging Functions.....	165
7.8. Using File Subsystems.....	170
7.8.1. Host-Based File System.....	171
7.9. Using Timer Devices.....	171
7.9.1. System Clock Driver.....	172
7.9.2. Alarms.....	172




7.9.3. Timestamp Driver.....	173
7.10. Using Flash Devices.....	174
7.10.1. Simple Flash Access.....	175
7.10.2. Block Erasure or Corruption.....	176
7.10.3. Fine-Grained Flash Access.....	177
7.11. Using DMA Devices.....	181
7.11.1. DMA Transmit Channels.....	182
7.11.2. DMA Receive Channels.....	183
7.12. Using Interrupt Controllers.....	185
7.13. Reducing Code Footprint in Embedded Systems.....	186
7.13.1. Enable Compiler Optimizations.....	186
7.13.2. Use Reduced Device Drivers.....	187
7.13.3. Reduce the File Descriptor Pool.....	187
7.13.4. Use /dev/null.....	187
7.13.5. Use a Smaller File I/O Library.....	188
7.13.6. Use the Lightweight Device Driver API.....	195
7.13.7. Use the Minimal Character-Mode API.....	196
7.13.8. Eliminate Unused Device Drivers.....	197
7.13.9. Eliminate Unneeded Exit Code.....	198
7.13.10. Turn off C++ Support.....	198
7.14. Boot Sequence and Entry Point.....	198
7.14.1. Hosted Versus Free-Standing Applications.....	198
7.14.2. Boot Sequence for HAL-Based Programs.....	199
7.14.3. Customizing the Boot Sequence.....	200
7.15. Memory Usage.....	201
7.15.1. Memory Sections.....	201
7.15.2. Assigning Code and Data to Memory Partitions.....	202
7.15.3. Placement of the Heap and Stack.....	204
7.15.4. Global Pointer Register.....	205
7.15.5. Boot Modes.....	206
7.16. Working with HAL Source Files.....	207
7.16.1. Finding HAL Files.....	207
7.16.2. Overriding HAL Functions.....	207
8. Developing Device Drivers for the Hardware Abstraction Layer.....	209
8.1. Driver Integration in the HAL API.....	209
8.2. The HAL Peripheral-Specific API.....	210
8.3. Preparing for HAL Driver Development.....	210
8.4. Development Flow for Creating Device Drivers.....	210
8.5. Nios II Hardware Design Concepts.....	211
8.5.1. The Relationship Between the .sopcinfo File and system.h.....	211
8.5.2. Using the System Generation Tool to Optimize Hardware.....	211
8.5.3. Components, Devices, and Peripherals.....	211
8.6. Accessing Hardware.....	212
8.7. Creating Embedded Drivers for HAL Device Classes.....	214
8.7.1. Character-Mode Device Drivers.....	214
8.7.2. File Subsystem Drivers.....	216
8.7.3. Timer Device Drivers.....	217
8.7.4. Flash Device Drivers.....	218
8.7.5. DMA Device Drivers.....	219
8.7.6. Ethernet Device Drivers.....	221



8.8. Integrating a Device Driver in the HAL.....	225
8.8.1. Overview.....	225
8.8.2. Assumptions and Requirements.....	226
8.8.3. The Nios II BSP Generator.....	227
8.8.4. File Names and Locations.....	228
8.8.5. Driver and Software Package Tcl Script Creation.....	229
8.9. Creating a Custom Device Driver for the HAL.....	238
8.9.1. Header Files and alt_sys_init.c.....	238
8.9.2. Device Driver Source Code.....	240
8.10. Reducing Code Footprint in HAL Embedded Drivers.....	240
8.10.1. Provide Reduced Footprint Drivers.....	240
8.10.2. Support the Lightweight Device Driver API.....	241
8.11. HAL Namespace Allocation.....	242
8.12. Overriding the HAL Default Device Drivers.....	242
9. Exception Handling.....	244
9.1. Nios II Exception Handling Overview.....	244
9.1.1. Exception Handling Terminology.....	244
9.1.2. Interrupt Controllers.....	246
9.1.3. Latency and Response Time.....	248
9.2. Nios II Interrupt Service Routines.....	250
9.2.1. HAL APIs for Hardware Interrupts.....	251
9.2.2. HAL ISR Restrictions.....	255
9.2.3. Writing an ISR.....	255
9.2.4. Registering an ISR with the Enhanced Interrupt API.....	258
9.2.5. Enabling and Disabling Interrupts.....	259
9.2.6. Configuring an External Interrupt Controller.....	260
9.2.7. C Example.....	260
9.2.8. Upgrading to the Enhanced HAL Interrupt API.....	261
9.3. Improving Nios II ISR Performance.....	262
9.3.1. Software Performance Improvements.....	262
9.3.2. Hardware Performance Improvements.....	268
9.4. Debugging Nios II ISRs.....	270
9.5. HAL Exception Handling System Implementation.....	271
9.5.1. Exception Handling System Structure.....	271
9.5.2. General Exception Funnel.....	272
9.5.3. Hardware Interrupt Funnel.....	273
9.5.4. Software Exception Funnel.....	275
9.5.5. Invalid Instructions.....	279
9.6. The Nios II Instruction-Related Exception Handler.....	279
9.6.1. Writing an Instruction-Related Exception Handler.....	280
9.6.2. Registering an Instruction-Related Exception Handler.....	281
9.6.3. Removing an Instruction-Related Exception Handler.....	282
10. Cache and Tightly-Coupled Memory.....	283
10.1. Nios II Cache Implementation.....	283
10.1.1. Defining Cache Properties.....	284
10.2. HAL API Functions for Managing Cache.....	284
10.3. Initializing the Nios II Cache after Reset.....	284
10.3.1. Assembly Code to Initialize the Instruction Cache.....	285
10.3.2. Assembly Code to Initialize the Data Cache.....	285



10.3.3. HAL Behavior for Initializing the Nios II Cache after Reset.....	285
10.4. Nios II Device Driver Cache Considerations.....	286
10.4.1. HAL Behavior for Nios II Device Driver Cache Considerations.....	286
10.5. Cache Considerations for Writing Program Loaders.....	287
10.5.1. HAL Behavior for Cache Considerations for Writing Program Loaders.....	287
10.6. Managing Cache in Multi-Master and Multi-Processor Systems.....	287
10.6.1. Cache Implementation.....	288
10.6.2. Bit-31 Cache Bypass.....	288
10.6.3. HAL Behavior for Managing Cache in Multi-Master and Multi-Processor Systems.....	288
10.7. Nios II Tightly-Coupled Memory.....	289
11. MicroC/OS-II Real-Time Operating System.....	290
11.1. Overview of the MicroC/OS-II RTOS.....	290
11.1.1. Licensing.....	291
11.2. Other RTOS Providers.....	291
11.3. The Nios II Implementation of MicroC/OS-II.....	291
11.3.1. MicroC/OS-II Architecture.....	292
11.3.2. MicroC/OS-II Device Drivers.....	292
11.3.3. Thread-Safe HAL Drivers.....	293
11.3.4. The newlib ANSI C Standard Library.....	294
11.3.5. Interrupt Service Routines for MicroC/OS-II.....	295
11.4. Implementing MicroC/OS-II Projects for the Nios II Processor.....	295
12. Ethernet and the NicheStack TCP/IP Stack.....	296
12.1. Prerequisites for Understanding the NicheStack TCP/IP Stack.....	296
12.2. Introduction to the NicheStack TCP/IP Stack - Nios II Edition.....	297
12.2.1. The NicheStack TCP/IP Stack Files and Directories.....	297
12.2.2. Support and Licensing.....	298
12.3. Other TCP/IP Stack Providers for the Nios II Processor.....	298
12.4. Using the NicheStack TCP/IP Stack - Nios II Edition.....	298
12.4.1. Nios II System Requirements.....	298
12.4.2. The NicheStack TCP/IP Stack Tasks.....	299
12.4.3. Initializing the Stack.....	299
12.4.4. Calling the Sockets Interface.....	302
12.5. Configuring the NicheStack TCP/IP Stack in a Nios II Program.....	303
12.5.1. NicheStack TCP/IP Stack General Settings.....	304
12.5.2. IP Options.....	304
12.5.3. TCP Options.....	304
12.6. Further Information.....	305
12.7. Known Limitations.....	305
13. Read-Only Zip File System.....	306
13.1. Using the Read-Only Zip File System in a Project.....	306
13.1.1. Preparing the Zip File.....	307
13.1.2. Programming the Zip File to Flash.....	307
14. Publishing Component Information to Embedded Software.....	308
14.1. Embedded Component Information Flow.....	308
14.1.1. Embedded Component Information Flow Diagram.....	308
14.1.2. Tcl Assignment Statements.....	309
14.2. Embedded Software Assignments.....	309



14.2.1. C Macro Namespace.....	309
14.2.2. Configuration Namespace.....	310
14.2.3. Memory Initialization Namespace.....	313
15. HAL API Reference.....	315
15.1. HAL API Functions.....	315
15.1.1. _exit().....	315
15.1.2. _rename().....	316
15.1.3. alt_dcache_flush().....	316
15.1.4. alt_dcache_flush_all().....	317
15.1.5. alt_dcache_flush_no_writeback().....	318
15.1.6. alt_uncached_malloc().....	319
15.1.7. alt_uncached_free().....	319
15.1.8. alt_remap_uncached().....	320
15.1.9. alt_remap_cached().....	321
15.1.10. alt_icache_flush_all().....	322
15.1.11. alt_icache_flush().....	323
15.1.12. alt_alarm_start().....	323
15.1.13. alt_alarm_stop().....	325
15.1.14. alt_dma_rxchan_depth().....	325
15.1.15. alt_dma_rxchan_close().....	326
15.1.16. alt_dev_reg().....	327
15.1.17. alt_dma_rxchan_open().....	328
15.1.18. alt_dma_rxchan_prepare().....	329
15.1.19. alt_dma_rxchan_reg().....	330
15.1.20. alt_dma_txchan_close().....	331
15.1.21. alt_dma_txchan_ioctl().....	332
15.1.22. alt_dma_txchan_open().....	333
15.1.23. alt_dma_txchan_reg().....	334
15.1.24. alt_flash_close_dev().....	335
15.1.25. alt_exception_cause_generated_bad_addr().....	336
15.1.26. alt_erase_flash_block().....	336
15.1.27. alt_dma_rxchan_ioctl().....	337
15.1.28. alt_dma_txchan_space().....	339
15.1.29. alt_dma_txchan_send().....	340
15.1.30. alt_flash_open_dev().....	341
15.1.31. alt_fs_reg().....	341
15.1.32. alt_get_flash_info().....	342
15.1.33. alt_ic_irq_disable().....	343
15.1.34. alt_ic_irq_enabled().....	344
15.1.35. alt_ic_isr_register().....	345
15.1.36. alt_ic_irq_enable().....	347
15.1.37. alt_instruction_exception_register().....	348
15.1.38. alt_irq_disable().....	349
15.1.39. alt_irq_cpu_enable_interrupts ().....	350
15.1.40. alt_irq_disable_all().....	351
15.1.41. alt_irq_enable().....	352
15.1.42. alt_irq_enable_all().....	352
15.1.43. alt_irq_enabled().....	353
15.1.44. alt_irq_init().....	354
15.1.45. alt_irq_pending ().....	355

15.1.46. alt_irq_register()	356
15.1.47. alt_llist_insert()	357
15.1.48. alt_llist_remove()	358
15.1.49. alt_load_section()	359
15.1.50. alt_nticks()	360
15.1.51. alt_read_flash()	360
15.1.52. alt_tick()	361
15.1.53. alt_ticks_per_second()	362
15.1.54. alt_timestamp()	363
15.1.55. alt_timestamp_freq()	364
15.1.56. alt_timestamp_start()	364
15.1.57. alt_write_flash()	365
15.1.58. alt_write_flash_block()	366
15.1.59. close()	367
15.1.60. fstat()	368
15.1.61. fork()	369
15.1.62. fcntl()	369
15.1.63. execve()	371
15.1.64. getpid()	371
15.1.65. kill()	372
15.1.66. stat()	373
15.1.67. settimeofday()	374
15.1.68. wait()	374
15.1.69. unlink()	375
15.1.70. sbrk()	376
15.1.71. link()	376
15.1.72. lseek()	377
15.1.73. alt_sysclk_init()	378
15.1.74. open()	379
15.1.75. times()	380
15.1.76. read()	381
15.1.77. write()	382
15.1.78. usleep()	383
15.1.79. alt_lock_flash()	384
15.1.80. gettimeofday()	385
15.1.81. ioctl()	386
15.1.82. isatty()	387
15.2. HAL Standard Types	388
15.2.1. alt_getchar()	389
15.2.2. alt_putstr()	389
15.2.3. alt_putchar()	390
15.2.4. alt_printf()	391
15.3. ADC HAL Device Driver	391
15.3.1. adc_stop	391
15.3.2. adc_start	392
15.3.3. adc_set_mode_run_once	392
15.3.4. adc_set_mode_run_continuously	392
15.3.5. adc_recalibrate	393
15.3.6. adc_interrupt_enable	393
15.3.7. adc_interrupt_disable	394
15.3.8. adc_clear_interrupt_status	394



15.3.9. adc_wait_for_interrupt - ADC Sample Storage Status Register.....	394
15.3.10. adc_interrupt_asserted.....	395
15.3.11. adc_wait_for interrupt - IRQ Status Register.....	395
15.3.12. alt_adc_word_read.....	395
16. Nios II Software Build Tools Reference.....	396
16.1. Nios II Software Build Tools Utilities.....	396
16.1.1. Logging Levels.....	396
16.1.2. Setting Values.....	397
16.1.3. Utility and Script Summary.....	397
16.1.4. nios2-app-generate-makefile.....	398
16.1.5. nios2-bsp-create-settings.....	400
16.1.6. nios2-bsp-generate-files.....	402
16.1.7. nios2-bsp-query-settings.....	403
16.1.8. nios2-bsp-update-settings.....	404
16.1.9. nios2-lib-generate-makefile.....	405
16.1.10. nios2-bsp-editor.....	407
16.1.11. nios2-app-update-makefile.....	407
16.1.12. nios2-lib-update-makefile.....	410
16.1.13. nios2-swexample-create.....	412
16.1.14. nios2-elf-insert.....	413
16.1.15. nios2-elf-query.....	414
16.1.16. nios2-flash-programmer-generate.....	415
16.1.17. nios2-bsp.....	417
16.1.18. nios2-bsp-console.....	419
16.1.19. alt-file-convert (BETA).....	420
16.2. Nios II Design Example Scripts.....	421
16.2.1. create-this-bsp.....	421
16.2.2. create-this-app.....	421
16.2.3. Finding create-this-app and create-this-bsp.....	422
16.3. Settings Managed by the Software Build Tools.....	423
16.3.1. Overview of BSP Settings.....	424
16.3.2. Overview of Component and Driver Settings.....	425
16.3.3. Settings Reference.....	426
16.4. Application and User Library Makefile Variables.....	462
16.4.1. Application Makefile Variables.....	462
16.4.2. User Library Makefile Variables.....	464
16.4.3. Standard Build Flag Variables.....	465
16.5. Software Build Tools Tcl Commands.....	465
16.5.1. Tcl Command Environments.....	465
16.5.2. Tcl Commands for BSP Settings.....	466
16.5.3. Tcl Commands for BSP Generation Callbacks.....	491
16.5.4. Tcl Commands for Drivers and Packages.....	500
16.6. Software Build Tools Path Names.....	511
16.6.1. Command Arguments.....	511
16.6.2. Object File Directory Tree.....	512

1. Nios® II Software Developer's Handbook Revision History

Table 1. Nios® II Software Developer's Handbook Revision History Summary

Chapter	Date of Last Update
Overview of Nios® II Embedded Development Revision History on page 13	October 29, 2018
Getting Started with the Graphical User Interface Revision History on page 13	April 30, 2019
Getting Started from the Command Line Revision History on page 13	October 29, 2018
Nios II Software Build Tools Revision History on page 14	October 29, 2018
Overview of the Hardware Abstraction Layer Revision History on page 14	October 29, 2018
Developing Programs Using the Hardware Abstraction Layer Revision History on page 14	October 29, 2018
Developing Device Drivers for the Hardware Abstraction Layer Revision History on page 15	October 29, 2018
Exception Handling Revision History on page 15	October 29, 2018
Cache and Tightly-Coupled Memory Revision History on page 15	October 29, 2018
MicroC/OS-II Real-Time Operating System Revision History on page 15	October 29, 2018
Ethernet and the NicheStack TCP/IP Stack - Nios II Edition Revision History on page 16	October 29, 2018
Read-Only Zip File System Revision History on page 16	October 29, 2018
Publishing Component Information to Embedded Software Revision History on page 16	October 29, 2018
HAL API Reference Revision History on page 17	October 29, 2018
Nios II Software Build Tools Reference Revision History on page 17	October 29, 2018



1.1. Overview of Nios® II Embedded Development Revision History

Document Version	Intel® Quartus® Prime Version	Changes
2019.07.01	19.2	Added section: <i>Installing Windows* Subsystem for Linux* (WSL) on Windows.</i>
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Overview of Nios II Embedded Development](#) on page 18

1.2. Getting Started with the Graphical User Interface Revision History

Document Version	Intel Quartus Prime Version	Changes
2019.04.30	19.1	Added section: <i>Installing Eclipse IDE into Nios II EDS.</i>
2018.10.29	18.1	<ul style="list-style-type: none"> Removed section: <i>Nios II Hardware v2 (beta).</i> Editorial changes: Rebranding.
2017.05.08	17.0	<ul style="list-style-type: none"> Added information about when to use the <i>Nios II Hardware v2 (beta)</i> section. Added information about using Intel Quartus Prime Programmer when using the Intel Quartus Prime Pro Edition in the <i>Programming Flash in Intel FPGA Embedded Systems</i> section.
2015.12.14	15.1	Removed references of the SOPC Builder.
2015.10.30	15.1	Corrected the available versions of the GCC.
2015.05.14	15.0	Initial release.

Related Information

[Getting Started with the Graphical User Interface](#) on page 26

1.3. Getting Started from the Command Line Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Getting Started from the Command Line](#) on page 73



1.4. Nios II Software Build Tools Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Removed the <i>MacroC/OS-II Thread-Aware Debugging</i> section.
2015.05.14	15.0	Initial release.

Related Information

- [Nios II Software Build Tools](#) on page 87
- [GNU Website](#)

1.5. Overview of the Hardware Abstraction Layer Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Overview of the Hardware Abstraction Layer](#) on page 152

1.6. Developing Programs Using the Hardware Abstraction Layer Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.10.09	17.1	<ul style="list-style-type: none">• In section <i>Advanced_Placement_Options</i>, replaced instances of "txt" with "text"• In section <i>Boot Modes</i>, updated the description for <code>alt_load_section()</code>
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158



1.7. Developing Device Drivers for the Hardware Abstraction Layer Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

1.8. Exception Handling Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Exception Handling](#) on page 244

1.9. Cache and Tightly-Coupled Memory Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Cache and Tightly-Coupled Memory](#) on page 283

1.10. MicroC/OS-II Real-Time Operating System Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.



Related Information

[MicroC/OS-II Real-Time Operating System](#) on page 290

1.11. Ethernet and the NicheStack TCP/IP Stack - Nios II Edition Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

- [Appendix A: Using the Nios II Integrated Development Environment](#)
- [Ethernet and the NicheStack TCP/IP Stack](#) on page 296

1.12. Read-Only Zip File System Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Read-Only Zip File System](#) on page 306

1.13. Publishing Component Information to Embedded Software Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Publishing Component Information to Embedded Software](#) on page 308



1.14. HAL API Reference Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	Editorial changes: Rebranding.
2017.10.09	17.1	Updated the description for <code>alt_load_section()</code> .
2017.05.08	17.0	Added the ADC HAL Device Driver APIs.
2015.05.14	15.0	Initial release.

Related Information


[HAL API Reference](#) on page 315

1.15. Nios II Software Build Tools Reference Revision History

Document Version	Intel Quartus Prime Version	Changes
2018.10.29	18.1	<ul style="list-style-type: none">Clarified the big endian support in <code>hal.make.ignore_system_derived.big_endian</code> setting.Editorial changes: Rebranding.
2017.05.08	17.0	Maintenance release.
2015.05.14	15.0	Initial release.

Related Information

[Nios II Software Build Tools Reference](#) on page 396



2. Overview of Nios II Embedded Development

There are two variation of *Nios II Software Developer's Handbook*:

- The *Nios II Classic Software Developer's Handbook* describes embedded software development tools for the Nios II Classic cores; and there are no future updates planned.
- The *Nios II Software Developer's Handbook* describes embedded software development tools for the Nios II. It does not describe IP cores.

This handbook describes the basic information needed to develop embedded software for the Intel FPGA Nios II processor. The Intel FPGA Nios II processor contains new features added after the Intel Quartus Prime 14.0 version. The chapters in this handbook describes the Nios II software development environment, the Nios II Embedded Design Suite (EDS) tools that are available to you, and the process for developing software.

Related Information

[Overview of Nios II Embedded Development Revision History](#) on page 13

For details on the document revision history of this chapter

2.1. Installing Windows Subsystem for Linux (WSL) on Windows

Starting with Nios II EDS in Intel Quartus Prime Pro Edition version 19.2 and Intel Quartus Prime Standard Edition version 19.1, the Cygwin component in the Windows version of Nios II EDS has been removed and replaced with WSL.


The procedure for installing WSL:

1. Go to <https://docs.microsoft.com/en-us/windows/wsl/install-win10> and follow Microsoft*'s instructions to install Ubuntu 18.04 LTS for WSL.

Note: Windows 10 build version 16215.0 or higher is the recommended operating system version.

2. After installation has successfully completed, launch Ubuntu 18.04.
3. Install additional `distro` packages required for Nios II EDS using the following commands:

```
a. sudo apt install wsl
b. sudo apt install doc2unix
c. sudo apt install make
```



Note:

- For the Nios II Command Shell, use all command line tools, as before, but you need to add .exe to launch a Windows executable, like `eclipse-nios2.exe` or `jtagconfig.exe`.
- Nios II BSP and application projects from previous Intel Quartus Prime Pro Edition releases are not compatible with this WSL solution. You are required to regenerate your projects.

2.2. Prerequisites for Understanding the Nios II Embedded Design Suite

The *Nios II Software Developer's Handbook* assumes you have a basic familiarity with embedded processor concepts. You do not need to be familiar with any specific Intel FPGA technology or with Intel FPGA development tools. Familiarity with Intel FPGA hardware development tools can give you a deeper understanding of the reasoning behind the Nios II software development environment. However, software developers can create and debug applications without further knowledge of Intel FPGA technology.

2.3. Finding Nios II EDS Files

When you install the Nios II EDS, you specify a root directory for the EDS file structure. This root directory must be adjacent to the Quartus II installation. When you install the latest release of the Nios II EDS on the Windows operating system, choose a local root folder that identifies the content, for example: `c:\altera\<latest release number>\nios2eds`.

Note: For simplicity, this handbook refers to this directory as *<Nios II EDS install path>*.

2.4. Nios II Software Development Environment

The Nios II EDS provides a consistent software development environment that works for all Nios II processor systems. With the Nios II EDS running on a host computer, an Intel FPGA, and a JTAG download cable (such as an Intel FPGA USB-Blaster™ download cable), you can write programs for and communicate with any Nios II processor system. The Nios II processor's JTAG debug module provides a single, consistent method to connect to the processor using a JTAG download cable. Accessing the processor is the same, regardless of whether a device implements only a Nios II processor system, or whether the Nios II processor is embedded deeply in a complex multiprocessor system. Therefore, you do not need to spend time manually creating interface mechanisms for the embedded processor.

The Nios II EDS includes proprietary and open-source tools (such as the GNU C/C++ tool chain) for creating Nios II programs. The Nios II EDS automates board support package (BSP) creation for Nios II processor-based systems, eliminating the need to spend time manually creating BSPs. The BSP provides a C/C++ runtime environment, insulating you from the hardware in your embedded system. Intel FPGA BSPs contain the Intel FPGA hardware abstraction layer (HAL), an optional RTOS, and device drivers.

2.5. Nios II EDS Development Flows

A development flow is a way of using a set of development tools together to create a software project. The Nios II EDS provides the following development flows for creating Nios II programs:

- The Nios II Software Build Tools (SBT), which provides two user interfaces:
 - The Nios II SBT command line
 - The Nios II SBT for Eclipse

2.5.1. Nios II SBT Development Flow

The Nios II SBT allows you to create Nios II software projects, with detailed control over the software build process. The same Nios II SBT utilities, scripts and Tcl commands are available from both the command line and the Nios II SBT for Eclipse graphical user interface (GUI).

The SBT allows you to create and manage single-threaded programs as well as complex applications based on an RTOS and middleware libraries available from Intel FPGA and third-party vendors.

The SBT provides powerful Tcl scripting capabilities. In a Tcl script, you can query project settings, specify project settings conditionally, and incorporate the software project creation process in a scripted software development flow. Tcl scripting is supported both in Eclipse and at the command line.

Related Information

[Nios II Software Build Tools](#) on page 87

For more information about Tcl scripting.

2.5.1.1. Nios II SBT for Eclipse

The Nios II SBT for Eclipse is a thin GUI layer that runs the Nios II SBT utilities and scripts behind the scenes, presenting a unified development environment. The SBT for Eclipse provides a consistent development platform that works for all Nios II processor systems. You can accomplish all software development tasks within Eclipse, including creating, editing, building, running, debugging, and profiling programs.

The Nios II SBT for Eclipse is based on the popular Eclipse framework and the Eclipse C/C++ development toolkit (CDT) plugins. The Nios II SBT creates your project makefiles for you, and Eclipse provides extensive capabilities for interactive debugging and management of source files.

The SBT for Eclipse also allows you to import and debug projects you created in the Nios II Command Shell.

Related Information

- [Getting Started with the Graphical User Interface](#) on page 26
For more information about the Nios II SBT for Eclipse.
- [Eclipse Foundation](#)
For more information about Eclipse, visit the Eclipse Foundation website.



2.5.1.2. Nios II SBT Command Line

In the Nios II SBT command line development flow, you create, modify, build, and run Nios II programs with Nios II SBT commands typed at a command line or embedded in a script. You run the Nios II SBT commands from the Nios II Command Shell.

Note: To debug your command-line program, import your SBT projects to Eclipse. You can further edit, rebuild, run, and debug your imported project in Eclipse.

Related Information

[Getting Started from the Command Line](#) on page 73

For more information about the Nios II SBT in command-line mode

2.6. Nios II Programs

Each Nios II program you develop consists of an application project, optional user library projects, and a BSP project. You build your Nios II program to create an Executable and Linking Format File (**.elf**) which runs on a Nios II processor.

The Nios II SBT creates software projects for you. Each project is based on a makefile.

2.6.1. Makefiles and the SBT

The makefile is the central component of a Nios II software project, whether the project is created with the Nios II SBT for Eclipse, or on the command line. The makefile describes all the components of a software project and how they are compiled and linked. With a makefile and a complete set of C/C++ source files, your Nios II software project is fully defined.

As a key part of creating a software project, the SBT creates a makefile for you. Nios II projects are sometimes called "user-managed," because you, the user, are responsible for the content of the project makefile. You use the Nios II SBT to control what goes in the makefile.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

For more information about creating makefiles.

2.6.2. Nios II Software Project Types

2.6.2.1. Application Project

A Nios II C/C++ application project consists of a collection of source code, plus a makefile. A typical characteristic of an application is that one of the source files contains function `main()`. An application includes code that calls functions in libraries and BSPs. The makefile compiles the source code and links it with a BSP and one or more optional libraries, to create one **.elf** file.

2.6.2.2. User Library Project

A user library project is a collection of source code compiled to create a single library archive file (.a). Libraries often contain reusable, general purpose functions that multiple application projects can share. A collection of common arithmetical functions is one example. A user library does not contain a `main()` function.

2.6.2.3. BSP Project

A Nios II BSP project is a specialized library containing system-specific support code. A BSP provides a software runtime environment customized for one processor in a Nios II hardware system. The Nios II EDS provides tools to modify settings that control the behavior of the BSP.

A BSP contains the following elements:

- Hardware abstraction layer
- Optional custom newlib C standard library⁽¹⁾
- Device drivers
- Optional software packages
- Optional real-time operating system

Related Information

- [Intel FPGA Software Packages for Embedded Systems](#) on page 22
- [Overview of the Hardware Abstraction Layer](#) on page 152
- [Nios II Software Build Tools Reference](#) on page 396
For more information, refer to the "Nios II Embedded Software Projects" chapter.
- [Intel FPGA Software Packages for Embedded Systems](#) on page 22
- [MicroC/OS-II Real-Time Operating System](#) on page 290

2.7. Intel FPGA Software Packages for Embedded Systems

The Nios II EDS includes software packages to extend the capabilities of your software. You can include these software packages in your BSP.

Table 2. Intel FPGA Nios II Software Packages Distributed with the Nios II EDS

Name	Description
NicheStack TCP/IP Stack - Nios II Edition	Refer to the "Ethernet and the NicheStack TCP/IP Stack - Nios II Edition" chapter.
Read-only zip file system	Refer to the "Read-Only Zip File System" chapter.
Host file system	Refer to the "Developing Programs Using the Hardware Abstraction Layer" chapter.

Related Information

- [Read-Only Zip File System](#) on page 306

⁽¹⁾ The complete HTML documentation for newlib resides in the Nios II EDS directory.



- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [Ethernet and the NicheStack TCP/IP Stack](#) on page 296
- [Embedded Software](#)
For more information about a complete list of the additional software packages available from Intel FPGA's partners

2.8. Nios II Embedded Design Examples

The Nios II EDS includes documented software examples to demonstrate all prominent features of the Nios II processor and the development environment. The examples can help you start the development of your custom design. They provide a stable starting point for exploring design options. Also, they demonstrate many commonly used features of the Nios II EDS.

Note: The hardware design examples are available on the Embedded Processor Design Examples web page.

Related Information

[Embedded Processor Design Examples](#)

2.8.1. Hardware Examples

You can run Nios II hardware designs on many Intel development boards. The hardware examples for each Intel development board are available on the Design Examples web page..

Note: **The Nios II with MMU design** is intended to demonstrate Linux. This design does not work with the SBT, because the SBT does not support the Nios II MMU.

Related Information

- [Nios II Ethernet Standard Design Example](#)
- [Nios II Processor with Memory Management Unit Design Example](#)
- [Intel FPGA Development Kits](#)
- [Design Examples](#)


2.8.2. Software Examples

You can run Nios II software examples that run on many of the hardware design examples described in the previous section.

The Nios II software examples directory contains the following files:

- Source file (.c)
- Header file (.h)
- readme.txt
- template.xml

Figure 1. Software Design Example Directory Structure



Related Information

[Getting Started from the Command Line](#) on page 73

For more information about using these scripts to create software projects.

2.9. Third-Party Embedded Tools Support

Several third-party vendors support the Nios II processor, providing products such as design services, operating systems, stacks, other software libraries, and development tools.

Related Information


[Nios II Processor](#)

For more information about the most up-to-date information about third-party support for the Nios II processor

2.10. Additional Nios II Information

This handbook is one part of the complete Nios II processor documentation suite. Consult the following references for further Nios II information:


- The *Nios II Processor Reference Guide* defines the processor hardware architecture and features, including the instruction set architecture.
- The *Embedded Peripherals IP User Guide* provides a reference for the peripherals distributed with the Nios II processor. This handbook describes the hardware structure and Nios II software drivers for each peripheral.
- The *Embedded Design Handbook* describes how to use the software development tools effectively, and recommends design styles and practices for developing, debugging, and optimizing embedded systems.



- The Intel FPGA Knowledge Database is an Internet resource that offers solutions to frequently asked questions with an easy-to-use search engine.
- Application notes and tutorials offer step-by-step instructions on using the Nios II processor for a specific application or purpose. These documents are available on the Intel FPGA Nios II Processor Documentation web page.
- The Nios II EDS documentation launchpad. The launchpad is an HTML page installed with the Nios II EDS, which provides links to Nios II documentation, examples, and other resources. The way you open the launchpad depends on your software platform.
 - In the Windows operating system, on the Start menu, point to **Programs > Intel FPGA > Nios II EDS**, and click **Nios II <version> Documentation**.
 - In the Linux operating system, open <Nios II EDS install path>/**documents/index.html** in a web browser.

Related Information

- [Nios II Processor Reference Guide](#)
For more information on hardware architecture and features, including the instruction set architecture
- [Embedded Peripherals IP User Guide](#)
For more information on hardware structure and Nios II software drivers for each peripheral
- [Embedded Design Handbook](#)
For more information on design styles and practices for developing, debugging, and optimizing embedded systems
- [Intel FPGA Knowledge Database](#)
For more information, refer to the Knowledge Database page of the Intel FPGA website.
- [Intel FPGA Nios II Processor Documentation](#)



3. Getting Started with the Graphical User Interface

The Nios II Software Build Tools (SBT) for Eclipse is a set of plugins based on the Eclipse framework and the Eclipse C/C++ development toolkit (CDT) plugins. The Nios II SBT for Eclipse provides a consistent development platform that works for all Nios II embedded processor systems. You can accomplish all Nios II software development tasks within Eclipse, including creating, editing, building, running, debugging, and profiling programs.

Related Information

[Getting Started with the Graphical User Interface Revision History](#) on page 13
For details on the document revision history of this chapter

3.1. Installing Eclipse IDE into Nios II EDS

Starting with Nios II EDS v19.1, the Nios II EDS requires the Eclipse IDE component to be manually installed.

The procedure for installing Eclipse IDE:

1. Download CDT 8.8.1 which is Eclipse C/C++ IDE for Mars.2.
 - a. Windows: https://www.eclipse.org/downloads/download.php?file=/technology/epp/downloads/release/mars/2/eclipse-cpp-mars-2-win32-x86_64.zip
 - b. Linux: https://www.eclipse.org/downloads/download.php?file=/technology/epp/downloads/release/mars/2/eclipse-cpp-mars-2-linux-gtk-x86_64.tar.gz
2. Extract the downloaded file into this directory: <Intel Quartus Prime installation directory>/nios2eds/bin.
You should see the <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse folder after extraction is done.
3. Rename the <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse folder to <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse_nios2.
4. Extract <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse_nios2_plugins.zip for Windows or <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse_nios2_plugins.tar.gz for Linux to <Intel Quartus Prime installation directory>/nios2eds/bin.



The extraction overrides files in <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse_nios2.

5. Verify the extraction is done correctly by making sure you see the <Intel Quartus Prime installation directory>/nios2eds/bin/eclipse_nios2/plugin_customization.ini file.
6. You can now launch Nios II SBT for Eclipse using eclipse-nios2.exe.

Note: The instructions are also included in the <Intel Quartus Prime installation directory>/nios2eds/bin/README file.

3.2. Getting Started with Nios II Software in Eclipse

Writing software for the Nios II processor is similar to writing software for any other microcontroller family. The easiest way to start designing effectively is to purchase a development kit from Intel FPGA that includes documentation, a ready-made evaluation board, a getting-started reference design, and all the development tools necessary to write Nios II programs.

Modifying existing code is a common, easy way to learn to start writing software in a new environment. The Nios II Embedded Design Suite (EDS) provides many example software designs that you can examine, modify, and use in your own programs. The provided examples range from a simple "Hello world" program, to a working RTOS example, to a full TCP/IP stack running a web server. Each example is documented and ready to compile.

This section guides you through the most fundamental operations in the Nios II SBT for Eclipse in a tutorial-like fashion. It shows how to create an application project for the Nios II processor, along with the board support package (BSP) project required to interface with your hardware. It also shows how to build the application and BSP projects in Eclipse, and how to run the software on an Intel FPGA development board.

3.2.1. The Nios II SBT for Eclipse Workbench

The term 'workbench' refers to the Nios II SBT for Eclipse desktop development environment. The workbench is where you edit, compile and debug your programs in Eclipse.

3.2.1.1. Perspectives, Editors, and Views

Each workbench window contains one or more perspectives. Each perspective provides a set of capabilities for accomplishing a specific type of task.

Most perspectives in the workbench comprise an editor area and one or more views. An editor allows you to open and edit a project resource (i.e., a file, folder, or project). Views support editors, and provide alternative presentations and ways to navigate the information in your workbench.

Any number of editors can be open at once, but only one can be active at a time. The main menu bar and toolbar for the workbench window contain operations that are applicable to the active editor. Tabs in the editor area indicate the names of resources that are currently open for editing. An asterisk (*) indicates that an editor has unsaved changes. Views can also provide their own menus and toolbars, which, if

present, appear along the top edge of the view. To open the menu for a view, click the drop-down arrow icon at the right of the view's toolbar or right-click in the view. A view might appear on its own, or stacked with other views in a tabbed notebook.

For detailed information about the Eclipse workbench, perspectives, and views, refer to the Eclipse help system.

Before you create a Nios II project, you must ensure that the Nios II perspective is visible. To open the Nios II perspective, on the Window menu, point to **Open Perspective**, then **Other**, and click **Nios II**.

3.2.1.2. The Intel FPGA Bytestream Console

The workbench in Eclipse for Nios II includes a bytestream console, available through the Eclipse **Console** view. The Intel FPGA bytestream console enables you to see output from the processor's `stdout` and `stderr` devices, and send input to its `stdin` device.

Related Information

[Using the Intel FPGA Bytestream Console](#) on page 34

For more information about the Altera bytestream console.

3.2.2. Creating a Project

In the Nios II perspective, on the File menu, point to **Nios II Application and BSP from Template**. The **Nios II Application and BSP from Template** wizard appears. This wizard provides a quick way to create an application and BSP at the same time.

Alternatively, you can create separate application, BSP and user library projects.

3.2.2.1. Specifying the Application

In the first page of the **Nios II Application and BSP from Template** wizard, you specify a hardware platform, a project name, and a project template. You optionally override the default location for the application project, and specify a processor name if you are targeting a multiprocessor hardware platform.

You specify a BSP in the second page of the wizard.

3.2.2.1.1. Specifying the Hardware Platform

You specify the target hardware design by selecting a SOPC Information File (**.sopcinfo**) in the **SOPC Information File name** box.

3.2.2.1.2. Specifying the Project Name

Select a descriptive name for your project. The SBT creates a folder with this name to contain the application project files.

Letters, numbers, and the underscore (`_`) symbol are the only valid project name characters. Project names cannot contain spaces or special characters. The first character in the project name must be a letter or underscore. The maximum filename length is 250 characters.



Related Information

[Specifying the BSP](#) on page 29

For more information about how the SBT also creates a folder to contain BSP project files.

3.2.2.1.3. Specifying the Project Template

Project templates are ready-made, working software projects that serve as examples to show you how to structure your own Nios II projects. It is often easier to start with a working project than to start a blank project from scratch.

You select the project template from the **Templates** list.

The hello_world template provides an easy way to create your first Nios II project and verify that it builds and runs correctly.

3.2.2.1.4. Specifying the Project Location

The project location is the parent directory in which the SBT creates the project folder. By default, the project location is under the directory containing the .sopcinfo file, in a folder named software.

To place your application project in a different folder, turn off **Use default location**, and specify the path in the **Project location** box.

3.2.2.1.5. Specifying the Processor

If your target hardware contains multiple Nios II processors, **CPU name** contains a list of all available processors in your design. Select the processor on which your software is intended to run.

3.2.2.2. Specifying the BSP

When you have finished specifying the application project in the first page of the **Nios II Application and BSP from Template** wizard, you proceed to the second page by clicking **Next**.

On the second page, you specify the BSP to link with your application. You can create a new BSP for your application, or select an existing BSP. Creating a new BSP is often the simplest way to get a project running the first time.

You optionally specify the name and location of the BSP.

3.2.2.2.1. Specifying the BSP Project Name

By default, if your application project name is *<project>*, the BSP is named *<project>_bsp*. You can type in a different name if you prefer. The SBT creates a directory with this name, to contain the BSP project files.

Related Information

[Specifying the Project Name](#) on page 28

For more information about how the BSP project names are subject to the same restrictions as application project names.

3.2.2.2. Specifying the BSP Project Location

The BSP project location is the parent directory in which the SBT creates the folder. The default project location is the same as the default location for an application project. To place your BSP in a different folder, turn off **Use default location**, and specify the BSP location in the **Project location** box.

3.2.2.3. Selecting an Existing BSP

As an alternative to creating a BSP automatically from a template, you can associate your application project with a pre-existing BSP. Select **Select an existing BSP project from your workspace**, and select a BSP in the list. The **Create** and **Import** buttons to the right of the existing BSP list provide convenient ways to add BSPs to the list.

3.2.2.3. Creating the Projects

When you have specified your BSP, you click **Finish** to create the projects.

The SBT copies required source files to your project directories, and creates makefiles and other generated files. Finally, the SBT executes a **make clean** command on your BSP.

Related Information

[Nios II Software Build Tools](#) on page 87

For more information about the folders and files in a Nios II BSP.

3.2.3. Navigating the Project

When you have created a Nios II project, it appears in the **Project Explorer** view, which is typically displayed at the left side of the Nios II perspective. You can expand each project to examine its folders and files.

Related Information

[Nios II Software Build Tools](#) on page 87

For more information about what happens when Nios II projects are created, refer to "Nios II Software Projects". For more information about the **make clean** command, refer to "Makefiles".

3.2.4. Building the Project

To build a Nios II project in the Nios II SBT for Eclipse, right-click the project name and click **Build Project**. A progress bar shows you the build status. The build process can take a minute or two for a simple project, depending on the speed of the host machine. Building a complex project takes longer.

During the build process, you view the build commands and command-line output in the Eclipse **Console** view.

When the build process is complete, the following message appears in the **Console** view, under the **C-Build [<project name>]** title:

```
[<project name> build complete]
```



If the project has a dependency on another project, such as a BSP or a user library, the SBT builds the dependency project first. This feature allows you to build an application and its BSP with a single command.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

3.2.5. Configuring the FPGA

Before you can run your software, you must ensure that the correct hardware design is running on the FPGA. To configure the FPGA, you use the Intel Quartus Prime Programmer.

In the Windows operating system, you start the Intel Quartus Prime Programmer from the Nios II SBT for Eclipse, through the Nios II menu. In the Linux operating system, you start Intel Quartus Prime Programmer from the Intel Quartus Prime software.

The project directory for your hardware design contains an SRAM Object File (.sof) along with the .sopcinfo file. The .sof file contains the hardware design to be programmed in the FPGA.

Related Information

[Intel Quartus Prime Programmer](#)

For more information about programming an FPGA with Intel Quartus Prime Programmer.

3.2.6. Running the Project on Nios II Hardware

This section describes how to run a Nios II program using the Nios II SBT for Eclipse on Nios II hardware, such as an Intel FPGA development board.

Note:

If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.

To run a software project, right-click the application project name, point to **Run As**, and click **Nios II Hardware**. To run a software project as a ModelSim simulation, right-click the application project name, point to **Run As**, and click **Nios II ModelSim**.

This command carries out the following actions:

- Creates a Nios II run configuration.
- Builds the project executable. If all target files are up to date, nothing is built.
- Establishes communications with the target, and verifies that the FPGA is configured with the correct hardware design.
- Downloads the Executable and Linking Format File (.elf) to the target memory
- Starts execution at the .elf entry point.

Program output appears in the Nios II Console view. The Nios II Console view maintains a terminal I/O connection with a communication device connected to the Nios II processor in the hardware system, such as a JTAG UART. When the Nios II

program writes to `stdout` or `stderr`, the Nios II Console view displays the text. The Nios II Console view can also accept character input from the host keyboard, which is sent to the processor and read as `stdin`.

To disconnect the terminal from the target, click the **Terminate** icon in the Nios II Console view. Terminating only disconnects the host from the target. The target processor continues executing the program.

Related Information

- [Run Configurations in the SBT for Eclipse](#) on page 49
For more information about about run configurations.
- [Lauterbach GmbH Website](#)
For more information about the Nios II instruction set.

3.2.7. Debugging the Project on Nios II Hardware

This section describes how to debug a Nios II program using the Nios II SBT for Eclipse on Nios II hardware, such as an Intel FPGA development board.

To debug a software project, right-click the application project name, point to **Debug As**, and click **Nios II Hardware**. This command carries out the following actions:

- Creates a Nios II run configuration.
- Builds the project executable. If all target files are up to date, nothing is built.
- If debugging on hardware, establishes communications with the target, and verifies that the FPGA is configured with the correct hardware design.
- Downloads the **.elf** to the target memory.
- Sets a breakpoint at the top of `main()`.
- Starts execution at the **.elf** entry point.

The Eclipse debugger with the Nios II plugins provides a Nios II perspective, allowing you to perform many common debugging tasks. Debugging a Nios II program with the Nios II plugins is generally the same as debugging any other C/C++ program with Eclipse and the CDT plugins.

For information about debugging with Eclipse and the CDT plugins, refer to the Eclipse help system.

Related Information

- [Run Configurations in the SBT for Eclipse](#) on page 49
For more information about about run configurations.

3.2.7.1. List of Debugging Tasks with the Nios II SBT for Eclipse

The debugging tasks you can perform with the Nios II SBT for Eclipse include the following tasks:



- Controlling program execution with commands such as:
 - Suspend (pause)
 - Resume
 - Terminate
 - Step Into
 - Step Over
 - Step Return
- Setting breakpoints and watchpoints
- Viewing disassembly
- Instruction stepping mode
- Displaying and changing the values of local and global variables in the following formats:
 - Binary
 - Decimal
 - Hexadecimal
- Displaying watch expressions
- Viewing and editing registers in the following formats:
 - Binary
 - Decimal
 - Hexadecimal
- Viewing and editing memory in the following formats:
 - Hexadecimal
 - ASCII
 - Signed integer
 - Unsigned integer
- Viewing stack frames in the **Debug** view

3.2.7.1.1. Console View

Just as when running a program, Eclipse displays program output in the Console view of Eclipse. The Console view maintains a terminal I/O connection with a communication device connected to the Nios II processor in the hardware system, such as a JTAG UART. When the Nios II program writes to `stdout` or `stderr`, the Console view displays the text. The Console view can also accept character input from the host keyboard, which is sent to the processor and read as `stdin`.

3.2.7.1.2. Disconnecting the Terminal from the Target

To disconnect the terminal from the target, click the **Terminate** icon in the Console view. Terminating only disconnects the host from the target. The target processor continues executing the program.

Note: If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.

3.2.7.2. Using the Intel FPGA Bytestream Console

The Intel FPGA bytestream console enables you to see output from the processor's `stdout` and `stderr` devices, and send input to its `stdin` device. The function of the Intel FPGA bytestream console is similar to the **nios2-terminal** command-line utility.

Open the Intel FPGA bytestream console in the Eclipse **Console** view the same way as any other Eclipse console, by clicking the **Open Console** button.

When you open the Intel FPGA bytestream console, the **Bytestream Console Selection** dialog box shows you a list of available bytestreams. This is the same set of bytestreams recognized by System Console. Select the bytestream connected to the processor you are debugging.

You can send characters to the processor's `stdin` device by typing in the bytestream console. Be aware that console input is buffered on a line-by-line basis. Therefore, the processor does not receive any characters until you press the Enter key.

Note: A bytestream device can support only one connection at a time. You must close the Intel FPGA bytestream console before attempting to connect to the processor with the **nios2-terminal** utility, and vice versa.

Related Information

[Analyzing and Debugging Designs with the System Console](#)

For more information about how System Console recognizes bytestreams.

3.2.7.3. Run Time Stack Checking And Exception Debugging

To enable extra exception information, navigate to **Nios II MegaWizard > Advanced Features Exception Checking > Extra Information Register**; and recompile the HW project and regenerate the BSP in the Nios II SBT for Eclipse.

1. Enable the **Run Time Stack Checking** in the BSP project from NIOS II SBT for Eclipse Nios II BSP Editor. From the BSP project, right-click and navigate to **Nios II > BSP editor Settings > Advanced > hal > enable_run_time_stack_checking**.
2. Rebuild BSP and software.
3. Ensure that the FPGA is configured.
4. Start the Debug Session by navigating to **Debug As > Nios II Hardware**.
5. Run the Software.

3.2.7.3.1. Nios II Exception Debugging

To allow easier debugging of Nios II exceptions, first enable the extra exception information in the Nios II.

Note: This is already enabled if you have an MMU.

Also you can navigate to **Nios II MegaWizard > Advanced Features Exception Checking > Extra Information Register**.

Note: There are other options you can choose, like unimplemented instructions.



When an exception is hit, the cause value in the **Nios II Exception Register** can be decoded using the Nios II Exceptions (In Decreasing Priority Order) table from the *Nios II Processor Reference Handbook*.

Note: This table only provides the general cause.

Related Information

- [Nios II Classic Processor Reference Handbook](#)
For more information about the Exception Register Decode Table, refer to the "Exception Overview" chapter in the "Programming Model" section.
- [Nios II Processor Reference Handbook](#)
For more information about the Exception Register Decode Table, refer to the "Exception Overview" chapter in the "Programming Model" section.
- [Nios II Classic Processor Reference Handbook](#)
For more information about the Exception Register Description, refer to the "The exception Register" chapter in the "Programming Model" section.
- [Nios II Processor Reference Handbook](#)
For more information about the Exception Register Description, refer to the "The exception Register" chapter in the "Programming Model" section.

3.2.7.3.2. Stack Overflow

To enable **Stack Checking**, go to the BSP Editor and click on the **Settings** tab, click on **Advanced**, **hal**, and then click **enable_runtime_stack_checking**. When the **Stack Checking** is enabled, extra code is added at the start of each function call to:

- Check the current value of the stack pointer
- Compare this to the **max stack size**, which is stored in the Exception Temp (ET) Register

If the stack pointed to is outside of the valid range, the software branches and calls a **"break 3"** instruction. This is seen by the Debug Control module.

Note: With stack checking on, **malloc()** and **new()** can detect heap exhaustion, as well.

Example 1. Example of function with stack checking code

```

__vfprintf_internal_r:
000002ec:   addi sp,sp,-1308
000002f0:   bgeu sp,et,0x2f8 <__vfprintf_internal_r+12>
000002f4:   break 3

```

The **bgeu** and **break 3** lines are what is added for the stack overflow checking. If the stack pointer has grown beyond its limits the **break** is called.

Related Information

[Embedded Design Handbook](#)

For more information, refer to the "Stack Overflow" chapter of the Embedded Design Handbook.

Recognizing and Debugging a Stack Overflow

When a stack overflow occurs, having registered an instruction-related exception handler helps you identify it by its behavior.

Default Instruction-Related Exception Handler



The default value for an instruction-related exception handler is when it is not registered.

If you don't register an instruction-related exception handler, the "**break 3**" instruction is picked up by the software trap logic and a break is passed to the debugger. You must roll back through the history in the debugger to find the memory operation that triggered the stack checking break.

Note: With stack checking on, **malloc()** and **new()** can detect heap exhaustion.

How to Isolate the Cause of a Sigtrap

How to isolate the cause of a **sigtrap** seen in the debugger with no instruction-related exception handle?

The Debugger breaks with **sigtrap**:

1. Use the thread view in the debug window and select the last state.
This is the highest number. The last thread is the actual call than overflowed.
2. Switch to instruction stepping mode in the debugger by pressing the i-> button in the debug window, which opens the memory disassembly view.
If there has been a stack overflow the disassembly view should show execution pointing to a **break3** after the stack check:

```
__vfprintf_internal_r:
000002ec: addi sp,sp,-1308
000002f0: bgeu sp,et,0x2f8 <__vfprintf_internal_r+12>
000002f4: break 3
```

3. Check the value of **sp** and **et** which holds the max stack side in the Nios II register view.
4. Move to the prior state in the debug window and re-check **sp** vs **et**.





Figure 2. Nios II Debug window



Custom Instruction-Related Exception Handler

For use outside the debugger, you can register your own instruction-related exception handler which is called when the break (or any exception) is seen.

On an exception, including overflow, the HAL calls the instruction-related exception handler, passing in the cause field from the exception register, and the address which caused the exception. At this point, it is up to you to decide what to do.

For more information about how to register an instruction-related exception, refer to

Related Information

- [Exception Handling](#) on page 244
This chapter provides more information about the details on how to register an instruction-related exception.
- [Writing an Instruction-Related Exception Handler](#) on page 280
This chapter provides more information about the details on how to register an instruction-related exception.
- [Registering an Instruction-Related Exception Handler](#) on page 281
This chapter provides more information about the details on how to register an instruction-related exception.
- [Programming Model](#)
For more information, refer to the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

3.2.8. Creating a Simple BSP

You create a BSP with default settings using the **Nios II Board Support Package** wizard. To start the wizard, on the **File** menu, point to **New** and click **Nios II Board Support Package**. The **Nios II Board Support Package** wizard enables you to specify the following BSP parameters:

- The name
- The underlying hardware design
- The location
- The operating system and version

You can select the operating system only at the time you create the BSP. To change operating systems, you must create a new BSP by using the Additional arguments to the **nios2-bsp** script.

If you intend to run the project in the Nios II ModelSim™ simulation environment, use the Additional arguments parameter to specify the location of the test bench simulation package descriptor file (**.spd**). The **.spd** file is located in the Intel Quartus Prime project directory. Specify the path as follows: `--set QUARTUS_PROJECT_DIR=<relative path>`.

Note: Intel FPGA recommends that you use a relative path name, to ensure that the location of your project is independent of the installation directory.

After you have created the BSP, you have the following options for GUI-based BSP editing:

- To access and modify basic BSP properties, right-click the BSP project, click **Properties** ► **Nios II BSP Properties**.
- To modify parameters and settings in detail using the Nios II BSP Editor, refer to *Using the BSP Editor*.

Related Information

- [Using the BSP Editor](#) on page 41
For more information on how to modify parameters and settings in detail using the Nios II BSP Editor.
- [Nios II Software Build Tools](#)
For more information about nios2-bsp command arguments.

3.3. Makefiles and the Nios II SBT for Eclipse

The Nios II SBT for Eclipse creates and manages the makefiles for Nios II software projects. When you create a project, the Nios II SBT creates a makefile based on the source content you specify and the parameters and settings you select. When you modify the project in Eclipse, the Nios II SBT updates the makefile to match.

Details of how each makefile is created and maintained vary depending on the project type, and on project options that you control. The authoritative specification of project contents is always the makefile, regardless how it is created or updated.



By default, the Nios II SBT manages the list of source files in your makefile, based on actions you take in Eclipse. However, in the case of applications and libraries, you have the option to manage sources manually. Both styles of source management are discussed in the following sections.

3.3.1. Eclipse Source Management

Nios II application and user library makefiles are based on source files and properties that you specify directly. Eclipse source management allows you to add and remove source files with standard Eclipse actions, such as dragging a source file into and out of the Project Explorer view and adding a new source file through the File menu.

You can examine and modify many makefile properties in the **Nios II Application Properties** or **Nios II Library Properties** dialog box. To open the dialog box, right-click the project, click **Properties** > **Nios II Application Properties** or **Properties** > **Nios II Library Properties**.

3.3.1.1. Modifying a Makefile with Eclipse Source Management

Table 3. GUI Actions that Modify an Application or Makefile with Eclipse Source Management

Modification	Where Modified
Specifying the application or user library name	Nios II Application Properties or Nios II Library Properties dialog box.
Adding or removing source files	For more information, refer to the Eclipse help system.
Specifying a path to an associated BSP	Project References dialog box.
Specifying a path to an associated user library	Project References dialog box.
Enabling, disabling or modifying compiler options	Nios II Application Properties or Nios II Library Properties dialog box.

After the SBT has created a makefile, you can modify the makefile in the following ways:

- With the Nios II SBT for Eclipse.
- With Nios II SBT commands from the Nios II Command Shell.

When modifying a makefile, the SBT preserves any previous nonconflicting modifications, regardless how those modifications were made.

After you modify a makefile with the Nios II Command Shell, in Eclipse you must right-click the project and click **Update linked resource** to keep the Eclipse project view in step with the makefile.

When the Nios II SBT for Eclipse modifies a makefile, it locks the makefile to prevent corruption by other processes. You cannot edit the makefile from the command line until the SBT has removed the lock.

If you want to exclude a resource (a file or a folder) from the Nios II makefile temporarily, without deleting it from the project, you can use the **Remove from Nios II Build** command. Right-click the resource and click **Remove from Nios II Build**. When a resource is excluded from the build, it does not appear in the makefile, and

Eclipse ignores it. However, it is still visible in the Project Explorer, with a modified icon. To add the resource back into the build, right-click the resource and click **Add to Nios II Build**.

Note: Do not use the Eclipse **Exclude from build** command. With Nios II software projects, you must use the **Remove from Nios II Build** and **Add to Nios II Build** commands instead.

3.3.1.2. Absolute Source Paths and Linked Resources

By default, the source files for an Eclipse project are stored under the project directory. If your project must incorporate source files outside the project directory, you can add them as linked resources.

An Eclipse linked resource can be either a file or a folder. With a linked folder, all source files in the folder and its subfolders are included in the build.

When you add a linked resource (file or folder) to your project, the SBT for Eclipse adds the file or folder to your makefile with an absolute path name. You might use a linked resource to refer to common source files in a fixed location. In this situation, you can move the project to a different directory without disturbing the common source file references.

A linked resource appears with a modified icon (green dot) in the Project Explorer, to distinguish it from source files and folders that are part of the project. You can use the Eclipse debugger to step into a linked source file, exactly as if it were part of the project.

You can reconfigure your project to refer to any linked resource either as an individual file, or through its parent folder. Right-click the linked resource and click **Update Linked Resource**.

You can use the **Remove from Nios II Build** and **Add to Nios II Build** commands with linked resources. When a linked resource is excluded from the build, its icon is modified with a white dot.

You can use Eclipse to create a path variable, defining the location of a linked resource. A path variable makes it easy to modify the location of one or more files in your project.

For information about working with path variables and creating linked resources, refer to the Eclipse help system.

3.3.2. User Source Management

You can remove a makefile from source management control through the **Nios II Application Properties** or **Nios II Library Properties** dialog box.

Simply turn off **Enable source management** to convert the makefile to user source management. When **Enable source management** is off, you must update your makefile manually to add or remove source files to or from the project. The SBT for Eclipse makes no changes to the list of source files, but continues to manage all other project parameters and settings in the makefile.



3.3.2.1. Modifying a Makefile with User Source Management

Editing a makefile manually is an advanced technique. Intel FPGA recommends that you avoid manual editing. The SBT provides extensive capabilities for manipulating makefiles while ensuring makefile correctness.

In a makefile with user-managed sources, you can refer to source files with an absolute path. You might use an absolute path to refer to common source files in a fixed location. In this situation, you can move the project to a different directory without disturbing the common source file references.

Projects with user-managed sources do not support the following features:

- Linked resources
- The **Add to Nios II Build** command
- The **Remove from Nios II Build** command

Table 4. GUI Actions that Modify an Application or a Makefile with User Source Management

Modification	Where Modified
Specifying the application or user library name	Nios II Application Properties or Nios II Library Properties dialog box
Specifying a path to an associated BSP	Project References dialog box
Specifying a path to an associated user library	Project References dialog box
Enabling, disabling or modifying compiler options	Nios II Application Properties or Nios II Library Properties dialog box

Note: With user source management, the source files shown in the Eclipse Project Explorer view do not necessarily reflect the sources built by the makefile. To update the Project Explorer view to match the makefile, right-click the project and click **Sync from Nios II Build**.

3.3.3. BSP Source Management

Nios II BSP makefiles are handled differently from application and user library makefiles. BSP makefiles are based on the operating system, BSP settings, selected software packages, and selected drivers. You do not specify BSP source files directly.

BSP makefiles must be managed by the SBT, either through the BSP Editor or through the SBT command-line utilities.

Related Information

[Using the BSP Editor](#) on page 41

For more information about specifying BSPs

3.4. Using the BSP Editor

Typically, you create a BSP with the Nios II SBT for Eclipse. The Nios II plugins provide the basic tools and settings for defining your BSP. For more advanced BSP editing, use the Nios II BSP Editor. The BSP Editor provides all the tools you need to create even the most complex BSPs.

3.4.1. Tcl Scripting and the Nios II BSP Editor

The Nios II BSP Editor provides support for Tcl scripting. When you create a BSP in the BSP Editor, the editor can run a Tcl script that you specify to supply BSP settings.

You can also export a Tcl script from the BSP Editor, containing all the settings in an existing BSP. By studying such a script, you can learn about how BSP Tcl scripts are constructed.

3.4.2. Starting the Nios II BSP Editor

You start the Nios II BSP Editor in one of the following ways:

- Right-click an existing project, point to **Nios II**, and click **BSP Editor**. The editor loads the BSP Settings File (.bsp) associated with your project, and is ready to update it.
- On the Nios II menu, click **Nios II BSP Editor**. The editor starts without loading a .bsp file.
- Right-click an existing BSP project and click **Properties**. In the **Properties** dialog box, select **Nios II BSP Properties > BSP Editor**. The editor loads your .bsp file for update.

3.4.3. The Nios II BSP Editor Screen Layout

The Nios II BSP Editor screen is divided into two areas. The top area is the command area, and the bottom is the console area. The details of the Nios II BSP Editor screen areas are described in this section.

Below the console area is the **Generate** button. This button is enabled when the BSP settings are valid. It generates the BSP target files, as shown in the **Target BSP Directory** tab.

3.4.4. The Command Area

In the command area, you specify settings and other parameters defining the BSP. The command area contains several tabs:

- The **Main** tab
- The **Software Packages** tab
- The **Drivers** tab
- The **Linker Script** tab
- The **Enable File Generation** tab
- The **Target BSP Directory** tab

Each tab allows you to view and edit a particular aspect of the .bsp, along with relevant command line parameters and Tcl scripts.

The settings that appear on the **Main**, **Software Packages** and **Drivers** tabs are the same as the settings you manipulate on the command line.

Related Information

[Nios II Software Build Tools Reference](#) on page 396



3.4.4.1. The Main Tab

The **Main** tab presents general settings and parameters, and operating system settings, for the BSP. The BSP includes the following settings and parameters:

- The path to the `.sopcinfo` file specifying the target hardware
- The processor name
- The operating system and version

Note: You cannot change the operating system in an existing BSP. You must create a new BSP based on the desired operating system.

- The BSP target directory—the destination for files that the SBT copies and creates for your BSP.
- BSP settings

BSP settings appear in a tree structure. Settings are organized into **Common** and **Advanced** categories. Settings are further organized into functional groups. The available settings depend on the operating system.

When you select a group of settings, the controls for those settings appear in the pane to the right of the tree. When you select a single setting, the pane shows the setting control, the full setting name, and the setting description.

Related Information

- [The Software Packages Tab](#) on page 43
- [The Drivers Tab](#) on page 44
For more information about how the software package and driver settings are presented separately.

3.4.4.2. The Software Packages Tab

The **Software Packages** tab allows you to insert and remove software packages in your BSP, and control software package settings.

At the top of the **Software Packages** tab is the software package table, listing each available software package. The table allows you to select the software package version, and enable or disable the software package.

The operating system determines which software packages are available.

Many software packages define settings that you can control in your BSP. When you enable a software package, the available settings appear in a tree structure, organized into **Common** and **Advanced** settings.

When you select a group of settings, the controls for those settings appear in the pane to the right of the tree. When you select a single setting, the pane shows the setting control, the full setting name, and the setting description.

Enabling and disabling software packages and editing software package settings can have a profound impact on BSP behavior. Refer to the documentation for the specific software package for details.

Related Information

- [The Drivers Tab](#) on page 44
For more information about how the software package and driver settings are presented separately.
- [The Main Tab](#) on page 43
- [Read-Only Zip File System](#) on page 306
For more information about the read-only zip file system.
- [Ethernet and the NicheStack TCP/IP Stack](#) on page 296

3.4.4.3. The Drivers Tab

The **Drivers** tab allows you to select, enable, and disable drivers for devices in your system, and control driver settings.

At the top of the **Drivers** tab is the driver table, mapping components in the hardware system to drivers. The driver table shows components with driver support. Each component has a module name, module version, module class name, driver name, and driver version, determined by the contents of the hardware system. The table allows you to select the driver by name and version, as well as to enable or disable each driver.

When you select a driver version, all instances of that driver in the BSP are set to the version you select. Only one version of a given driver can be used in an individual BSP.

Many drivers define settings that you can control in your BSP. Available driver settings appear in a tree structure below the driver table, organized into **Common** and **Advanced** settings.

When you select a group of settings, the controls for those settings appear in the pane to the right of the tree. When you select a single setting, the pane shows the setting control, the full setting name, and the setting description.

Enabling and disabling device drivers, changing drivers and driver versions, and editing driver settings, can have a profound impact on BSP behavior. Refer to the relevant component documentation and driver information for details.

Related Information

- [The Software Packages Tab](#) on page 43
- [The Main Tab](#) on page 43
- [Embedded Peripherals IP User Guide](#)
For more information about Intel FPGA components.

3.4.4.4. The Linker Script Tab

The **Linker Script** tab allows you to view available memory in your hardware system, and examine and modify the arrangement and usage of linker regions in memory.

When you make a change to the memory configuration, the SBT validates your change.

Note: Rearranging linker regions and linker section mappings can have a very significant impact on BSP behavior.



Related Information

The [Problems Tab](#) on page 47

If there is a problem, a message appears in the **Problems** tab in the console area.

3.4.4.4.1. Linker Section Mappings

At the top of the **Linker Script** tab, the **Linker Section Mappings** table shows the mapping from linker sections to linker regions. You can edit the BSP linker section mappings using the following buttons located next to the linker section table:

- **Add**—Adds a linker section mapping to an existing linker region. The **Add** button opens the **Add Section Mapping** dialog box, where you specify a new section name and an existing linker region.
- **Remove**—Removes a mapping from a linker section to a linker region.
- **Restore Defaults**—Restores the section mappings to the default configuration set up at the time of BSP creation.

3.4.4.4.2. Linker Regions

At the bottom of the **Linker Script** tab, the **Linker Memory Regions** table shows all defined linker regions. Each row of the table shows one linker region, with its address range, memory device name, size, and offset into the selected memory device.

You reassign a defined linker region to a different memory device by selecting a different device name in the **Memory Device Name** column. The **Size** and **Offset** columns are editable. You can also edit the list of linker regions using the following buttons located next to the linker region table:

- **Add**—Adds a linker region in unused space on any existing device. The **Add** button opens the **Add Memory Region** dialog box, where you specify the memory device, the new memory region name, the region size, and the region's offset from the device base address.
- **Remove**—Removes a linker region definition. Removing a region frees the region's memory space to be used for other regions.
- **Add Memory Device**—Creates a linker region representing a memory device that is outside the hardware system. The button launches the **Add Memory Device** dialog box, where you can specify the device name, memory size and base address. After you add the device, it appears in the linker region table, the **Memory Device Usage Table** dialog box, and the **Memory Map** dialog box. This functionality is equivalent to the `add_memory_device` Tcl command.

Note:

Ensure that you specify the correct base address and memory size. If the base address or size of an external memory changes, you must edit the BSP manually to match. The SBT does not automatically detect changes in external memory devices, even if you update the BSP by creating a new settings file.

- **Restore Defaults**—restores the memory regions to the default configuration set up at the time of BSP creation.
- **Memory Usage**—Opens the **Memory Device Usage Table**. The **Memory Device Usage Table** allows you to view memory device usage by defined memory region. As memory regions are added, removed, and adjusted, each device's free memory, used memory, and percentage of available memory are updated. The rightmost column is a graphical representation of the device's usage, according to the memory regions assigned to it.
- **Memory Map**—Opens the **Memory Map** dialog box. The memory map allows you to view a map of system memory in the processor address space. The **Device** table is a read-only reference showing memories in the hardware system that are mastered by the selected processor. Devices are listed in memory address order.
To the right of the **Device** table is a graphical representation of the processor's memory space, showing the locations of devices in the table. Gaps indicate unmapped address space.

Note: This representation is not to scale.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

3.4.4.5. Enable File Generation Tab

The **Enable File Generation** tab allows you to take ownership of specific BSP files that are normally generated by the SBT. When you take ownership of a BSP file, you can modify it, and prevent the SBT from overwriting your modifications. The **Enable File Generation** tab shows a tree view of all target files to be generated or copied when the BSP is generated. To disable generation of a specific file, expand the software component containing the file, expand any internal directory folders, select the file, and right-click. Each disabled file appears in a list at the bottom of the tab. This functionality is equivalent to the `set_ignore_file` Tcl command.

Note: If you take ownership of a BSP file, the SBT can no longer update it to reflect future changes in the underlying hardware. If you change the hardware, be sure to update the file manually.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

3.4.4.6. Target BSP Directory Tab

The **Target BSP Directory** tab is a read-only reference showing you what output to expect when the BSP is generated.

It does not depict the actual file system, but rather the files and directories to be created or copied when the BSP is generated. Each software component, including the operating system, drivers, and software packages, specifies source code to be copied into the BSP target directory. The files are generated in the directory specified on the **Main** tab.

When you generate the BSP, existing BSP files are overwritten, unless you disable generation of the file in the **Enable File Generation** tab.



3.4.5. The Console Area

The console area shows results of settings and commands that you select in the command area. The console area consists of the following tabs:

- The **Information** tab
- The **Problems** tab
- The **Processing** tab

3.4.5.1. The Information Tab

The **Information** tab shows a running list of high-level changes you make to your BSP, such as adding a software package or changing a setting value.

3.4.5.2. The Problems Tab

The **Problems** tab shows warnings and errors that impact or prohibit BSP creation. For example, if you inadvertently specify an invalid linker section mapping, a message appears in the **Problems** tab.

3.4.5.3. The Processing Tab

When you generate your BSP, the **Processing** tab shows files and folders created and copied in the BSP target directory.

3.4.6. Exporting a Tcl Script

When you have configured your BSP to your satisfaction, you can export the BSP settings as a Tcl script. This feature allows you to perform the following tasks:

- Regenerate the BSP from the command line
- Recreate the BSP as a starting point for a new BSP
- Recreate the BSP on a different hardware platform
- Examine the Tcl script to improve your understanding of Tcl command usage

The exported Tcl script captures all BSP settings that you have changed since the previous time the BSP settings file was saved. If you export a Tcl script after creating a new BSP, the script captures all nondefault settings in the BSP. If you export a Tcl script after editing a pre-existing BSP, the script captures your changes from the current editing session.

To export a Tcl script, in the Tools menu, click **Export Tcl Script**, and specify a filename and destination path. The file extension is `.tcl`.

You can later run your exported script as a part of creating a new BSP.

Related Information

- [Using a Tcl Script in BSP Creation](#) on page 48
For more information about how to run a Tcl script during BSP creation.
- [Revising Your BSP](#) on page 116
For more information about default BSP settings and recreating and regenerating BSPs.

3.4.7. Creating a New BSP

To create a BSP in the Nios II BSP Editor, use the **New BSP** command in the File menu to open the **New BSP** dialog box. This dialog box controls the creation of a new BSP settings file. The BSP Editor loads this new BSP after the file is created.

In this dialog box, you specify the following parameters:

- The `.sopcinfo` file defining the hardware platform.
- The CPU name of the targeted processor.
- The BSP type and version.

Note: You can select the operating system only at the time you create the BSP. To change operating systems, you must create a new BSP.

- The operating system version.
- The name of the BSP settings file. It is created with file extension `.bsp`.
- Absolute or relative path names in the BSP settings file. By default, relative paths are enabled for filenames in the BSP settings file.
- An optional Tcl script that you can run to supply additional settings.

Normally, you specify the path to your `.sopcinfo` file relative to the BSP directory. This enables you to move, copy and archive the hardware and software files together. If you browse to the `.sopcinfo` file, or specify an absolute path, the Nios II BSP Editor offers to convert your path to the relative form.

3.4.7.1. Using a Tcl Script in BSP Creation

When you create a BSP, the **New BSP Settings File** dialog box allows you to specify the path and filename of a Tcl script. The Nios II BSP Editor runs this script after all other BSP creation steps are done, to modify BSP settings.

This feature allows you to perform the following tasks:

- Recreate an existing BSP as a starting point for a new BSP
- Recreate a BSP on a different hardware platform
- Include custom settings common to a group of BSPs

The Tcl script can be created by hand or exported from another BSP.

Related Information

- [Exporting a Tcl Script](#) on page 47
For more information about how to create a Tcl script from an existing BSP.
- [Nios II Software Build Tools](#) on page 87
For more information about Tcl scripts and BSP settings, refer to "Tcl Scripts for BSP Settings".

3.4.8. BSP Validation Errors

If you modify a hardware system after basing a BSP on it, some BSP settings might no longer be valid. This is a very common cause of BSP validation errors. Eliminating these errors usually requires correcting a large number of interrelated settings.



If your modifications to the underlying hardware design result in BSP validation errors, the best practice is to update or recreate the BSP. Updating and recreating BSPs is very easy with the BSP Editor.

If you recreate your BSP, you might find it helpful to capture your old BSP settings by exporting them to a Tcl script. You can edit the Tcl script to remove any settings that are incompatible with the new hardware design.

Related Information

- [Using a Tcl Script in BSP Creation](#) on page 48
For more information about how to run a Tcl script during BSP creation.
- [Exporting a Tcl Script](#) on page 47
For more information about how to create a Tcl script from an existing BSP.
- [Nios II Software Build Tools](#) on page 87
For more information about Tcl scripts and BSP settings, refer to "Tcl Scripts for BSP Settings".

3.5. Run Configurations in the SBT for Eclipse

Eclipse uses run configurations to control how it runs and debugs programs. Run configurations in the Nios II SBT for Eclipse have several features that help you debug Nios II software running on FPGA platforms.

3.5.1. Opening the Run Configuration Dialog Box

You can open the run configuration dialog box two ways:

- You can right-click an application, point to **Run As**, and click **Run Configurations**.
- You can right-click an application, point to **Debug As**, and click **Debug Configurations**.

Depending on which way you opened the run configuration dialog box, the title is either **Run Configuration** or **Debug Configuration**. However, both views show the same run configurations.

Note: If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.

Each run configuration is presented on several tabs. This section describes each tab.

3.5.2. The Project Tab

On this tab, you specify the application project to run. The **Advanced** button opens the **Nios II ELF Section Properties** dialog box. In this dialog box, you can control the runtime parameters in the following ways:

- Specify the processor on which to execute the program (if the hardware design provides multiple processors)
- Specify the device to use for standard I/O
- Specify the expected location, timestamp and value of the system ID
- Specify the path to the Intel Quartus Prime JTAG Debugging Information File (.jdi)
- Enable or disable profiling

The Nios II SBT for Eclipse sets these parameters to reasonable defaults. Do not modify them unless you have a clear understanding of their effects.

3.5.3. The Target Connection Tab

This tab allows you to control the connection between the host machine and the target hardware in the following ways:

- Select the cable, if more than one cable is available
- Allow software to run despite a system ID value or timestamp that differs from the hardware
- Reset the processor when the software is downloaded

The **System ID Properties** button allows you to examine the system ID and timestamp in both the .elf file and the hardware. This can be helpful when you need to analyze the cause of a system ID or timestamp mismatch.

3.5.4. The Debugger Tab

In this tab, you optionally enable the debugger to halt at a specified entry point.

3.6. Optimizing Project Build Time

When you build a Nios II project, the project makefile builds any components that are unbuilt or out of date. For this reason, the first time you build a project is normally the slowest. Subsequent builds are fast, only rebuilding sources that have changed.

With Nios II Gen 2, the Windows host compile and build time performance has improved. For example, it is now three times faster to build the `webserver` example.

3.7. Importing a Command-Line Project

If you have software projects that were created with the Nios II SBT command line, you can import the projects into the Nios II SBT for Eclipse for debugging and further development. This section discusses the import process.

Your command-line C/C++ application, and its associated BSP, is created on the command line. Any Nios II SBT command-line project is ready to import into the Nios II SBT for Eclipse. No additional preparation is necessary.



3.7.1. Nios II Command-Line Projects

The Nios II SBT for Eclipse imports the following kinds of Nios II command-line projects:

- Command-line C/C++ application project
- Command-line BSP project
- Command-line user library project

You can edit, build, debug, and manage the settings of an imported project exactly the same way you edit, build, debug, and manage the settings of a project created in Nios II SBT for Eclipse.

3.7.2. Importing through the Import Wizard

The Nios II SBT for Eclipse imports each type of project through the **Import** wizard. The **Import** wizard determines the kind of project you are importing, and configures it appropriately.

You can continue to develop project code in your SBT project after importing the project into Eclipse. You can edit source files and rebuild the project, using the SBT either in Eclipse or on the command line.

Related Information

[Getting Started from the Command Line](#) on page 73

For more information about creating projects with the command line.

3.7.3. Road Map

Importing and debugging a project typically involves several of the following tasks. You do not need to perform these tasks in this order, and you can repeat or omit some tasks, depending on your needs.

- Import a command-line C/C++ application
- Import a supporting project
- Debug a command-line C/C++ application
- Edit command-line C/C++ application code

When importing a project, the SBT for Eclipse might make some minor changes to your makefile. If the makefile refers to a source file located outside the project directory tree, the SBT for Eclipse treats that file as a linked resource. However, it does not add or remove any source files to or from your makefile.

When you import an application or user library project, the Nios II SBT for Eclipse allows you to choose Eclipse source management or user source management. Unless your project has an unusual directory structure, choose Eclipse source management, to allow the SBT for Eclipse to automatically maintain your list of source files.

You debug and edit an imported project exactly the same way you debug and edit a project created in Eclipse.

3.7.4. Import a Command-Line C/C++ Application

To import a command-line C/C++ application, perform the following steps:

1. Start the Nios II SBT for Eclipse.
2. On the File menu, click **Import**. The **Import** dialog box appears.
3. Expand the **Nios II Software Build Tools Project** folder, and select **Import Nios II Software Build Tools Project**.
4. Click **Next**. The **File Import** wizard appears.
5. Click **Browse** and locate the directory containing the C/C++ application project to import.
6. Click **OK**. The wizard fills in the project path.
7. Specify the project name in the **Project name** box.

Note: You might see a warning saying "There is already a .project file at: <path>". This warning indicates that the directory already contains an Eclipse project. Either it is an Eclipse project, or it is a command-line project that is already imported into Eclipse. If the project is already in your workspace, do not re-import it.

8. Click **Finish**. The wizard imports the application project.

After you complete these steps, the Nios II SBT for Eclipse can build, debug, and run the complete program, including the BSP and any libraries. The Nios II SBT for Eclipse builds the project using the SBT makefiles in your imported C/C++ application project. Eclipse displays and steps through application source code exactly as if the project were created in the Nios II SBT for Eclipse. However, Eclipse does not have direct information about where BSP or user library code resides. If you need to view, debug or step through BSP or user library source code, you need to import the BSP or user library.

Related Information

[Import a Supporting Project](#) on page 52

For more information about the process of importing supporting projects, such as BSPs and libraries.

3.7.4.1. Importing a Project with Absolute Source Paths

If your project uses an absolute path to refer to a source file, the SBT for Eclipse imports that source file as a linked resource. In this case, the import wizard provides a page where you can manage how Eclipse refers to the source: as a file, or through a parent directory.

Related Information

[Absolute Source Paths and Linked Resources](#) on page 40

For more information about managing linked resources.

3.7.5. Import a Supporting Project

While debugging a C/C++ application, you might need to view, debug or step through source code in a supporting project, such as a BSP or user library. To make supporting project source code visible in the Eclipse debug perspective, you need to import the supporting project.



If you do not need BSP or user library source code visible in the debugger, you can skip this task, and proceed to debug your project exactly as if you had created it in Eclipse.

If you have several C/C++ applications based on one BSP or user library, import the BSP or user library once, and then import each application that is based on the BSP or user library. Each application's makefile contains the information needed to find and build any associated BSP or libraries.

Related Information

[Import a Command-Line C/C++ Application](#) on page 52

For more information about the steps for importing a supporting project.

3.7.6. User-Managed Source Files

When you import a Nios II application or user library project, the Nios II SBT for Eclipse offers the option of user source management. User source management is helpful if you prefer to update your makefile manually to reflect source files added to or removed from the project.

With user source management, Eclipse never makes any changes to the list of source files in your makefile. However, the SBT for Eclipse manages all other project parameters and settings, just as with any other Nios II software project.

If your makefile refers to a source file with an absolute path, when you import with user source management, the absolute path is untouched, like any other source path. You might use an absolute path to refer to common source files in a fixed location. In this situation, you can move the project to a different directory without disturbing the common source file references.

User source management is not available with BSP projects. BSP makefiles are based on the operating system, BSP settings, selected software packages, and selected drivers. You do not specify BSP source files directly.

Related Information

[User Source Management](#) on page 40

For more information about how the SBT for Eclipse handles makefiles with user-managed sources.

3.8. Packaging a Library for Reuse

This section shows how to create and use a library archive file (.a) in the Nios II Software Build Tools for Eclipse. This technique enables you to provide a library to another engineer or organization without providing the C source files. This process entails two tasks:

1. Create a Nios II user library
2. Create a Nios II application project based on the user library

3.8.1. Creating the User Library

To create a user library, perform the following steps:

1. In the File menu, point to **New** and click **Nios II Library**.
2. Type a project name, for example **test_lib**.
3. For **Location**, browse to the directory containing your library source files (**.c** and **.h**).
4. Click **Finish**.
5. Build the project to create the **.a** file (in this case **libtest_lib.a**).

3.8.2. Using the Library

To use the library in a Nios II application project, perform the following steps:

1. Create your Nios II application project.
2. To set the library path in the application project, right-click the project, and click **Properties**.
3. Expand **Nios II Application Properties**. In **Nios II Application Paths**, next to **Application include directories**, click **Add** and browse to the directory containing your library header files.
4. Next to **Application library directories**, click **Add** and browse to the directory containing your **.a** file.
5. Next to **Library name**, click **Add** and type the library project name you selected when you created your user library.
6. Click **OK**.
7. Build your application.

As this example shows, the **.c** source files are not required to build the application project. To hand off the library to another engineer or organization for reuse, you provide the following files:

- Nios II library archive file (**.a**)
- Software header files (**.h**)

Related Information

[Creating a Project](#) on page 28

3.9. Creating a Software Package

This section shows how you can build a custom library into a BSP as a software package. The software package can be linked to any BSP through the BSP Editor.

This section contains an example illustrating the steps necessary to include any software package into a Nios II BSP.



To create and exercise the example software package, perform the following steps:

1. Locate the `ip` directory in your Intel FPGA Complete Design Suite installation. For example, if the Intel FPGA Complete Design Suite version 14.1 is installed on the Windows operating system, the directory might be `c:\altera\14.1\ip`. Under the `ip` directory, create a directory for the software package. For simplicity, this section refers to this directory as `<example package>`.
2. In `<example package>`, create a subdirectory named `EXAMPLE_SW_PACKAGE`. In `<example package>/EXAMPLE_SW_PACKAGE`, create two subdirectories named `inc` and `lib`.
3. In `<example package>/EXAMPLE_SW_PACKAGE/inc`, create a new header file named `example_sw_package.h` containing the following code:

```
/* Example Software Package */
void example_sw_package(void);
```

4. In `<example package>/EXAMPLE_SW_PACKAGE/lib`, create a new C source file named `example_sw_package.c` containing the following code:

```
/* Example Software Package */
#include <stdio.h>
#include "..\inc\example_sw_package.h"

void example_sw_package(void)
{
    printf ("Example Software Package. \n");
}
```

5. In `<example package>`, create a new Tcl script file named `example_sw_package_sw.tcl` containing the following code:

```
#
# example_sw_package_sw.tcl
#

# Create a software package known as "example_sw_package"
create_sw_package example_sw_package

# The version of this software
set_sw_property version 14.1

# Location in generated BSP that sources should be copied into
set_sw_property bsp_subdirectory Example_SW_Package

#
# Source file listings...
#

# C/C++ source files
add_sw_property c_source EXAMPLE_SW_PACKAGE/src/my_source.c

# Include files
add_sw_property include_source
EXAMPLE_SW_PACKAGE/inc/example_sw_package.h
```

```
# Lib files
add_sw_property lib_source
EXAMPLE_SW_PACKAGE/lib/libexample_sw_package_library.a

# Include paths for headers which define the APIs for this package
# to share w/ app & bsp
# Include paths are relative to the location of this software
# package tcl file

add_sw_property include_directory EXAMPLE_SW_PACKAGE/inc

# This driver supports HAL & UCOSII BSP (OS) types
add_sw_property supported_bsp_type HAL
add_sw_property supported_bsp_type UCOSII

# Add example software package system.h setting to the BSP:
add_sw_setting quoted_string system_h_define \
    example_sw_package_system_value EXAMPLE_SW_PACKAGE_SYSTEM_VALUE 1 \
    "Example software package system value"
# End of file
```


6. In the SBT for Eclipse, create a Nios II application and BSP project based on the Hello World template. Set the application project name to `hello_example_sw_package`.
7. Create a new C file named `hello_example_sw_package.c` in the new application project containing the following code:

```
/*
 * "Hello World" example.
 *
 * This example prints 'Hello from Nios II' to the STDOUT stream. It
 * also
 * tests inclusion of a user software package.
 */

#include <stdio.h>
#include "example_sw_package.h"

int main()
{
    printf("Hello from Nios II!\n");
    example_sw_package();
    return 0;
}
```

8. Delete `hello_world.c` from the `hello_example_sw_package` application project.
9. In the File menu, point to **New** and click **Nios II Library**
10. Set the project name to `example_sw_package_library`.
11. For **Location**, browse to `<example package>\EXAMPLE_SW_PACKAGE\lib`
Note: Building the library here is required, because the resulting .a is referenced here by `example_sw_package_sw.tcl`.
12. Click **Finish**.
13. Build the `example_sw_package_library` project to create the `libexample_sw_package_library.a` library archive file.



14. Right-click the BSP project, point to **Nios II**, and click **BSP Editor** to open the BSP Editor.
15. In the **Software Packages** tab, find `example_sw_package` in the software package table, and enable it.
If there are any errors in a software package's `*_sw.tcl` file, such as an incorrect path that causes a file to not be found, the software package does not appear in the BSP Editor.
16. Click the **Generate** button to regenerate the BSP. On the File menu, click **Save** to save your changes to `settings.bsp`.
17. In the File menu, click **Exit** to exit the BSP Editor.
18. Build the `hello_example_sw_package_bsp` BSP project.
19. Build the `hello_example_sw_package` application project.
`hello_example_sw_package.elf` is ready to download and execute.

3.10. Programming Flash in Intel FPGA Embedded Systems

Many Nios II processor systems use external flash memory to store one or more of the following items:

- Program code
- Program data
- FPGA configuration data
- File systems

Flash programmer tools allow you to program software, FPGA configuration, and application-specific binary data into flash memory devices. The tools support combining these different types of data so that they can be stored in a single flash device.

In Intel Quartus Prime Standard Edition, the Nios II SBT for Eclipse provides the Nios II flash programmer GUI-based tool and associated utilities, to help you manage and program the contents of flash memory. The sections below describe how to use these tools.

In Intel Quartus Prime Pro Edition, the Nios II Flash programmer has been deprecated and the Intel Quartus Prime Professional programmer should be used instead. You can access the Intel Quartus Prime Professional Programmer by performing the following steps:

1. Start the Intel Quartus Prime software. The Intel Quartus Prime Pro Edition window appears.
2. Select **Tools > Programmer**. The **Programmer** window appears.

.

3.10.1. Starting the Flash Programmer

You start the flash programmer by clicking **Flash Programmer** in the Nios II menu.

When you first open the flash programmer, no controls are available until you open or create a Flash Programmer Settings File (`.flash-settings`).

3.10.2. Creating a Flash Programmer Settings File

The `.flash-settings` file describes how you set up the flash programmer GUI to program flash. This information includes the files to be programmed to flash, a `.sopcinfo` file describing the hardware configuration, and the file programming locations. You must create or open a flash programmer settings file before you can program flash.

You create a flash programmer settings file through the File menu. When you click **New**, the **New Flash Programmer Settings File** dialog box appears.

3.10.2.1. Specifying the Hardware Configuration

You specify the hardware configuration by opening a `.sopcinfo` file. You can locate the `.sopcinfo` file in either of two ways:

- Browse to a BSP settings file. The flash programmer finds the `.sopcinfo` file associated with the BSP.
- Browse directly to a `.sopcinfo` file.

Once you have identified a hardware configuration, details about the target hardware appear at the top of the Nios II flash programmer screen.

Also at the top of the Nios II flash programmer screen is the **Hardware Connections** button, which opens the **Hardware Connections** dialog box. This dialog box allows you to select a download cable, and control system ID behavior.

Related Information

[The Target Connection Tab](#) on page 50

3.10.3. The Flash Programmer Screen Layout

The flash programmer screen is divided into two areas. The top area is the command area, and the bottom is the console area. The details of the flash programmer screen areas are described in this section.

Below the console area is the **Start** button. This button is enabled when the flash programmer parameters are valid. It starts the process of programming flash.

3.10.4. The Command Area

In the command area, you specify settings and other parameters defining the flash programmer settings file. The command area contains one or more tabs. Each tab represents a flash memory component available in the target hardware. Each tab allows you to view the parameters of the memory component, and view and edit the list of files to be programmed in the component.

The **Add** and **Remove** buttons allow you to create and edit the list of files to be programmed in the flash memory component.

The **File generation command** box shows the commands used to generate the Motorola S-record Files (`.flash`) used to program flash memory.

The **File programming command** box shows the commands used to program the `.flash` files to flash memory.



The **Properties** button opens the **Properties** dialog box, which allows you to view and modify information about an individual file. In the case of a `.elf`, the **Properties** button provides access to the project reset address, the flash base and end addresses, and the boot loader file (if any).

The flash programmer determines whether a boot loader is required based on the load and run locations of the `.text` section. You can use the **Properties** dialog box to override the default boot loader configuration.

3.10.5. The Console Area

The console area shows results of settings and commands that you select in the command area. The console area consists of the following tabs:

- The **Information** tab
- The **Problems** tab
- The **Processing** tab

3.10.5.1. The Information Tab

The **Information** tab shows the high-level changes you make to your flash programmer settings file.

3.10.5.2. The Problems Tab

The **Problems** tab shows warnings and error messages about the process of flash programmer settings file creation.

3.10.5.3. The Processing Tab

When you program flash, the **Processing** tab shows the individual programming actions as they take place.

3.10.6. Saving a Flash Programmer Settings File

When you have finished configuring the input files, locations, and other settings for programming your project to flash, you can save the settings in a `.flash-settings` file. With a `.flash-settings` file, you can program the project again without reconfiguring the settings. You save a `.flash-settings` file through the File menu.

3.10.7. Flash Programmer Options

Through the Options menu, you can control several global aspects of flash programmer behavior, as described in this section.

Related Information

[Nios II Flash Programmer User's Guide](#)

For more information about these features.

3.10.7.1. Staging Directories

Through the **Staging Directories** dialog box, you control where the flash programmer creates its script and `.flash-settings` files.

3.10.7.2. Generate Files

If you disable this option, the flash programmer does not generate programming files, but programs files already present in the directory. You might use this feature to reprogram a set of files that you have previously created.

3.10.7.3. Program Files

If you disable this option, the flash programmer generates the programming files and the script, but does not program flash. You can use the files later to program flash by turning off the **Generate Files** option.

3.10.7.4. Erase Flash Before Programming

When enabled, this option erases flash memory before programming.

3.10.7.5. Run From Reset After Programming

When enabled, this option resets and starts the Nios II processor after programming flash.

3.11. Creating Memory Initialization Files

Sometimes it is useful to generate memory initialization files. For example, to program your FPGA with a complete, running Nios II system, you must include the memory contents in your `.sof` file. In this configuration, the processor can boot directly from internal memory without downloading.

Creating a Hexadecimal (Intel-Format) File (`.hex`) is a necessary intermediate step in creating such a `.sof` file. The Nios II SBT for Eclipse can create `.hex` files and other memory initialization formats.

To generate correct memory initialization files, the Nios II SBT needs details about the physical memory configuration and the types of files required. Typically, this information is specified when the hardware system is generated.

Note: If your system contains a user-defined memory, you must specify these details manually.

Related Information

[Generate Memory Initialization Files by the Legacy Method](#) on page 61

3.11.1. Generate Memory Initialization Files

To generate memory initialization files, perform the following steps:

1. Right-click the application project.
2. Point to **Make targets** and click **Build** to open the **Make Targets** dialog box.
3. Select **mem_init_generate**.



4. Click **Build**. The makefile generates a separate file (or files) for each memory device. It also generates a Intel Quartus Prime IP File (.qip). The .qip file tells the Intel Quartus Prime software where to find the initialization files.
5. Add the .qip file to your Intel Quartus Prime project.
6. Recompile your Intel Quartus Prime project.

3.11.2. Generate Memory Initialization Files by the Legacy Method

To generate memory initialization files by the legacy method, perform the following steps:

1. Right-click the application project.
2. Point to **Make targets** and click **Build** to open the **Make Targets** dialog box.
3. Select **mem_init_install**.
4. Click **Build**. The makefile generates a separate file (or files) for each memory device. The makefile inserts the memory initialization files directly in the Intel Quartus Prime project directory for you.
5. Recompile your Intel Quartus Prime project.

Related Information

Hardware Reference

For information about working in the stand-alone flow.

3.11.3. Memory Initialization Files for User-Defined Memories

Generating memory initialization files requires detailed information about the physical memory devices, such as device names and data widths. Normally, the Nios II SBT extracts this information from the .sopcinfo file. However, in the case of a user-defined memory, the .sopcinfo file does not contain information about the data memory, which is outside the system. Therefore, you must provide this information manually.

You specify memory device information when you add the user-defined memory device to your BSP. The device information persists in the BSP settings file, allowing you to regenerate memory initialization files at any time, exactly as if the memory device were part of the hardware system.

Specify the memory device information in the **Advanced** tab of the **Add Memory Device** dialog box. Settings in this tab control makefile variables in mem_init.mk. On the **Advanced** tab, you can control the following memory characteristics:

- The physical memory width. The device's name in the hardware system.
- The memory initialization file parameter name. Every memory device can have an HDL parameter specifying the name of the initialization file. The Nios II ModelSim launch configuration overrides the HDL parameter to specify the memory initialization filename. When available, this method is preferred for setting the memory initialization filename.
- The Mem init filename parameter can be used in Nios II systems as an alternative method of specifying the memory initialization filename. The Mem init filename parameter directly overrides any filename specified in the HDL.

- Connectivity to processor master ports. These parameters are used when creating the linker script.
- The memory type: volatile, CFI flash or EPCS flash.
- Byte lanes.
- You can also enable and disable generation of the following memory initialization file types:
 - .hex file
 - .dat and .sym files
 - .flash file

Related Information

[Publishing Component Information to Embedded Software](#) on page 308

For more information about this parameter, refer to "Embedded Software Assignments".

3.11.3.1. Specifying the Memory Device Information in the Advanced Tab

Specify the memory device information in the **Advanced** tab of the **Add Memory Device** dialog box. Settings in this tab control makefile variables in `mem_init.mk`.

On the **Advanced** tab, you can control the following memory characteristics:

- The physical memory width.
- The device's name in the hardware system.
- The memory initialization file parameter name. Every memory device can have an HDL parameter specifying the name of the initialization file. The Nios II ModelSim launch configuration overrides the HDL parameter to specify the memory initialization filename. When available, this method is preferred for setting the memory initialization filename.
- The **Mem init filename** parameter can be used in Nios II systems as an alternative method of specifying the memory initialization filename. The **Mem init filename** parameter directly overrides any filename specified in the HDL.
- Connectivity to processor master ports. These parameters are used when creating the linker script.
- The memory type: volatile, CFI flash or EPCS flash.
- Byte lanes.
- You can also enable and disable generation of the following memory initialization file types:
 - .hex file
 - .dat and .sym files
 - .flash file

Related Information

[Publishing Component Information to Embedded Software](#) on page 308

For more information about this parameter, refer to "Embedded Software Assignments".



3.12. Running a Nios II System with ModelSim

You can run a Nios II program on Nios II hardware, such as an Intel FPGA development board, or you can run it in the Nios II ModelSim simulation environment.

Note: If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.

3.12.1. Using ModelSim with an SOPC Builder-Generated System

If your hardware system was generated by SOPC Builder, running a software project in ModelSim is very similar to running it on Nios II hardware.

To run a Nios II software project in ModelSim, right-click on the application project name, point to **Run As**, and click **Nios II ModelSim**.

To debug a software project in ModelSim, right-click on the application project name, point to **Debug As**, and click **Nios II ModelSim**.

Related Information

[Running the Project on Nios II Hardware](#) on page 31

3.12.2. Using ModelSim with a Platform Designer-Generated System

To run a Platform Designer-generated Nios II system with ModelSim, you must first create a simulation model and test bench, and specify memory initialization files. You create your Nios II simulation model and test bench using the steps that apply to any Platform Designer design.

For more information, refer to the *Intel Quartus Prime Standard Edition Handbook Volume 1: Design and Synthesis Handbook*.

Related Information

[Quartus Prime Standard Edition Handbook Volume 1: Design and Synthesis](#)

3.12.2.1. Preparing your Software for ModelSim

Creating the software projects is nearly the same as when you run the project on hardware. To prepare your software for ModelSim simulation, perform the following steps:

1. Create your software project.
If you need to initialize a user-defined memory, you must take special steps to create memory initialization files correctly.
2. Build your software project.
3. Create a ModelSim launch configuration with the following steps:
 - a. Right-click the application project name, point to **Run As**, and click **Run Configurations**. In the **Run Configurations** dialog box, select **Nios II ModelSim**, and click the **New** button.
 - b. In the **Main** tab, ensure that the correct software project name and **.elf** file are selected.
 - c. Click **Apply** to save the launch configuration.

- d. Click **Close** to close the dialog box.
If you are simulating multiple processors, create a launch configuration for each processor, and create a launch group.
4. Open the run configuration you previously created. Click **Run**. The Nios II SBT for Eclipse performs a `make mem_init_generate` command to create memory initialization files, and launches ModelSim.
5. At the ModelSim command prompt, type `ldr`.

Related Information

- [Creating a Project](#) on page 28
- [Building the Project](#) on page 30
- [Generate Memory Initialization Files by the Legacy Method](#) on page 61
- [Creating a Simple BSP](#) on page 38

3.12.2.2. Potential Error Message

When you create the launch configuration, you might see the following error message:

SEVERE: The Intel Quartus Prime project location has not been set in the ELF section. You can manually override this setting in the launch configuration's ELF file 'Advanced' properties page.

Related Information

[Creating a Simple BSP](#) on page 38

3.12.2.3. Nios II GCC Tool Chain


The Nios II EDS version 14.0 is the first version of the Nios II cores. After 14.0, Nios II cores are used. The Nios II GNU tool chain has been upgraded, as well. The following GCC versions are available in the following Nios II EDS versions:

- GCC 4.8.3 in 14.1
- GCC 4.9.1 in 15.0

Note: When upgrading to a new tool chain, there are Nios II-specific changes and GCC changes and enhancements.

Related Information

- [Porting to GCC 4.8](#)
For more information about how GNU also provides a porting guide to GCC 4.8 to document common issues.
- [Porting to GCC 4.9](#)
For more information about how GNU also provides a porting guide to GCC 4.9 to document common issues.
- [GCC Releases](#)
For more information about full GCC release notes.



3.12.2.3.1. Nios II Specific Changes

- Use `__buildin_custom_*` instead of `-mcustom-*` or `#pragma` to reliably generate Nios II Floating Point Custom Instructions (FPCI), independent of compiler optimization level and command line flags.
- To use `-mcustom-*` or `#pragma` for Nios II Floating Point Custom Instructions (FPCI):
 - The `-ffinite-math-only` flag must be used to generate `fmins` and `fmax` FPCI
 - The optimization (non `-O0` flag) must be used to generate `fsqrts` FPCI
- Users implementing transcendental functions in hardware must use the `-funsafe-math-optimizations` flag to generate the FPCI for the transcendental functions `fsins()`, `fcoss()`, `ftans()`, `fatans()`, `fexps()`, `flogs()` and corresponding double-precision functions.
- The Pragma format has changed from eg. `#pragma custom_fadds 253` to `#pragma GCC target("custom-fadds=253")` and function attributes provide an alternative format `__attribute__((target("custom-fadds=253")))`.
- Use the `-mel/-meh` flags instead of `-EL/-EB` for endian settings. Software Build Tool for Eclipse (SBTE) users must regenerate the BSP for this setting to take effect.
- The `-mreverse-bitfields` flag and `reverse_bitfields` pragma are no longer supported.
- The `-fstack-check` flag must be used instead of `-mstack-check` to enable stack checking.

3.12.2.3.2. GCC Changes and Enhancements

- The `-Wa,-relax-all` flag in `nios2-elf-gcc` GCC 4.7.3 supports function calls and programs exceeding the 256 MB limit.
- When used with optimization, inline assembly code with the `asm` operator needs to declare values imported from C and exported back to C, using the mechanisms described on the "Extended Asm - Assembler Instructions with C Expression Operands" page.
- Pre-standard C++ headers are not supported in GCC 4.7.3. Replace pre-standard C++ with standard C++ eg. `#include <iostream.h>`, `cout`, `endl` with `#include <iostream>`, `std::cout` and `std::endl`, respectively.
- The compile flag `-Wl,--defsym foo=bar` where `bar` is an undefined symbol, generates error at the linker level in GCC 4.7.3. GCC 4.1.2 does not include this check.

Related Information

- [Nios II Software Build Tools](#) on page 87
For more information about the GCC toolchains.
- [Getting Started from the Command Line](#) on page 73
- [Extended Asm - Assembler Instructions with C Expression Operands](#)
- [Intel FPGA Software Installation and Licensing Manual](#)
For more information about installing the Quartus Prime software.

3.13. Eclipse Usage Notes

The behavior of certain Eclipse and CDT features is modified by the Nios II SBT for Eclipse. If you attempt to use these features the same way you would with a non-Nios II project, you might have problems configuring or building your project. This section discusses such features.

If you launch the Nios II Software Build Tools for Eclipse from the Nios II command shell, you cannot pause execution of the Nios II application when debugging the application. Running the program in this way closes the GDB connection to the target, leaving the processor running. This is caused by running Eclipse from the Cygwin environment.

To ensure that the pause button works, launch the Nios II Software Build Tool for Eclipse either from Platform Designer or directly from your operating system's **Start** menu.

3.13.1. Configuring Application and Library Properties

To configure project properties specific to Nios II SBT application and library projects, use the **Nios II Application Properties** and **Nios II Library Properties** tabs of the **Properties** dialog box.

To open the appropriate properties tab, right-click the application or library project and click **Properties**. Depending on the project type, **Nios II Application Properties** or **Nios II Library Properties** tab appears in the list of tabs. Click the appropriate Properties tab to open it.

3.13.1.1. Comparing the Nios II Application Properties and Nios II Library Properties tabs

The **Nios II Application Properties** and **Nios II Library Properties** tabs are nearly identical. These tabs allow you to control the following project properties:

- The name of the target `.elf` file (application project only)
- The library name (library project only)
- A list of symbols to be defined in the makefile
- A list of symbols to be undefined in the makefile
- A list of assembler flags
- Warning level flags
- A list of user flags
- Generation of debug symbols
- Compiler optimization level
- Generation of object dump file (application project only)
- Source file management
- Path to associated BSP (required for application, optional for library)

3.13.2. Configuring BSP Properties

To configure BSP settings and properties, use the Nios II BSP Editor.



Related Information

- [Using the BSP Editor](#) on page 41
For more information about the BSP Editor.
- [Using the BSP Editor](#) on page 41
For more information about the BSP Editor.

3.13.3. Exclude from Build Not Supported

The **Exclude from Build** command is not supported. You must use the **Remove from Nios II Build** and **Add to Nios II Build** commands instead.

This behavior differs from the behavior of the Nios II SBT for Eclipse in version 9.1.

3.13.4. Selecting the Correct Launch Configuration Type

If you try to debug a Nios II software project as a CDT Local C/C++ Application launch configuration type, you see an error message, and the Nios II Debug perspective fails to open. This is expected CDT behavior in the Eclipse platform. Local C/C++ Application is the launch configuration type for a standard CDT project. To invoke the Nios II plugins, you must use a Nios II launch configuration type.

Note: If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.

3.13.5. Target Connection Options

The Nios II launch configurations offer the following Nios II-specific options in the **Target Connection** tab:

- Disable 'Nios II Console' view
- Ignore mismatched system ID
- Ignore mismatched system timestamp
- Download ELF to selected target system
- Start processor
- Reset the selected target system

3.13.6. Renaming Nios II Projects

To rename a project in the Nios II SBT for Eclipse, perform the following steps:

1. Right-click the project and click **Rename**.
2. Type the new project name.
3. Right-click the project and click **Refresh**.

If you neglect to refresh the project, you might see the following error message when you attempt to build it:

```
Resource <original_project_name> is out of sync with the  
system
```

3.13.7. Running Shell Scripts from the SBT for Eclipse

Many SBT utilities are implemented as shell scripts. You can use Eclipse external tools configurations to run shell scripts. However, you must ensure that the shell environment is set up correctly.

To run shell scripts from the SBT for Eclipse, execute the following steps:

1. Start the Nios II Command Shell.
2. Start the Nios II SBT for Eclipse by typing the following command:
`eclipse-nios2`
You must start the SBT for Eclipse from the command line in both the Linux and Windows operating systems, to set up the correct shell environment.
3. From the Eclipse Run menu, select to **External Tools > External Tools Configurations**.
4. Create a new tools configuration, or open an existing tools configuration.
5. On the **Main** tab, set **Location** and **Argument**.

Table 5. Location and Argument to Run Shell Script from Eclipse

Platform	Location	Argument
Windows	<code>\${env_var:QUARTUS_ROOTDIR}\bin\cygwin\bin\sh.exe</code>	<code>-c "<script name> <script args>"</code>
Linux	<code>\${env_var:SOPC_KIT_NIOS2}/bin/<script name></code>	<code><script args></code>

Table 6. Location and Argument Values Used to Run elf2hex --help from Eclipse

Platform	Location	Argument
Windows	<code>\${env_var:QUARTUS_ROOTDIR}\bin\cygwin\bin\sh.exe</code>	<code>-c "elf2hex --help"</code>
Linux	<code>\${env_var:SOPC_KIT_NIOS2}/bin/elf2hex</code>	<code>--help</code>

6. On the **Build** tab, ensure that **Build before launch** and its related options are set appropriately.
By default, a new tools configuration builds all projects in your workspace before executing the command. This might not be the desired behavior.
7. Click **Run**. The command executes in the Nios II Command Shell, and the command output appears in the Eclipse **Console** tab.

Related Information

[Getting Started from the Command Line](#) on page 73

3.13.8. Must Use Nios II Build Configuration

Although Eclipse can support multiple build configurations, you must use the Nios II build configuration for Nios II projects.

Note: If your project was created with version 10.1 or earlier of the Nios II SBT, you must re-import it to create the Nios II launch configuration correctly.



3.13.9. CDT Limitations

The following tables describe the Eclipse CDT features not supported by the Nios II plugins. The features listed in the left column are supported by the Eclipse CDT plugins, but are not supported by Nios II plugins; and the right column lists alternative features supported by the Nios II plugins.

Table 7. New Project Wizard

Unsupported CDT Feature	Alternative Nios II Feature
C/C++ <ul style="list-style-type: none"> • C Project • C++ Project • Convert to a C/C++ Project • Source Folder 	To create a new project, use one of the following Nios II wizards: <ul style="list-style-type: none"> • Nios II Application • Nios II Application and BSP from Template • Nios II Board Support Package • Nios II Library

Table 8. Build configurations

Unsupported CDT Feature	Alternative Nios II Feature
<ul style="list-style-type: none"> • Right-click project and point to Build Configurations • Debugger tab <ul style="list-style-type: none"> — Stop on startup 	The Nios II plugins only support a single build configuration. This feature is supported only at the top of <code>main()</code> .

Table 9. Exclude from Build (from version 10.0 onwards)

Unsupported CDT Feature	Alternative Nios II Feature
Right-click source files	Use Remove from Nios II Build and Add to Nios II Build .

Table 10. Project Properties

Unsupported CDT Feature	Alternative Nios II Feature
C/C++ Build <ul style="list-style-type: none"> • Builder Settings <ul style="list-style-type: none"> — Makefile generation — Build location • Behavior <ul style="list-style-type: none"> — Build on resource save (Auto build) • Build Variables • Discovery Options • Environment • Settings • Tool Chain Editor <ul style="list-style-type: none"> — Current builder — Used tools 	By default, the Nios II SBT generates makefiles automatically. The build location is determined with the Nios II Application Properties or Nios II BSP Properties dialog box. To change the toolchain, use the Current tool chain option.
C/C++ General <ul style="list-style-type: none"> • Enable project specific settings • Documentation tool comments • Documentation • File Types • Indexer <ul style="list-style-type: none"> — Build configuration for the indexer • Language Mappings • Paths and Symbols 	The Nios II plugins only support a single build configuration. Use Nios II Application Properties and Nios II Application Paths .

Table 11. Window Preferences

Unsupported CDT Feature	Alternative Nios II Feature
C/C++ <ul style="list-style-type: none"> Build scope Build project configurations Build Variables Environment File Types Indexer <ul style="list-style-type: none"> Build configuration for the indexer Language Mappings New CDT project wizard 	The Nios II plugins only support a single build configuration. The Nios II plugins only support a single build configuration.

3.13.10. Enhancements for Build Configurations in SBT and SBT for Eclipse

The SBT command line tools `nios2-app-update-make` and `nios2-lib-update-makefile` now support six new options specifically for handling build configurations, which are fully backwards compatible even if it is unused and omitted.

For SBT for Eclipse, a few GUI options are added:

- Dropdown combo box showing selected build config
- Button for managing build configs (add/remove/activate)

3.13.10.1. Build Configurations in SBT

Application and library `makefile` are enhanced to support multiple build configurations. There are new command line options in `nios2-app-update-makefile` and `nios2-lib-update-makefile` for creating, deleting and updating build configurations.

These command line options are:

Table 12. New Command Line Options

Option	Description
<code>--add-build-config <config> <base></code>	Adds a new build configuration with the name <code><config></code> , initializes the new build configuration using an existing build configuration named <code><base></code> . <code><base></code> is optional and defaults to the active configuration. <code><base></code> is always ignored if only one build configuration is available.
<code>--remove-build-config <config></code>	Removes an existing build configuration. No effect if only one build configuration is available.
<code>--list-build-config <config></code>	Returns name of all build configurations. Returns empty string if only one build configuration is available.
<code>--get-active-build-config</code>	Returns the name of active build configuration. Returns empty string if only one build configuration is available.
<code>--set-active-build-config <config></code>	Set the build configuration named <code><config></code> active.
continued...	



Option	Description
	No effect if only one build configuration is available.
<code>--build-config <config></code>	Only use (read or modify) the build configuration named <code><config></code> but do not set it as the active build configuration. No effect if only one build configuration is available.

Note: These new options are optional and can be used together with all existing `nios2-app-update-makefile` and `nios2-lib-update-makefile` command line options.


Note: The BSP makefile does not support multiple build configurations.

3.13.10.2. Build Configurations in SBT for Eclipse

Application and library projects are enhanced to support multiple build configurations. There are new GUI options available for creating, deleting, and updating build configurations.


The following shows how the application properties page looks with the new build configuration options highlighted in red:

Figure 3. Nios II Application Properties



Clicking on the **Managed Configurations** button shows the following dialog for adding, removing, and activating build configurations:

Figure 4. Managed Configurations



Note: The BSP project does not support multiple build configurations.



4. Getting Started from the Command Line

The Nios II Software Build Tools (SBT) allows you to construct a wide variety of complex embedded software systems using a command-line interface. From this interface, you can execute Software Built Tools command utilities, and use scripts (or other tools) to combine the command utilities in many useful ways.

Related Information

[Getting Started from the Command Line Revision History](#) on page 13
For details on the document revision history of this chapter

4.1. Advantages of Command-Line Software Development

The Nios II SBT command line offers the following advantages over the Nios II SBT for Eclipse:

- You can invoke the command line tools from custom scripts or other tools that you might already use in your development flow.
- On a command line, you can run several Tcl scripts to control the creation of a board support package (BSP).
- You can use command line tools in a bash script to build several projects at once.

The Nios II SBT command-line interface is designed to work in the Nios II Command Shell.

Related Information

[The Nios II Command Shell](#) on page 77

4.2. Outline of the Nios II SBT Command-Line Interface

The Nios II SBT command-line interface consists of:

- Command-line utilities
- Command-line scripts
- Tcl commands
- Tcl scripts

These elements work together in the Nios II Command Shell to create software projects.



4.2.1. Utilities

The Nios II SBT command-line utilities enable you to create software projects. You can call these utilities from the command line or from a scripting language of your choice (such as perl or bash). On Windows, these utilities have a `.exe` extension. The Nios II SBT resides in the `<Nios II EDS install path>/sdk2/bin` directory.

For more information about the command-line utilities provided by the Nios II SBT, refer to "Intel FPGA-Provided Development Tools" in the *Nios II Software Build Tools* section.

Related Information

[Nios II Software Build Tools](#) on page 134

4.2.2. Scripts

Nios II SBT scripts implement complex behavior that extends the capabilities provided by the utilities.

Command	Summary
nios2-bsp	Creates or updates a BSP
create-this-app	Creates a software example and builds it
create-this-bsp	Creates a BSP for a specific hardware design example and builds it

Note: There are **create-this-app** scripts for each software example and several **create-this-bsp** scripts for each hardware design example. For more information, refer to "Nios II Design Example Scripts" in the "Nios II Software Build Tools Reference" section.

Related Information

[Nios II Design Example Scripts](#) on page 421

4.2.2.1. nios2-bsp

Usage

```
nios2-bsp <bsp-type> <bsp-dir> [<sopc>] [<override>]...
```

Options

- `<bsp-type>`: `hal` or `ucosii`.
- `<bsp-dir>`: Path to the BSP directory.
- `<sopc>`: The path to the `.sopcinfo` file or its directory.
- `<override>`: Options to override defaults.



Description

The **nios2-bsp** script calls **nios2-bsp-create-settings** or **nios2-bsp-update-settings** to create or update a BSP settings file, and the **nios2-bsp-generate-files** command to create the BSP files. The Nios II Embedded Design Suite (EDS) supports the following BSP types:

- `hal`
- `ucosii`

BSP type names are case-insensitive.

This utility produces a BSP of `<bsp-type>` in `<bsp-dir>`. If the BSP does not exist, it is created. If the BSP already exists, it is updated to be consistent with the associated hardware system.

The default Tcl script is used to set the following system-dependent settings:

- `stdio` character device
- System timer device
- Default linker memory
- Boot loader status (enabled or disabled)

If the BSP already exists, **nios2-bsp** overwrites these system-dependent settings.

The default Tcl script is installed at `<Nios II EDS install path>/sdk2/bin/bsp-set-defaults.tcl`

When creating a new BSP, this utility runs **nios2-bsp-create-settings**, which creates `settings.bsp` in `<bsp-dir>`.

When updating an existing BSP, this utility runs **nios2-bsp-update-settings**, which updates `settings.bsp` in `<bsp-dir>`.

After creating or updating the `settings.bsp` file, this utility runs **nios2-bsp-generate-files**, which generates files in `<bsp-dir>`

Required arguments:

- `<bsp-type>`: Specifies the type of BSP. This argument is ignored when updating a BSP. This argument is case-insensitive. The **nios2-bsp** script supports the following values of `<bsp-type>`:
 - `hal`
 - `ucosii`
- `<bsp-dir>`: Path to the BSP directory. Use `"."` to specify the current directory.

Optional arguments:

- `<sopc>`: The path name of the `.sopcinfo` file. Alternatively, specify a directory containing a `.sopcinfo` file. In the latter case, the tool finds a file with the extension `.sopcinfo`. This argument is ignored when updating a BSP. If you omit this argument, it defaults to the current directory.
- `<override>`: Options to override defaults. The **nios2-bsp** script passes most overrides to **nios2-bsp-create-settings** or **nios2-bsp-update-settings**. It also passes the `--silent`, `--verbose`, `--debug`, and `--log` options to **nios2-bsp-generate-files**.

nios2-bsp passes the following overrides to the default Tcl script:

- `--default_stdio <device>|none|DONT_CHANGE`
Specifies stdio device.
- `--default_sys_timer <device>|none|DONT_CHANGE`
Specifies system timer device.
- `--default_memory_regions DONT_CHANGE`
Suppresses creation of new default memory regions when updating a BSP. Do not use this option when creating a new BSP.
- `--default_sections_mapping <region>|DONT_CHANGE`
Specifies the memory region for the default sections.
- `--use_bootloader 0|1|DONT_CHANGE`
Specifies whether a boot loader is required.
On a preexisting BSP, the value `DONT_CHANGE` prevents associated settings from changing their current value.

Note: The "--" prefix is stripped when the option is passed to the underlying utility.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

4.2.2.2. create-this-app

Each application subdirectory contains a **create-this-app** script. The **create-this-app** script copies the C/C++ application source code to the current directory, runs **nios2-app-generate-makefile** to create a makefile (named **Makefile**), and then runs `make` to build the Executable and Linking Format File (`.elf`) for your application. Each **create-this-app** script uses a particular example BSP. For further information, refer to the script to determine the associated example BSP. If the BSP does not exist when **create-this-app** runs, **create-this-app** calls the associated **create-this-bsp** script to create the BSP.

The **create-this-app** script takes no command-line arguments. Your current directory must be the same directory as the **create-this-app** script. The exit value is zero on success and one on error.



4.2.2.3. create-this-bsp

Each BSP subdirectory contains a **create-this-bsp** script. The **create-this-bsp** script calls the **nios2-bsp** script to create a BSP in the current directory. The **create-this-bsp** script has a relative path to the directory containing the **.sopcinfo** file.

The **.sopcinfo** file resides two directory levels above the directory containing the **create-this-bsp** script.

The **create-this-bsp** script takes no command-line arguments. Your current directory must be the same directory as the **create-this-bsp** script. The exit value is zero on success and one on error.

4.2.3. Tcl Commands

Tcl commands are a crucial component of the Nios II SBT. Tcl commands allow you to exercise detailed control over BSP generation, as well as to define drivers and software packages.

4.2.4. Tcl Scripts

The SBT provides powerful Tcl scripting capabilities. In a Tcl script, you can query project settings, specify project settings conditionally, and incorporate the software project creation process in a scripted software development flow. The SBT uses Tcl scripting to customize your BSP according to your hardware and the settings you select. You can also write custom Tcl scripts for detailed control over the BSP.

4.2.5. The Nios II Command Shell

The Nios II Command Shell is a bash command-line environment initialized with the correct settings to run Nios II command-line tools. The Command Shell supports the GCC toolchain.

For more information about GCC toolchains, refer to "Intel FPGA-Provided Development Tools" in the "Nios II Software Build Tools" section.

Related Information

- [Nios II Software Build Tools](#) on page 134
- [GNU Compiler Tool Chain](#) on page 132
- [Overview of Nios II Embedded Development](#) on page 18

4.2.5.1. Starting the Nios II Command Shell

To open the Nios II Command Shell, perform the following steps, depending on your environment:

- In the Windows operating system, on the Start menu, point to **Programs > Intel FPGA > Nios II EDS <version>**, and click **Nios II <version> Command Shell**.
- In the Linux operating system, in a command shell, change directories to *<Nios II EDS install path>*, and type the command `nios2_command_shell.sh`.

4.2.5.2. Auto-Executing a Command in the Nios II Command Shell

In certain situations, you might need to run a command or a script automatically after the Nios II Command Shell is initialized. When you start the Nios II Command Shell environment, to automatically execute a command perform one of the following steps, depending on your environment:

- In the Windows operating system, execute the following command:
`"<Nios II EDS install path>/Nios II Command Shell.bat" <command>`
- In the Linux operating system, execute the following command:
`<Nios II EDS install path>/nios2_command_shell.sh <command>`

For example, in Windows, to run an automated build, you might execute the following command:

```
"<Nios II EDS install path>/Nios II Command Shell.bat" custom_build.sh
```

The Nios II Command Shell startup script (Nios II Command Shell.bat or `nios2_command_shell.sh`) makes no special assumptions about its initial environment. You can use the Nios II Command Shell with auto-execution from any environment that accepts commands native to your host operating system. For example, in Linux you can use **crontab** to schedule a job to run in the Nios II Command Shell at a later time.

4.3. Getting Started in the SBT Command Line

Using the Nios II SBT on the command line is the best way to learn about it. The following tutorial guides you through the process of creating, building, running, and debugging a "Hello World" program with a minimal number of steps. Later chapters provide more of the underlying details, allowing you to take more control of the process. The goal of this chapter is to show you that the basic process is simple and straightforward.

The Nios II SBT includes a number of scripts that demonstrate how to combine command utilities to obtain the results you need. This tutorial uses a **create-this-app** script as an example.

4.3.1. Prerequisites

To complete this tutorial, you must have the following:

- Intel FPGA Quartus Prime development software, version 8.0 or later. The software must be installed on a Windows or Linux computer that meets the Quartus Prime minimum requirements.
- The Intel FPGA Nios II Embedded Design Suite (EDS), version 8.0 or later.
- An Intel FPGA development board.
- A download cable such as the Intel FPGA USB-Blaster™ cable.

You run the Nios II SBT commands from the Nios II Command Shell.

Related Information

[The Nios II Command Shell](#) on page 77



4.3.2. Creating Hello_World for an Intel FPGA Development Board

In this section you create a simple "Hello World" project. To create and build the `hello_world` example for an Intel FPGA development board, perform the following steps:

1. Start the Nios II Command Shell.⁽²⁾
2. Create a working directory for your hardware and software projects. The following steps refer to this directory as `<projects>`.
3. Change to the `<projects>` directory by typing the following command:

```
cd <projects>
```
4. Locate a Nios II hardware example for your Intel FPGA development board. For example, if you have a Stratix® IV GX FPGA Development Kit, you might select `<Nios II EDS install path>/examples/verilog/niosII_stratixIV_4sgx230/triple_speed_ethernet_design`.
5. Copy the hardware example to your `<projects>` working directory, using a command such as the following:

```
cp -R /altera/100/nios2eds/examples/verilog/niosII_stratixIV_4sgx230/triple_speed_ethernet_design .
```
6. Ensure that the working directory and all subdirectories are writable by typing the following command:

```
chmod -R +w
```
7. The `<projects>` directory contains a subdirectory named **software_examples/app/hello_world**. The following steps refer to this directory as `<application>`.
8. Change to the `<application>` directory by typing the following command:

```
cd <application>
```
9. Type the following command to create and build the application:

```
./create-this-app
```

The **create-this-app** script copies the application source code to the `<application>` directory, runs **nios2-app-generate-makefile** to create a makefile (named **Makefile**), and then runs **make** to create an Executable and Linking Format File (`.elf`). The **create-this-app** script finds a compatible BSP by looking in `<projects>/software_examples/bsp`. In the case of `hello_world`, it selects the `hal_default` BSP.

To create the example BSP, **create-this-app** calls the **create-this-bsp** script in the BSP directory.

Related Information

[The Nios II Command Shell](#) on page 77

4.3.3. Running Hello_World on an Intel FPGA Development Board

To run the `hello_world` example on an Intel FPGA development board, perform the following steps:

⁽²⁾ For more information, refer to the "The Nios II Command Shell" chapter.

1. Start the Nios II Command Shell.
2. Download the SRAM Object File (.sof) for the Quartus Prime project to the Intel FPGA development board.

This step configures the FPGA on the Intel FPGA development board.

Note: The .sof file resides in <projects>, along with your Intel Quartus Prime Project File (.qpf). You download it by typing the following commands:

- `cd <projects>`
- `nios2-configure-sof`

The board is configured and ready to run the project's executable code.

The **nios2-configure-sof** utility runs the Intel Quartus Prime Programmer to download the .sof file. You can also run the `quartus_pgm` command directly.

For more information about programming the hardware, refer to the *Nios II Hardware Development Tutorial*.

3. Start another command shell displaying both command shells on your desktop.
4. In the second command shell, run the Nios II terminal application to connect to the Intel FPGA development board through the JTAG UART port by typing the `nios2-terminal` command.
5. Return to the original command shell and ensure that `<projects>/software_examples/app/hello_world` is the current working directory.
6. Download and run the `hello_world` executable program using the `nios2-download -g hello_world.elf` command.
Hello from Nios II! appears in the second command shell.

Related Information

- [Nios II Hardware Development Tutorial](#)
- [Nios II Hardware Development Tutorial](#)

4.3.4. Debugging hello_world


An integrated development environment is the most powerful environment for debugging a software project. You debug a command-line project by importing it to the Nios II SBT for Eclipse. After you import the project, Eclipse uses your makefiles to build the project. This two-step process combines the advantages of the SBT command line development flow with the convenience of a GUI debugger.

This section discusses the process of importing and debugging the **hello_world** application.

4.3.4.1. Import the hello_world Application

To import the **hello_world** application, perform the following steps:

1. Launch the Nios II SBT for Eclipse.
2. On the File menu, click **Import**. The **Import** dialog box appears.
3. Expand the **Nios II Project** folder, and select **Import Nios II project**.



4. Click **Next**. The **File Import** wizard appears.
5. Click **Browse** and navigate to the <application> directory, containing the **hello_world** application project.
6. Click **OK**. The wizard fills in the project path.
7. Type the project name `hello_world` in the **Project name** box.
8. Click **Finish**. The wizard imports the application project.

Note: If you want to view the BSP source files while debugging, you also need to import the BSP project into the Nios II SBT for Eclipse.

Related Information

[Getting Started with the Graphical User Interface](#) on page 26

For a description of importing BSPs into Eclipse, refer to "Importing a Command-Line Project".

4.3.4.2. Download Executable Code and Start the Debugger

1. Right-click the `hello_world` project, point to **Debug As**, and click **Nios II Hardware**.
2. If the **Confirm Perspective Switch** dialog box appears, click **Yes**.

After a moment, the `main()` function appears in the editor. There is a blue arrow next to the first line of code, indicating that execution has stopped on this line.

Note: When targeting Nios II hardware, the **Debug As** command does the following tasks:

- Creates a default debug configuration for the target board
 - Establishes communication with the target board
 - Downloads the **.elf** file to memory on the target board
 - Sets a breakpoint at `main()`
 - Instructs the Nios II processor to begin executing the code
3. In the Run menu, click **Resume** to resume execution. You can also resume execution by pressing **F8**.

Note: When debugging a project in Eclipse, you can also pause, stop, and single-step the program, set breakpoints, examine variables, and perform many other common debugging tasks.

Related Information


- [Importing a Command-Line Project](#) on page 50
For more information about debugging projects in the Nios II SBT for Eclipse.
- [Getting Started with the Graphical User Interface](#) on page 26
For more information about debugging projects in the Nios II SBT for Eclipse, refer to "Getting Started with Eclipse".

4.4. Software Build Tools Scripting Basics

This section provides an example to teach you how you can create a software application using a command line script.

In this section, assume that you want to build a software application for a Nios II system that features the **LAN91C111 10/100 Non-PCI Ethernet Single Chip MAC + PHY** component and supports the NicheStack[®] TCP/IP stack. Furthermore, assume that you have organized the hardware design files and the software source files.

Figure 5. Simple Software Project Directory Structure



4.4.1. Creating a BSP with a Script


A simple method for creating a BSP is to use the **nios2-bsp** script as in the following example:

```
nios2-bsp ucosii . ../SOPC/ --cmd enable_sw_package altera_iniche \
--set altera_iniche.iniche_default_if lan91c111
nios2-bsp lwhal . ../user/data/FastNetProject/FastNetHW/
make
```

Table 13. Description of nios2-bsp Arguments

Argument	Purpose	Further Information
ucosii	Sets the operating system to MicroC/OS-II	For more information, refer to "Settings Managed by the Software Build Tools".
.	Specifies the directory in which the BSP is to be created	—
../SOPC/	Points to the location of the hardware project	—
--cmd enable_sw_package altera_iniche	Adds the NicheStack TCP/IP stack software package to the BSP	For more information, refer to "Settings Managed by the Software Build Tools".


continued...



Argument	Purpose	Further Information
		For more information, refer to "Software Build Tools Tcl Commands".
--set altera_iniche.iniche_default_if lan91c111	Specifies the default hardware interface for the NicheStack TCP/IP Stack - Nios II Edition	For more information, refer to "Settings Managed by the Software Build Tools".

The **nios2-bsp** script uses the **.sopcinfo** file to create the BSP files. You can override default settings chosen by **nios2-bsp** by supplying command-line arguments, Tcl scripts, or both.

Figure 6. nios2-bsp Command Flow



Related Information

- [Nios II Software Build Tools Utilities](#) on page 396
For more information about the nios2-bsp command.
- [Settings Managed by the Software Build Tools](#) on page 423



- [Software Build Tools Tcl Commands](#) on page 465

4.4.2. Creating an Application Project with a Script

To create application projects, use **nios2-app-generate-makefile** as in the following example:

```
nios2-app-generate-makefile --bsp-dir ../BSP \  
--elf-name telnet-test.elf \  
--src-dir source/ make
```

Table 14. Description of nios2-app-generate-makefile Arguments

Argument	Purpose
--bsp-dir ../BSP	Specifies the location of the BSP on which this application is based
--elf-name telnet-test.elf	Specifies the name of the executable file
--src-dir source/	Tells nios2-app-generate-makefile where to find the C source files

Related Information

- [Nios II Software Build Tools](#) on page 87
For more information about the software example scripts, refer to "Nios II Design Example Scripts".
- [Nios II Software Build Tools Reference](#) on page 396
For further information about each command argument in the table, refer to "Nios II Software Build Tools Utilities" chapter; and for more information about the software example scripts, refer to "Nios II Design Example Scripts".

4.5. Running make

nios2-bsp places all BSP files in the BSP directory, specified on the command line with argument **--bsp-dir**. After running **nios2-bsp**, you run **make**, which compiles the source code. The result of compilation is the BSP library file, also in the BSP directory. The BSP is ready to be linked with your application.

You can specify multiple targets on a **make** command line. For example, the following command removes existing object files in the current project directory, builds the project, downloads the project to a board, and runs it:

```
make clean download-elf
```

You can modify an application or user library makefile with the **nios2-lib-update-makefile** and **nios2-app-update-makefile** utilities. With these utilities, you can execute the following tasks:

- Add source files to a project
- Remove source files from a project
- Add compiler options to a project's make rules
- Modify or remove compiler options in a project's make rules




4.5.1. Creating Memory Initialization Files

To create memory initialization files for a Nios II system, you can use the Nios II Command Shell. Change to the software application folder, and type:

```
make mem_init_generate
```

This command creates the memory initialization and simulation files for all memory devices. It also generates a Quartus Prime IP File (.qip). The .qip file tells the Quartus Prime software where to find the initialization files. Add the .qip file to your Quartus Prime project.



5. Nios II Software Build Tools

This chapter describes the Nios II Software Build Tools (SBT), a set of utilities and scripts that creates and builds embedded C/C++ application projects, user library projects, and board support packages (BSPs). The Nios II SBT supports a repeatable, scriptable, and archivable process for creating your software product.

You can invoke the Nios II SBT through either of the following user interfaces:

- The EclipseGUI
- The Nios II Command Shell

The purpose of this chapter is to make you familiar with the internal functionality of the Nios II SBT, independent of the user interface employed.

Before reading this chapter, consider getting an introduction to the Nios II SBT by first reading one of the following chapters:

- "Getting Started with the Graphical User Interface"
- "Getting Started from the Command Line"

This chapter assumes you are familiar with the following topics:

- The GNU **make** utility. Intel FPGA recommends you use version 3.80 or later. On the Windows platform, GNU **make** version 3.80 is provided with the Nios II EDS.
You can obtain general information about GNU **make** from the Free Software Foundation, Inc. website.
- Board support packages.

Depending on how you use the tools, you might also need to be familiar with the following topics:

- Micrium MicroC/OS-II.
For information, refer to *MicroC/OS-II - The Real Time Kernel* by Jean J. Labrosse (CMP Books).
- Tcl scripting language.

Related Information

- [Overview of Nios II Embedded Development](#) on page 18
- [Getting Started with the Graphical User Interface](#) on page 26
- [Getting Started from the Command Line](#) on page 73
- [Nios II Software Build Tools Revision History](#) on page 14
For details on the document revision history of this chapter
- [GNU Website](#)

5.1. Road Map for the SBT

Before you start using the Nios II SBT, it is important to understand its scope. This section helps you understand their purpose, what they include, and what each tool does. Understanding these points helps you determine how each tool fits in with your development process, what parts of the tools you need, and what features you can disregard for now.

5.1.1. What the Build Tools Create

The purpose of the build tools is to create and build Nios II software projects. A Nios II project is a makefile with associated source files.

The SBT creates the following types of projects:

- Nios II application—A program implementing some desired functionality, such as control or signal processing.
- Nios II BSP—A library providing access to hardware in the Nios II system, such as UARTs and other I/O devices. A BSP provides a software runtime environment customized for one processor in a hardware system. A BSP optionally also includes the operating system, and other basic system software packages such as communications protocol stacks.
- User library—A library implementing a collection of reusable functions, such as graphics algorithms.

5.1.2. Comparing the Command Line with Eclipse

Aside from the Eclipse GUI, there are very few differences between the SBT command line and the Nios II SBT for Eclipse.

Table 15. Differences between Nios II SBT for Eclipse and the Command Line

Feature	Eclipse	Command Line
Project source file management	Specify sources automatically, e.g. by dragging and dropping into project	Specify sources manually using command arguments
Debugging	Yes	Import project to Eclipse environment
Integrates with custom shell scripts and tool flows	No	Yes

The Nios II SBT for Eclipse provides access to a large, useful subset of SBT functionality. Any project you create in Eclipse can also be created using the SBT from the command line or in a script. Create your software project using the interface that is most convenient for you. Later, it is easy to perform additional project tasks in the other interface if you find it advantageous to do so.

5.2. Makefiles

Makefiles are a key element of Nios II C/C++ projects. The Nios II SBT includes powerful tools to create makefiles. An understanding of how these tools work can help you make the most optimal use of them.



The Nios II SBT creates two kinds of makefiles:

- Application or user library makefile—A simple makefile that builds the application or user library with user-provided source files
- BSP makefile—A more complex makefile, generated to conform to user-specified settings and the requirements of the target hardware system

It is not necessary to use to the generated application and user library makefiles if you prefer to write your own. However, Intel FPGA recommends that you use the SBT to manage and modify BSP makefiles.

Generated makefiles are platform-independent, calling only utilities provided with the Nios II EDS (such as **nios2-elf-gcc**).

The generated makefiles have a straightforward structure, and each makefile has in-depth comments explaining how it works. Intel FPGA recommends that you study these makefiles for further information about how they work. Generated BSP makefiles consist of a single main file and a small number of makefile fragments, all of which reside in the BSP directory. Each application and user library has one makefile, located in the application or user library directory.

5.2.1. Modifying Makefiles

It is not necessary to edit makefiles by hand. The Nios II SBT for Eclipse offers GUI tools for makefile management.

For more information, refer to the *Getting Started with the Graphical User Interface* section.

Table 16. Command-Line Utilities for Updating Makefiles

Project Type	Utilities
Application	nios2-app-update-makefile
Library	nios2-lib-update-makefile
BSP ⁽³⁾	nios2-bsp-update-settings nios2-bsp-generate-files

Note: After making changes to a makefile, run **make clean** before rebuilding your project. If you are using the Nios II SBT for Eclipse, this happens automatically.

Related Information

- [Getting Started with the Graphical User Interface](#) on page 26
- [Updating Your BSP](#) on page 119

5.2.2. Makefile Targets

Intel FPGA recommends that you study the generated makefiles for further details about the application makefile targets.

⁽³⁾ For more information about updating BSP makefiles, refer to [“Updating Your BSP” on page 4–30](#).

Table 17. Application Makefile Targets

Target	Operation
help	Displays all available application makefile targets.
all (default)	Builds the associated BSP and libraries, and then builds the application executable file.
app	Builds only the application executable file.
bsp	Builds only the BSP.
libs	Builds only the libraries and the BSP.
clean	Performs a clean build of the application. Deletes all application-related generated files. Leaves associated BSP and libraries alone.
clean_all	Performs a clean build of the application, and associated BSP and libraries (if any).
clean_bsp	Performs a clean build of the BSP.
clean_libs	Performs a clean build of the libraries and the BSP.
download-elf	Builds the application executable file and then downloads and runs it.
program-flash	Runs the Nios II flash programmer to program your flash memory.

Note: You can use the `download-elf` makefile target if the host system is connected to a single USB-Blaster download cable. If you have more than one download cable, you must download your executable with a separate command. Set up a run configuration in the Nios II SBT for Eclipse, or use **nios2-download**, with the `--cable` option to specify the download cable.

5.3. Nios II Embedded Software Projects

The Nios II SBT supports the following kinds of software projects:

- C/C++ application projects
- C/C++ user library projects
- BSP projects

This section discusses each type of project in detail.

5.3.1. Applications and Libraries

The Nios II SBT has nearly identical support for C/C++ applications and libraries. The support for applications and libraries is very simple. For each case, the SBT generates a private makefile (named **Makefile**). The private makefile is used to build the application or user library.

The private makefile builds one of two types of files:

- A **.elf** file—For an application
- A library archive file (**.a**)—For a user library

For a user library, the SBT also generates a public makefile, called `public.mk`. The public makefile is included in the private makefile for any application (or other user library) that uses the user library.



When you create a makefile for an application or user library, you provide the SBT with a list of source files and a reference to a BSP directory. The BSP directory is mandatory for applications and optional for libraries.

5.3.1.1. Supported Source File Types

The Nios II SBT examines the extension of each source file to determine the programming language.

Table 18. Supported Programming Languages with the Corresponding File Extensions

Programming Language	File Extensions ⁽⁴⁾
C	.c
C++	.cpp, .cxx, .cc
Nios II assembly language; sources are built directly by the Nios II assembler without preprocessing	.s
Nios II assembly language; sources are preprocessed by the Nios II C preprocessor, allowing you to include header files	.S

5.3.2. Board Support Packages

A Nios II BSP project is a specialized library containing system-specific support code. A BSP provides a software runtime environment customized for one processor in a hardware system. The BSP isolates your application from system-specific details such as the memory map, available devices, and processor configuration.

A BSP includes a .a file, header files (for example, `system.h`), and a linker script (`linker.x`). You use these BSP files when creating an application.

The Nios II SBT supports two types of BSPs: Intel FPGA Hardware Abstraction Layer (HAL) and Micrium MicroC/OS-II. MicroC/OS-II is a layer on top of the Intel FPGA HAL and shares a common structure.

5.3.2.1. Overview of BSP Creation

The Nios II SBT creates your BSP for you. The tools provide a great deal of power and flexibility, enabling you to control details of your BSP implementation while maintaining compatibility with a hardware system that might change.

By default, the tools generate a basic BSP for a Nios II system. If you require more detailed control over the characteristics of your BSP, the Nios II SBT provides that control, as described in the remaining sections of this chapter.

5.3.2.2. Parts of a Nios II BSP

5.3.2.2.1. Hardware Abstraction Layer

The HAL provides a single-threaded UNIX-like C/C++ runtime environment. The HAL provides generic I/O devices, allowing you to write programs that access hardware using the newlib C standard library routines, such as `printf()`. The HAL interfaces to

⁽⁴⁾ All file extensions are case-sensitive.

HAL device drivers, which access peripheral registers directly, abstracting hardware details from the software application. This abstraction minimizes or eliminates the need to access hardware registers directly to connect to and control peripherals.

For more information about the HAL, refer to the "HAL API Reference" section.

Related Information

[HAL API Reference](#) on page 315

5.3.2.2.2. newlib C Standard Library

newlib is an open source implementation of the C standard library intended for use on embedded systems. It is a collection of common routines such as `printf()`, `malloc()`, and `open()`.

5.3.2.2.3. Device Drivers

Each device driver manages a hardware component. By default, the HAL instantiates a device driver for each component in your hardware system that needs a device driver. In the Nios II software development environment, a device driver has the following properties:

- A device driver is associated with a specific hardware component.
- A device driver might have settings that impact its compilation. These settings become part of the BSP settings.

5.3.2.2.4. Optional Software Packages

A software package is source code that you can optionally add to a BSP project to provide additional functionality. The NicheStack TCP/IP - Nios II Edition is an example of a software package.

In the Nios II software development environment, a software package typically has the following properties:

- A software package is not associated with specific hardware.
- A software package might have settings that impact its compilation. These settings become part of the BSP settings.

Note: In the Nios II software development environment, a software package is distinct from a library project. A software package is part of the BSP project, not a separate library project.

5.3.2.2.5. Optional Real-Time Operating System

The Nios II EDS includes an implementation of the third-party MicroC/OS-II RTOS that you can optionally include in your BSP. MicroC/OS-II is built on the HAL, and implements a simple, well-documented RTOS scheduler. You can modify settings that become part of the BSP settings. Other operating systems are available from third-party vendors.

The Micrium MicroC/OS-II is a multi-threaded run-time environment. It is built on the Intel FPGA HAL.

The MicroC/OS-II directory structure is a superset of the HAL BSP directory structure. All HAL BSP generated files also exist in the MicroC/OS-II BSP.



The MicroC/OS-II source code resides in the **UCOSII** directory. The **UCOSII** directory is contained in the BSP directory, like the **HAL** directory, and has the same structure (that is, **src** and **inc** directories). The **UCOSII** directory contains only copied files.

The MicroC/OS-II BSP library archive is named `libucosii_bsp.a`. You use this file the same way you use `libhal_bsp.a` in a HAL BSP.

5.3.3. Software Build Process

To create a software project with the Nios II SBT, you perform several high-level steps:

1. Obtain the hardware design on which the software is to run. When you are learning about the build tools, this might be a Nios II design example. When you are developing your own design, it is probably a design developed by someone in your organization. Either way, you need to have the SOPC Information File (**.sopcinfo**).

2. Decide what features the BSP requires. For example, does it need to support an RTOS? Does it need other specialized software support, such as a TCP/IP stack? Does it need to fit in a small memory footprint? The answers to these questions tell you what BSP features and settings to use.

For more information about available BSP settings, refer to the "Nios II Software Build Tools Reference" chapter.

3. Define a BSP. Use the Nios II SBT to specify the components in the BSP, and the values of any relevant settings. The result of this step is a BSP settings file, called **settings.bsp**.

For more information about creating BSPs, refer to the "Board Support Packages" chapter.

4. Create a BSP makefile using the Nios II build tools.
5. Optionally create a user library. If you need to include a custom software user library, you collect the user library source files in a single directory, and create a user library makefile. The Nios II build tools can create a makefile for you. You can also create a makefile by hand, or you can autogenerate a makefile and then customize it by hand.

For more information about creating user library projects, refer to the "Applications and Libraries" chapter.

6. Collect your application source code. When you are learning, this might be a Nios II software example. When you are developing a product, it is probably a collection of C/C++ source files developed by someone in your organization.

For more information about creating application projects, refer to the "Applications and Libraries" chapter.

7. Create an application makefile. The easiest approach is to let the Nios II build tools create the makefile for you. You can also create a makefile by hand, or you can autogenerate a makefile and then customize it by hand.

For more information about creating makefiles, refer to the "Makefiles" chapter.

Note: You must use the correct directory path for fetching the respective files from your project folder.

Related Information

- [Applications and Libraries](#) on page 90

- [Makefiles](#) on page 88
- [Board Support Packages](#) on page 91
- [Nios II Software Build Tools Reference](#) on page 396

5.4. Common BSP Tasks

The Nios II SBT creates a BSP for you with useful default settings. However, for many tasks you must manipulate the BSP explicitly. This section describes the following common BSP tasks, and how you carry them out.

Although this section describes tasks in terms of the SBT command line flow, you can also carry out most of these tasks with the Nios II SBT for Eclipse.

Related Information

- [Using Version Control](#) on page 94
- [Copying, Moving, or Renaming a BSP](#) on page 96
- [Handing Off a BSP](#) on page 96
- [Changing the Default Linker Memory Region](#) on page 101
- [Changing a Linker Section Mapping](#) on page 102
- [Managing Device Drivers](#) on page 103
- [Creating a Custom Version of newlib](#) on page 104
- [Creating a BSP for an Intel FPGA Development Board](#) on page 102
- [Creating Memory Initialization Files](#) on page 97
- [Modifying Linker Memory Regions](#) on page 97
- [Creating a Custom Linker Section](#) on page 99
- [Querying Settings](#) on page 103
- [Controlling the stdio Device](#) on page 104
- [Configuring Optimization and Debugger Options](#) on page 105
- [Getting Started with the Graphical User Interface](#) on page 26

For more information about carrying out the tasks with the Nios II SBT for Eclipse, refer to the "Getting Started with the Graphical User Interface" chapter.

5.4.1. Adding the Nios II SBT to Your Tool Flow

A common reason for using the SBT is to enable you to integrate your software build process with other tools that you use for system development, including non-Intel FPGA tools. This section describes several scenarios in which you can incorporate the build tools in an existing tool chain.

5.4.1.1. Using Version Control

One common tool flow requirement is version control. By placing an entire software project, including both source and makefiles, under version control, you can ensure reproducible results from software builds.



When you are using version control, it is important to know which files to add to your version control database. With the Nios II SBT, the version control requirements depend on what you are trying to do and how you create the BSP.

5.4.1.1.1. Creating BSP by Running a User Defined Script to Call **nios2-bsp**

If you create a BSP by running your own script that calls **nios2-bsp**, you can put your script under version control. If your script provides any Tcl scripts to **nios2-bsp** (using the `--script` option), you must also put these Tcl scripts under version control. If you install a new release of Nios II EDS and run your script to create a new BSP or to update an existing BSP, the internal implementation of your BSP might change slightly due to improvements in Nios II EDS.

For more information, refer to [“Revising Your BSP” on page 4–28](#) for a discussion of BSP regeneration with Nios II EDS updates.

Related Information

[Revising Your BSP](#) on page 116

5.4.1.1.2. Creating BSP by Manually Running **nios2-bsp**

If you create a BSP by running **nios2-bsp** manually on the command line or by running your own script that calls **nios2-bsp-generate-files**, you can put your BSP settings file (typically named `settings.bsp`) under version control. As in the scripted **nios2-bsp** case, if you install a new release of Nios II EDS and recreate your BSP, the internal implementation might change slightly.

5.4.1.1.3. Creating BSP before Running Make

If you want the exact same BSP after installing a new release of Nios II EDS, create your BSP and then put the entire BSP directory under version control before running `make`. If you have already run `make`, run `make clean` to remove all built files before adding the directory contents to your version control database. The SBT places all the files required to build a BSP in the BSP directory. If you install a new release of Nios II EDS and run `make` on your BSP, the implementation is the same, but the binary output might not be identical.

5.4.1.1.4. Creating a Script that Uses the Command-Line Tools

If you create a script that uses the command-line tools **nios2-bsp-create-settings** and **nios2-bsp-generate-files** explicitly, or you use these tools directly on the command line, it is possible to create the BSP settings file in a directory different from the directory where the generated BSP files reside. However, in most cases, when you want to store a BSP’s generated files directory under source control, you also want to store the BSP settings file. Therefore, it is best to keep the settings file with the other BSP files. You can rebuild the project without the BSP settings file, but the settings file allows you to update and query the BSP.

Note: Because the BSP depends on a `.sopcinfo` file, you must usually store the `.sopcinfo` file in source control along with the BSP. The BSP settings file stores the `.sopcinfo` file path as a relative or absolute path, according to the definition on the **nios2-bsp** or **nios2-bsp-create-settings** command line. You must take the path into account when retrieving the BSP and the `.sopcinfo` file from source control.

5.4.1.2. Copying, Moving, or Renaming a BSP

BSP makefiles have only relative path references to project source files. Therefore you are free to copy, move, or rename the entire BSP. If you specify a relative path to the SOPC system file when you create the BSP, you must ensure that the **.sopcinfo** file is still accessible from the new location of the BSP. This **.sopcinfo** file path is stored in the BSP settings file.

Run `make clean` when you copy, move, or rename a BSP. The `make` dependency files (`.d`) have absolute path references. `make clean` removes the `.d` files, as well as linker object files (`.o`) and `.a` files. You must rebuild the BSP before linking an application with it. You can use the `make clean_bsp` command to combine these two operations.

For more information about `.d` files, refer to the GNU `make` documentation, available from the Free Software Foundation, Inc. website.

Another way to copy a BSP is to run the **nios2-bsp-generate-files** command to populate a BSP directory and pass it the path to the BSP settings file of the BSP that you wish to copy.

If you rename or move a BSP, you must manually revise any references to the BSP name or location in application or user library makefiles.

Related Information

- [GNU Website](#)
For more information about `.d` files.
- [Nios II Embedded Design Suite Support](#)

5.4.1.3. Handing Off a BSP

In some engineering organizations, one group (such as systems engineering) creates a BSP and hands it off to another group (such as applications software) to use while developing an application. In this situation, Intel FPGA recommends that you as the BSP developer generate the files for a BSP without building it (that is, do not run `make`) and then bundle the entire BSP directory, including the settings file, with a utility such as **tar** or **zip**. The software engineer who receives the BSP can simply run `make` to build the BSP.

5.4.2. Linking and Locating

When auto-generating a HAL BSP, the SBT makes some reasonable assumptions about how you want to use memory.

For more information, refer to [“Specifying the Default Memory Map” on page 4–35](#).

However, in some cases these assumptions might not work for you. For example, you might implement a custom boot configuration that requires a bootloader in a specific location; or you might want to specify which memory device contains your interrupt service routines (ISRs).

This section describes several common scenarios in which the SBT allows you to control details of memory usage.



Related Information

Specifying the Default Memory Map on page 125

5.4.2.1. Creating Memory Initialization Files

The `mem_init.mk` file includes targets designed to help you create memory initialization files (`.dat`, `.hex`, `.sym`, and `.flash`). The `mem_init.mk` file is designed to be included in your application makefile. Memory initialization files are used for HDL simulation, for Quartus Prime compilation of initializable FPGA on-chip memories, and for flash programming. Memories that can be initialized include M512 and M4K, but not MRAM.

Although the application makefile provides the **mem_init.mk** targets, it does not build any of them by default. The SBT creates the memory initialization files in the application directory (under a directory named **mem_init**). The SBT optionally copies them to your Quartus Prime project directory and HDL simulation directory.

Note: The Nios II SBT does not generate a definition of `QUARTUS_PROJECT_DIR` in your application makefile.

If you have an on-chip RAM, and require that a compiled software image be inserted in your SRAM Object File (`.sof`) at Quartus Prime compilation, you must manually specify the value of `QUARTUS_PROJECT_DIR` in your application makefile. You must define `QUARTUS_PROJECT_DIR` before the `mem_init.mk` file is included in the application makefile, as in the following example:

```
QUARTUS_PROJECT_DIR = ../my_hw_design
MEM_INIT_FILE := $(BSP_ROOT_DIR)/mem_init.mk
include $(MEM_INIT_FILE)
```

Table 19. mem_init.mk Targets

Target	Operation
<code>mem_init_install</code>	Generates memory initialization files in the application mem_init directory. If the <code>QUARTUS_PROJECT_DIR</code> variable is defined, <code>mem_init.mk</code> copies memory initialization files to your Intel Quartus Prime project directory named <code>\$ (QUARTUS_PROJECT_DIR)</code> .
<code>mem_init_generate</code>	Generates all memory initialization files in the application mem_init directory. This target also generates a Quartus Prime IP File (<code>.qip</code>). The <code>.qip</code> file tells the Quartus Prime software where to find the initialization files.
<code>mem_init_clean</code>	Removes the memory initialization files from the application mem_init directory.
<code>.hex</code>	Generates all <code>.hex</code> files.
<code>.dat</code>	Generates all <code>.dat</code> files.
<code>.sym</code>	Generates all <code>.sym</code> files.
<code>.flash</code>	Generates all <code>.flash</code> files.
<code><memory name></code>	Generates all memory initialization files for <code><memory name></code> component.

5.4.2.2. Modifying Linker Memory Regions

If the linker memory regions that are created by default do not meet your needs, BSP Tcl commands let you modify the memory regions as desired.

Suppose you have a memory region named `onchip_ram`. The Tcl script named `reserve_1024_onchip_ram.tcl` separates the top 1024 bytes of `onchip_ram` to create a new region named `onchip_special`.

For more information about an explanation of each Tcl command used in this example, refer to the "Nios II Software Build Tools Reference" chapter.

```
# Get region information for onchip_ram memory region.
# Returned as a list.
set region_info [get_memory_region onchip_ram]
# Extract fields from region information list.
set region_name [lindex $region_info 0]
set slave_desc [lindex $region_info 1]
set offset [lindex $region_info 2]
set span [lindex $region_info 3]
# Remove the existing memory region.
delete_memory_region $region_name
# Compute memory ranges for replacement regions.
set split_span 1024
set new_span [expr $span-$split_span]
set split_offset [expr $offset+$new_span]
# Create two memory regions out of the original region.
add_memory_region onchip_ram $slave_desc $offset $new_span
add_memory_region onchip_special $slave_desc $split_offset $split_span
```

If you pass this Tcl script to **nios2-bsp**, it runs after the default Tcl script runs and sets up a linker region named `onchip_ram0`. You pass the Tcl script to **nios2-bsp** as follows:

```
nios2-bsp hal my_bsp --script reserve_1024_onchip_ram.tcl
```

Note: Take care that one of the new memory regions has the same name as the original memory region.

If you run **nios2-bsp** again to update your BSP without providing the `--script` option, your BSP reverts to the default linker memory regions and your `onchip_special` memory region disappears. To preserve it, you can either provide the `--script` option to your Tcl script or pass the `DONT_CHANGE` keyword to the default Tcl script as follows:

```
nios2-bsp hal my_bsp --default_memory_regions DONT_CHANGE
```

Intel FPGA recommends that you use the `--script` approach when updating your BSP. This approach allows the default Tcl script to update memory regions if memories are added, removed, renamed, or resized. Using the `DONT_CHANGE` keyword approach does not handle any of these cases because the default Tcl script does not update the memory regions at all.

For more information about using the `--script` argument, refer to the "Calling a Custom BSP Tcl Script" section.

Related Information

- [Calling a Custom BSP Tcl Script](#) on page 113
- [Nios II Software Build Tools Reference](#) on page 396



- [Nios II Software Build Tools Reference](#) on page 396
For an explanation of each Tcl command used in this example, refer to the "Nios II Software Build Tools Reference" chapter.

5.4.2.3. Creating a Custom Linker Section

The Nios II SBT provides a Tcl command, `add_section_mapping`, to create a linker section.

The default Tcl script creates these default sections for you using the `add_section_mapping` Tcl command:

- `.entry`
- `.exceptions`
- `.text`
- `.rodata`
- `.rwdata`
- `.bss`
- `.heap`
- `.stack`

5.4.2.3.1. Creating a Linker Section for an Existing Region

To create your own section named `special_section` that is mapped to the linker region named `onchip_special`, use the following command to run **nios2-bsp**:

```
nios2-bsp hal my_bsp --cmd add_section_mapping special_section
onchip_special
```

When the **nios2-bsp-generate-files** utility (called by **nios2-bsp**) generates the linker script `linker.x`, the linker script has a new section mapping. The order of section mappings in the linker script is determined by the order in which the `add_section_mapping` command creates the sections. If you use **nios2-bsp**, the default Tcl script runs before the `--cmd` option that creates the `special_section` section.

If you run **nios2-bsp** again to update your BSP, you do not need to provide the `add_section_mapping` command again because the default Tcl script only modifies section mappings for the default sections listed in the Nios II Default Section Names table.

5.4.2.3.2. Dividing a Linker Region to Create a New Region and Section

This example works with any hardware design containing an on-chip memory named `tightly_coupled_instruction_memory` connected to a Nios II instruction master.

Example 4–2. To Create a Section named `.isrs` in the `tightly_coupled_instruction_memory` on-chip memory

```
# Get region information for tightly_coupled_instruction_memory memory region.
# Returned as a list.
set region_info [get_memory_region tightly_coupled_instruction_memory]
# Extract fields from region information list.
set region_name [lindex $region_info 0]
```

```
set slave [lindex $region_info 1]
set offset [lindex $region_info 2]
set span [lindex $region_info 3]
# Remove the existing memory region.
delete_memory_region $region_name
# Compute memory ranges for replacement regions.
set split_span 1024
set new_span [expr $span-$split_span]
set split_offset [expr $offset+$new_span]
# Create two memory regions out of the original region.
add_memory_region tightly_coupled_instruction_memory $slave $offset $new_span
add_memory_region isrs_region $slave $split_offset $split_span
add_section_mapping .isrs isrs_region
```

The above Tcl script splits off 1 KB of RAM from the region named `tightly_coupled_instruction_memory`, gives it the name `isrs_region`, and then calls `add_section_mapping` to add the `.isrs` section to `isrs_region`.

Using the Create a New Region and Section Tcl Script

To use such a Tcl script, you would execute the following steps:

1. Create the Tcl script as shown in the example, above.
2. Edit your **create-this-bsp** script, and add the following argument to the **nios2-bsp** command line:
`--script <script name>.tcl`
3. In the BSP project, edit **timer_interrupt_latency.h**. In the `timer_interrupt_latency_irq()` function, change the `.section` directive from `.exceptions` to `.isrs`.
4. Rebuild the application by running `make`.

5.4.2.3.3. Excerpts from Object Dump Files

After `make` completes successfully, you can examine the object dump file, `<project name>.objdump`. The object dump file shows that the new `.isrs` section is located in the tightly coupled instruction memory. This object dump file excerpt shows a hardware design with an on-chip memory whose base address is `0x04000000`.

Example 4–3. Excerpts from Object Dump File

```
Sections:
Idx Name Size VMA LMA File off Algn
.
.
.

6 .isrs 000000c0 04000c00 04000c00 000000b4 2**2
CONTENTS, ALLOC, LOAD, READONLY, CODE
.
.
.

9 .tightly_coupled_instruction_memory 00000000 04000000 04000000 00013778 2**0
CONTENTS
.
.
.
SYMBOL TABLE:
00000000 1 d .entry 00000000
30000020 1 d .exceptions 00000000
```



```

30000150 1 d .text 00000000
30010e14 1 d .rodata 00000000
30011788 1 d .rwdata 00000000
30013624 1 d .bss 00000000
04000c00 1 d .isrs 00000000
00000020 1 d .ext_flash 00000000
03200000 1 d .epcs_controller 00000000
04000000 1 d .tightly_coupled_instruction_memory 00000000
04004000 1 d .tightly_coupled_data_memory 00000000
.
.
.

```

5.4.2.3.4. Excerpt from Linker.x

If you examine the linker script file, `linker.x`, you can see that `linker.x` places the new region `isrs_region` in tightly-coupled instruction memory, adjacent to the `tightly_coupled_instruction_memory` region.

Example 4–4. Excerpt From `linker.x`

```

MEMORY
{
  reset : ORIGIN = 0x0, LENGTH = 32
  tightly_coupled_instruction_memory : ORIGIN = 0x4000000, LENGTH = 3072
  isrs_region : ORIGIN = 0x4000c00, LENGTH = 1024
  .
  .
  .
}

```

5.4.2.4. Changing the Default Linker Memory Region

The default Tcl script chooses the largest memory region connected to your Nios II processor as the default region.

For more information about all default memory sections mapped to this default region, refer to the previous chapter, "Creating a Custom Linker Section".

You can pass in a command-line option to the default Tcl script to override this default mapping. To map all default sections to `onchip_ram`, type the following command:

```
nios2-bsp hal my_bsp --default_sections_mapping onchip_ram
```

If you run **nios2-bsp** again to update your BSP, the default Tcl script overrides your default sections mapping. To prevent your default sections mapping from being changed, provide **nios2-bsp** with the original `--default_sections_mapping` command-line option or pass it the `DONT_CHANGE` value for the memory name instead of `onchip_ram`.

Related Information

[Creating a Custom Linker Section](#) on page 99

5.4.2.5. Changing a Linker Section Mapping

If some of the default section mappings created by the default Tcl script do not meet your needs, you can use a Tcl command to override the section mappings selectively. To map the `.stack` and `.heap` sections into a memory region named `ram0`, use the following command:

```
nios2-bsp hal my_bsp --cmd add_section_mapping .stack ram0 \  
--cmd add_section_mapping .heap ram0
```

The other section mappings (for example, `.text`) are still mapped to the default linker memory region.

If you run **nios2-bsp** again to update your BSP, the default Tcl script overrides your section mappings for `.stack` and `.heap` because they are default sections. To prevent your section mappings from being changed, provide **nios2-bsp** with the original `add_section_mapping` command-line options or pass the `--default_sections_mapping DONT_CHANGE` command line to **nios2-bsp**.

Intel FPGA recommends using the `--cmd add_section_mapping` approach when updating your BSP because it allows the default Tcl script to update the default sections mapping if memories are added, removed, renamed, or resized.

5.4.3. Other BSP Tasks

This section covers some other common situations in which the SBT is useful.

5.4.3.1. Creating a BSP for an Intel FPGA Development Board

In some situations, you need to create a BSP separate from any application. Creating a BSP is similar to creating an application. To create a BSP, perform the following steps:

1. Start the Nios II Command Shell.
For details about the Nios II Command Shell, refer to the "Getting Started from the Command Line" chapter.
2. Create a working directory for your hardware and software projects. The following steps refer to this directory as `<projects>`.
3. Make `<projects>` the current working directory.
4. Find a Nios II hardware example corresponding to your Intel FPGA development board. For example, if you have a Stratix® IV development board, you might select `<Nios II EDS install path>/examples/verilog/niosII_stratixIV_4sgx230/triple_speed_ethernet_design`.
5. Copy the hardware example to your working directory, using a command such as the following:

```
cp -R /altera/100/nios2eds/examples/verilog\  
/niosII_stratixIV_4sgx230/triple_speed_ethernet_design
```
6. Ensure that the working directory and all subdirectories are writable by typing the following command:

```
chmod -R +w
```



The <projects> directory contains a subdirectory named **software_examples/bsp**. The **bsp** directory contains several BSP example directories, such as **hal_default**. Select the directory containing an appropriate BSP, and make it the current working directory.

For a description of the example BSPs, refer to “Nios II Design Example Scripts” in the Nios II Software Build Tools Reference section.

7. Create and build the BSP with the **create-this-bsp** script by typing the following command:

```
./create-this-bsp
```

Now you have a BSP, with which you can create and build an application.

Note: Intel FPGA recommends that you examine the contents of the **create-this-bsp** script. It is a helpful example if you are creating your own script to build a BSP. **create-this-bsp** calls **nios2-bsp** with a few command-line options to create a customized BSP, and then calls `make` to build the BSP.

Related Information

- [Overview of Nios II Embedded Development](#) on page 18
- [Nios II Software Build Tools Reference](#) on page 396
For a description of the example BSPs, refer to “Nios II Design Example Scripts” chapter.
- [Getting Started from the Command Line](#) on page 73
For details about the Nios II Command Shell.

5.4.3.2. Querying Settings

If you need to write a script that gets some information from the BSP settings file, use the **nios2-bsp-query-settings** utility. To maintain compatibility with future releases of the Nios II EDS, avoid developing your own code to parse the BSP settings file.

If you want to know the value of one or more settings, run **nios2-bsp-query-settings** with the appropriate command-line options. This command sends the values of the settings you requested to `stdout`. Just capture the output of `stdout` in some variable in your script when you call **nios2-bsp-query-settings**. By default, the output of **nios2-bsp-query-settings** is an ordered list of all option values. Use the `-show-names` option to display the name of the setting with its value.

For more information about the **nios2-bsp-query-settings** command-line options, refer to the Nios II Software Build Tools Reference section.

Related Information

- [Nios II Software Build Tools Reference](#) on page 396
For more information about the `nios2-bsp-query-settings` command-line options.

5.4.3.3. Managing Device Drivers

The Nios II SBT creates an `alt_sys_init.c` file. By default, the SBT assumes that if a device is connected to the Nios II processor, and a driver is available, the BSP must include the most recent version of the driver. However, you might want to use a different version of the driver, or you might not want a driver at all (for example, if your application accesses the device directly).

The SBT includes BSP Tcl commands to manage device drivers. With these commands you can control which driver is used for each device. When the `alt_sys_init.c` file is generated, it is set up to initialize drivers as you have requested.

If you are using **nios2-bsp**, you disable the driver for the `uart0` device as follows:

```
nios2-bsp hal my_bsp --cmd set_driver none uart0
```

Use the `--cmd` option to call a Tcl command on the command line. The **nios2-bsp-create-settings** command also supports the `--cmd` option. Alternatively, you can put the `set_driver` command in a Tcl script and pass the script to **nios2-bsp** or **nios2-bsp-create-settings** with the `--script` option.

You replace the default driver for `uart0` with a specific version of a driver as follows:

```
nios2-bsp hal my_bsp --cmd set_driver altera_avalon_uart:6.1
uart0
```

5.4.3.4. Creating a Custom Version of newlib

The Nios II EDS comes with a number of precompiled libraries. These libraries include the newlib libraries (`libc.a` and `libm.a`). The Nios II SBT allows you to create your own custom compiled version of the newlib libraries.

To create a custom compiled version of newlib, set a BSP setting to the desired compiler flags. If you are using **nios2-bsp**, type the following command:

```
nios2-bsp hal my_bsp --set hal.custom_newlib_flags "-O0 -pg"
```

Because newlib uses the open source **configure** utility, its build flow differs from other files in the BSP. When **Makefile** builds the BSP, it runs the **configure** utility. The **configure** utility creates a makefile in the build directory, which compiles the newlib source. The newlib library files are copied to the BSP directory named newlib. The newlib source files are not copied to the BSP.

Note: The Nios II SBT recompiles newlib whenever you introduce new compiler flags. For example, if you use compiler flags to add floating point math hardware support, newlib is recompiled to use the hardware. Recompiling newlib might take several minutes.

For the most up-to-date list of precompiled libraries and the corresponding switches, enter the following command:

```
nios2-elf-gcc --print-multi-lib
```

For more information about Nios II specific flags, refer to the "Nios II Options" section in the GCC online documentation.

Related Information

[Nios II Options](#)

5.4.3.5. Controlling the stdio Device

The build tools offer several ways to control the details of your `stdio` device configuration, such as the following:



- To prevent a default `stdio` device from being chosen, use the following command:

```
nios2-bsp hal my_bsp --default_stdio none
```
- To override the default `stdio` device and replace it with `uart1`, use the following command:

```
nios2-bsp hal my_bsp --default_stdio uart1
```
- To override the `stderr` device and replace it with `uart2`, while allowing the default Tcl script to choose the default `stdout` and `stdin` devices, use the following command:

```
nios2-bsp hal my_bsp --set hal.stderr uart2
```

In all these cases, if you run **nios2-bsp** again to update your BSP, you must provide the original command-line options again to prevent the default Tcl script from choosing its own default `stdio` devices. Alternatively, you can call `--default_stdio` with the `DONT_CHANGE` keyword to prevent the default Tcl script from changing the `stdio` device settings.

5.4.3.6. Configuring Optimization and Debugger Options

By default, the Nios II SBT creates your project with the correct compiler options for debugging environments. These compiler options turn off code optimization, and generate a symbol table for the debugger.

You can control the optimization and debug level through the project makefile, which determines the compiler options.

Example 4–5. Default Application Makefile Settings

```
APP_CFLAGS_OPTIMIZATION := -O0
APP_CFLAGS_DEBUG_LEVEL := -g
```

When your project is fully debugged and ready for release, you might want to enable optimization and omit the symbol table, to achieve faster, smaller executable code. To enable optimization and turn off the symbol table, edit the application makefile to contain the symbol definitions shown in the following example. The absence of a value on the right hand side of the `APP_CFLAGS_DEBUG_LEVEL` definition causes the compiler to omit generating a symbol table.

Example 4–6. Application Makefile Settings with Optimization

```
APP_CFLAGS_OPTIMIZATION := -O3
APP_CFLAGS_DEBUG_LEVEL :=
```

Note: When you change compiler options in a makefile, before building the project, run `make clean` to ensure that all sources are recompiled with the correct flags.

For more information about makefile editing and `make clean`, refer to the “Applications and Libraries” chapter.

Related Information

[Applications and Libraries](#) on page 90

5.4.3.6.1. Configuring a BSP for Debugging

You individually specify the optimization and debug level for the application and BSP projects, and any user library projects you might be using. You use the BSP settings `hal.make.bsp_cflags_debug` and `hal.make.bsp_cflags_optimization` to specify the optimization and debug level in a BSP, as shown in the “Configuring a BSP for Debugging” example.

Example 4–7. Configuring a BSP for Debugging

```
nios2-bsp hal my_bsp --set hal.make.bsp_cflags_debug -g \  
--set hal.make.bsp_cflags_optimization -O0r
```

Alternatively, you can manipulate the BSP settings with a Tcl script.

You can easily copy an existing BSP and modify it to create a different build configuration.

For more information, refer to the “Copying, Moving, or Renaming a BSP” chapter.

To change the optimization and debug level for a user library, use the same procedure as for an application.

Note: Normally you must set the optimization and debug levels the same for the application, the BSP, and all user libraries in a software project. If you mix settings, you cannot debug those components which do not have debug settings. For example, if you compile your BSP with the `-O0` flag and without the `-g` flag, you cannot step into the `newlib printf()` function.

Related Information

[Copying, Moving, or Renaming a BSP](#) on page 96

5.5. Details of BSP Creation

BSP creation is the same in the Nios II SBT for Eclipse as at the command line. The **nios2-bsp-create-settings** utility creates a new BSP settings file.

For more information about BSP settings files, refer to the “BSP Settings File Creation” chapter.

nios2-bsp-generate-files creates the BSP files. The **nios2-bsp-generate-files** utility places all source files in your BSP directory. It copies some files from the Nios II EDS installation directory. Others, such as `system.h` and **Makefile**, it generates dynamically.


The SBT manages copied files slightly differently from generated files. If a copied file (such as a HAL source file) already exists, the tools check the file timestamp against the timestamp of the file in the Nios II EDS installation. The tools do not replace the BSP file unless it differs from the distribution file. The tools normally overwrite generated files, such as the BSP **Makefile**, `system.h`, and `linker.x`, unless you have disabled generation of the individual file with the `set_ignore_file` Tcl command or the **Enable File Generation** tab in the BSP Editor. A comment at the top of each generated file warns you not to edit it.



For more information about `set_ignore_file` and other SBT Tcl commands, refer to Software Build Tools Tcl Commands in the "Nios II Software Build Tools Reference" chapter.

Note: Avoid modifying BSP files. Use BSP settings, or custom device drivers or software packages, to customize your BSP.

Figure 7. Default Tcl Script and nios2-bsp-generate-files Both Using the .sopcinfo file



Note: Nothing prevents you from modifying a BSP generated file. However, after you do so, it becomes difficult to update your BSP to match changes in your hardware system. If you regenerate your BSP, your previous changes to the generated file are destroyed.

For more information about regenerating your BSP, refer to the “Revising Your BSP” chapter.

Related Information

- [Revising Your BSP](#) on page 116
- [BSP Settings File Creation](#) on page 108
- [Nios II Software Build Tools Reference](#) on page 396


5.5.1. BSP Settings File Creation

Each BSP has an associated settings file that saves the values of all BSP settings. The BSP settings file is in extensible markup language (XML) format and has a **.bsp** extension by convention. When you create or update your BSP, the Nios II SBT writes the value of all settings to the settings file.

The BSP settings file does not need to duplicate system information (such as base addresses of devices), because the **nios2-bsp-generate-files** utility has access to the **.sopcinfo** file.

The **nios2-bsp-create-settings** utility creates a new BSP settings file. The **nios2-bsp-update-settings** utility updates an existing BSP settings file. The **nios2-bsp-query-settings** utility reports the setting values in an existing BSP settings file. The **nios2-bsp-generate-files** utility generates a BSP from the BSP settings file.

Figure 8. Interaction between the Nios II SBT and the BSP Settings File



5.5.2. Generated and Copied Files

To understand how to build and modify Nios II C/C++ projects, it is important to understand the difference between copied and generated files.

A copied file is installed with the Nios II EDS, and copied to your BSP directory when you create your BSP. It does not replace the BSP file unless it differs from the distribution file.

A generated file is dynamically created by the **nios2-bsp-generate-files** utility. Generated files reside in the top-level BSP directory. BSP files are normally written every time **nios2-bsp-generate-files** runs.



You can disable generation of any BSP file in the BSP Editor, or on the command line with the `set_ignore_file` Tcl command. Otherwise, if you modify a BSP file, it is destroyed when you regenerate the BSP.

5.5.3. HAL BSP Files and Folders

The Nios II SBT creates the HAL BSP directory in the location you specify.

5.5.3.1. HAL BSP After Generating Files

The SBT places generated files in the top-level BSP directory, and copied files in the **HAL** and **drivers** directories.

Figure 9. HAL BSP After Generating Files




Table 20. Generated BSP Files

File Name	Function
settings.bsp	Contains all BSP settings. This file is coded in XML. On the command line, settings.bsp is created by the nios2-bsp-create-settings command, and optionally updated by the nios2-bsp-update-settings command. The nios2-bsp-query-settings command is available to parse information from the settings file for your scripts. The settings.bsp file is an input to nios2-bsp-generate-files .
continued...	



File Name	Function
	The Nios II SBT for Eclipse provides equivalent functionality.
summary.html	Provides summary documentation of the BSP. You can view <code>summary.html</code> with a hypertext viewer or browser, such as Internet Explorer or Firefox . If you change the <code>settings.bsp</code> file, the SBT updates the <code>summary.html</code> file the next time you regenerate the BSP.
Makefile	Used to build the BSP. The targets you use most often are <code>all</code> and <code>clean</code> . The <code>all</code> target (the default) builds the <code>libhal_bsp.a</code> library file. The <code>clean</code> target removes all files created by a <code>make</code> of the <code>all</code> target.
public.mk	A makefile fragment that provides public information about the BSP. The file is designed to be included in other makefiles that use the BSP, such as application makefiles. The BSP Makefile also includes <code>public.mk</code> .
mem_init.mk	A makefile fragment that defines targets and rules to convert an application executable file to memory initialization files (<code>.dat</code> , <code>.hex</code> , and <code>.flash</code>) for HDL simulation, flash programming, and initializable FPGA memories. The <code>mem_init.mk</code> file is designed to be included by an application makefile. For usage, refer to any application makefile generated when you run the SBT. For more information, refer to the "Creating Memory Initialization Files" chapter.
alt_sys_init.c	Used to initialize device driver instances and software packages.
system.h	Contains the C declarations describing the BSP memory map and other system information needed by software applications.
linker.h	Contains information about the linker memory layout. <code>system.h</code> includes the <code>linker.h</code> file.
linker.x	Contains a linker script for the GNU linker.
memory.gdb	Contains memory region declarations for the GNU debugger.
obj Directory	Contains the object code files for all source files in the BSP. The hierarchy of the BSP source files is preserved in the obj directory.
libhal_bsp.a Library	Contains the HAL BSP library. All object files are combined in the library file. The HAL BSP library file is always named <code>libhal_bsp.a</code> .

Note: For more information about the `alt_sys_init.c` and `system.h` files, refer to the *Developing Programs Using the Hardware Abstraction Layer* section.

Related Information

- [Creating Memory Initialization Files](#) on page 97
- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158


5.5.3.2. Copied BSP Files

Table 21. Copied BSP Files

File Name	Function
HAL Directory	Contains HAL source code files. These are all copied files. The src directory contains the C-language and assembly-language source files. The inc directory contains the header files. The crt0.S source file, containing HAL C run-time startup code, resides in the HAL/src directory.
drivers Directory	Contains all driver source code. The files in this directory are all copied files. The drivers directory has src and inc subdirectories like the HAL directory.

5.5.3.3. HAL BSP After Build

HAL BSP After Build





5.5.4. Linker Map Validation

When a BSP is generated, the SBT validates the linker region and section mappings, to ensure that they are valid for a HAL project. The tools display an error in each of the following cases:

- The `.entry` section maps to a nonexistent region.
- The `.entry` section maps to a memory region that is less than 32 bytes in length.
- The `.entry` section maps to a memory region that does not start on the reset vector base address.
- The `.exceptions` section maps to a nonexistent region.
- The `.exceptions` section maps to a memory region that does not start on the exception vector base address.
- The `.entry` section and `.exceptions` section map to the same device, and the memory region associated with the `.exceptions` section precedes the memory region associated with the `.entry` section.
- The `.entry` section and `.exceptions` section map to the same device, and the base address of the memory region associated with the `.exceptions` section is less than 32 bytes above the base address of the memory region associated with the `.entry` section.

5.6. Tcl Scripts for BSP Settings

In many cases, you can fully specify your Nios II BSP with the Nios II SBT settings and defaults. However, in some cases you might need to create some simple Tcl scripts to customize your BSP.

You control the characteristics of your BSP by manipulating BSP settings, using Tcl commands. The most powerful way of using Tcl commands is by combining them in Tcl scripts.

Tcl scripting gives you maximum control over the contents of your BSP. One advantage of Tcl scripts over command-line arguments is that a Tcl script can obtain information from the hardware system or pre-existing BSP settings, and then use it later in script execution.

For more information about the Tcl commands used to manipulate BSPs, refer to “Software Build Tools Tcl Commands” in the *Nios II Software Build Tools Reference* section.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

5.6.1. Calling a Custom BSP Tcl Script

From the Nios II Command Shell, you can call a custom BSP Tcl script with any of the following commands:

```
nios2-bsp --script custom_bsp.tcl
```

```
nios2-bsp-create-settings --script custom_bsp.tcl
```

```
nios2-bsp-query-settings --script custom_bsp.tcl
```

```
nios2-bsp-update-settings --script custom_bsp.tcl
```

In the Nios II BSP editor, you can execute a Tcl script when generating a BSP, through the **New BSP Settings File** dialog box.

For more information about using Tcl scripts in the SBT for Eclipse, refer to Using the BSP Editor in the "Getting Started with the Graphical User Interface" chapter.

For more information, refer to an example of custom Tcl script usage in the "Creating Memory Initialization Files" chapter.

Note: Any settings you specify in your script override the BSP default values.

For more information about BSP defaults, refer to the "Specifying BSP Defaults" chapter.

Note: When you update an existing BSP, you must include any scripts originally used to create it. Otherwise, your project's settings revert to the defaults.

Note: When you use a custom Tcl script to create your BSP, you must include the script in the set of files archived in your version control system.

For more information, refer to the "Using Version Control" chapter.

Related Information

- [Specifying BSP Defaults](#) on page 122
- [Using Version Control](#) on page 94
- [Creating Memory Initialization Files](#) on page 97
- [Getting Started with the Graphical User Interface](#) on page 26

5.6.1.1. Simple Tcl Script


Example 4–8. To Set stdio to a Device with the name my_uart

```
set default_stdio my_uart
set_setting hal.stdin $default_stdio
set_setting hal.stdout $default_stdio
set_setting hal.stderr $default_stdio
```

5.6.1.2. Tcl Script to Examine Hardware and Choose Settings

Note: The Nios II SBT uses slave descriptors to refer to components connected to the Nios II processor. A slave descriptor is the unique name of a hardware component's slave port.

If a component has only one slave port connected to the Nios II processor, the slave descriptor is the same as the name of the component (for example, onchip_mem_0). If a component has multiple slave ports connecting the Nios II to multiple resources in the component, the slave descriptor is the name of the component followed by an underscore and the slave port name (for example, onchip_mem_0_s1).



```

# Select a device connected to the processor as the default STDIO device.
# It returns the slave descriptor of the selected device.
# It gives first preference to devices with stdio in the name.
# It gives second preference to JTAG UARTs.
# If no JTAG UARTs are found, it uses the last character device.
# If no character devices are found, it returns "none".
# Procedure that does all the work of determining the stdio device
proc choose_default_stdio {} {
    set last_stdio "none"
    set first_jtag_uart "none"
# Get all slaves attached to the processor.
    set slave_descs [get_slave_descs]
    foreach slave_desc $slave_descs {
# Lookup module class name for slave descriptor.
        set module_name [get_module_name $slave_desc]
        set module_class_name [get_module_class_name $module_name]
# If the module_name contains "stdio", we choose it
# and return immediately.
        if { [regexp .*stdio.* $module_name] } {
            return $slave_desc
        }
# Assume it is a JTAG UART if the module class name contains
# the string "jtag_uart". In that case, return the first one
# found.
        if { [regexp .*jtag_uart.* $module_class_name] } {
            if { $first_jtag_uart == "none" } {
                set first_jtag_uart $slave_desc
            }
        }
# Track last character device in case no JTAG UARTs found.
        if { [is_char_device $slave_desc] } {
            set last_stdio $slave_desc
        }
    }
    if { $first_jtag_uart != "none" } {
        return $first_jtag_uart
    }
    return $last_stdio
}
# Call routine to determine stdio
set default_stdio [choose_default_stdio]
# Set stdio settings to use results of above call.
set_setting hal.stdin $default_stdio
set_setting hal.stdout $default_stdio
set_setting hal.stderr $default_stdio
# Select a device connected to the processor as the default STDIO device.
# It returns the slave descriptor of the selected device.
# It gives first preference to devices with stdio in the name.
# It gives second preference to JTAG UARTs.
# If no JTAG UARTs are found, it uses the last character device.
# If no character devices are found, it returns "none".
# Procedure that does all the work of determining the stdio device
proc choose_default_stdio {} {
    {
        set last_stdio "none" set first_jtag_uart "none"
# Get all slaves attached to the processor.
        set slave_descs [get_slave_descs] foreach slave_desc $slave_descs
    {
# Lookup module class name for slave descriptor.
        set module_name [get_module_name $slave_desc]
        set module_class_name [get_module_class_name $module_name]
# If the module_name contains "stdio", we choose it
# and return immediately.
    }
}

```

```

    if { [regexp .*stdio.* $module_name] }
    {
        return $slave_desc
    }
    # Assume it is a JTAG UART if the module class name contains
    # the string "jtag_uart". In that case, return the first one
    # found.
    if { [regexp .*jtag_uart.* $module_class_name] }
    {
        if { $first_jtag_uart == "none" }
        {
            set first_jtag_uart $slave_desc
        }
    }
    # Track last character device in case no JTAG UARTs found.
    if { [is_char_device $slave_desc] }
    {
        set last_stdio $slave_desc
    }
    if { $first_jtag_uart != "none" }
    {
        return $first_jtag_uart
    }
    return $last_stdio
}
# Call routine to determine stdio set default_stdio
[choose_default_stdio]
# Set stdio settings to use results of above call.
set_setting hal.stdin $default_stdio set_setting hal.stdout
$default_stdio set_setting hal.stderr $default_stdio

```

Related Information

- [Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209
- [Specifying BSP Defaults](#) on page 122

5.7. Revising Your BSP

Your BSP is customized to your hardware design and your software requirements. If your hardware design or software requirements change, you usually need to revise your BSP.

Every BSP is based on a Nios II processor in a hardware system. The BSP settings file does not duplicate information available in the **.sopcinfo** file, but it does contain system-dependent settings that reference system information. Because of these system-dependent settings, a BSP settings file can become inconsistent with its system if the system changes.

You can revise a BSP at several levels. This section describes each level, and provides guidance about when to use it.

5.7.1. Rebuilding Your BSP

Rebuilding a BSP is the most superficial way to revise a BSP.



5.7.1.1. What Happens

Rebuilding the BSP simply recreates all BSP object files and the **.a** library file. BSP settings, source files, and compiler options are unchanged.

Related Information

[Regenerating Your BSP](#) on page 117

5.7.1.2. How to Rebuild Your BSP

In the Nios II SBT for Eclipse, right-click the BSP project and click **Build**.

On the command line, change to the BSP directory and type `make`.

5.7.2. Regenerating Your BSP

Regenerating the BSP refreshes the BSP source files without updating the BSP settings.

5.7.2.1. What Happens

Regenerating a BSP has the following effects:

- Reads the **.sopcinfo** file for basic system parameters such as module base addresses and clock frequencies.
- Retrieves the current system identification (ID) from the **.sopcinfo** file. Ensures that the correct system ID is inserted in the **.elf** file the next time the BSP is built.
- Adjusts the default memory map to correspond to changes in memory sizes. If you are using a custom memory map, it is untouched.
- Retains all other existing settings in the BSP settings file.

Note: Except for adjusting the default memory map, the SBT does not ensure that the settings are consistent with the hardware design in the **.sopcinfo** file.

- Ensures that the correct set of BSP files is present, as follows:
 - Copies all required source files to the BSP directory tree. Copied BSP files are listed in the "Copied BSP Files" ([Table 4–8 on page 4–23](#)).
 - If a copied file (such as a HAL source file) already exists, the SBT checks the file timestamp against the timestamp of the file in the Nios II EDS installation. The tools do not replace the BSP file unless it differs from the distribution file.
 - Recreates all generated files. Generated BSP files are listed in the "Generated BSP Files" table ([Table 4–7 on page 4–23](#)).

Note: You can disable generation of any BSP file in the BSP Editor, or on the command line with the `set_ignore_file` Tcl command. Otherwise, changes you make to a BSP file are lost when you regenerate the BSP. Whenever possible, use BSP settings, or custom device drivers or software packages, to customize your BSP.

- Removes any files that are not required, for example, source files for drivers that are no longer in use.

5.7.2.2. When to Regenerate Your BSP

Regenerating your BSP is required (and sufficient) in the following circumstances:

- You change your hardware design, but all BSP system-dependent settings remain consistent with the new **.sopcinfo** file. The following are examples of system changes that do not affect BSP system-dependent settings:
 - Changing a component's base address
 - With the internal interrupt controller (IIC), adding or removing hardware interrupts
 - With the IIC, changing a hardware interrupt number
 - Changing a clock frequency
 - Changing a simple processor option, such as cache size or core type
 - Changing a simple component option, other than memory size.
 - Adding a bridge
 - Adding a new component
 - Removing or renaming a component, other than a memory component, the `stdio` device, or the system timer device
 - Changing the size of a memory component when you are using the default memory map

Note: Unless you are sure that your modified hardware design remains consistent with your BSP settings, update your BSP. For more information, refer to the "Updating Your BSP" chapter.

- You want to eliminate any customized source files and revert to the distributed BSP code.

Note: To revert to the distributed BSP code, you must ensure that you have not disabled generation on any BSP files.

- You have installed a new version of the Nios II EDS, and you want the updated BSP software implementations.
- When you attempt to rebuild your project, an error message indicates that the BSP must be updated.
- You have updated or recreated the BSP settings file.

Related Information

[Updating Your BSP](#) on page 119

5.7.2.3. How to Regenerate Your BSP

You can regenerate your BSP in the Nios II SBT for Eclipse, or with SBT commands at the command line.

5.7.2.3.1. Regenerating Your BSP in Eclipse

In the Nios II SBT for Eclipse, right-click the BSP project, point to **Nios II**, and click **Generate BSP**.

For more information about generating a BSP with the SBT for Eclipse, refer to the *Getting Started with the Graphical User Interface* section.



Related Information

[Getting Started with the Graphical User Interface](#) on page 26

5.7.2.3.2. Regenerating Your BSP from the Command Line

From the command line, use the **nios2-bsp-generate-files** command.

For more information about the **nios2-bsp-generate-files** command, refer to the *Nios II Software Build Tools Reference* section.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

5.7.3. Updating Your BSP

When you update a BSP, you recreate the BSP settings file based on the current hardware definition and previous BSP settings.

Note: You must always regenerate your BSP after updating the BSP settings file.

5.7.3.1. What Happens

Updating a BSP has the following effects:

- System-dependent settings are derived from the original BSP settings file, but adjusted to correspond with any changes in the hardware system.
- Non-system-dependent BSP settings persist from the original BSP settings file.

For more information about actions taken when you regenerate the BSP after updating it, refer to the “Regenerating Your BSP” chapter.

Related Information

[Regenerating Your BSP](#) on page 117

5.7.3.2. When to Update Your BSP

Updating your BSP is necessary in the following circumstances:

- A change to your BSP settings is required.
- Changes to your **.sopcinfo** file make it inconsistent with your BSP. The following are examples of system changes that affect BSP system-dependent settings:
 - Renaming the processor
 - Renaming or removing a memory, the `stdio` device, or the system timer device
 - Changing the size of a memory component when using a custom memory map
 - Changing the processor reset or exception slave port or offset
 - Adding or removing an external interrupt controller (EIC)
 - Changing the parameters of an EIC
- When you attempt to rebuild your project, an error message indicates that you must update the BSP.

5.7.3.3. How to Update Your BSP

You can update your BSP at the command line. You have the option to use a Tcl script to control your BSP settings.

From the command line, use the **nios2-bsp-update-settings** command. You can use the `--script` option to define the BSP with a Tcl script.

For more information about the **nios2-bsp-update-settings** command, refer to the "Nios II Software Build Tools Reference" chapter.

nios2-bsp-update-settings does not reapply default settings unless you explicitly call the top-level default Tcl script with the `--script` option.

For more information about using the default Tcl script, refer to the "Specifying BSP Defaults" chapter.

Alternatively, you can update your BSP with the **nios2-bsp** script. **nios2-bsp** determines that your BSP already exists, and uses the **nios2-bsp-update-settings** command to update the BSP settings file.

The **nios2-bsp** script executes the default Tcl script every time it runs, overwriting previous default settings.

For more information about preserving all settings, including the default settings, use the `DONT_CHANGE` keyword, described in the "Top Level Tcl Script for BSP Defaults" chapter.

Alternatively, you can provide **nios2-bsp** with command-line options or Tcl scripts to override the default settings.

For more information about using the **nios2-bsp** script, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

- [Specifying BSP Defaults](#) on page 122
- [Top Level Tcl Script for BSP Defaults](#) on page 123
- [Nios II Software Build Tools Reference](#) on page 396
For more information about the **nios2-bsp-update-settings** command and using the **nios2-bsp** script.

5.7.4. Recreating Your BSP

When you recreate your BSP, you start over as if you were creating a new BSP.

Note: After you recreate your BSP, you must always regenerate it.

5.7.4.1. What Happens

Recreating a BSP has the following effects:



- System-dependent settings are created based on the current hardware system.
- Non-system-dependent settings can be selected by the default Tcl script, by values you specify, or both.

For more information about actions taken when you generate the BSP after recreating it, refer to the “Regenerating Your BSP” chapter.

5.7.4.2. When to Recreate Your BSP

If you are working exclusively in the Nios II SBT for Eclipse, and you modify the underlying hardware design, the best practice is to create a new BSP. Creating a BSP is very easy with the SBT for Eclipse. Manually correcting a large number of interrelated settings, on the other hand, can be difficult.

5.7.4.3. How to Recreate Your BSP

You can recreate your BSP in the Nios II SBT for Eclipse, or using the SBT at the command line. Regardless which method you choose, you can use Tcl scripts to control and reproduce your BSP settings. This section describes the options for recreating BSPs.

5.7.4.3.1. Using Tcl Scripts When Recreating Your BSP

A Tcl script automates selection of BSP settings. This automation ensures that you can reliably update or recreate your BSP with its original settings. Except when creating very simple BSPs, Intel FPGA recommends specifying all BSP settings with a Tcl script.

To use Tcl scripts most effectively, it is best to create a Tcl script at the time you initially create the BSP. However, the BSP Editor enables you to export a Tcl script from an existing BSP.

For more information about exporting Tcl scripts, refer to Using the BSP Editor in the “Getting Started with the Graphical User Interface” chapter.

By recreating the BSP settings file with a Tcl script that specifies all BSP settings, you can reproduce the original BSP while ensuring that system-dependent settings are adjusted correctly based on any changes in the hardware system.

For more information about Tcl scripting with the SBT, refer to the “Tcl Scripts for BSP Settings”.

Related Information

- [Tcl Scripts for BSP Settings](#) on page 113
- [Getting Started with the Graphical User Interface](#) on page 26

5.7.4.3.2. Recreating Your BSP in Eclipse

The process for recreating a BSP is the same as the process for creating a new BSP. The Nios II SBT for Eclipse provides an option to import a Tcl script when creating a BSP.

For more information, refer to “Getting Started with Nios II Software in Eclipse” and “Using the BSP Editor” in the Getting Started with the Graphical User Interface section.



Related Information

[Getting Started with the Graphical User Interface](#) on page 26

5.7.4.3.3. Recreating Your BSP at the Command Line

Recreate your BSP using the **nios2-bsp-create-settings** command. You can use the `--script` option to define the BSP with a Tcl script.

The **nios2-bsp-create-settings** command does not apply default settings to your BSP. However, you can use the `--script` command-line option to run the default Tcl script.

For more information about the default Tcl script, refer to the "Specifying BSP Defaults" chapter.

For more information about using the **nios2-bsp-create-settings** command, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

- [Specifying BSP Defaults](#) on page 122
- [Nios II Software Build Tools Reference](#) on page 396

5.8. Specifying BSP Defaults

The Nios II SBT sets BSP defaults using a set of Tcl scripts. These scripts specify default BSP settings. The scripts are located in the following directory:

<Nios II EDS install path>/**sdk2/bin**

Table 22. Default Tcl Script Components

Script	Level	Summary
bsp-set-defaults.tcl	Top-level	Sets system-dependent settings to default values.
bsp-call-proc.tcl	Top-level	Calls a specified procedure in one of the helper scripts.
bsp-stdio-utils.tcl	Helper	Specifies <code>stdio</code> device settings.
bsp-timer-utils.tcl	Helper	Specifies system timer device setting.
bsp-linker-utils.tcl	Helper	Specifies memory regions and section mappings for linker script.
bsp-bootloader-utils.tcl	Helper	Specifies boot loader-related settings.

For more information about Tcl scripting with the SBT, refer to the "Tcl Scripts for BSP Settings" chapter.

The Nios II SBT uses the default Tcl scripts to specify default values for system-dependent settings. System-dependent settings are BSP settings that reference system information in the **.sopcinfo** file.

The SBT executes the default Tcl script before any user-specified Tcl scripts. As a result, user input overrides settings made by the default Tcl script.

You can pass command-line options to the default Tcl script to override the choices it makes or to prevent it from making changes to settings.



For more information, refer to the “Top Level Tcl Script for BSP Defaults” chapter.

The default Tcl script makes the following choices for you based on your hardware system:

- `stdio` character device
- System timer device
- Default linker memory regions
- Default linker sections mapping
- Default boot loader settings

The default Tcl scripts use slave descriptors to assign devices.

Related Information

- [Tcl Scripts for BSP Settings](#) on page 113
- [Top Level Tcl Script for BSP Defaults](#) on page 123
- [Tcl Scripts for BSP Settings](#) on page 113
- [Top Level Tcl Script for BSP Defaults](#) on page 123

5.8.1. Top Level Tcl Script for BSP Defaults

The top level Tcl script for setting BSP defaults is `bsp-set-defaults.tcl`. This script specifies BSP system-dependent settings, which depend on the hardware system. The **nios2-bsp-create-settings** and **nios2-bsp-update-settings** utilities do not call the default Tcl script when creating or updating a BSP settings file. The `--script` option must be used to specify `bsp-set-defaults.tcl` explicitly. Both the Nios II SBT for Eclipse and the **nios2-bsp** script call the default Tcl script by invoking either **nios2-bsp-create-settings** or **nios2-bsp-update-settings** with the `--script bsp-set-defaults.tcl` option.

The default Tcl script consists of a top-level Tcl script named `bsp-set-defaults.tcl` plus the helper Tcl scripts listed in the “Default Tcl Script Components” table ([Table 4-9](#)). The helper Tcl scripts do the real work of examining the **.sopcinfo** file and choosing appropriate defaults.

The `bsp-set-defaults.tcl` script sets the following defaults:

- `stdio` character device (`bsp-stdio-utils.tcl`)
- System timer device (`bsp-timer-utils.tcl`)
- Default linker memory regions (`bsp-linker-utils.tcl`)
- Default linker sections mapping (`bsp-linker-utils.tcl`)
- Default boot loader settings (`bsp-bootloader-utils.tcl`)

You run the default Tcl script on the **nios2-bsp-create-settings**, **nios2-bsp-query-settings**, or **nios2-bsp-update-settings** command line, by using the `--script` argument. It has the following usage:

```
bsp-set-defaults.tcl [<argument name> <argument value>]*
```

All arguments are optional. If present, each argument must be in the form of a name and argument value, separated by white space. All argument values are strings. For any argument not specified, the corresponding helper script chooses a suitable default value. In every case, if the argument value is `DONT_CHANGE`, the default Tcl scripts leave the setting unchanged. The `DONT_CHANGE` value allows fine-grained control of what settings the default Tcl script changes and is useful when updating an existing BSP.

Table 23. Default Tcl Script Command-Line Options

Argument Name	Argument Value
<code>default_stdio</code>	Slave descriptor of default stdio device (stdin, stdout, stderr). Set to none if no stdio device desired.
<code>default_sys_timer</code>	Slave descriptor of default system timer device. Set to none if no system timer device desired.
<code>default_memory_regions</code>	Controls generation of memory regions By default, <code>bsp-linker-utils.tcl</code> removes and regenerates all current memory regions. Use the <code>DONT_CHANGE</code> keyword to suppress this behavior.
<code>default_sections_mapping</code>	Slave descriptor of the memory device to which the default sections are mapped. This argument has no effect if <code>default_memory_regions == DONT_CHANGE</code> .
<code>enable_bootloader</code>	Boolean: 1 if a boot loader is present; 0 otherwise.

5.8.2. Specifying the Default stdio Device

The `bsp-stdio-utils.tcl` script provides procedures to choose a default stdio slave descriptor and to set the `hal.stdin`, `hal.stdout`, and `hal.stderr` BSP settings to that value.

For more information about these settings, refer to the *Nios II Software Build Tools Reference* section.

The script searches the `.sopcinfo` file for a slave descriptor with the string `stdio` in its name. If `bsp-stdio-utils.tcl` finds any such slave descriptors, it chooses the first as the default stdio device. If the script finds no such slave descriptor, it looks for a slave descriptor with the string `jtag_uart` in its component class name. If it finds any such slave descriptors, it chooses the first as the default stdio device. If the script finds no slave descriptors fitting either description, it chooses the last character device slave descriptor connected to the Nios II processor. If `bsp-stdio-utils.tcl` does not find any character devices, there is no stdio device.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

5.8.3. Specifying the Default System Timer

The `bsp-timer-utils.tcl` script provides procedures to choose a default system timer slave descriptor and to set the `hal.sys_clk_timer` BSP setting to that value.

For more information about this setting, refer to the *Nios II Software Build Tools Reference* section.



The script searches the **.sopcinfo** file for a timer component to use as the default system timer. To be an appropriate system timer, the component must have the following characteristics:

- It must be a timer, that is, `is_timer_device` must return true.
- It must have a slave port connected to the Nios II processor.

When the script finds an appropriate system timer component, it sets `hal.sys_clk_timer` to the timer slave port descriptor. The script prefers a slave port whose descriptor contains the string `sys_clk`, if one exists. If no appropriate system timer component is found, the script sets `hal.sys_clk_timer` to none.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

5.8.4. Specifying the Default Memory Map

The `bsp-linker-utils.tcl` script provides procedures to add the default linker script memory regions and map the default linker script sections to a default region. The `bsp-linker-utils.tcl` script uses the `add_memory_region` and `add_section_mapping` BSP Tcl commands.

For more information about these commands, refer to the Nios II Software Build Tools Reference section.

The script chooses the largest volatile memory region as the default memory region. If there is no volatile memory region, `bsp-linker-utils.tcl` chooses the largest non-volatile memory region. The script assigns the `.text`, `.rodata`, `.rdata`, `.bss`, `.heap`, and `.stack` section mappings to this default memory region. The script also sets the `hal.linker.exception_stack_memory_region` BSP setting to the default memory region. The setting is available in case the separate exception stack option is enabled (this setting is disabled by default).

For more information about this setting, refer to the Nios II Software Build Tools Reference section.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

5.8.5. Specifying Default Bootloader Parameters

The `bsp-bootloader-utils.tcl` script provides procedures to specify the following BSP Boolean settings:

- `hal.linker.allow_code_at_reset`
- `hal.linker.enable_alt_load_copy_rodata`
- `hal.linker.enable_alt_load_copy_rdata`
- `hal.linker.enable_alt_load_copy_exceptions`

For more information about these settings, refer to the Nios II Software Build Tools Reference section.

Related Information

Nios II Software Build Tools Reference on page 396

5.8.5.1. Boot Loader Dependent Settings

The script examines the `.text` section mapping and the Nios II reset slave port. If the `.text` section is mapped to the same memory as the Nios II reset slave port and the reset slave port is a flash memory device, the script assumes that a boot loader is being used. You can override this behavior by passing the `enable_bootloader` option to the default Tcl script.

If a boot loader is enabled, the assumption is that the boot loader is located at the reset address and handles the copying of sections on reset. If there is no boot loader, the BSP might need to provide code to handle these functions. You can use the `alt_load()` function to implement a boot loader.

Table 24. Boot Loader-Dependent Settings

Setting name ⁽⁵⁾	Value When Boot Loader Enabled	Value When Boot Loader Disabled
<code>hal.linker.allow_code_at_reset</code>	0	
<code>hal.linker.enable_alt_load_copy_rodata</code>	0	if <code>.rodata</code> memory different than <code>.text</code> memory and <code>.rodata</code> memory is volatile; 0 otherwise
<code>hal.linker.enable_alt_load_copy_rwdata</code>	0	if <code>.rwdata</code> memory different than <code>.text</code> memory; 0 otherwise
<code>hal.linker.enable_alt_load_copy_exceptions</code>	0	if <code>.exceptions</code> memory different than <code>.text</code> memory and <code>.exceptions</code> memory is volatile; 0 otherwise

Related Information

Nios II Software Build Tools Reference on page 396

5.8.6. Using Individual Default Tcl Procedures

The default Tcl script consists of the top-level `bsp-call-proc.tcl` script plus the helper scripts listed in the "Default Tcl Script Components" table (Table 4-9 on page 4-33). The procedure call Tcl script allows you to call a specific procedure in the helper scripts, if you want to invoke some of the default Tcl functionality without running the entire default Tcl script.

The procedure call Tcl script has the following usage:

```
bsp-call-proc.tcl <proc-name> [<args>]*
```

`bsp-call-proc.tcl` calls the specified procedure with the specified (optional) arguments. Refer to the default Tcl scripts to view the available functions and their arguments. The `bsp-call-proc.tcl` script includes the same files as the `bsp-set-defaults.tcl` script, so any function in those included files is available.

⁽⁵⁾ For more information about the settings in this table, refer to the *Nios II Software Build Tools Reference* section.



5.9. Device Drivers and Software Packages

The Nios II SBT can incorporate device drivers and software packages supplied by Intel FPGA, other third-party developers, or created by you.

For more information about integrating device drivers and software packages with the Nios II SBT, refer to the *Developing Device Drivers for the Hardware Abstraction Layer* section.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

5.10. Boot Configurations for Intel FPGA Embedded Software

The HAL and MicroC/OS-II BSPs support several boot configurations. The default Tcl script configures an appropriate boot configuration based on your hardware system and other settings.

For more information about the HAL boot loader process, refer to the *Developing Programs Using the Hardware Abstraction Layer* section.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

5.10.1. Memory Types

The default Tcl script uses the `IsFlash` and `IsNonVolatileStorage` properties to determine what kind of memory is in the system.

The `IsFlash` property of the memory module (defined in the `.sopcinfo` file) indicates whether the `.sopcinfo` file identifies the memory as a flash memory device. The `IsNonVolatileStorage` property indicates whether the `.sopcinfo` file identifies the memory as a non-volatile storage device. The contents of a non-volatile memory device are fixed and always present.

Note:

Some FPGA memories can be initialized when the FPGA is configured. They are not considered non-volatile because the default Tcl script has no way to determine whether they are actually initialized in a particular system.

Table 25. Memory Types Recognized when Making Decisions about Your Boot Configuration

Memory Type	Examples	IsFlash	IsNonVolatileStorage
Flash	Common flash interface (CFI), erasable programmable configurable serial (EPCS) device	true	true
ROM	On-chip memory configured as ROM, HardCopy ROM	false	true
RAM	On-chip memory configured as RAM, HardCopy RAM, SDRAM, synchronous static RAM (SSRAM)	false	false

The following sections describe each supported build configuration in detail. The `alt_load()` facility is HAL code that optionally copies sections from the boot memory to RAM. You can set an option to enable the boot copy. This option only adds the code to your BSP if it needs to copy boot segments. The `hal.enable_alt_load` setting enables `alt_load()` and there are settings for each of the three sections it can copy (such as `hal.enable_alt_load_copy_rodata`). Enabling `alt_load()` also modifies the memory layout specified in your linker script.

5.10.2. Boot from Flash Configuration

The reset address points to a boot loader in a flash memory. The boot loader initializes the instruction cache, copies each memory section to its virtual memory address (VMA), and then jumps to `start`.

This boot configuration has the following characteristics:

- `alt_load()` not called
- No code at reset in executable file

The default Tcl script chooses this configuration when the memory associated with the processor reset address is a flash memory and the `.text` section is mapped to a different memory (for example, SDRAM).

Intel FPGA provides example boot loaders for CFI and EPCS memory in the Nios II EDS, precompiled to Motorola S-record Files (`.srec`). You can use one of these example boot loaders, or provide your own.

5.10.3. Boot from Monitor Configuration

The reset address points to a monitor in a nonvolatile ROM or initialized RAM. The monitor initializes the instruction cache, downloads the application memory image (for example, using a UART or Ethernet connection), and then jumps to the entry point provided in the memory image.

This boot configuration has the following characteristics:

- `alt_load()` not called
- No code at reset in executable file

The default Tcl script assumes no boot loader is in use, so it chooses this configuration only if you enable it. To enable this configuration, pass the following argument to the default Tcl script: `enable_bootloader 1`

If you are using the **nios2-bsp** script, call it as follows:

```
nios2-bsp hal my_bsp --use_bootloader 1
```

5.10.4. Run from Initialized Memory Configuration

The reset address points to the beginning of the application in memory (no boot loader). The reset memory must have its contents initialized before the processor comes out of reset. The initialization might be implemented by using a non-volatile reset memory (for example, flash, ROM, initialized FPGA RAM) or by an external master (for example, another processor) that writes the reset memory. The HAL C run-time startup code (`crt0`) initializes the instruction cache, uses `alt_load()` to copy select sections to their VMAs, and then jumps to `_start`. For each associated



section (.rdata, .rodata, .exceptions), Boolean settings control this behavior. The default Tcl scripts set these to default values as described in the "Boot Loader-Dependent Settings" table (Table 4-11 on page 4-36).

alt_load() must copy the .rdata section (either to another RAM or to a reserved area in the same RAM as the .text RAM) if .rdata needs to be correct after multiple resets.

This boot configuration has the following characteristics:

- alt_load() called
- Code at reset in executable file

The default Tcl script chooses this configuration when the reset and .text memory are the same.

In this boot configuration, when the processor core resets, by default the .rdata section is not reinitialized. Reinitialization would normally be done by a boot loader. However, this configuration has no boot loader, because the software is running out of memory that is assumed to be preinitialized before startup.

If your software has a .rdata section that must be reinitialized at processor reset, turn on the hal.linker.enable_alt_load_copy_rdata setting in the BSP.

5.10.5. Run-time Configurable Reset Configuration

The reset address points to a memory that contains code that executes before the normal reset code. When the processor comes out of reset, it executes code in the reset memory that computes the desired reset address and then jumps to it. This boot configuration allows a processor with a hard-wired reset address to appear to reset to a programmable address.

This boot configuration has the following characteristics:

- alt_load() might be called (depends on boot configuration)
- No code at reset in executable file

Because the processor reset address points to an additional memory, the algorithms used by the default Tcl script to select the appropriate boot configuration might make the wrong choice. The individual BSP settings specified by the default Tcl script need to be explicitly controlled.

5.11. Intel FPGA-Provided Embedded Development Tools

This section lists the components of the Nios II SBT, and other development tools that Intel FPGA provides for use with the SBT. This section does not describe detailed usage of the tools, but refers you to the most appropriate documentation.

5.11.1. Nios II Software Build Tool GUIs

The Nios II EDS provides the following SBT GUIs for software development:



- The Nios II SBT for Eclipse
- The Nios II BSP Editor
- The Nios II Flash Programmer

For more information about how each GUI is primarily a thin layer providing graphical control of the command-line tools, refer to “The Nios II Command-Line Commands” chapter.

Table 26. Summary of the Correlation Between GUI Features and the SBT Command Line

Task	Tool	Feature	Nios II SBT Command Line
Creating an example Nios II program	Nios II SBT for Eclipse	Nios II Application and BSP from Template wizard	create-this-app script
Creating an application	Nios II SBT for Eclipse	Nios II Application wizard	nios2-app-generate-makefile utility
Creating a user library	Nios II SBT for Eclipse	Nios II Library wizard	nios2-lib-generate-makefile utility
Creating a BSP	Nios II SBT for Eclipse	Nios II Board Support Package wizard	<ul style="list-style-type: none">• Simple: nios2-bsp script• Detailed: nios2-bsp-create-settings utility nios2-bsp-generate-files utility
	BSP Editor	New BSP Setting File dialog box	
Modifying an application	Nios II SBT for Eclipse	Nios II Application Properties page	nios2-app-update-makefile utility
Modifying a user library	Nios II SBT for Eclipse	Nios II Library Properties page	nios2-lib-update-makefile utility
Updating a BSP	Nios II SBT for Eclipse	Nios II BSP Properties page	nios2-bsp-update-settings utility nios2-bsp-generate-files utility
	BSP Editor	—	
Examining properties of a BSP	Nios II SBT for Eclipse	Nios II BSP Properties page	nios2-bsp-query-settings utility
	BSP Editor	—	
Programming flash memory	Nios II Flash Programmer	—	nios2-flash-programmer
Importing a command-line project	Nios II SBT for Eclipse	Import dialog box	—

Related Information

[The Nios II Command-Line Commands](#) on page 132

5.11.1.1. The Nios II SBT for Eclipse

The Nios II SBT for Eclipse is a configuration of the popular Eclipse development environment, specially adapted to the Nios II family of embedded processors. The Nios II SBT for Eclipse includes Nios II plugins for access to the Nios II SBT, enabling you to create applications based on the Intel FPGA HAL, and debug them using the JTAG debugger.



You can launch the Nios II SBT for Eclipse either of the following ways:

- In the Windows operating system, on the Start menu, point to **Programs > Nios II EDS <version>**, and click **Nios II <version> Software Build Tools for Eclipse**.
- From the Nios II Command Shell, by typing `eclipse-nios2`.

For more information about the Nios II SBT for Eclipse, refer to the Getting Started with the Graphical User Interface section.

Related Information

[Getting Started with the Graphical User Interface](#) on page 26

5.11.1.2. The Nios II BSP Editor

You can create or modify a Nios II BSP project with the Nios II BSP Editor, a standalone GUI that also works with the Nios II SBT for Eclipse. You can launch the BSP Editor either of the following ways:

- From the Nios II menu in the Nios II SBT for Eclipse
- From the Nios II Command Shell, by typing **`nios2-bsp-editor`**.

The Nios II BSP Editor enables you to edit settings, linker regions, and section mappings, and to select software packages and device drivers.

The capabilities of the Nios II BSP Editor constitute a large subset of the capabilities of the **`nios2-bsp-create-settings`**, **`nios2-bsp-update-settings`**, and **`nios2-bsp-generate-files`** utilities. Any project created in the BSP Editor can also be created using the command-line utilities.

For more information about the BSP Editor, refer to “Using the BSP Editor” in the Getting Started with the Graphical User Interface section.

Related Information

[Getting Started with the Graphical User Interface](#) on page 26

5.11.1.3. The Nios II Flash Programmer

The Nios II flash programmer allows you to program flash memory devices on a target board. The flash programmer supports programming flash on any board, including Intel FPGA development boards and your own custom boards. The flash programmer facilitates programming flash for the following purposes:

- Executable code and data
- Bootstrap code to copy code from flash to RAM, and then run from RAM
- HAL file subsystems
- FPGA hardware configuration data

You can launch the flash programmer either of the following ways:

- From the Nios II menu in the Nios II SBT for Eclipse
- From the Nios II Command Shell, by typing:

```
nios2-flash-programmer-generate
```

5.11.2. The Nios II Command Shell

The Nios II Command Shell is a **bash** command-line environment initialized with the correct settings to run Nios II command-line tools. The Nios II EDS includes two versions of the Nios II Command Shell, for the two supported GCC toolchain versions.

For more information, refer to the "GNU Compiler Tool Chain" chapter.

For more information about launching the Nios II Command Shell, refer to the "Getting Started from the Command Line" chapter.

5.11.3. The Nios II Command-Line Commands

This section describes the Intel FPGA Nios II command-line tools. You can run these tools from the Nios II Command Shell.

Each tool provides its own documentation in the form of help accessible from the command line. To view the help, open the Nios II Command Shell, and type the following command: `<name of tool> --help`

5.11.3.1. GNU Compiler Tool Chain

The Nios II compiler tool chain is based on the standard GNU **GCC** compiler, assembler, linker, and make facilities. Intel FPGA provides and supports the standard GNU compiler tool chain for the Nios II processor.

The Nios II EDS includes version GCC 4.8.3 of the GCC toolchain.

For more information about installing the Quartus Prime, refer to the *Intel FPGA Software Installation and Licensing Manual*.

The following options are new for the GCC toolchain:

Code density and performance

Use of the `-mgpopt=global` setting is recommended as it generally deliver results with better code density *and* performance. (Note: this requires that everything is compiled with the same `-Gn` switch setting; use of `-Gn` is not generally recommended).

C++ code size reduction: -fno-exceptions

When a developer is using C++ but trying not to link in the (big) C++ exception-handling machinery, `nios2-elf-g++` does, in some cases, link in the exception-handling machinery where it is not actually required. This switch suppresses that behaviour, which results in a smaller code footprint for those situations.

Response to address 0x00 access: -fdelete-null-pointer-checks

Developers often have RAM at address 0x00 (== NULL pointer in gcc and most C compilers). From gcc 4.9 onwards, by default gcc detects attempts to read or write to address 0x00 and converts them to traps; typically in embedded/Nios II-based systems, these traps are not handled so the code fails silently. This means that code that works when compiled with earlier versions of gcc could silently fail when compiled with gcc-4.9 (onwards).



In order to avoid this for Nios II this behavior has been modified so that accesses to address 0x00 works as expected for Nios II systems but there may be a slight negative effect on code performance. In Nios II systems that are known not to read/write RAM at address 0x00, use of the switch `--fdelete-null-pointer-checks` restores the original gcc behavior and may provide a small performance boost.

Expansion of `__builtin_trap`

The latest versions of GCC now produce trap 3 instead of break 3 in the expansion of the `__builtin_trap` function and in other situations where a trap is emitted to indicate undefined runtime behaviour. This is for compliance with the Nios II ABI for Linux targets, which does not permit the use of the break instruction in user code.

GDB breakpoint instruction

GDB now uniformly uses trap 31 instead of a break instruction for software breakpoints. This is for consistency with the Nios II ABI for Linux targets.

GNU tools for the Nios II processor are generally named **nios2-elf-`<tool name>`**. The following list shows some examples:

- **nios2-elf-gcc**
- **nios2-elf-as**
- **nios2-elf-ld**
- **nios2-elf-objdump**
- **nios2-elf-size**

The exception is the **make** utility, which is simply named **make**.

The Nios II GNU tools reside in the following location:

- `<Nios II EDS install path>/bin/gnu` directory

Refer to the following additional sources of information:

- For more information about managing GCC toolchains in the SBT for Eclipse—"Managing Toolchains in Eclipse" in the "Getting Started with the Graphical User Interface" chapter.
- For more information about selecting the toolchain on the command line—the "Getting Started from the Command Line" chapter.
- For more information about a comprehensive list of Nios II GNU tools—the GNU HTML documentation, refer to the *Nios II Embedded Design Suite Support* page on the Intel FPGA website.
- For more information about GNU, refer to the Free Software Foundation website.

Related Information

- [Overview of Nios II Embedded Development](#) on page 18
- [Getting Started with the Graphical User Interface](#) on page 26
- [Getting Started from the Command Line](#) on page 73
- [GNU website](#)

5.11.3.2. Nios II Software Build Tools

The Nios II SBT utilities and scripts provide the functionality underlying the Nios II SBT for Eclipse. You can create, modify, and build Nios II programs with commands typed at a command line or embedded in a script.

You can call these utilities and scripts on the command line or from the scripting language of your choice (such as **perl** or **bash**).

Note: For usage information, enter "--help" after the command and a list of required and optional arguments for the command appears.

Table 27. Utilities and Scripts Included in the Nios II SBT

Command	Summary	Utility	Script
nios2-app-generate-makefile	Creates an application makefile	x	
nios2-lib-generate-makefile	Creates a user library makefile	x	
nios2-app-update-makefile	Modifies an existing application makefile	x	
nios2-lib-update-makefile	Modifies an existing user library makefile	x	
nios2-bsp-create-settings	Creates a BSP settings file	x	
nios2-bsp-update-settings	Updates the contents of a BSP settings file	x	
nios2-bsp-query-settings	Queries the contents of a BSP settings file	x	
nios2-bsp-generate-files	Generates all files for a given BSP settings file	x	
nios2-bsp	Creates or updates a BSP		x

The Nios II SBT utilities reside in the <Nios II EDS install path>/**sdk2/bin** directory.

For more information about the Nios II SBT, refer to the "Getting Started from the Command Line" chapter.

Related Information

- [Overview of Nios II Embedded Development](#) on page 18
- [Getting Started from the Command Line](#) on page 73

5.11.3.3. File Format Conversion Tools

File format conversion is sometimes necessary when passing data from one utility to another.

Note: For usage information, enter "-h" after the command and a list of options for the command appears.

The file conversion utilities are:

- **alt-file-convert**
- **bin2flash**
- **elf2dat**
- **elf2flash**
- **elf2hex**



- **elf2mif**
- **flash2dat**

The file format conversion tools are in the <Nios II EDS install path>/bin/ directory.

5.11.3.3.1. alt-file-convert (BETA)

Description

alt-file-convert (BETA): General file conversion tool. For Nios II, it is primarily used for generating a Nios II application image for Max Onchip Flash and EPCQ.

Usage

```
alt-file-convert -I <input_type> -O <output_type> [option(s)] --
input=<input_file> --output=<output_file>
```

For Nios II, the BETA version is limited to the following uses:

- Convert between Intel HEX (byte addressed) and Quartus HEX (word addressed)
- Convert between Quartus HEX files of various widths
- Convert an .elf file to a HEX file and append a bootcopier (used for application flash image for Max On-chip Flash and EPCQ)

Options

```
-h, --help - prints usage
-I - input type
-O - output type
--base - base address (in hex) of target memory (default 0x0)
--end - end address (in hex) of target memory (default 0xFFFFFFFF)
--reset - reset address (in hex) of target memory (default None)
--input - path to input file
--output - path to output file
--in-data-width - data width of inputfile [8, 16, 32, 64, 128, 256] (default 8)
--out-data-width - data width of target memory [8, 16, 32, 64, 128, 256]
(default None)
--boot - location of boot file to be appended (srec format)
```

Examples

Converting from Intel Hex (IHEX) to a Quartus Hex (HEX) for a memory with a 32-bit data width:

```
alt-file-convert -I ihex -O
hex out-data-width 32 in.ihex out.hex
```

Converting from an .elf file to a flash and appending a bootcopier given as a srec file:

```
alt-file-convert -I elf32-littlenios2 -O flash in.elf out.flash --have-boot-
copier --boot boot.elf
```

5.11.3.3.2. bin2flash

Description

The bin2flash utility converts any binary data file to a FLASH file that can be used by the flash programmer.

Usage

```
bin2flash [--debug] [--silent] [--help] [--log=file]
          [--location=addr] [--quiet] [--input=file] [--verbose] [--output=file]
```

Options

--debug	debug mode
--help	print this message
--input=<file>	input Binary file to process
--location=<addr>	design location within the flash
--log=<file>	file for logging progress
--output=<file>	output flash file
--quiet	only print errors
--silent	silent mode - same as quiet
--verbose	lots of interesting information

5.11.3.3.3. elf2dat

Description

Converts a **.elf** file to a **.dat** file format appropriate for Verilog HDL hardware simulators.

Usage

```
elf2dat --infile=file --outfile=file --width=width --base=address
        --end=address [--pad=number] [--create-lanes=number]
        [--little-endian-mem] [--big-endian-mem]
```

Options

```
--infile=<elf-input-filename>
--outfile=<dat-output-filename>
--base=<base address>
--end=<end address>
--pad=[0 | 1] (default 1)
--create-lanes=[0 | 1] (default 0)
--width=[ 8 | 16 | 32 | 64 | 128]
--little-endian-mem
--big-endian-mem
```

Transforms the data within an ELF file in the address range [base, end] into the corresponding DAT file. Lane files are optionally created (`--create-lanes=1`, default is 0). Lane file names are generated based on the output file by inserting "_lane0", "_lane1", etc. before the ".dat" extension of the output filename. If "`--pad=1`" is specified, any unspecified locations in memory is filled with zeros. If "`--little-endian-mem`" is specified, the memory is assumed to be little-endian. If "`--big-endian-mem`" is specified, the memory is assumed to be big-endian. If neither `--little-endian-mem` or `--big-endian-mem` is specified, the memory is assumed to be little-endian. Note that the endianness of the ELF file never effects the result.

Example

```
elf2dat --infile=foo.elf --outfile=bar.dat --width=32 --create-lanes=1
        --base=0 --end=0x1000
```

creates DAT files `bar.dat`, `bar_lane0.dat`, `bar_lane1.dat`, `bar_lane2.dat`, `bar_lane3.dat`



5.11.3.3.4. elf2flash

Description

The elf2flash utility takes a software file in ELF format and translates it to a FLASH file that can be programmed into the flash memory connected to an Intel FPGA.

Usage

```
elf2flash [--boot=file] [--debug] [--base=addr] [--save]
          [--quiet] [--epcs] [--end=addr] [--verbose] [--silent] [--help]
          [--log=file] [--after[=file]] [--input=file] [--reset=addr]
          [--offset=offset] [--sim_optimize[=value]] [--output=file]
```

Options

--after[=<file>]	Start output at address immediately following data in specified .flash file
--base=<addr>	flash base address
--boot=<file>	boot copier SREC file
--debug	debug mode
--end=<addr>	flash end address
--epcs	epcs flash mode
--help	print this message
--input=<file>	input ELF file to process
--log=<file>	file for logging progress
--offset=<offset>	EPCS offset
--output=<file>	output flash file
--quiet	only print errors
--reset=<addr>	CPU reset address
--save	save intermediate files
--silent	silent mode - same as quiet
--sim_optimize[=<value>]	Optimize for simulation
--verbose	lots of interesting information

The elf2flash utility converts the software and data within an ELF file in the address range [base, end] into a FLASH file. This utility can also optionally insert a boot copier into the FLASH file to copy the software from flash memory to RAM before running it.

5.11.3.3.5. elf2hex

Description

The elf2hex utility takes a software file in ELF format and translates it to a HEX file that can be used as the initialization data for a memory component.

Usage

```
elf2hex [--debug] [--record=length] [--base=addr] [--quiet]
        [--width=value] [--big-endian-mem] [--no-zero-fill]
        [--create-lanes[=value]] [--lower] [--end=addr] [--verbose] [--silent]
        [--help] [--log=file] [--input=file] [--little-endian-mem]
        [--output=file]
```

Options

--base=<addr>	Hex data base address
--big-endian-mem	Force big-endian memory layout
--create-lanes[=<value>]	1 if lane files should be created
--debug	debug mode
--end=<addr>	Hex data end address
--help	print this message
--input=<file>	input ELF file to process
--little-endian-mem	Force little-endian memory layout

```
--log=<file>           file for logging progress
--lower                If you prefer your hex in lower case
--no-zero-fill         No zero fill of empty sections
--output=<file>         output Hex file
--quiet                only print errors
--record=<length>       Output record length, in bytes.
--silent               silent mode - same as quiet
--verbose              lots of interesting information
--width=<value>         [ 8 | 16 | 32 | 39 | 64 | 128]
```

The elf2hex utility converts the software and data within an ELF file in the address range [base, end] into a HEX file. The width option is used to insure that the resulting HEX file is formatted properly for its corresponding memory component. This utility can also create lane files which are used to initialize multi-laned memory components.

5.11.3.3.6. elf2mif

Description

elf2-h transforms the data within an elf file in the address range [low, high] into the corresponding -H file. Lane files are optionally created (--create-lanes=1, default is 0). Lane file names are generated based on the output file by inserting "_lane0", "_lane1", etc. before the ".-h" extension of the output filename.

Usage

```
elf2-h elf_file [low_address high_address] [--width=width]
               [--create-lanes=lanes] [-h_file]
```

Options

```
elf_file       the elf input file
low address     beginning of the range to transform
high address    end of the range to transform
--width=width   [ 8 | 16 | 32 | 64 | 128]
--create-lanes=lanes [0 | 1] (default 0)
-h_file        the -H file to create
```

Example

```
elf2-h foo.elf 0 0x0FFF --width=32 --create_lanes=1 bar.-h
```

creates -H files—bar.-h, bar_lane0.-h, bar_lane1.-h, bar_lane2.-h, and bar_lane3.-h

5.11.3.3.7. flash2dat

Description

Converts an SRAM Object File (.sof) to a .flash file.

Usage

```
flash2dat --infile=<flash-input-filename>
           --outfile=<dat-output-filename>
           --width=[ 8 | 16 | 32 | 39 | 64 | 128]
           --base=<base byte-address of range of interest>
           --end=<last byte-address of range of interest>
           --pad=<1 if all locations should be represented in output>
```



```
--create-lanes=<1 if lane files should be created>
--relocate-input=<input-data relocation offset (usually=base)>
[--little-endian-mem] [--big-endian-mem]
```

Example

```
flash2dat --infile=foo.flash --outfile=foo.dat --width=32 --base=0x1000000 \
--end=0x1000FFF --pad=1 --create-lanes=1 --relocate=0x1000000
```

Creates files `foo.dat`, `foo_lane0.dat`, `foo_lane1.dat`, `foo_lane2.dat` and `foo_lane3.dat`. `foo.dat` contains 4K bytes of data, padded with 0 where data was not present in the `.flash` file. `foo_lane[0123].dat` each contain 1K bytes of data from their respective byte lanes. The input `.flash` file data should be relocated by `0x1000000` to correspond to the specified `--base` address.

5.11.3.3.8. sof2flash

Description

The `sof2flash` utility takes an FPGA configuration file in SOF format and translates it to a FLASH file that can be programmed into the flash memory connected to an Intel FPGA.

Usage

```
sof2flash [--programmingmode=programmingmode] [--debug]
  [--optionbit=optionbitaddress] [--save] [--quiet] [--pfl] [--epcs]
  [--epcq128] [--epcq] [--verbose] [--activeparallel] [--timestamp]
  [--help] [--log=file] [--input=file] [--offset=addr] [--compress]
  [--options=file] [--output=file]
```

Options

<code>--activeparallel</code>	create parallel flash contents for active parallel programming
<code>--compress</code>	compress the SOF
<code>--debug</code>	debug mode
<code>--epcq</code>	EPCQ flash mode of size 256Mbits
<code>--epcq128</code>	EPCQ flash mode of size 128Mbits or less
<code>--epcs</code>	EPCS flash mode
<code>--help</code>	print this message
<code>--input=<file></code>	input SOF file to process
<code>--log=<file></code>	file for logging progress
<code>--offset=<addr></code>	design location within the flash
<code>--optionbit=<optionbitaddress></code>	Option Bit Address
<code>--options=<file></code>	intermediate Options file (for EPCS only)
<code>--output=<file></code>	output flash file
<code>--pfl</code>	Pfl mode
<code>--programmingmode=<programmingmode></code>	Programming mode
<code>--quiet</code>	only print errors
<code>--save</code>	save intermediate files
<code>--timestamp</code>	produce a s0 record with timestamp of input file
<code>--verbose</code>	lots of interesting information

5.11.3.4. Other Command-Line Tools

Note: For usage information, enter "--help" after the command and a list of options for the command appears.

The command-line tools for developing Nios II programs are:

- **nios2-download**
- **nios2-flash-programmer-generate**
- **nios2-flash-programmer (64-bit support)**
- **nios2-gdb-server (64-bit support)**
- **nios2-terminal (64-bit support)**
- **validate_zip**
- **nios2-configure-sof**
- **jtagconfig**

The command-line tools described in this section are in the <Nios II EDS install path>/bin/ directory.

5.11.3.4.1. nios2-download

Description

This tool prepares a target system for debugging, it checks that the hardware and software are compatible, downloads the software and optionally makes the target processor run the downloaded code.

Usage

```
nios2-download [-h/--help] [-C/--directory <dir name>]
               [-c/--cable <cable name>] [-d/--device <device index>]
               [-i/--instance <instance>] [-r/--reset-target]
               [-s/--sidp <address> -I/--id <id> -t/--timestamp <timestamp>]
               [--accept-bad-sysid] [-w/--wait <seconds>] [-g/--go] [--stop]
               [--tcpport <port> | auto] [--write-gmon <file>]
               [--jdi <file>] [--cpu_name <name>]
               [<filename>]
```

Options

-h/--help	Prints this message.
-C/--directory <dir name>	Change to this directory before running
-c/--cable <cable name>	Specifies which JTAG cable to use (not needed if you only have one cable).
-d/--device <device index>	Specifies in which device you want to look for the Nios II CPU (1 = device nearest TDI etc.)
-i/--instance <instance>	Specifies the INSTANCE value of the Nios II CPU JTAG debug module (auto-detected if you specify an ELF file or use --directory to point to one)
-r/--reset-target	Reset the target SOPC system before use.
-s/--sidp <address>	Base-address of System ID peripheral on target This base-address must be specified in hex (0x...)
-I/--id <system-id-value>	Unique ID code for target system
-t/--timestamp <time-stamp>	Timestamp for target-system (when last generated)
--accept-bad-sysid	Continue even if the system ID comparison fails



<code><filename.elf></code>	An ELF file to download to the target
<code>-w/--wait <seconds></code>	Wait for time specified before starting processor
<code>-g/--go</code>	Run processor from entry point after downloading.
<code>--stop</code>	Stop processor (leave it in a paused state).
<code>--tcpport <port> auto</code>	Listen on specified TCP port for a connection from GDB (with "auto" a free port is used).
<code>--write-gmon <file></code>	Write profiling data to the file specified when the target exits.
<code>--jdi <file></code>	Specify which .jdi file to read the INSTANCE value of the Nios II CPU JTAG debug module from. (if not specified, looks in the same folder as the .ptf file, as specified in generated.sh)
<code>--cpu_name <name></code>	CPU module name to use when trying to scan for INSTANCE value from the .jdi file. Uses the name specified in generated.sh if it is not passed in.

NOTE: nios2-download needs a .jdi file and a cpu_name to search for the INSTANCE value. This can be supplied through the command line, or searched for with information from generated.sh

If you specify the `--go` option then the target processor starts before this tool exits. If `--go` is not specified but a file is downloaded or the target processor needs to be reset then it is left in the paused state. Otherwise the target processor state is left unchanged unless `--stop` is specified (in which case it is paused). Return codes are: 0 for success; 1 if the system ID did not match; 2 if no Nios II CPUs are found; a return code of 4 or more indicates an error which needs manual intervention to solve.

5.11.3.4.2. nios2-flash-programmer-generate

Description

The `nios2-flash-programmer-generate` command converts multiple files to the .flash format and then program them to the designated target flash devices (`--program-flash`). This is a convenience utility that manages calls to the following command line utilities: `bin2flash`, `elf2flash`, `sof2flash`, and `nios2-flash-programmer`. This utility also generates a convenience shell script that captures the sequence of conversion and flash programmer command line tool expressions.

Usage

```
nios2-flash-programmer-generate --sopcinfo <filename> --flash-dir
<filepath> [<options>]
```

Options

<code>--flash-dir <filepath></code>	Path to the directory where the flash files are generated. Use . for the current directory. This command overwrites pre-existing files in <filepath> without warning.
<code>--sopcinfo <filename></code>	The SOPC Builder system file (.sopcinfo).

Optional Arguments:

<code>--accept-bad-sysid</code>	Continue even if the system ID comparison fails
<code>--add-bin <fname> <flash-slave-desc> <offset></code>	Specify an bin file to convert and program. The filename, target flash slave descriptor, and target offset amount are required. This option can be used multiple times for .sof files.



```
--add-elf <fname> <flash-slave-desc> <extra-elf2flash-arguments>
Specify an elf file to convert and program. The
filename, and target flash slave descriptor are
required. This option can be used multiple times for
.elf files. The [<extra-elf2flash-arguments>] can
be any of these options supported by 'elf2flash':
'save', 'sim_optimize'. The 'elf2flash' options:
'base', 'boot', 'end', 'reset' have default values
computed, but are also supported as
[<extra-elf2flash-arguments>] for manual override
of those defaults. Do not prepend extra arguments with
'--'.

--add-sof <fname> <flash-slave-desc> <offset> <extra-sof2flash-arguments>
Specify an sof file to convert and program. The
filename, target flash slave descriptor, and target
offset amount are required. This option can be used
multiple times for .sof files. The
[<extra-sof2flash-arguments>] can be any of these
options supported by 'sof2flash':
'activeparallel', 'compress', 'save',
'timestamp'. Do not prepend extra arguments with
'--'.

--cable <cable name> Specifies which JTAG cable to use (not needed if you
only have one cable). Not used without
--program-flash option

--cpu <cpu name> The SOPC Builder system file Nios II CPU name. Not
required if only one Nios II CPU in the system.

--debug Sends debug information, exception traces, verbose
output, and default information about the command's
operation, to stdout.

--device <device name> Specifies in which device you want to look for the Nios
II debug core ('1' is device nearest TDI etc.). Not used
without --program-flash option

--erase-first Erase entire flash targets before programming them.
Not used without --program-flash option

--extended-help Displays full information about this command and its
options.

--go Run processor from reset vector after program.

--help Displays basic information about this command and its
options.

--id <address> Unique ID code for target system. Not used without
--program-flash option

--instance <instance value> Specifies the INSTANCE value of the debug core (not
needed if there is exactly one on the chain). Not used
without --program-flash option

--jvm-max-heap-size <value> Optional. The maximum memory size to be used for
allocations when running this tool. This value is
specified as <size><unit> where unit can be m (or M) for
multiples of megabytes or g (or G) for multiples of
gigabytes. The default value is 512m.

--log <filename> Creates a debug log and write to specified file. Also
logs debug information to stdout.

--mmu Specifies if the CPU with the corresponding INSTANCE
value has an MMU (not needed if there is exactly one CPU
in the system). Not used without --program-flash
option
```



<code>--program-flash</code>	Providing this flag causes calls to <code>nios2-flash-programmer</code> to be generated and executed. This results in flash targets being programmed.
<code>--script-dir <filepath></code>	Path to the directory where a shell script of this tools executed command lines is generated. This convenient script can be used in place of this <code>'nios2-flash-programmer-generate'</code> command. Use <code>.</code> for the current directory. This command overwrites pre-existing files in <code><filepath></code> without warning.
<code>--sidp <address></code>	Base-address of System ID peripheral on target. Not used without <code>--program-flash</code> option
<code>--silent</code>	Suppresses information about the command's operation normally sent to stdout.
<code>--timestamp <time-stamp></code>	Timestamp for target-system (when last generated).
<code>--verbose</code>	Sends verbose output, and default information about the command's operation, to stdout.
<code>--version</code>	Displays the version of this command and exits with a zero exit status.

5.11.3.4.3. nios2-flash-programmer

Description

Programs data to flash memory on the target board.

Usage

```
nios2-flash-programmer [-h/--help] [-c/--cable <cable name>]
                      [-d/--device <device index>] [-i/--instance <instance>]
                      [-s/--sidp <address>] [-I/--id <id>] [-t/--timestamp <timestamp>]
                      -b/--base <address> [-e/--epcs]
                      <action> [-g/--go] [--dualdie]
```

Options

<code>-h/--help</code>	Print this message
<code>-Q/--quiet</code>	Don't print anything if everything works
<code>--debug</code>	Print debug information
<code>-c/--cable <cable name></code>	Specifies which JTAG cable to use (not needed if you only have one cable)
<code>-d/--device <device index></code>	Specifies in which device you want to look for the Nios II debug core (1 = device nearest TDI etc.)
<code>--dualdie</code>	Force override the die size to be dual die.
<code>-i/--instance <instance></code>	Specifies the INSTANCE value of the debug core (not needed if there is exactly one on the chain)
<code>-s/--sidp <address></code>	Base-address of System ID peripheral on target
<code>-I/--id <system-id-value></code>	Unique ID code for target system
<code>-t/--timestamp <time-stamp></code>	Timestamp for target-system (when last generated)
<code>--accept-bad-sysid</code>	Continue even if the system ID comparison fails
<code>-b/--base <address></code>	Base address of FLASH/EPCS to operate on
<code>-e/--epcs</code>	This operation is on an EPCS flash
<code>-M/--mmu</code>	MMU present in the Nios II cpu.
<code>-E/--erase <start>+<size></code>	Erase a range of bytes in the flash, or the entire flash before/instead of programming it.
<code>--erase-all</code>	
<code>-P/--program</code>	Program flash from the input files (the default)
<code>--no-keep-nearby</code>	Don't preserve bytes which need to be erased but which aren't specified in the input file
<code>-Y/--verify</code>	Verify that contents of flash match input files



<filename>*	The names of the file(s) to program or verify
-R/--read <file>	Read flash contents into file
-B/--read-bytes <start>+<size>	Specify which bytes to read
-g/--go	Run processor from reset vector after program.

Input files should be in Motorola S-Record format. Addresses within the files are interpreted as offsets from the base address of the flash. Output files written by the tool are in the same format. The flash programmer supports all CFI flashes which use the AMD programming algorithm (CFI algorithm 2) or the Intel algorithm (1 or 3).

5.11.3.4.4. nios2-flash-programmer (64-bit support)

Description

Programs data to flash memory on the target board.

Usage

```
nios2-flash-programmer [-h/--help] [-c/--cable <cable name>]
                        [-d/--device <device index>] [-i/--instance <instance>]
                        [-s/--sidp <address>] [-I/--id <id>] [-t/--timestamp <timestamp>]
                        -b/--base <address> [-e/--epcs]
                        <action> [-g/--go] [--dualdie]
```

Options

-h/--help	Print this message
-Q/--quiet	Don't print anything if everything works
--debug	Print debug information
-c/--cable <cable name>	Specifies which JTAG cable to use (not needed if you only have one cable)
-d/--device <device index>	Specifies in which device you want to look for the Nios II debug core (1 = device nearest TDI etc.)
--dualdie	Force override the die size to be dual die.
-i/--instance <instance>	Specifies the INSTANCE value of the debug core (not needed if there is exactly one on the chain)
-s/--sidp <address>	Base-address of System ID peripheral on target
-I/--id <system-id-value>	Unique ID code for target system
-t/--timestamp <time-stamp>	Timestamp for target-system (when last generated)
--accept-bad-sysid	Continue even if the system ID comparison fails
-b/--base <address>	Base address of FLASH/EPCS to operate on
-e/--epcs	This operation is on an EPCS flash
-M/--mmu	MMU present in the Nios II cpu.
-E/--erase <start>+<size>	Erase a range of bytes in the flash, or the entire flash before/instead of programming it.
--erase-all	Program flash from the input files (the default)
-P/--program	Don't preserve bytes which need to be erased but which aren't specified in the input file
--no-keep-nearby	Verify that contents of flash match input files
-Y/--verify	The names of the file(s) to program or verify
<filename>*	
-R/--read <file>	Read flash contents into file
-B/--read-bytes <start>+<size>	Specify which bytes to read
-g/--go	Run processor from reset vector after program.

Input files should be in Motorola S-Record format. Addresses within the files are interpreted as offsets from the base address of the flash. Output files written by the tool are in the same format. The flash programmer supports all CFI flashes which use the AMD programming algorithm (CFI algorithm 2) or the Intel algorithm (1 or 3).



5.11.3.4.5. nios2-gdb-server

Description

Translates GNU debugger (GDB) remote serial protocol packets over Transmission Control Protocol (TCP) to JTAG transactions with a target Nios II processor.

Usage

```
nios2-gdb-server [-h/--help] [-c/--cable <cable name>]
                [-d/--device <device index>] [-i/--instance <instance>]
                [-s/--sidp <address>] [-I/--id <id>] [-t/--timestamp <timestamp>]
                [-w/--wait <seconds>] [--no-verify] [-g/--go] [--stop]
                [--tcpport=<port> | auto] [--tcpdebug] [--tcptimeout <seconds>]
                [--tcppersist] [--thread-vars <vars>]
                [--write-gmon <gmonfile>] [--wait-target-exit]
                <filename.srec>*
```

Options

-h/--help	Print this message
--write-pid <filename>	Write the process ID to the file specified
--signal-pid <filename>	Send a SIGUSR1 to the other process when ready
-c/--cable <cable name>	Specifies which JTAG cable to use (not needed if you only have one cable)
-d/--device <device index>	Specifies in which device you want to look for the Nios II OCI core (1 = device nearest TDI etc.)
-i/--instance <instance>	Specifies the INSTANCE value of the JTAG debug core (not needed if there is exactly one on the chain)
-r/--reset-target	Always reset the target system before use
-C/--init-cache	Always initialize target processor cache before use
-s/--sidp <address>	Base-address of System ID peripheral on target
-I/--id <system-id-value>	Unique ID code for target system
-t/--timestamp <time-stamp>	Timestamp for target-system (when last generated)
--accept-bad-sysid	Continue even if the system ID comparison fails
<filename.srec>*	S-Record file(s) to download to the target
--no-verify	Don't verify after downloading
-w/--wait <seconds>	Wait for time specified before starting processor (signal USR1 terminates the wait early)
-g/--go	Run processor from entry point after downloading
--stop	Stop processor (leave it in a paused state).
--tcpport <port> auto	Listen on specified TCP port for a connection from GDB (with "auto" a free port is used).
--tcpdebug	Display the GDB remote protocol running over TCP
--tcptimeout <seconds>	Timeout if GDB has not connected in time specified
--tcppersist	Don't stop when GDB disconnects
--thread-vars <vars>	Decode target thread list using specified string
--write-gmon <gmonfile>	Wait for target to complete and write GMON data (if available) to the file specified
--wait-target-exit	Wait for target to complete and return target exit code as our return code if no other errors

The processor state after execution is chosen as follows:

- If the GDB remote protocol is enabled then this chooses the state.
- If the `--go` option is specified then the processor is started.
- If the `--stop` option is specified then the processor is left paused.
- If a file is downloaded or the processor is reset then it is paused.
- Otherwise, the processor state is restored.

5.11.3.4.6. nios2-gdb-server (64-bit support)

Description

Translates GNU debugger (GDB) remote serial protocol packets over Transmission Control Protocol (TCP) to JTAG transactions with a target Nios II processor.

Usage

```
nios2-gdb-server [-h/--help] [-c/--cable <cable name>]
  [-d/--device <device index>] [-i/--instance <instance>]
  [-s/--sidp <address>] [-I/--id <id>] [-t/--timestamp <timestamp>]
  [-w/--wait <seconds>] [--no-verify] [-g/--go] [--stop]
  [--tcpport=<port> | auto] [--tcpdebug] [--tcptimeout <seconds>]
  [--tcpersist] [--thread-vars <vars>]
  [--write-gmon <gmonfile>] [--wait-target-exit]
  <filename.srec>*
```

Options

<code>-h/--help</code>	Print this message
<code>--write-pid <filename></code>	Write the process ID to the file specified
<code>--signal-pid <filename></code>	Send a SIGUSR1 to the other process when ready
<code>-c/--cable <cable name></code>	Specifies which JTAG cable to use (not needed if you only have one cable)
<code>-d/--device <device index></code>	Specifies in which device you want to look for the Nios II OCI core (1 = device nearest TDI etc.)
<code>-i/--instance <instance></code>	Specifies the INSTANCE value of the JTAG debug core (not needed if there is exactly one on the chain)
<code>-r/--reset-target</code>	Always reset the target system before use
<code>-C/--init-cache</code>	Always initialize target processor cache before use
<code>-s/--sidp <address></code>	Base-address of System ID peripheral on target
<code>-I/--id <system-id-value></code>	Unique ID code for target system
<code>-t/--timestamp <time-stamp></code>	Timestamp for target-system (when last generated)
<code>--accept-bad-sysid</code>	Continue even if the system ID comparison fails
<code><filename.srec>*</code>	S-Record file(s) to download to the target
<code>--no-verify</code>	Don't verify after downloading
<code>-w/--wait <seconds></code>	Wait for time specified before starting processor (signal USR1 terminates the wait early)
<code>-g/--go</code>	Run processor from entry point after downloading
<code>--stop</code>	Stop processor (leave it in a paused state).
<code>--tcpport <port> auto</code>	Listen on specified TCP port for a connection from GDB (with "auto" a free port is used).
<code>--tcpdebug</code>	Display the GDB remote protocol running over TCP
<code>--tcptimeout <seconds></code>	Timeout if GDB has not connected in time specified
<code>--tcpersist</code>	Don't stop when GDB disconnects
<code>--thread-vars <vars></code>	Decode target thread list using specified string
<code>--write-gmon <gmonfile></code>	Wait for target to complete and write GMON data



<code>--wait-target-exit</code>	(if available) to the file specified Wait for target to complete and return target exit code as our return code if no other errors
---------------------------------	---

The processor state after execution is chosen as follows:

- If the GDB remote protocol is enabled then this chooses the state.
- If the `--go` option is specified then the processor is started.
- If the `--stop` option is specified then the processor is left paused.
- If a file is downloaded or the processor is reset then it is paused.
- Otherwise, the processor state is restored.

5.11.3.4.7. nios2-terminal

Description

Performs terminal I/O with a JTAG UART in a Nios II system.

Usage

```
nios2-terminal [TERMINAL OPTIONS] [CONNECTION OPTIONS] [TARGET OPTIONS]
```

Options

Terminal Options

<code>-V, --version</code>	display version number
<code>-h, --help</code>	show this message and exit
<code>-v, --verbose</code>	show extra information during run (default)
<code>-q, --quiet</code>	show minimal information
<code>--write-pid</code>	write process ID to filename specified
<code>-w, --wait</code>	wait for a signal before starting
<code>--flush</code>	empty buffers before displaying output
<code>--signal-pid</code>	send signal to process ID when ready
<code>-o, --quit-after=SECS</code>	quit after SECS second(s) (default is never)
<code>--no-quit-on-ctrl-d</code>	don't quit if Ctrl-D received from target
<code>-u, --dump=OPTS</code>	dump extra debug information for OPTS
<code>--gmon</code>	write gmon.out file if seen from target
<code>--no-gmon</code>	do not write gmon.out

Connection Options

<code>-H, --hardware</code>	connect to a hardware target (default)
<code>-I, --iss</code>	launch and connect to iss target
<code>-M, --modelsim</code>	connect to a modelsim target
<code>-U, --uart</code>	connect to hardware using a UART
<code>--persistent</code>	try to reconnect after an I/O error
<code>--no-persistent</code>	opposite of persistent

Connect to Hardware Options

<code>-c, --cable=CABLE</code>	use CABLE JTAG cable (default auto-detect)
<code>-d, --device=DEVICE</code>	connect to DEVICE device (default auto-detect)
<code>-i, --instance=INSTANCE</code>	connect to INSTANCE instance (default auto-detect)

Launch and Connect to ISS Options

<code>-f, --elf=FILE</code>	launch ISS with FILE in simulation memory
<code>-p, --ptf=FILE</code>	launch ISS with FILE as system description
<code>-g, --debug</code>	launch ISS in debug mode waiting for

-r, --no-debug	gdb connection at reset or entry point
-a, --iss-arg=ARG	launch ISS in run mode
	pass additional argument ARG to nios2-iss, may be specified repeatedly

Connect to ModelSim Options

-n, --instance_name=NAME	connect to jtag_uart instance name
--------------------------	------------------------------------

Connect to Hardware using UART Options

--port=PORT	full name of port to connect to (e.g. /dev/com1)
--baud-rate=RATE	baud rate to connect to UART

Note: If a development board has more than one JTAG port, the `nios2-terminal` command cannot work unless the correct JTAG cable is identified. In order to identify the correct JTAG cable, you must first run the `jtagconfig` command. For example, if the output states that USB-Blaster is port 2, then you can run the command using the correct JTAG port `nios2-terminal -c 2`.

5.11.3.4.8. nios2-terminal (64-bit support)

Description

Performs terminal I/O with a JTAG UART in a Nios II system.

Usage

```
nios2-terminal [TERMINAL OPTIONS] [CONNECTION OPTIONS] [TARGET OPTIONS]
```

Options

Terminal Options

-V, --version	display version number
-h, --help	show this message and exit
-v, --verbose	show extra information during run (default)
-q, --quiet	show minimal information
--write-pid	write process ID to filename specified
-w, --wait	wait for a signal before starting
--flush	empty buffers before displaying output
--signal-pid	send signal to process ID when ready
-o, --quit-after=SECS	quit after SECS second(s) (default is never)
--no-quit-on-ctrl-d	don't quit if Ctrl-D received from target
-u, --dump=OPTS	dump extra debug information for OPTS
--gmon	write gmon.out file if seen from target
--no-gmon	do not write gmon.out

Connection Options

-H, --hardware	connect to a hardware target (default)
--persistent	try to reconnect after an I/O error
--no-persistent	opposite of persistent

Connect to Hardware Options

-c, --cable=CABLE	use CABLE JTAG cable (default auto-detect)
-d, --device=DEVICE	connect to DEVICE device (default auto-detect)
-i, --instance=INSTANCE	connect to INSTANCE instance (default auto-detect)



Note: If a development board has more than one JTAG port, the `nios2-terminal` command cannot work unless the correct JTAG cable is identified. In order to identify the correct JTAG cable, you must first run the `jtagconfig` command. For example, if the output states that USB-Blaster is port 2, then you can run the command using the correct JTAG port `nios2-terminal -c 2`.

5.11.3.4.9. validate_zip

Description

This utility checks that the zip file you have chosen is compatible with the Read Only Zip Filing system. It returns 0 if the zip file is compatible, -1 if not.

Usage

```
validate_zip name_of_zip_file
```

5.11.3.4.10. nios2-configure-sof

Description

This tool configures an Intel configurable part. If no explicit SOF file is provided then it tries and work out the correct file to use.

Usage

```
nios2-configure-sof [-h/--help] [-C/--directory <dir name>]
                  [-c/--cable <cable name>] [-d/--device <device index>]
                  [ <filename.sof> ]
```

Options

<code>-h/--help</code>	Prints this message.
<code>-C/--directory <dir name></code>	Change to this directory before running
<code>-c/--cable <cable name></code>	Specifies which JTAG cable to use (not needed if you only have one cable).
<code>-d/--device <device index></code>	Specifies in which device you want to look for the Nios II CPU (1 = device nearest TDI etc.)
<code><filename.sof></code>	The SOF file you want to download

If you have exactly one cable attached then `nios2-configure-sof` uses this cable by default. If you have more than one cable attached then you must specify one. Use ``jtagconfig`` to find out which cables you have available. If a SOF file is specified, then that file is configured into the part. If no file is specified, or if the specified filename does not have a path associated with it then the tool searches for matching SOF files, first in the current directory and then in the directory which contains the PTF file for the project in the current directory.

5.11.3.4.11. jtagconfig

Description

Allows you configure the JTAG server on the host machine. It can also detect a JTAG chain and set up the download hardware configuration.

Usage

```
jtagconfig [--enum]
jtagconfig --add <type> <port> [<name>]
jtagconfig --remove <cable>
jtagconfig --getparam <cable> <param>
jtagconfig --setparam <cable> <param> <value>
jtagconfig --define <jtagid> <name> <irlength>
jtagconfig --undefine <jtagid> <name> <irlength>
jtagconfig --defined
jtagconfig --addserver <server> <password>
jtagconfig --enableremote <password>
jtagconfig --disableremote
jtagconfig --version
jtagconfig --help
jtagconfig --extrahelp
```

Options

<code>--version -v</code>	Displays the version of the jtagconfig utility you are using.
<code>--help -h</code>	Displays the options for the jtagconfig utility.
<code>--extrahelp</code>	Displays this help information.
<code>--enum</code>	<p>Displays the JTAG ID code for the devices in each JTAG chain attached to programming hardware. If the JTAG Server recognizes a device, it displays the device name. If the JTAG Server cannot use a device, it marks the device with an exclamation mark (!).</p> <p>The following code is an example of output from the 'jtagconfig --enum' command:</p> <pre>1) ByteBlasterMV on LPT1 090010DD EPXA10 049220DD EPXA_ARM922 04000101 ! 090000DD ! EP20K1000E 04056101 ! 010020DD EPC2 010020DD EPC2 010020DD EPC2</pre> <p>In this example, the JTAG Server does not recognize two of the eight devices, and cannot use three devices. If you need to use one of the unused devices then use the --define option to define unused devices with JTAG IDs.</p> <p>You can also use this option by typing the command 'jtagconfig' without an argument.</p>
<code>--add <hardware> <port> [<name>]</code>	<p>Specifies the port to which you attached new programming hardware. For example, 'jtagconfig --add byteblastermv lpt1' specifies that you attached a ByteBlasterMV cable to port LPT1. You can also use '['<name>']' to add a string that describes the hardware to the output from the 'jtagconfig --enum' command.</p> <p>The JTAG Server automatically detects cables that you attach to a USB port, therefore you do not need to use this command for these cables.</p>
<code>--remove <cable></code>	<p>Removes the hardware setup that is indicated with the number listed for the hardware in the output of the '--enum' command. In the example for the '--enum' command, above, the number '1)' is listed for the ByteBlasterMV cable. Therefore, the command-line 'jtagconfig --remove 1' removes the hardware setup for the ByteBlasterMV cable.</p>



instead.	If the hardware specified is attached to a remote JTAG server then the connection to the remote JTAG server is removed
--getparam <cablen> <param>	Get a hardware specific parameter from the cable specified. The parameters supported vary by cable type, see the documentation for your cable for details.
--setparam <cablen> <param> <value>	Set a hardware specific parameter on the cable specified. The parameters supported vary by cable type, see the documentation for your cable for details. This command can only set numeric parameters (the suffixes k and M are recognized when parsing the value).
--define <jtagid> <name> <irlength>	Tells the JTAG server about the name and IR length of a new device. This is stored and used in future enumerations to reduce the number of devices which cannot be used
--undefine <jtagid> <name>	Tells the JTAG server to remove information about the name and IR length of a device.
--defined FPGA	Displays the JTAG IDs, names and IR lengths of all non-Intel devices known about by the JTAG server.
--addserver <servername> <password>	Tells Quartus to connect to the remote JTAG server and make all cables on that server available to local applications.
	An IP address or DNS name may be used to specify the server to connect to. The password given here must match the password used on the remote server.
--enableremote <password>	Tells the JTAG server to allow connections from remote machines. These machines must specify the same password when connecting.
--disableremote	Tells the JTAG server not to accept any more connections from remote machines. Remote connections currently in use are not terminated.

Note: If a development board has more than one JTAG port, you must run this command first to identify the correct JTAG cable. For example, you have to run this command to identify the correct JTAG cable and then run the `nios2-terminal` command using the correct JTAG port: `nios2-terminal -c 2`.

5.12. Restrictions

The Nios II SBT supports BSPs incorporating the Intel FPGA HAL and Micrium MicroC/OS-II only.

6. Overview of the Hardware Abstraction Layer

The HAL is a lightweight embedded runtime environment that provides a simple device driver interface for programs to connect to the underlying hardware. The HAL application program interface (API) is integrated with the ANSI C standard library. The HAL API allows you to access devices and files using familiar C library functions, such as `printf()`, `fopen()`, `fwrite()`, etc.

The HAL serves as a device driver package for Nios II processor systems, providing a consistent interface to the peripherals in your system. The Nios II software development tools extract system information from your SOPC Information File (**.sopcinfo**). The Nios II Software Build Tools (SBT) generate a custom HAL board support package (BSP) specific to your hardware configuration. Changes in the hardware configuration automatically propagate to the HAL device driver configuration. As a result, changes in the underlying hardware are prevented from creating bugs.

HAL device driver abstraction provides a clear distinction between application and device driver software. This driver abstraction promotes reusable application code that is resistant to changes in the underlying hardware. In addition, the HAL standard makes it straightforward to write drivers for new hardware peripherals that are consistent with existing peripheral drivers.

Related Information

[Overview of the Hardware Abstraction Layer Revision History](#) on page 14
For details on the document revision history of this chapter

6.1. Getting Started with the Hardware Abstraction Layer

The easiest way to get started using the HAL is to create a software project. In the process of creating a new project, you also create a HAL BSP. You do not need to create or copy HAL files, nor edit any of the HAL source code. The Nios II SBT generates the HAL BSP for you.

For an example on creating a simple Nios II HAL software project, refer to the “Getting Started with Nios II Software in Eclipse” chapter.

In the Nios II SBT command line, you can create an example BSP based on the HAL using one of the **create-this-bsp** scripts supplied with the Nios II Embedded Design Suite.

You must base the HAL on a specific hardware system. A Nios II system consists of a Nios II processor core integrated with peripherals and memory. Nios II systems are generated by Platform Designer.



If you do not have a custom Nios II system, you can base your project on an Intel FPGA-provided example hardware system. In fact, you can first start developing projects targeting an Intel FPGA development board, and later re-target the project to a custom board. You can easily change the target hardware system later.

For more information about creating a new project with the Nios II SBT command line, refer to either:

- "Getting Started with Nios II Software in Eclipse" section or
- "Getting Started from the Command Line" section

Related Information

- [Getting Started with Nios II Software in Eclipse](#) on page 27
- [Getting Started with the Graphical User Interface](#) on page 26
- [Getting Started from the Command Line](#) on page 73

6.2. HAL Architecture for Embedded Software Systems


6.2.1. Services

The HAL provides the following services:

- Integration with the newlib ANSI C standard library—Provides the familiar C standard library functions
- Device drivers—Provides access to each device in the system
- The HAL API—Provides a consistent, standard interface to HAL services, such as device access, interrupt handling, and alarm facilities
- System initialization—Performs initialization tasks for the processor and the runtime environment before `main()`
- Device initialization—Instantiates and initializes each device in the system before `main()` runs

6.2.2. Layers of a HAL-Based System

The Layers of a HAL-Based System



6.2.3. Applications versus Drivers

Application developers are responsible for writing the system's `main()` routine, among other routines. Applications interact with system resources either through the C standard library, or through the HAL API. Device driver developers are responsible for making device resources available to application developers. Device drivers communicate directly with hardware through low-level hardware access macros.

For further details about the HAL, refer to the "Developing Programs Using the Hardware Abstraction Layer" and "Developing Device Drivers for the Hardware Abstraction Layer" chapters.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

6.2.4. Generic Device Models

The HAL provides generic device models for classes of peripherals found in embedded systems, such as timers, Ethernet MAC/PHY chips, and I/O peripherals that transmit character data. The generic device models are at the core of the HAL's power. The generic device models allow you to write programs using a consistent API, regardless of the underlying hardware.

6.2.4.1. Device Model Classes

The HAL provides models for the following classes of devices:

- Character-mode devices—Hardware peripherals that either or both send or receive characters serially, such as a UART.
- Timer devices—Hardware peripherals that count clock ticks and can generate periodic interrupt requests.
- File subsystems—A mechanism for accessing files stored in physical device(s). Depending on the internal implementation, the file subsystem driver might access the underlying device(s) directly or use a separate device driver. For example, you can write a flash file subsystem driver that accesses flash using the HAL API for flash memory devices.
- Ethernet devices—Devices that provide access to an Ethernet connection for a networking stack such as the Intel FPGA-provided NicheStack TCP/IP Stack - Nios II Edition. You need a networking stack to use an ethernet device.
- Direct memory access (DMA) devices—Peripherals that perform bulk data transactions from a data source to a destination. Sources and destinations can be memory or another device, such as an Ethernet connection.
- Flash memory devices—Nonvolatile memory devices that use a special programming protocol to store data.

6.2.4.2. Benefits to Application Developers

The HAL defines a set of functions that you use to initialize and access each class of device. The API is consistent, regardless of the underlying implementation of the device hardware. For example, to access character-mode devices and file subsystems,



you can use the C standard library functions, such as `printf()` and `fopen()`. For application developers, you need not write low-level routines just to establish basic communication with the hardware for these classes of peripherals.

6.2.4.3. Benefits to Device Driver Developers

Each device model defines a set of driver functions necessary to manipulate the particular class of device. If you are writing drivers for a new peripheral, you need only provide this set of driver functions. As a result, your driver development task is predefined and well documented. In addition, you can use existing HAL functions and applications to access the device, which saves software development effort. The HAL calls driver functions to access hardware. Application programmers call the ANSI C or HAL API to access hardware, rather than calling your driver routines directly. Therefore, the usage of your driver is already documented as part of the HAL API.

6.2.5. C Standard Library—newlib

The HAL integrates the ANSI C standard library in its runtime environment. The HAL uses `newlib`, an open-source implementation of the C standard library. `newlib` is a C library for use on embedded systems, making it a perfect match for the HAL and the Nios II processor. `newlib` licensing does not require you to release your source code or pay royalties for projects based on `newlib`.

Note: For Nios II, `newlib` is upgraded to version 1.18.

The ANSI C standard library is well documented.

For more information about the most well-known reference of the ANSI C standard library, refer to the book: [The C Programming Language](#) by B. Kernighan and D. Ritchie, published by Prentice Hall. It is also available in over 20 languages.

Related Information

[Redhat Website](#)

For more information, refer to the online documentation for `newlib` by Red Hat.

6.3. Embedded Hardware Supported by the HAL

6.3.1. Nios II Processor Core Support

The Nios II HAL supports all available Nios II processor core implementations.

6.3.2. Supported Peripherals

6.3.2.1. Provide Full HAL Support

Intel FPGA provides many peripherals for use in Nios II processor systems. Most Intel FPGA peripherals provide HAL device drivers that allow you to access the hardware with the HAL API. The following Intel FPGA peripherals provide full HAL support:

- Character mode devices
 - UART core
 - JTAG UART core
 - LCD 16207 display controller
- Flash memory devices
 - Common flash interface compliant flash chips
 - Intel FPGA's erasable programmable configurable serial (EPCS) serial configuration device controller
- File subsystems
 - Intel FPGA host based file system
 - Intel FPGA read-only zip file system
- Timer devices
 - Timer core
- DMA devices
 - DMA controller core
 - Scatter-gather DMA controller core
- Ethernet devices
 - Triple Speed Ethernet IP core® function
 - Standard Microchip Solutions (SMSC) LAN91C111 10/100 Non-PCI Ethernet Single Chip MAC + PHY
- EPCQ soft IP peripheral
 - Upgraded to add support for x4 mode and L devices, giving faster access to the EPCQ device from Nios or other FPGA based masters

The LAN91C111 and Triple Speed Ethernet components require the MicroC/OS-II runtime environment.

For more information, refer to the "Ethernet and the NicheStack TCP/IP Stack - Nios II Edition" chapter.

Note: Third-party vendors offer additional peripherals not listed here.

Related Information

- [Ethernet and the NicheStack TCP/IP Stack](#) on page 296
- <https://www.altera.com/products/general/nios2/benefits/ni2-peripherals.html>

6.3.2.2. Provide Partial HAL Support

All peripherals (both from Intel FPGA and third party vendors) must provide a header file that defines the peripheral's low-level interface to hardware. Therefore, all peripherals support the HAL to some extent. However, some peripherals might not provide device drivers. If drivers are not available, use only the definitions provided in the header files to access the hardware. Do not use unnamed constants, such as hard-coded addresses, to access a peripheral.



Inevitably, certain peripherals have hardware-specific features with usage requirements that do not map well to a general-purpose API. The HAL handles hardware-specific requirements by providing the UNIX-style `ioctl()` function. Because the hardware features depend on the peripheral, the `ioctl()` options are documented in the description for each peripheral.

Some peripherals provide dedicated accessor functions that are not based on the HAL generic device models. For example, Intel FPGA provides a general-purpose parallel I/O (PIO) core for use with the Nios II processor system. The PIO peripheral does not fit in any class of generic device models provided by the HAL, and so it provides a header file and a few dedicated accessor functions only.

For complete details regarding software support for a peripheral, refer to the peripheral's description.

For more information about Intel FPGA-provided peripherals, refer to the *Embedded Peripherals IP User Guide*.

Related Information

[Embedded Peripherals IP User Guide](#)

6.3.3. MPU Support

The HAL does not include explicit support for the optional memory protection unit (MPU) hardware. However, it does support an advanced exception handling system that can handle Nios II MPU exceptions.

For more information about handling MPU and other advanced exceptions, refer to the *Exception Handling* section.

For more information about the MPU hardware implementation, refer to the *Programming Model* chapter of the *Nios II Processor Reference Handbook*.

Related Information

- [Exception Handling](#) on page 244
For more information about handling MPU and other advanced exceptions.
- [Programming Model](#)
For more information about the MPU hardware implementation.

6.3.4. MMU Support


The HAL does not support the optional memory management unit (MMU) hardware. To use the MMU, you need to implement a full-featured operating system.

For more information about the Nios II MMU, refer to the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Programming Model](#)

For more information about the Nios II MMU.



7. Developing Programs Using the Hardware Abstraction Layer

This chapter discusses how to develop embedded programs for the Nios[®] II embedded processor based on the Intel FPGA[®] hardware abstraction layer (HAL). The application program interface (API) for HAL-based systems is readily accessible to software developers who are new to the Nios II processor. Programs based on the HAL use the ANSI C standard library functions and runtime environment, and access hardware resources with the HAL API's generic device models. The HAL API largely conforms to the familiar ANSI C standard library functions, though the ANSI C standard library is separate from the HAL. The close integration of the ANSI C standard library and the HAL makes it possible to develop useful programs that never call the HAL functions directly. For example, you can manipulate character mode devices and files using the ANSI C standard library I/O functions, such as `printf()` and `scanf()`.

For more information, refer to the book: *The C Programming Language, Second Edition*, by Brian Kernighan and Dennis M. Ritchie (Prentice-Hall).

Related Information

[Developing Programs Using the Hardware Abstraction Layer Revision History](#) on page 14

For details on the document revision history of this chapter

7.1. HAL BSP Settings

Every Nios II board support package (BSP) has settings that determine the BSP's characteristics. For example, HAL BSPs have settings to identify the hardware components associated with standard devices such as `stdout`. Defining and manipulating BSP settings is an important part of Nios II project creation. You manipulate BSP settings with the Nios II BSP Editor, with command-line options, or with Tcl scripts.

Note: For details about how to control BSP settings, refer to one or more of the following documents:

- For more information about the Nios II SBT for Eclipse, refer to the "Getting Started with the Graphical User Interface" chapter.
- For more information about the Nios II SBT command line, refer to the "Nios II Software Build Tools" chapter.

For more information about detailed descriptions of available BSP settings, refer to the "Nios II Software Build Tools Reference" chapter.

Many HAL settings are reflected in the `system.h` file, which provides a helpful reference for details about your BSP.



For more information about `system.h`, refer to the “The `system.h` System Description File” chapter.

Note: Do not edit `system.h`. The Nios II EDS provides tools to manipulate system settings.

Related Information


- [The `system.h` System Description File](#) on page 160
- [Getting Started with the Graphical User Interface](#) on page 26
- [Nios II Software Build Tools](#) on page 87
- [Nios II Software Build Tools Reference](#) on page 396

7.2. The Nios II Embedded Project Structure

The creation and management of software projects based on the HAL is integrated tightly with the Nios II SBT. This section discusses the Nios II projects as a basis for understanding the HAL.

Note: The label for each block describes what or who generated that block, and an arrow points to each block’s dependency.

Figure 10. The Nios II HAL Project Structure Emphasizing How the HAL BSP Fits In



Every HAL-based Nios II program consists of two Nios II projects.

For more information, refer to the figure above. Your application-specific code is contained in one project (the user application project), and it depends on a separate BSP project (the HAL BSP).

The application project contains all the code you develop. The executable image for your program ultimately results from building both projects.

With the Nios II SBT for Eclipse, the tools create the HAL BSP project when you create your application project. In the Nios II SBT command line flow, you create the BSP using **nios2-bsp** or a related tool.

The HAL BSP project contains all information needed to interface your program to the hardware. The HAL drivers relevant to your hardware system are incorporated in the BSP project.

The BSP project depends on the hardware system, defined by a SOPC Information File (**.sopcinfo**). The Nios II SBT can keep your BSP up-to-date with the hardware system. This project dependency structure isolates your program from changes to the underlying hardware, and you can develop and debug code without concern about whether your program matches the target hardware.

You can use the Nios II SBT to update your BSP to match updated hardware. You control whether and when these updates occur.

For more information about how the SBT keeps your BSP up-to-date with your hardware system, refer to "Revising Your BSP" in the "Nios II Software Build Tools" chapter.

In summary, when your program is based on a HAL BSP, you can always keep it synchronized with the target hardware with a few simple SBT commands.

Related Information

- [Nios II Software Build Tools Reference](#) on page 396
- [Nios II Embedded Software Projects](#) on page 90

7.3. The system.h System Description File

The `system.h` file provides a complete software description of the Nios II system hardware. Not all information in `system.h` is useful to you as a programmer, and it is rarely necessary to include it explicitly in your C source files. Nonetheless, `system.h` holds the answer to the question, "What hardware is present in this system?"

The `system.h` file describes each peripheral in the system and provides the following details:

- The hardware configuration of the peripheral
- The base address
- Interrupt request (IRQ) information (if any)
- A symbolic name for the peripheral

The Nios II SBT generates the `system.h` file for HAL BSP projects. The contents of `system.h` depend on both the hardware configuration and the HAL BSP properties.

Note: Do not edit `system.h`. The SBT provides facilities to manipulate system settings.

For more information about how to control BSP settings, refer to the "HAL BSP Settings" chapter.

Example 6–1. Excerpts from a `system.h` File Detailing Hardware Configuration Options

```
/*
 * sys_clk_timer configuration
 *
 */
#define SYS_CLK_TIMER_NAME "/dev/sys_clk_timer"
#define SYS_CLK_TIMER_TYPE "altera_avalon_timer"
```




```
#define SYS_CLK_TIMER_BASE 0x00920800
#define SYS_CLK_TIMER_IRQ 0
#define SYS_CLK_TIMER_ALWAYS_RUN 0
#define SYS_CLK_TIMER_FIXED_PERIOD 0
/*
 * jtag_uart configuration
 */
#define JTAG_UART_NAME "/dev/jtag_uart"
#define JTAG_UART_TYPE "altera_avalon_jtag_uart"
#define JTAG_UART_BASE 0x00920820
#define JTAG_UART_IRQ 1
```

Related Information

[HAL BSP Settings](#) on page 158

7.4. Data Widths and the HAL Type Definitions

For embedded processors such as the Nios II processor, it is often important to know the exact width and precision of data. Because the ANSI C data types do not explicitly define data width, the HAL uses a set of standard type definitions instead. The ANSI C types are supported, but their data widths are dependent on the compiler's convention.

The header file `alt_types.h` defines the HAL type definitions.

Table 28. The HAL Type Definitions

Type	Meaning
<code>alt_8</code>	Signed 8-bit integer.
<code>alt_u8</code>	Unsigned 8-bit integer.
<code>alt_16</code>	Signed 16-bit integer.
<code>alt_u16</code>	Unsigned 16-bit integer.
<code>alt_32</code>	Signed 32-bit integer.
<code>alt_u32</code>	Unsigned 32-bit integer.
<code>alt_64</code>	Signed 64-bit integer.
<code>alt_u64</code>	Unsigned 64-bit integer.

Table 29. GNU Toolchain Data Widths

Type	Meaning
<code>char</code>	8 bits.
<code>short</code>	16 bits.
<code>long</code>	32 bits.
<code>int</code>	32 bits.

7.5. UNIX-Style Interface

The HAL API provides a number of UNIX-style functions. The UNIX-style functions provide a familiar development environment for new Nios II programmers, and can ease the task of porting existing code to run in the HAL environment. The HAL uses these functions primarily to provide the system interface for the ANSI C standard library. For example, the functions perform device access required by the C library functions defined in `stdio.h`.

The following list contains all of the available UNIX-style functions:

- `_exit()`
- `close()`
- `fstat()`
- `getpid()`
- `gettimeofday()`
- `ioctl()`
- `isatty()`
- `kill()`
- `lseek()`
- `open()`
- `read()`
- `sbrk()`
- `settimeofday()`
- `stat()`
- `usleep()`
- `wait()`
- `write()`

The most commonly used functions are those that relate to file I/O.

For more information, refer to the "File System" chapter.

For more information about the use of these functions, refer to the "HAL API Reference" chapter.

Related Information

- [File System](#) on page 162
- [HAL API Reference](#) on page 315

7.6. File System

The HAL provides infrastructure for UNIX-style file access. You can use this infrastructure to build a file system on any storage devices available in your hardware.

For more information, refer to an example in the "Read-Only Zip File System" chapter.



You can access files in a HAL-based file system by using either the C standard library file I/O functions in the newlib C library (for example `fopen()`, `fclose()`, and `fread()`), or using the UNIX-style file I/O provided by the HAL.

The HAL provides the following UNIX-style functions for file manipulation:

- `close()`
- `fstat()`
- `ioctl()`
- `isatty()`
- `lseek()`
- `open()`
- `read()`
- `stat()`
- `write()`

For more information about these functions, refer to the "HAL API Reference" chapter.

The HAL registers a file subsystem as a mount point in the global HAL file system. Attempts to access files below that mount point are directed to the file subsystem. For example, if a read-only zip file subsystem (**zipfs**) is mounted as **/mount/zipfs0**, the **zipfs** file subsystem handles calls to `fopen()` for **/mount/zipfs0/myfile**.

There is no concept of a current directory. Software must access all files using absolute paths.

The HAL file infrastructure also allows you to manipulate character mode devices with UNIX-style path names. The HAL registers character mode devices as nodes in the HAL file system. By convention, `system.h` defines the name of a device node as the prefix **/dev/** plus the name assigned to the hardware component at system generation time. For example, a UART peripheral that appears as **uart1** in Platform Designer is named **/dev/uart1** in `system.h`.

Note: The standard header files `stdio.h`, `stddef.h`, and `stdlib.h` are installed with the HAL.

```
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#define BUF_SIZE (10)
int main(void)
{
    FILE* fp;
    char buffer[BUF_SIZE];
    fp = fopen ("/mount/rozipfs/test", "r"); if (fp == NULL)
    {
        printf ("Cannot open file.\n");
        exit (1);
    }
    fread (buffer, BUF_SIZE, 1, fp);
    fclose (fp);
    return 0;
}
```

For more information about the use of these functions, refer to the newlib C library documentation installed with the Nios II EDS. To access the documentation, go to the Windows Start menu, click **Programs > Intel FPGA > Nios II > Nios II Documentation**.

Related Information

- [HAL API Reference](#) on page 315
- [Read-Only Zip File System](#) on page 306

7.7. Using Character-Mode Devices

A character-mode device is a hardware peripheral that either or both send or receive characters serially. A common example is the UART. Character mode devices are registered as nodes in the HAL file system. In general, a program associates a file descriptor to a device's name, and then writes and reads characters to or from the file using the ANSI C file operations defined in `file.h`. The HAL also supports the concept of standard input, standard output, and standard error, allowing programs to call the `stdio.h` I/O functions.

7.7.1. Standard Input, Standard Output and Standard Error

Using standard input (`stdin`), standard output (`stdout`), and standard error (`stderr`) is the easiest way to implement simple console I/O. The HAL manages `stdin`, `stdout`, and `stderr` behind the scenes, which allows you to send and receive characters through these channels without explicitly managing file descriptors. For example, the HAL directs the output of `printf()` to standard out, and `perror()` to standard error. You associate each channel to a specific hardware device by manipulating BSP settings.

Note: This program sends characters to whatever device is associated with `stdout` when the program is compiled.

Example 6–3. Hello World

```
#include <stdio.h>
int main ()
{
    printf ("Hello world!");
    return 0;
}
```

When using the UNIX-style API, you can use the file descriptors `stdin`, `stdout`, and `stderr`, defined in `unistd.h`, to access, respectively, the standard in, standard out, and standard error character I/O streams. **`unistd.h`** is installed with the Nios II EDS as part of the newlib C library package.

7.7.2. General Access to Character Mode Devices

Accessing a character-mode device other than `stdin`, `stdout`, or `stderr` is as easy as opening and writing to a file.



Example 6-4. Writing Characters to a UART Called `uart1`

```
#include <stdio.h>
#include <string.h>
int main (void)
{
    char* msg = "hello world";
    FILE* fp;
    fp = fopen ("/dev/uart1", "w");
    if (fp!=NULL)
    {
        fprintf(fp, "%s",msg);
        fclose (fp);
    }
    return 0;
}
```

7.7.3. C++ Streams

HAL-based systems can use the C++ streams API for manipulating files from C++.

7.7.4. `/dev/null`

All systems include the device `/dev/null`. Writing to `/dev/null` has no effect, and all data is discarded. `/dev/null` is used for safe I/O redirection during system startup. This device can also be useful for applications that wish to sink unwanted data.

This device is purely a software construct. It does not relate to any physical hardware device in the system.

7.7.5. Lightweight Character-Mode I/O

The HAL offers several methods of reducing the code footprint of character-mode device drivers.

For more information, refer to the "Reducing Code Footprint in Embedded Systems" chapter.

Related Information

[Reducing Code Footprint in Embedded Systems](#) on page 186

7.7.6. Intel FPGA Logging Functions

The Intel FPGA logging functions provide a separate channel for sending logging and debugging information to a character-mode device, supplementing `stdout` and `stderr`. The Intel FPGA logging information can be printed in response to several conditions. Intel FPGA logging can be enabled and disabled independently of any normal `stdio` output, making it a powerful debugging tool.

When Intel FPGA logging is enabled, your software can print extra messages to a specified port with HAL function calls. The logging port, specified in the BSP, can be a UART or a JTAG UART device. In its default configuration, Intel FPGA logging prints out boot messages, which trace each step of the boot process.

Note: Avoid setting the Intel FPGA logging device to the device used for `stdout` or `stderr`. If Intel FPGA logging output is sent to `stdout` or `stderr`, the logging output might appear interleaved with the `stdout` or `stderr` output

Several logging options are available, controlled by C preprocessor symbols. You can also choose to add custom logging messages.

Note: Intel FPGA logging changes system behavior. The logging implementation is designed to be as simple as possible, loading characters directly to the transmit register. It can have a negative impact on software performance.

Intel FPGA logging functions are conditionally compiled. When logging is disabled, it has no impact on code footprint or performance.

Note: The Intel FPGA reduced device drivers do not support Intel FPGA logging.

7.7.6.1. Enabling Logging

Logging is enabled by setting **hal.log_port** to a JTAG UART or a UART device. The setting allows the HAL to send log messages to the specified device.

Once **hal.log_port** is set, **ALT_LOG_ENABLE** is defined in **public.mk** and the **ALT_LOG_FLAGS** flag is set to 0, the default value.

Note: You can set **ALT_LOG_FLAGS** to any value from 1 to 4, to determine the level of output.

Note: If **hal.log_port** is not set, then **ALT_LOG_ENABLE** and **ALT_LOG_FLAGS** do not appear in **public.mk**.

The build tools also set the **ALT_LOG_PORT_TYPE** and **ALT_LOG_PORT_BASE** values in **system.h** to point to the specified device.

When logging is enabled without special options, the HAL prints out boot messages to the selected port. For typical software that uses the standard **alt_main.c** (such as the Hello World software example), the messages appear as in the following example.

Example 6–5. Default Boot Logging Output

```
[crt0.S] Inst & Data Cache Initialized.
[crt0.S] Setting up stack and global pointers.
[crt0.S] Clearing BSS
[crt0.S] Calling alt_main.
[alt_main.c] Entering alt_main, calling alt_irq_init.
[alt_main.c] Done alt_irq_init, calling alt_os_init.
[alt_main.c] Done OS Init, calling alt_sem_create.
[alt_main.c] Calling alt_sys_init.
[alt_main.c] Done alt_sys_init. Redirecting IO.
[alt_main.c] Calling C++ constructors.
[alt_main.c] Calling main.
[alt_exit.c] Entering _exit() function.
[alt_exit.c] Exit code from main was 0.
[alt_exit.c] Calling ALT_OS_STOP().
[alt_exit.c] Calling ALT_SIM_HALT().
[alt_exit.c] Spinning forever.
```

Note: A write operation to the logging device stalls in **ALT_LOG_PRINTF()** until the characters are read from the logging device's output buffer. To ensure that the Nios II application completes initialization, run the **nios2-terminal** command from the Nios II Command Shell to accept the logging output.



7.7.6.2. Extra Logging Options

In addition to the default boot messages, logging options are incorporated in Intel FPGA logging. Each option is controlled by a C preprocessor symbol.

Table 30. Intel FPGA Logging Options and Option Modifiers

Name	Description	
System clock log	Purpose	Prints out a message from the system clock interrupt handler at a specified interval. This indicates that the system is still running. The default interval is every 1 second.
	Preprocessor symbol	ALT_LOG_SYS_CLK_ON_FLAG_SETTING
	Modifiers	The system clock log has two modifiers, providing two different ways to specify the logging interval. <ul style="list-style-type: none"> ALT_LOG_SYS_CLK_INTERVAL—Specifies the logging interval in system clock ticks. The default is <clock ticks per second>, that is, one second. ALT_LOG_SYS_CLK_INTERVAL_MULTIPLIER—Specifies the logging interval in seconds. The default is 1. When you modify ALT_LOG_SYS_CLK_INTERVAL_MULTIPLIER, ALT_LOG_SYS_CLK_INTERVAL is recalculated.
	Sample Output	System Clock On 0 System Clock On 1
Write echo	Purpose	Every time alt_write() is called (normally, whenever characters are sent to stdout), the first <n> characters are echoed to a logging message. The message starts with the string "Write Echo:". <n> is specified with ALT_LOG_WRITE_ECHO_LEN. The default is 15 characters.
	Preprocessor symbol	ALT_LOG_WRITE_ON_FLAG_SETTING
	Modifiers	ALT_LOG_WRITE_ECHO_LEN—Number of characters to echo. Default is 15.
	Sample Output	Write Echo: Hello from Nio
JTAG startup log	Purpose	At JTAG UART driver initialization, print out a line with the number of characters in the software transmit buffer followed by the JTAG UART control register contents. The number of characters, prefaced by the string "SW CirBuf", might be negative, because it is computed as (<tail_pointer> - <head_pointer>) on a circular buffer. For more information about the JTAG UART control register fields, refer to the <i>Embedded Peripherals IP User Guide</i> .
	Preprocessor symbol	ALT_LOG_JTAG_UART_STARTUP_INFO_ON_FLAG_SETTING
	Modifiers	None
	Sample Output	JTAG Startup Info: SW CirBuf = 0, HW FIFO wspace=64 AC=0 WI=0 RI=0 WE=0 RE=1
JTAG interval log	Purpose	Creates an alarm object to print out the same JTAG UART information as the JTAG startup log, but at a repeated interval. Default interval is 0.1 second, or 10 messages a second.
	Preprocessor symbol	ALT_LOG_JTAG_UART_ALARM_ON_FLAG_SETTING
	Modifiers	The JTAG interval log has two modifiers, providing two different ways to specify the logging interval.

continued...

Name	Description	
		<ul style="list-style-type: none"> ALT_LOG_JTAG_UART_TICKS—Logging interval in ticks. Default is <ticks_per_second> / 10. ALT_LOG_JTAG_UART_TICKS_DIVISOR—Specifies the number of logs per second. The default is 10. When you modify ALT_LOG_JTAG_UART_TICKS_DIVISOR, ALT_LOG_JTAG_UART_TICKS is recalculated.
	Sample Output	JTAG Alarm: SW CirBuf = 0, HW FIFO wspace=45 AC=0 WI=0 RI=0 WE=0 RE=1
JTAG interrupt service routine (ISR) log	Purpose	Prints out a message every time the JTAG UART near-empty interrupt triggers. Message contains the same JTAG UART information as in the JTAG startup log.
	Preprocessor symbol	ALT_LOG_JTAG_UART_ISR_ON_FLAG_SETTING
	Modifiers	None
	Sample Output	JTAG IRQ: SW CirBuf = -20, HW FIFO wspace=64 AC=0 WI=1 RI=0 WE=1 RE=1
Boot log	Purpose	Prints out messages tracing the software boot process. The boot log is turned on by default when Intel FPGA logging is enabled.
	Preprocessor symbol	ALT_LOG_BOOT_ON_FLAG_SETTING
	Modifiers	None
	Sample Output	For more information, refer to the "Enabling Intel FPGA Logging" chapter .

Note: An option's modifiers are meaningful only when the option is enabled.

Setting a preprocessor flag to 1 enables the corresponding option. Any value other than 1 disables the option.

Several options have modifiers, which are additional preprocessor symbols controlling details of how the options work. For example, the system clock log's modifiers control the logging interval.

Related Information

- [Embedded Peripherals IP User Guide](#)
- [Enabling Logging](#) on page 166

7.7.6.3. Logging Levels

An additional preprocessor symbol, ALT_LOG_FLAGS, can be set to provide some grouping for the extra logging options. ALT_LOG_FLAGS implements logging levels based on performance impact. With higher logging levels, the Intel FPGA logging options take more processor time.

Table 31. ALT_LOG_FLAGS Logging Levels

Logging Level	Logging
0	Boot log (default)
1	Level 0 plus system clock log and JTAG startup log
continued...	



Logging Level	Logging
2	Level 1 plus JTAG interval log and write echo
3	Level 2 plus JTAG ISR log
-1	Silent mode—No Intel FPGA logging

Note: You can use logging level -1 to turn off logging without changing the program footprint. The logging code is still present in your executable image, as determined by other logging options chosen. This is useful when you wish to switch the log output on or off without disturbing the memory map.

Because each logging option is controlled by an independent preprocessor symbol, individual options in the logging levels can be overridden.

7.7.6.4. Example: Creating a BSP with Logging

- System clock log
- JTAG startup log
- JTAG interval log, logging twice a second
- No write echo

Example 6–6. Creating BSP With Logging and Options

```
nios2-bsp hal my_bsp ../my_hardware.sopcinfo \
--set hal.log_port uart1 \
--set hal.make.bsp_cflags_user_flags \
-DALT_LOG_FLAGS=2 \
-DALT_LOG_WRITE_ON_FLAG_SETTING=0 \
-DALT_LOG_JTAG_UART_TICKS_DIVISOR=2r
```

The `-DALT_LOG_FLAGS=2` argument adds `-DALT_LOG_FLAGS=2` to the `ALT_CPP_FLAGS` make variable in `public.mk`.

7.7.6.5. Custom Logging Messages

You can add custom messages that are sent to the Intel FPGA logging device. To define a custom message, include the header file `alt_log_printf.h` in your C source file as follows:

```
#include "sys/alt_log_printf.h"
```

Then use the following macro function:

```
ALT_LOG_PRINTF(const char *format, ...)
```

This C preprocessor macro is a pared-down version of `printf()`. The `format` argument supports most `printf()` options. It supports `%c`, `%d`, `%I`, `%o`, `%s`, `%u`, `%x`, and `%X`, as well as some precision and spacing modifiers, such as `%-9.3o`. It does not support floating point formats, such as `%f` or `%g`. This function is not compiled if Intel FPGA logging is not enabled.

If you want your custom logging message to be controlled by Intel FPGA logging preprocessor options, use the appropriate Intel FPGA logging option preprocessor flags from the "ALT_LOG_FLAGS Logging Levels" table (Table 6–4), or the "Intel FPGA Logging Options and Option Modifiers" table (Table 6–3 on page 6–10).

Example 6–7. Implementing Logging Options with Custom Logging Messages

```
/* The following example prints "Level 2 logging message" if
logging is set to level 2 or higher */
#if ( ALT_LOG_FLAGS >= 2 )
ALT_LOG_PRINTF ( "Level 2 logging message" );
#endif
/* The following example prints "Boot logging message" if boot logging
is turned on */
#if ( ALT_LOG_BOOT_ON_FLAG_SETTING == 1)
ALT_LOG_PRINTF ( "Boot logging message" );
#endif
```

7.7.6.6. Intel FPGA Logging Files

Table 32. HAL Implementation Files for Intel FPGA Logging

Location	File Name
components/altera_hal/HAL/inc/sys/	alt_log_printf.h
components/altera_hal/HAL/src/	alt_log_printf.c
components/altera_nios2/HAL/src/	alt_log_macro.S

Note: All file locations are relative to <Nios II EDS install path>.

These files implement the logging options listed in the "Intel FPGA Logging Options and Option Modifiers" table (Table 6–3 on page 6–10). They also serve as examples of logging usage.

Table 33. HAL Example Files for Intel FPGA Logging

Location	File Name
components/altera_avalon_jtag_uart/HAL/src/	altera_avalon_jtag_uart.c
components/altera_avalon_timer/HAL/src/	altera_avalon_timer_sc.c
components/altera_hal/HAL/src/	alt_exit.c
components/altera_hal/HAL/src/	alt_main.c
components/altera_hal/HAL/src/	alt_write.c
components/altera_nios2/HAL/src/	crt0.S

Note: All file locations are relative to <Nios II EDS install path>.

7.8. Using File Subsystems

The HAL generic device model for file subsystems allows access to data stored in an associated storage device using the C standard library file I/O functions. For example, the Intel FPGA read-only zip file system provides read-only access to a file system stored in flash memory.

A file subsystem is responsible for managing all file I/O access beneath a given mount point. For example, if a file subsystem is registered with the mount point **/mnt/rozipfs**, all file access beneath this directory, such as `fopen("/mnt/rozipfs/myfile", "r")`, is directed to that file subsystem.



As with character mode devices, you can manipulate files in a file subsystem using the C file I/O functions defined in `file.h`, such as `fopen()` and `fread()`.

For more information about the use of file I/O functions, refer to the newlib C library documentation installed with the Nios II EDS. On the Windows Start menu, click **Programs > Intel FPGA > Nios II <version> > Nios II EDS <version> Documentation**.

7.8.1. Host-Based File System

The host-based file system enables programs executing on a target board to read and write files stored on the host computer. The Nios II SBT for Eclipse transmits file data over the Intel FPGA download cable. Your program accesses the host based file system using the ANSI C standard library I/O functions, such as `fopen()` and `fread()`. The host-based file system is a software package which you add to your BSP.

The following features and restrictions apply to the host based file system:

- The host-based file system makes the Nios II C/C++ application project directory and its subdirectories available to the HAL file system on the target hardware.
- The target processor can access any file in the project directory. Be careful not to corrupt project source files.
- The host-based file system only operates while debugging a project. It cannot be used for run sessions.
- Host file data travels between host and target serially through the Intel FPGA download cable, and therefore file access time is relatively slow. Depending on your host and target system configurations, it can take several milliseconds per call to the host. For higher performance, use buffered I/O function such as `fread()` and `fwrite()`, and increase the buffer size for large files.

You configure the host-based file system using the Nios II BSP Editor. The host-based file system has one setting: the mount point, which specifies the mount point within the HAL file system. For example, if you name the mount point `/mnt/host` and the project directory on your host computer is `/software/project1`, in a HAL-based program, the following code opens the file `/software/project1/datafile.dat`:

```
fopen("/mnt/host/datafile.dat", "r");
```

7.9. Using Timer Devices

Timer devices are hardware peripherals that count clock ticks and can generate periodic interrupt requests. You can use a timer device to provide a number of time-related facilities, such as the HAL system clock, alarms, the time-of-day, and time measurement. To use the timer facilities, the Nios II processor system must include a timer peripheral in hardware.

The HAL API provides two types of timer device drivers:

- System clock driver—Supports alarms, such as you would use in a scheduler.
- Timestamp driver—Supports high-resolution time measurement.

An individual timer peripheral can behave as either a system clock or a timestamp, but not both.

For more information about where the HAL-specific API functions for accessing timer devices are defined, refer to the `sys/alt_alarm.h` and `sys/alt_timestamp.h` files.

7.9.1. System Clock Driver

The HAL system clock driver provides a periodic heartbeat, causing the system clock to increment on each beat. Software can use the system clock facilities to execute functions at specified times, and to obtain timing information. You select a specific hardware timer peripheral as the system clock device by manipulating BSP settings.

For more information about how to control BSP settings, refer to the "HAL BSP Settings" chapter.

The HAL provides implementations of the following standard UNIX functions: `gettimeofday()`, `settimeofday()`, and `times()`. The times returned by these functions are based on the HAL system clock.

The system clock measures time in clock ticks. For embedded engineers who deal with both hardware and software, do not confuse the HAL system clock with the clock signal driving the Nios II processor hardware. The period of a HAL system clock tick is generally much longer than the hardware system clock. `system.h` defines the clock tick frequency.

At runtime, you can obtain the current value of the system clock by calling the `alt_nticks()` function. This function returns the elapsed time in system clock ticks since reset. You can get the system clock rate, in ticks per second, by calling the function `alt_ticks_per_second()`. The HAL timer driver initializes the tick frequency when it creates the instance of the system clock.

The standard UNIX function `gettimeofday()` is available to obtain the current time. You must first calibrate the time of day by calling `settimeofday()`. In addition, you can use the `times()` function to obtain information about the number of elapsed ticks. The prototypes for these functions appear in `times.h`.

For more information about the use of these functions, refer to the "HAL API Reference" chapter.

Related Information

- [HAL BSP Settings](#) on page 158
- [HAL API Reference](#) on page 315

7.9.2. Alarms

You can register functions to be executed at a specified time using the HAL alarm facility. A software program registers an alarm by calling the function `alt_alarm_start()`:

```
int alt_alarm_start(alt_alarm* alarm,
    alt_u32 nticks,
    alt_u32 (*callback) (void* context),
    void* context);
```



The function `callback()` is called after `nticks` have elapsed. The input argument `context` is passed as the input argument to `callback()` when the call occurs. The HAL does not use the `context` parameter. It is only used as a parameter to the `callback()` function.

Your code must allocate the `alt_alarm` structure, pointed to by the input argument `alarm`. This data structure must have a lifetime that is at least as long as that of the alarm. The best way to allocate this structure is to declare it as a static or global. `alt_alarm_start()` initializes `*alarm`.

The callback function can reset the alarm. The return value of the registered callback function is the number of ticks until the next call to `callback`. A return value of zero indicates that the alarm should be stopped. You can manually cancel an alarm by calling `alt_alarm_stop()`.

One alarm is created for each call to `alt_alarm_start()`. Multiple alarms can run simultaneously.

Alarm callback functions execute in an exception context. This imposes functional restrictions which you must observe when writing an alarm callback.

For more information about the use of these functions, refer to the "Exception Handling" chapter.

Example 6–8. Using a Periodic Alarm Callback Function

```
#include <stddef.h>
#include <stdio.h>
#include "sys/alt_alarm.h"
#include "alt_types.h"
/*
 * The callback function.
 */
alt_u32 my_alarm_callback (void* context)
{
    /* This function is called once per second */
    return alt_ticks_per_second();
}
...
/* The alt_alarm must persist for the duration of the alarm. */
static alt_alarm alarm;
...
if (alt_alarm_start (&alarm,
    alt_ticks_per_second(),
    my_alarm_callback,
    NULL) < 0)
{
    printf ("No system clock available\n");
}
```

Related Information

[Exception Handling](#) on page 244

7.9.3. Timestamp Driver

Sometimes you want to measure time intervals with a degree of accuracy greater than that provided by HAL system clock ticks. The HAL provides high resolution timing functions using a timestamp driver. A timestamp driver provides a monotonically increasing counter that you can sample to obtain timing information. The HAL only supports one timestamp driver in the system.

You specify a hardware timer peripheral as the timestamp device by manipulating BSP settings. The Intel FPGA-provided timestamp driver uses the timer that you specify.

If a timestamp driver is present, the following functions are available:

- `alt_timestamp_start()`
- `alt_timestamp()`

Calling `alt_timestamp_start()` starts the counter running. Subsequent calls to `alt_timestamp()` return the current value of the timestamp counter. Calling `alt_timestamp_start()` again resets the counter to zero. The behavior of the timestamp driver is undefined when the counter reaches $(2^{32} - 1)$.

You can obtain the rate at which the timestamp counter increments by calling the function `alt_timestamp_freq()`. This rate is typically the hardware frequency of the Nios II processor system—usually millions of cycles per second. The timestamp drivers are defined in the `alt_timestamp.h` header file.

For more information about the use of these functions, refer to the *HAL API Reference* section.

Example 6–9. Using the Timestamp to Measure Code Execution Time

```
#include <stdio.h>
#include "sys/alt_timestamp.h"
#include "alt_types.h"
int main (void)
{
    alt_u32 time1;
    alt_u32 time2;
    alt_u32 time3;
    if (alt_timestamp_start() < 0)
    {
        printf ("No timestamp device available\n");
    }
    else
    {
        time1 = alt_timestamp();
        func1(); /* first function to monitor */
        time2 = alt_timestamp();
        func2(); /* second function to monitor */
        time3 = alt_timestamp();
        printf ("time in func1 = %u ticks\n",
            (unsigned int) (time2 - time1));
        printf ("time in func2 = %u ticks\n",
            (unsigned int) (time3 - time2));
        printf ("Number of ticks per second = %u\n",
            (unsigned int) alt_timestamp_freq());
    }
    return 0;
}
```

Related Information

[HAL API Reference](#) on page 315

7.10. Using Flash Devices

The HAL provides a generic device model for nonvolatile flash memory devices. Flash memories use special programming protocols to store data. The HAL API provides functions to write data to flash memory. For example, you can use these functions to implement a flash-based file subsystem.



The HAL API also provides functions to read flash, although it is generally not necessary. For most flash devices, programs can treat the flash memory space as simple memory when reading, and do not need to call special HAL API functions. If the flash device has a special protocol for reading data, such as the Intel FPGA erasable programmable configurable serial (EPCS) configuration device, you must use the HAL API to both read and write data.

This section describes the HAL API for the flash device model. The following two APIs provide two different levels of access to the flash:

- Simple flash access—Functions that write buffers to flash and read them back at the block level. In writing, if the buffer is less than a full block, these functions erase preexisting flash data above and below the newly written data.
- Fine-grained flash access—Functions that write buffers to flash and read them back at the buffer level. In writing, if the buffer is less than a full block, these functions preserve preexisting flash data above and below the newly written data. This functionality is generally required for managing a file subsystem.

The API functions for accessing flash devices are defined in `sys/alt_flash.h`.

For more information about the use of these functions, refer to the *HAL API Reference* section.

For more information about the Common Flash Interface, including the organization of common flash interface (CFI) erase regions and blocks, refer to the JEDEC website.

For more information about the CFI standard, refer to the JEDEC website and search for document JESD68.

Related Information

- [HAL API Reference](#) on page 315
- [JEDEC Website](#)
For more information about the Common Flash Interface standard, including the organization of common flash interface (CFI) erase regions and blocks, refer to the JEDEC website and search for document JESD68.

7.10.1. Simple Flash Access

This interface consists of the functions `alt_flash_open_dev()`, `alt_write_flash()`, `alt_read_flash()`, and `alt_flash_close_dev()`.

For more information about the use of all of these functions in one code example, refer to the code in the "Using the Simple Flash API Functions to Access a Flash Device Named `/dev/ext/flash`" example in the "Fine-Grained Flash Access" section.

You open a flash device by calling `alt_flash_open_dev()`, which returns a file handle to a flash device. This function takes a single argument that is the name of the flash device, as defined in `system.h`.

After you obtain a handle, you can use the `alt_write_flash()` function to write data to the flash device. The prototype is:

```
int alt_write_flash( alt_flash_fd* fd,
int offset,
const void* src_addr,
int length )
```

A call to this function writes to the flash device identified by the handle `fd`. The driver writes the data starting at `offset` bytes from the base of the flash device. The data written comes from the address pointed to by `src_addr`, and the amount of data written is `length`.

There is also an `alt_read_flash()` function to read data from the flash device. The prototype is:

```
int alt_read_flash( alt_flash_fd* fd,
int offset,
void* dest_addr,
int length )
```

A call to `alt_read_flash()` reads from the flash device with the handle `fd`, `offset` bytes from the beginning of the flash device. The function writes the data to location pointed to by `dest_addr`, and the amount of data read is `length`. For most flash devices, you can access the contents as standard memory, making it unnecessary to use `alt_read_flash()`.

The function `alt_flash_close_dev()` takes a file handle and closes the device. The prototype for this function is:

```
void alt_flash_close_dev(alt_flash_fd* fd )
```

Related Information

[Fine-Grained Flash Access](#) on page 177

7.10.2. Block Erasure or Corruption

Generally, flash memory is divided into blocks. `alt_write_flash()` might need to erase the contents of a block before it can write data to it. In this case, it makes no attempt to preserve the existing contents of the block. This action can lead to unexpected data corruption (erasure), if you are performing writes that do not fall on block boundaries. If you wish to preserve existing flash memory contents, use the fine-grained flash functions. These are discussed in the following section.

The "Example of Writing Flash and Causing Unexpected Data Corruption" table ([Table 6–7](#)) shows the example of an 8-kilobyte (KB) flash memory comprising two 4-KB blocks. First write 5 KB of all `0xAA` to flash memory at address `0x0000`, and then write 2 KB of all `0xBB` to address `0x1400`. After the first write succeeds (at time `t(2)`), the flash memory contains 5 KB of `0xAA`, and the rest is empty (that is, `0xFF`). Then the second write begins, but before writing to the second block, the block is erased. At this point, `t(3)`, the flash contains 4 KB of `0xAA` and 4 KB of `0xFF`. After the second write finishes, at time `t(4)`, the 2 KB of `0xFF` at address `0x1000` is corrupted.



7.10.3. Fine-Grained Flash Access

Three additional functions provide complete control for writing flash contents at the highest granularity:

- `alt_get_flash_info()`
- `alt_erase_flash_block()`
- `alt_write_flash_block()`

By the nature of flash memory, you cannot erase a single address in a block. You must erase (that is, set to all ones) an entire block at a time. Writing to flash memory can only change bits from 1 to 0; to change any bit from 0 to 1, you must erase the entire block along with it.

Therefore, to alter a specific location in a block while leaving the surrounding contents unchanged, you must read out the entire contents of the block to a buffer, alter the value(s) in the buffer, erase the flash block, and finally write the whole block-sized buffer back to flash memory. The fine-grained flash access functions automate this process at the flash block level.

```
#include <stdio.h>
#include <string.h>
#include "sys/alt_flash.h"
#define BUF_SIZE 1024
int main ()
{
    alt_flash_fd* fd;
    int ret_code;
    char source[BUF_SIZE];
    char dest[BUF_SIZE];
    /* Initialize the source buffer to all 0xAA */
    memset(source, 0xAA, BUF_SIZE);
    fd = alt_flash_open_dev("/dev/ext_flash");
    if (fd!=NULL)
    {
        ret_code = alt_write_flash(fd, 0, source, BUF_SIZE);
        if (ret_code==0)
        {
            ret_code = alt_read_flash(fd, 0, dest, BUF_SIZE);
            if (ret_code==0)
            {
                /*
                 * Success.
                 * At this point, the flash is all 0xAA and we
                 * have read that all back to dest
                 */
            }
        }
        alt_flash_close_dev(fd);
    }
    else
    {
        printf("Cannot open flash device\n");
    }
    return 0;
}
```

7.10.3.1. alt_get_flash_info()

alt_get_flash_info() gets the number of erase regions, the number of erase blocks in each region, and the size of each erase block. The function prototype is as follows:

```
int alt_get_flash_info (
alt_flash_fd* fd,
flash_region** info,
int* number_of_regions )
```

If the call is successful, on return the address pointed to by number_of_regions contains the number of erase regions in the flash memory, and *info points to an array of flash_region structures. This array is part of the file descriptor.

Table 34. Example of Writing Flash and Causing Unexpected Data Corruption

Address	Block	Time t(0)	Time t(1)	Time t(2)	Time t(3)	Time t(4)
		Before First Write	First Write		Second Write	
			After Erasing Block(s)	After Writing Data 1	After Erasing Block(s)	After Writing Data 2
0x0000	1	Unknown	FF	AA	AA	AA
0x0400	1	Unknown	FF	AA	AA	AA
0x0800	1	Unknown	FF	AA	AA	AA
0x0C00	1	Unknown	FF	AA	AA	AA
0x1000	2	Unknown	FF	AA	FF	FF ⁽⁶⁾
0x1400	2	Unknown	FF	FF	FF	BB
0x1800	2	Unknown	FF	FF	FF	BB
0x1C00	2	Unknown	FF	FF	FF	FF

The flash_region structure is defined in sys/alt_flash_types.h. The data structure is defined as follows:

```
typedef struct flash_region
{
int offset; /* Offset of this region from start of the flash */
int region_size; /* Size of this erase region */
int number_of_blocks; /* Number of blocks in this region */
int block_size; /* Size of each block in this erase region */
}flash_region;
```

With the information obtained by calling alt_get_flash_info(), you are in a position to erase or program individual blocks of the flash device.

7.10.3.2. alt_erase_flash()

alt_erase_flash() erases a single block in the flash memory. The function prototype is as follows:

⁽⁶⁾ Unintentionally cleared to FF during erasure for second write.



```
int alt_erase_flash_block ( alt_flash_fd* fd, int offset, int
length )
```

The flash memory is identified by the handle `fd`. The block is identified as being `offset` bytes from the beginning of the flash memory, and the block size is passed in `length`.

7.10.3.3. alt_write_flash_block()

`alt_write_flash_block()` writes to a single block in the flash memory. The prototype is:

```
int alt_write_flash_block( alt_flash_fd* fd,
int block_offset,
int data_offset,
const void *data,
int length)
```

This function writes to the flash memory identified by the handle `fd`. It writes to the block located `block_offset` bytes from the start of the flash device. The function writes `length` bytes of data from the location pointed to by `data` to the location `data_offset` bytes from the start of the flash device.

Note: These program and erase functions do not perform address checking, and do not verify whether a write operation spans into the next block. You must pass in valid information about the blocks to program or erase.

Example 6–11. Using the Fine-Grained Flash Access API Functions

```
#include <string.h>
#include "sys/alt_flash.h"
#include "stdtypes.h"
#include "system.h"
#define BUF_SIZE 100
int main (void)
{
    flash_region* regions;
    alt_flash_fd* fd;
    int number_of_regions;
    int ret_code;
    char write_data[BUF_SIZE];
    /* Set write_data to all 0xA */
    memset(write_data, 0xA, BUF_SIZE);
    fd = alt_flash_open_dev(EXT_FLASH_NAME);
    if (fd)
    {
        ret_code = alt_get_flash_info(fd, &regions, &number_of_regions);
        if (number_of_regions && (regions->offset == 0))
        {
            /* Erase the first block */
            ret_code = alt_erase_flash_block(fd,
            regions->offset,
            regions->block_size);
            if (ret_code == 0) {
                /*
                 * Write BUF_SIZE bytes from write_data 100 bytes to
                 * the first block of the flash
                 */
                ret_code = alt_write_flash_block (
                fd,
                regions->offset,
                regions->offset+0x100,
                write_data,
```

```
BUF_SIZE );
}
}
return 0;
}
```

7.10.3.4. alt_lock_flash()

Prototype

```
int alt_lock_flash(alt_flash_dev * flash_info,
alt_u32 sectors_to_lock)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_flash.h>
```

Description

Locking to range of the flash memory sectors, which protected from writing and erasing by passing the uninteger 32 bits value to the sectors_to_lock argument, where this argument depends on the specific flash device being used, and this argument value can be found in the flash device datasheet. The flash devices can be supported are shown as below:

```
EPCQ16, EPCQ32, EPCQ64, EPCQ128, EPCQ256, N25Q512, EPCQ512,
EPCQL512, EPCQL1024
```

More Micron flash devices are supported in future, and being updated into this document.

Arguments

- *flash_info: Pointer to general flash device structure.
- sectors_to_lock: Block protection bits, including the top/bottom (TB) bit in the EPCQ or QSPI, according to the device. For example, in the EPCQ128 device, the bits are Bit4=TB Bit3=BP3 Bit2=BP2 Bit1=BP1 Bit0=BP0.

Return

- ***0 > Success**
- **-EINVL > Invalid arguments**
- **-ETIME > Time out and skipping the looping after 0.7 sec**
- **-ENOLCK > Sectors lock failed**


7.11. Using DMA Devices

The HAL provides a device abstraction model for direct memory access (DMA) devices. These are peripherals that perform bulk data transactions from a data source to a destination. Sources and destinations can be memory or another device, such as an Ethernet connection.

In the HAL DMA device model, there are two categories of DMA transactions: transmit and receive. The HAL provides two device drivers to implement transmit channels and receive channels. A transmit channel takes data in a source buffer and transmits it to a destination device. A receive channel receives data from a device and deposits it in a destination buffer. Depending on the implementation of the underlying hardware, software might have access to only one of these two endpoints.

Copying data from memory to memory involves both receive and transmit DMA channels simultaneously.

Figure 11. Three Basic Types of DMA Transactions



The API for access to DMA devices is defined in `sys/alt_dma.h`.

For more information about the use of these functions, refer to the *HAL API Reference* section.

DMA devices operate on the contents of physical memory, therefore when reading and writing data you must consider cache interactions.

For more information about cache memory, refer to the *Cache and Tightly-Coupled Memory* section.

Related Information

- [HAL API Reference](#) on page 315
- [Cache and Tightly-Coupled Memory](#) on page 283

7.11.1. DMA Transmit Channels

DMA transmit requests are queued using a DMA transmit device handle. To obtain a handle, use the function `alt_dma_txchan_open()`. This function takes a single argument, the name of a device to use, as defined in `system.h`.

Example 6–12. Obtaining a File Handle for a DMA Transmit Device `dma_0`

```
#include <stddef.h>
#include "sys/alt_dma.h"
int main (void)
{
    alt_dma_txchan tx;
    tx = alt_dma_txchan_open ("/dev/dma_0");
    if (tx == NULL)
    {
        /* Error */
    }
    else
    {
        /* Success */
    }
    return 0;
}
```

You can use this handle to post a transmit request using `alt_dma_txchan_send()`. The prototype is:

```
typedef void (alt_txchan_done)(void* handle);

int alt_dma_txchan_send (alt_dma_txchan dma,
    const void* from,
    alt_u32 length,
    alt_txchan_done* done,
    void* handle);
```

Calling `alt_dma_txchan_send()` posts a transmit request to channel `dma`. Argument `length` specifies the number of bytes of data to transmit, and argument `from` specifies the source address. The function returns before the full DMA transaction completes. The return value indicates whether the request is successfully queued. A negative return value indicates that the request failed. When the transaction completes, the user-supplied function `done` is called with argument `handle` to provide notification.



Two additional functions are provided for manipulating DMA transmit channels: `alt_dma_txchan_space()`, and `alt_dma_txchan_ioctl()`. The `alt_dma_txchan_space()` function returns the number of additional transmit requests that can be queued to the device. The `alt_dma_txchan_ioctl()` function performs device-specific manipulation of the transmit device.

Note: If you are using the Avalon Memory-Mapped® (Avalon-MM®) DMA device to transmit to hardware (not memory-to-memory transfer), call the `alt_dma_txchan_ioctl()` function with the request argument set to `ALT_DMA_TX_ONLY_ON`.

For more information, refer to the *HAL API Reference* section.

Related Information

[HAL API Reference](#) on page 315

7.11.2. DMA Receive Channels

DMA receive channels operate similarly to DMA transmit channels. Software can obtain a handle for a DMA receive channel using the `alt_dma_rxchan_open()` function. You can then use the `alt_dma_rxchan_prepare()` function to post receive requests. The prototype for `alt_dma_rxchan_prepare()` is:

```
typedef void (alt_rxchan_done)(void* handle, void* data);

int alt_dma_rxchan_prepare (alt_dma_rxchan dma,
    void* data,
    alt_u32 length,
    alt_rxchan_done* done,
    void* handle);
```

A call to this function posts a receive request to channel `dma`, for up to `length` bytes of data to be placed at address `data`. This function returns before the DMA transaction completes. The return value indicates whether the request is successfully queued. A negative return value indicates that the request failed. When the transaction completes, the user-supplied function `done()` is called with argument `handle` to provide notification and a pointer to the receive data.

Certain errors can prevent the DMA transfer from completing. Typically this is caused by a catastrophic hardware failure; for example, if a component involved in the transfer fails to respond to a read or write request. If the DMA transfer does not complete (that is, less than `length` bytes are transferred), function `done()` is never called.

Two additional functions are provided for manipulating DMA receive channels: `alt_dma_rxchan_depth()` and `alt_dma_rxchan_ioctl()`.

Note: If you are using the Avalon-MM DMA device to receive from hardware (not memory-to-memory transfer), call the `alt_dma_rxchan_ioctl()` function with the request argument set to `ALT_DMA_RX_ONLY_ON`.

`alt_dma_rxchan_depth()` returns the maximum number of receive requests that can be queued to the device. `alt_dma_rxchan_ioctl()` performs device-specific manipulation of the receive device.

```
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include "sys/alt_dma.h"
#include "alt_types.h"
/* flag used to indicate the transaction is complete */
volatile int dma_complete = 0;
/* function that is called when the transaction completes */
void dma_done (void* handle, void* data)
{
    dma_complete = 1;
}
int main (void)
{
    alt_u8 buffer[1024];
    alt_dma_rxchan rx;
    /* Obtain a handle for the device */
    if ((rx = alt_dma_rxchan_open ("/dev/dma_0")) == NULL)
    {
        printf ("Error: failed to open device\n");
        exit (1);
    }
    else
    {
        /* Post the receive request */
        if (alt_dma_rxchan_prepare (rx, buffer, 1024, dma_done, NULL) <
0)
        {
            printf ("Error: failed to post receive request\n");
            exit (1);
        }
        /* Wait for the transaction to complete */
        while (!dma_complete);
        printf ("Transaction complete\n");
        alt_dma_rxchan_close (rx);
    }
    return 0;
}
```

Related Information

[HAL API Reference](#) on page 315

7.11.2.1. Memory-to-Memory DMA Transactions

```
#include <stdio.h>
#include <stdlib.h>
#include "sys/alt_dma.h"
#include "system.h"
static volatile int rx_done = 0;
/*
 * Callback function that obtains notification that the data
 * is received.*/
static void done (void* handle, void* data)
{
    rx_done++;
}
/*
 *
```




```

*/
int main (int argc, char* argv[], char* envp[])
{
    int rc;
    alt_dma_txchan txchan;
    alt_dma_rxchan rxchan;
    void* tx_data = (void*) 0x901000; /* pointer to data to send */
    void* rx_buffer = (void*) 0x902000; /* pointer to rx buffer */
    /* Create the transmit channel */
    if ((txchan = alt_dma_txchan_open("/dev/dma_0")) == NULL)
    {
        printf ("Failed to open transmit channel\n");
        exit (1);
    }
    /* Create the receive channel */
    if ((rxchan = alt_dma_rxchan_open("/dev/dma_0")) == NULL)
    {
        printf ("Failed to open receive channel\n");
        exit (1);
    }

    /* Post the transmit request */
    if ((rc = alt_dma_txchan_send (txchan,
        tx_data,
        128,
        NULL,
        NULL)) < 0)
    {
        printf ("Failed to post transmit request, reason = %i\n", rc);
        exit (1);
    }
    /* Post the receive request */
    if ((rc = alt_dma_rxchan_prepare (rxchan,
        rx_buffer,
        128,
        done,
        NULL)) < 0)
    {
        printf ("Failed to post read request, reason = %i\n", rc);
        exit (1);
    }
    /* wait for transfer to complete */
    while (!rx_done);
    printf ("Transfer successful!\n");
    return 0;
}

```

7.12. Using Interrupt Controllers

The HAL supports two types of interrupt controllers:

- The Nios II internal interrupt controller
- An external interrupt controller component

For more information about working with interrupt controllers, refer to the "Exception Handling" chapter.

Related Information

[Exception Handling](#) on page 244

7.13. Reducing Code Footprint in Embedded Systems

Code size is always a concern for embedded systems developers, because there is a cost associated with the memory device that stores code. The ability to control and reduce code size is important in controlling this cost.

The HAL environment is designed to include only those features that you request, minimizing the total code footprint. If your Nios II hardware system contains exactly the peripherals used by your program, the HAL contains only the drivers necessary to control the hardware.

The following sections describe options to consider when you need to further reduce code size. The **hello_world_small** example project demonstrates the use of some of these options to reduce code size to the absolute minimum.

Implementing the options in the following sections entails making changes to BSP settings.

For more information about manipulating BSP settings, refer to the "HAL BSP Settings".

Related Information

[HAL BSP Settings](#) on page 158

7.13.1. Enable Compiler Optimizations

A number of **nios2-elf-gcc** compiler switches may be of use when optimizing code for small RAM footprints. These switches may be set directly on the compiler command line (typically in a Makefile, in the CFLAGS definition) or by the BSP GUI editor settings.

- **-fno-delete-null-pointer-checks:** (IMPORTANT!) You should always set this switch if your design includes valid data at address zero. If you do not, **nios2-elf-gcc** may silently produce incorrect code, since the C standard specifies that a NULL pointer must never be dereferenced. GCC v. 4.9 is particularly prone to this.
- **-Os:** This is the most important compiler switch when optimizing for space. This instructs **nios2-elf-gcc** to pervasively optimize for space rather than speed. (But you may wish to use **-Og** when debugging. This generates code easier to understand in the debugger.)
- **-fno-exceptions:** If you are coding a small RAM footprint program in C++ (risky, because C++ tends to add unwanted overhead) and attempting to avoid linking in C++ exception handling code to save space, this switch can dissuade **nios2-elf-g++** from linking in the exception handling code "just to be safe" in cases where it is not sure whether exception handling is needed.
- **-mgpopt=global:** This switch improves code in both space and speed relative to the **-mgpopt=local** default. You should always use **-mgpopt=global** unless you using different **-Gn** compile switch settings for different compilation units, which should seldom if ever be the case.
- **-mgpopt=data:** This improves code in both space and speed relative to **-mgpopt=global** if all of your data fits in 64 KB of address space, which is often the case for small embedded projects. You may need to edit your linker script to ensure that **_gp** is defined to be 32 KB beyond the start of your 64 KB of data. (You may use the **"-Wl,-verbose"** compiler switch to display your current linker script and the **"-T"** compiler switch to specify a different linker script.)



- **-gpopt=all:** This improved code in both space and speed relative to "**-mgpopt=data**" if all of your data AND code fit in 64 KB of address space. As above, you may need to modify your linker script to set **_gp** to be 32 KB beyond the start of your 64 KB of combined code and data.
- **-ffunction-sections:** This places each function in a separate code section in the **.o** file, making it possible for **ld** to produce smaller executables by not linking in unused functions. This results in larger **.o** files (due to the increased number of code section headers) and in slower links (since **ld** must process the increased number of code section headers) but that is rarely an issue on contemporary machines.
- **-ffunction-sections:** As above, but placing each global data item in its own **.o** file section.

Related Information

[Specifying BSP Defaults](#) on page 122

7.13.2. Use Reduced Device Drivers

Some devices provide two driver variants, a fast variant and a small variant. The feature sets provided by these two variants are device specific. The fast variant is full-featured, and the small variant provides a reduced code footprint.

By default the HAL always uses the fast driver variants. You can select the reduced device driver for all hardware components, or for an individual component, through HAL BSP settings.

The small footprint option might also affect other peripherals. Refer to each peripheral's data sheet for complete details of its driver's small footprint behavior.

Table 35. Intel FPGA Peripherals Offering Small Footprint Drivers

Peripheral	Small Footprint Behavior
UART	Polled operation, rather than IRQ-driven
JTAG UART	Polled operation, rather than IRQ-driven
Common flash interface controller	Driver excluded in small footprint mode
LCD module controller	Driver excluded in small footprint mode
EPCS serial configuration device	Driver excluded in small footprint mode

7.13.3. Reduce the File Descriptor Pool

The file descriptors that access character mode devices and files are allocated from a file descriptor pool. You can change the size of the file descriptor pool through a BSP setting. The default is 32.

7.13.4. Use `/dev/null`

At boot time, standard input, standard output, and standard error are all directed towards the null device, that is, **/dev/null**. This direction ensures that calls to `printf()` during driver initialization do nothing and therefore are harmless. After all drivers are installed, these streams are redirected to the channels configured in the HAL. The footprint of the code that performs this redirection is small, but you can

eliminate it entirely by selecting `null` for `stdin`, `stdout`, and `stderr`. This selection assumes that you want to discard all data transmitted on standard out or standard error, and your program never receives input through `stdin`. You can control the assignment of `stdin`, `stdout`, and `stderr` channels by manipulating BSP settings.

7.13.5. Use a Smaller File I/O Library

7.13.5.1. Definition of "`asnprintf()`"

`newlib` implements a maze of 22 `printf()` variants, all based on the same core engine, and all with slightly different interfaces. Some are specified by the C standard, some by Posix, some are GNU extensions, and some are `newlib` extensions. The `newlib libc` web page documents the functions that conform to their respective standards.

For more information about `libc`, refer to the "The Red Hat `newlib` C Library" web page.

The 22 variants fill a four-dimensional space of design alternatives:

- Plain vs `varargs`
- File vs buffer output
- Output buffer management alternatives:
 - Fixed buffer, unknown length
 - Fixed buffer, known length
 - `malloc()`-ed-and-returned buffer
 - `realloc()`-able buffer
- Plain vs no-floating-point formatting support

The map to the maze is the set of prefix chars.

`v*printf` (mnemonic: `v-for-varargs`)

The canonical `printf()` functions take a variable number of arguments including one for each percent-specifier in the format string. This is convenient for you, but inconvenient for wrapper functions taking a variable number of arguments and then doing some sort of value-added before invoking the regular `printf()` library, because C provides no convenient, portable way for a function to read a variable number of arguments and then pass them to another function taking a variable number of arguments. Consequently, for each plain `printf()` function, the C library provides a `v*printf` variant which accepts the extra arguments in `varargs` vector format.

The "plain" (variable number of arguments) `printf` functions are:

- `fprintf()`
- `printf()`
- `asprintf()`
- `asnprintf()`
- `snprintf()`



- `sprintf()`
- `fiprintf()`
- `iprintf()`
- `asiprintf()`
- `asniprintf()`
- `sniprintf()`
- `siprintf()`

The fixed-number-of-argument (vararg-based) variants are:

- `vprintf()`
- `vasprintf()`
- `vasnprintf()`
- `vsprintf()`
- `vsnprintf()`
- `viprintf()`
- `vasiprintf()`
- `vasniprintf()`
- `vsiprintf()`
- `vsniprintf()`

***s*printf (mnemonic: prints to string buffer)**

The canonical `printf()` function prints to an output stream; the `*s*printf` functions instead print into a RAM buffer, allowing the buffered results to be further processed. The functions in this family are:

- `asprintf()`
- `asnprintf()`
- `snprintf()`
- `sprintf()`
- `vasprintf()`
- `vasnprintf()`
- `vsprintf()`
- `vsnprintf()`
- `asiprintf()`
- `asniprintf()`
- `sniprintf()`
- `siprintf()`
- `vasiprintf()`
- `vasniprintf()`

- `vsprintf()`
- `vsnprintf()`

These functions differ in part in how the destination buffer is managed:

- The original functions in this family, like `sprintf` took a buffer pointer as input and wrote into it. Since the length of the buffer was not given, these functions would frequently overrun the given buffer, resulting in reliability and security issues. The functions in this family are:
 - `sprintf()`
 - `vsprintf()`
 - `snprintf()`
 - `vsnprintf()`
- ***sn*printf (mnemonic: 'n' for number of bytes in buffer):** variants attempted to deal with this problem by passing a buffer length as well as a buffer, allowing the function to avoid overrunning the buffer. This mitigates the security issues but results in incorrect output when the buffer is insufficient. The functions in this family are:
 - `snprintf()`
 - `vsnprintf()`
 - `sniprintf()`
 - `vsniprintf()`
- ***as*printf (mnemonic: 'a' for aallocate):** variants deal with this problem by `malloc()`ing and returning the buffer holding the result string. The caller must then `free()` the buffer. This avoids the security and reliability issues at the cost of significant added de/allocation overhead. The functions in this family are:
 - `asprintf()`
 - `vasprintf()`
 - `asiprintf()`
 - `vasiprintf()`
- ***asn*printf:** variants try to reduce this overhead by taking a buffer and a limit and `realloc()`ing it only if the output won't fit in the provided buffer. The functions in this family are:
 - `asnprintf()`
 - `vasnprintf()`
 - `asniprintf()`
 - `vasniprintf()`

***i*printf (mnemonic: 'i' for 'integer-only)**

The usual `printf()` functions support formatting of floating point numbers. Consequently they not only contain a fair amount of logic to do the actual formatting of floating point numbers, but can also link into the executable image such things as a floating point emulation library. If the application does not actually use floating point



numbers, and if a small RAM footprint is desired, this can be very counterproductive. Consequently, `newlib` defines a parallel set of `printf` functions which lack floating-point formatting support.

The usual set of `printf()` functions is:

- `fprintf()`
- `vprintf()`
- `printf()`
- `asprintf()`
- `asnprintf()`
- `snprintf()`
- `sprintf()`
- `vasprintf()`
- `vasnprintf()`
- `vsprintf()`
- `vsnprintf()`

The parallel set of no-floating-point formatting support `printf` functions is:

- `fiprintf()`
- `iprintf()`
- `viprintf()`
- `asiprintf()`
- `asniprintf()`
- `sniprintf()`
- `siprintf()`
- `vasiprintf()`
- `vasniprintf()`
- `vsiprintf()`
- `vsniprintf()`

Note: Despite the mnemonic, these functions are not really integer-only: They also support (for example) unsigned, char and string values.

Lumping all the above variants together, the full list of `printf()` functions supported by `newlib` is:

- `fprintf()`
- `vprintf()`
- `printf()`
- `asprintf()`
- `asnprintf()`

- `snprintf()`
- `sprintf()`
- `vasprintf()`
- `vasnprintf()`
- `vsprintf()`
- `vsnprintf()`
- `fiprintf()`
- `iprintf()`
- `viprintf()`
- `asiprintf()`
- `asniprintf()`
- `sniprintf()`
- `siprintf()`
- `vasiprintf()`
- `vasniprintf()`
- `vsiprintf()`
- `vsniprintf()`

Additional `printf` variants supported by `newlib` libc (but not `libsmallc`!) are:

- `dprintf`, `vdprintf`: Print to a file descriptor (vs `FILE*`).
- `diprintf`, `vdiprintf`: No-floating-point-formatting versions of above.
- `fwprintf`, `swprintf`, `vfwprintf`, `vswprintf`, `vwprintf`, `wprintf`: Versions with wide-char support.

For more information about these `printf()` variants, refer to the "The Red Hat `newlib` C Library" web page.

Related Information

[The Red Hat `newlib` C Library](#)

7.13.5.2. Use the Small `newlib` C Library

The full `newlib` library functionality is often unnecessary for embedded systems, and undesirably large for systems needing a minimal RAM footprint. Intel FPGA provides a reduced-functionality reduced-size "Small C" version of `newlib` which allows smaller RAM footprints to be achieved.

The Intel FPGA "Small C" `newlib` implementation is selected via the `-msmallc` command line option to **`nios2-elf-gcc`**.

When using the GUI interface, you may select the small `newlib` library through the "Small C" BSP setting.



Table 36 on page 193 summarizes the differences between the Nios II "Normal C" and "Small C" newlib library versions.

You can select the small newlib library through BSP settings.

Table 36. Comparison of Nios II "Small C" and "Normal C" newlib Libraries


Limitation	Functions Affected
Both Small C and Normal C libraries implement the traditional <code>printf()</code> family of routines. However, in Small C, floating point formatting is not implemented because the %f and %g options are not supported.	<pre> asnprintf() asprintf() fprintf() printf() snprintf() sprintf() vasnprintf() vasprintf() vprintf() vsnprintf() vsprintf() </pre>
Both Small C and Normal C libraries implement alternate integer-only <code>printf()</code> functions with no %f and %g support. The functionality of these functions are identical between Small C and Normal C libraries. Using these can save RAM and make core portable between the Small C and Normal C libraries.	<pre> asiprintf() asniprintf() fiprintf() iprintf() siprintf() sniprintf() vasiprintf() vasniprintf() viprintf() vsiprintf() vsniprintf() </pre>
Wide-character functions are implemented in the Normal C but NOT in the Small C library.	<p>These functions are provided ONLY in the Normal C library:</p> <pre> fgetwc() fgetws() fputsw() fputwc() fwprintf() fwide() fwprintf() fwscanf() fwscanf() getw() getwc() getwchar() putw() putwc() putwchar() swprintf() ungetwc() vfwprintf() vfwscanf() vswprintf() vwprintf() wbuf() wprintf() wscanf() wsetup() </pre>
The <code>scanf()</code> family of routines is supported in the Normal C but NOT in the Small C library.	<p>These functions are provided ONLY in the Normal C library:</p> <pre> fiscanf() fscanf() fwscanf() iscanf() scanf() siscanf() sscanf() swscanf() vfscanf() vfwscanf() viscanf() </pre>

continued...



Limitation	Functions Affected
	<code>vscanf()</code> <code>vswscanf()</code> <code>wscanf()</code>
Seeking is supported in the Normal C but NOT in the Small C library.	These functions are provided ONLY in the Normal C library: <code>fseek()</code> <code>ftell()</code>
The Small C library has no support for opening or closing FILE * . Only pre-opened stdout , stderr , and stdin are available.	These functions are provided ONLY in the Normal C Library: <code>fopen()</code> <code>fclose()</code> <code>fdopen()</code> <code>fcloseall()</code> <code>fileno()</code>
The Small C library implements NO buffering of stdio.h() output routines.	These functions provide no buffering in the Small C library: <code>fiprintf()</code> <code>fputc()</code> <code>fputs()</code> <code>perror()</code> <code>putc()</code> <code>putchar()</code> <code>puts()</code> <code>printf()</code> These functions are provided ONLY in the Normal C Library: <code>setbuf</code> <code>setvbuf</code>
The Small C library provides NO stdio.h() input routines.	These functions are provided ONLY in the Normal C library: <code>fgetc()</code> <code>fgets()</code> <code>fgetwc()</code> <code>fgetws()</code> <code>fiscanf()</code> <code>gets()</code> <code>fread()</code> <code>fscanf()</code> <code>fwsscanf()</code> <code>getc()</code> <code>getchar()</code> <code>getline()</code> <code>gets()</code> <code>getw()</code> <code>getwchar()</code> <code>iscanf()</code> <code>scanf()</code> <code>sscanf()</code> <code>swscanf()</code> <code>vfscanf()</code> <code>vfwscanf()</code> <code>viscanf()</code> <code>vscanf()</code> <code>vswscanf()</code> <code>vwsscanf()</code> <code>wscanf()</code>
The Small C library provides NO support for locale.	These functions are provided ONLY in the Normal C library: <code>setlocale()</code> <code>localeconv()</code>

Note: These functions are a Nios II extension. GCC does not implement them in the small `newlib` C library.



Note: The small `newlib` C library does not support MicroC/OS-II.

For more information about the Intel FPGA "Small C" version of the `newlib` C library, refer to the `newlib` documentation installed with the Nios II EDS. You can get to this location by clicking on the Windows **Start** menu, and then navigating to **Programs > Intel FPGA > Nios II > Nios II Documentation**. You can also find this information by referring to the "Red Hat `newlib` C Library Documentation" web page.

Note: The Intel FPGA "Small C" version of the `newlib` C library differs considerably from the normal C version. [Table 36](#) on page 193 summarizes the differences.

Related Information

[Red Hat `newlib` C Library Documentation web page](#)

7.13.5.3. Use UNIX-Style File I/O

If you need to reduce the code footprint further, you can omit the `newlib` C library, and use the UNIX-style API.

For more information, refer to the "UNIX-Style Interface" chapter.

The Nios II EDS provides ANSI C file I/O, in the `newlib` C library, because there is a per-access performance overhead associated with accessing devices and files using the UNIX-style file I/O functions. The ANSI C file I/O provides buffered access, thereby reducing the total number of hardware I/O accesses performed. Also the ANSI C API is more flexible and therefore easier to use. However, these benefits are gained at the expense of code footprint.

Related Information

[UNIX-Style Interface](#) on page 162

7.13.5.4. Emulate ANSI C Functions

If you choose to omit the full implementation of `newlib`, but you need a limited number of ANSI-style functions, you can implement them easily using UNIX-style functions.

Example 6–15. Unbuffered `getchar()`

```
/* getchar: unbuffered single character input */
int getchar ( void )
{
    char c;
    return ( read ( 0, &c, 1 ) == 1 ) ? ( unsigned char ) c : EOF;
}
```

This example is from the book: *The C Programming Language, Second Edition*, by Brian W. Kernighan and Dennis M. Ritchie. This standard textbook contains many other useful functions.

7.13.6. Use the Lightweight Device Driver API

The lightweight device driver API allows you to minimize the overhead of accessing device drivers. It has no direct effect on the size of the drivers themselves, but lets you eliminate driver API features which you might not need, reducing the overall size of the HAL code.

The lightweight device driver API is available for character-mode devices. The following device drivers support the lightweight device driver API:

- JTAG UART
- UART
- Optrex 16207 LCD

For these devices, the lightweight device driver API conserves code space by eliminating the dynamic file descriptor table and replacing it with three static file descriptors, corresponding to `stdin`, `stdout`, and `stderr`. Library functions related to opening, closing, and manipulating file descriptors are unavailable, but all other library functionality is available. You can refer to `stdin`, `stdout`, and `stderr` as you would to any other file descriptor. You can also refer to the following predefined file numbers:

```
#define STDIN 0
#define STDOUT 1
#define STDERR 2
```

This option is appropriate if your program has a limited need for file I/O. The Intel FPGA host-based file system and the Intel FPGA read-only zip file system are not available with the reduced device driver API. You can select the reduced device drivers through BSP settings.

By default, the lightweight device driver API is disabled.

For more information about the lightweight device driver API, refer to the Developing Device Drivers for the Hardware Abstraction Layer section.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

7.13.7. Use the Minimal Character-Mode API

If you can limit your use of character-mode I/O to very simple features, you can reduce code footprint by using the minimal character-mode API. This API includes the following functions:

- `alt_printf()`
- `alt_putchar()`
- `alt_putstr()`
- `alt_getchar()`

These functions are appropriate if your program only needs to accept command strings and send simple text messages. Some of them are helpful only in conjunction with the lightweight device driver API.

For more information, refer to the “Use the Lightweight Device Driver API” chapter.

To use the minimal character-mode API, include the header file `sys/alt_stdio.h`.

The following sections outline the effects of the functions on code footprint.



Related Information

Use the [Lightweight Device Driver API](#) on page 195

7.13.7.1. alt_printf()

This function is similar to `printf()`, but supports only the `%c`, `%s`, `%x`, and `%%` substitution strings. `alt_printf()` takes up substantially less code space than `printf()`, regardless whether you select the lightweight device driver API. `alt_printf()` occupies less than 1 KBKB with compiler optimization level `-O2`.

7.13.7.2. alt_putchar()

Equivalent to `putchar()`. In conjunction with the lightweight device driver API, this function further reduces code footprint. In the absence of the lightweight API, it calls `putchar()`.

7.13.7.3. alt_putstr()

Similar to `puts()`, except that it does not append a newline character to the string. In conjunction with the lightweight device driver API, this function further reduces code footprint. In the absence of the lightweight API, it calls `puts()`.

7.13.7.4. alt_getchar()

Equivalent to `getchar()`. In conjunction with the lightweight device driver API, this function further reduces code footprint. In the absence of the lightweight API, it calls `getchar()`.

For more information about the minimal character-mode functions, refer to the "HAL API Reference" chapter.

Related Information

[HAL API Reference](#) on page 315

7.13.8. Eliminate Unused Device Drivers

If a hardware device is present in the system, by default the Nios II development flows assume the device needs drivers, and configure the HAL BSP accordingly. If the HAL can find an appropriate driver, it creates an instance of this driver. If your program never actually accesses the device, resources are being used unnecessarily to initialize the device driver.

If the hardware includes a device that your program never uses, consider removing the device from the hardware. This reduces both code footprint and FPGA resource usage.

However, there are cases when a device must be present, but runtime software does not require a driver. The most common example is flash memory. The user program might boot from flash, but not use it at runtime; thus, it does not need a flash driver.

You can selectively omit any individual driver, select a specific driver version, or substitute your own driver.

For more information about controlling driver configurations, refer to the "Nios II Software Build Tools" chapter.

Another way to control the device driver initialization process is to use the free-standing environment.

For more information, refer to the "Boot Sequence and Entry Point" chapter.

Related Information

- [Boot Sequence and Entry Point](#) on page 198
- [Nios II Software Build Tools](#) on page 87
- [Boot Sequence and Entry Point](#) on page 198

7.13.9. Eliminate Unneeded Exit Code

The HAL calls the `exit()` function at system shutdown to provide a clean exit from the program. `exit()` flushes all of the C library internal I/O buffers and calls any C++ functions registered with `atexit()`. In particular, `exit()` is called on return from `main()`. Two HAL options allow you to minimize or eliminate this exit code.

7.13.9.1. Eliminate Clean Exit

To avoid the overhead associated with providing a clean exit, your program can use the function `_exit()` in place of `exit()`. This function does not require you to change source code. You can select the `_exit()` function through a BSP setting.

7.13.9.2. Eliminate All Exit Code

Many embedded systems never exit at all. In such cases, exit code is unnecessary. You can eliminate all exit code through a BSP setting.

Note: If you enable this option, ensure that your `main()` function (or `alt_main()` function) does not return.

7.13.10. Turn off C++ Support

By default, the HAL provides support for C++ programs, including default constructors and destructors. You can disable C++ support through a BSP setting.

7.14. Boot Sequence and Entry Point

Normally, your program's entry point is the function `main()`. There is an alternate entry point, `alt_main()`, that you can use to gain greater control of the boot sequence. The difference between entering at `main()` and entering at `alt_main()` is the difference between hosted and free-standing applications.

7.14.1. Hosted Versus Free-Standing Applications

The ANSI C standard defines a hosted application as one that calls `main()` to begin execution. At the start of `main()`, a hosted application presumes the runtime environment and all system services are initialized and ready to use. This is true in the HAL environment. If you are new to Nios II programming, the HAL's hosted



environment helps you come up to speed more easily, because you need not consider what devices exist in the system or how to initialize each one. The HAL initializes the whole system.

The ANSI C standard also provides for an alternate entry point that avoids automatic initialization, and assumes that the Nios II programmer initializes any needed hardware explicitly. The `alt_main()` function provides a free-standing environment, giving you complete control over the initialization of the system. The free-standing environment places on the programmer the responsibility to initialize any system features used in the program. For example, calls to `printf()` do not function correctly in the free-standing environment, unless `alt_main()` first instantiates a character-mode device driver, and redirects `stdout` to the device.

Note: Using the free-standing environment increases the complexity of writing Nios II programs, because you assume responsibility for initializing the system.

For more information about reducing code footprint, refer to and use the suggestions described in the “Reducing Code Footprint in Embedded Systems” chapter.

Note: It is easier to reduce the HAL BSP footprint by using BSP settings, than to use the free-standing mode.

The Nios II EDS provides examples of both free-standing and hosted programs.

Related Information

[Reducing Code Footprint in Embedded Systems](#) on page 186

7.14.2. Boot Sequence for HAL-Based Programs

7.14.2.1. System Initialization Code Boot Sequence

The HAL provides system initialization code in the C runtime library (**crt0.S**). This code performs the following boot sequence:

- Flushes the instruction and data cache.
- Configures the stack pointer.
- Configures the global pointer register.
- Initializes the block started by symbol (BSS) region to zeroes using the linker-supplied symbols `__bss_start` and `__bss_end`. These are pointers to the beginning and the end of the BSS region.
- If there is no boot loader present in the system, copies to RAM any linker section whose run address is in RAM, such as `.rwdata`, `.rodata`, and `.exceptions`.
For more information, refer to “[Global Pointer Register](#)” on page 6–41.
- Calls `alt_main()`.

Related Information

[Global Pointer Register](#) on page 205

7.14.2.2. Default Implementation Steps

The HAL provides a default implementation of the `alt_main()` function, which performs the following steps:

- Calls the `alt_irq_init()` function, located in **`alt_sys_init.c`**.
`alt_irq_init()` initializes the hardware interrupt controller. The Nios II development flow creates the file `alt_sys_init.c` for each HAL BSP.
- Calls `ALT_OS_INIT()` to perform any necessary operating system specific initialization. For a system that does not include an operating system (OS) scheduler, this macro has no effect.
- If you are using the HAL with an operating system, initializes the `alt_fd_list_lock` semaphore, which controls access to the HAL file systems.
- Enables interrupts.
- Calls the `alt_sys_init()` function, also located in **`alt_sys_init.c`**.
`alt_sys_init()` initializes all device drivers and software packages in the system.
- Redirects the C standard I/O channels (`stdin`, `stdout`, and `stderr`) to use the appropriate devices.
- Calls the C++ constructors, using the `_do_ctors()` function.
- Registers the C++ destructors to be called at system shutdown.
- Calls `main()`.
- Calls `exit()`, passing the return code of `main()` as the input argument for `exit()`.

`alt_main.c`, installed with the Nios II EDS, provides this default implementation. The SBT copies `alt_main.c` to your BSP directory.

7.14.3. Customizing the Boot Sequence

You can provide your own implementation of the start-up sequence by simply defining `alt_main()` in your Nios II project. This gives you complete control of the boot sequence, and allows you to selectively enable HAL services. If your application requires an `alt_main()` entry point, you can copy the default implementation as a starting point and customize it to your needs.

Function `alt_main()` calls function `main()`. After `main()` returns, the default `alt_main()` enters an infinite loop. Alternatively, your custom `alt_main()` might terminate by calling `exit()`. Do not use a `return` statement.

The following line of code is the prototype for `alt_main()`:

```
void alt_main (void)
```

The HAL build environment includes mechanisms to override default HAL BSP code. This lets you override boot loaders, as well as default device drivers and other system code, with your own implementation.



`alt_sys_init.c` is a generated file, which you must not modify. However, the Nios II SBT enables you to control the generated contents of `alt_sys_init.c`. To specify the initialization sequence in `alt_sys_init.c`, you manipulate the `auto_initialize` and `alt_sys_init_priority` properties of each driver, using the `set_sw_property` Tcl command.

For more information about generated files and how to control the contents of `alt_sys_init.c`, refer to the "Nios II Software Build Tools" chapter.

For more information about `alt_sys_init.c`, refer to the "Developing Device Drivers for the Hardware Abstraction Layer" chapter.

For more information about the `set_sw_property` Tcl command, refer to the "Nios II Software Build Tools" chapter.

Related Information

- [Nios II Software Build Tools](#) on page 87
For more information about generated files and how to control the contents of `alt_sys_init.c`; and for more information about the `set_sw_property` Tcl command.
- [Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209
For more information about `alt_sys_init.c`.

7.15. Memory Usage

This section describes how the HAL uses memory and arranges code, data, stack, and other logical memory sections, in physical memory.

7.15.1. Memory Sections

By default, HAL-based systems are linked using a generated linker script that is created by the Nios II SBT. This linker script controls the mapping of code and data to the available memory sections. The autogenerated linker script creates standard code and data sections (`.text`, `.rodata`, `.rwdata`, and `.bss`), plus a section for each physical memory device in the system. For example, if a memory component named `sdram` is defined in the `system.h` file, there is a memory section named `.sdram`.

The memory devices that contain the Nios II processor's reset and exception addresses are a special case. The Nios II tools construct the 32-byte `.entry` section starting at the reset address. This section is reserved exclusively for the use of the reset handler. Similarly, the tools construct a `.exceptions` section, starting at the exception address.

In a memory device containing the reset or exception address, the linker creates a normal (nonreserved) memory section above the `.entry` or `.exceptions` section. If there is a region of memory below the `.entry` or `.exceptions` section, it is unavailable to the Nios II software.

7.15.2. Assigning Code and Data to Memory Partitions

This section describes how to control the placement of program code and data in specific memory sections. In general, the Nios II development flow specifies a sensible default partitioning. However, you might wish to change the partitioning in special situations.

For example, to enhance performance, it is a common technique to place performance-critical code and data in RAM with fast access time. It is also common during the debug phase to reset (that is, boot) the processor from a location in RAM, but then boot from flash memory in the released version of the software. In these cases, you must specify manually which code belongs in which section.

Figure 12. HAL Link Map - Unavailable Memory Region Below the .exceptions Section

Physical Memory	HAL Memory Sections
	.entry
ext_flash	.ext_flash
⋮	⋮
sdram	(unused)
	.exceptions
	.text
	.rodata
	.rwdata
	.bss
	.sdram
⋮	⋮
ext_ram	.ext_ram
⋮	⋮
epcs_controller	.epcs_controller

7.15.2.1. Simple Placement Options

The reset handler code is always placed at the base of the .reset partition. The general exception funnel code is always the first code in the section that contains the exception address. By default, the remaining code and data are divided into the following output sections:



- `.text`—All remaining code
- `.rodata`—The read-only data
- `.rwdata`—Read-write data
- `.bss`—Zero-initialized data

You can control the placement of `.text`, `.rodata`, `.rwdata`, and all other memory partitions by manipulating BSP settings.

For more information about how to control BSP settings, refer to the "HAL BSP Settings" chapter.

The Nios II BSP Editor is a very convenient way to manipulate the linker's memory map. The BSP Editor displays memory section and region assignments graphically, allowing you to see overlapping or unused sections of memory. The BSP Editor is available either through the Nios II SBT for Eclipse, or at the command line of the Nios II SBT.

For more information, refer to the "Getting Started from the Command Line" chapter.

Related Information

- [HAL BSP Settings](#) on page 158
- [Getting Started from the Command Line](#) on page 73

7.15.2.2. Advanced Placement Options

In your program source code, you can specify a target memory section for each piece of data or code. In C or C++, you can use the `section` attribute. This attribute must be placed in a function prototype; you cannot place it in the function declaration itself.

Example 6–16. Manually Assigning C Code to a Specific Memory Section

```
/* data should be initialized when using the section attribute */  
int foo __attribute__((section (".ext_ram.rwdata"))) = 0;  
void bar (void) __attribute__((section (".sdram.text")));  
void bar (void)  
{  
    foo++;  
}
```

Note:

A variable `foo` is placed in the memory named `ext_ram`, and the function `bar()` is placed in the memory named `sdram`.

In assembly you do this using the `.section` directive. For example, all code after the following line is placed in the memory device named `ext_ram`:

```
.section .ext_ram.text
```

The section names `ext_ram` and `sdram` are examples. You need to use section names corresponding to your hardware.

When creating section names, use the following extensions:

- `.text` for code: for example, `.sdram.text`
- `.rodata` for read-only data: for example, `.cfi_flash.rodata`
- `.rdata` for read-write data: for example, `.ext_ram.rdata`

For more information about the use of these features, refer to the GNU compiler and assembler documentation. This documentation is installed with the Nios II EDS. To find it, open the Nios II EDS documentation launchpad, scroll down to **Software Development**, and click **Using the GNU Compiler Collection (GCC)**.

Note: A powerful way to manipulate the linker memory map is by using the Nios II BSP Editor. With the BSP Editor, you can assign linker sections to specific physical regions, and then review a graphical representation of memory showing unused or overlapping regions. You start the BSP Editor from the Nios II Command Shell. For details about using the BSP Editor, refer to the editor's tool tips.

7.15.3. Placement of the Heap and Stack

By default, the heap and stack are placed in the same memory partition as the `.rdata` section. The stack grows downwards (toward lower addresses) from the end of the section. The heap grows upwards from the last used memory in the `.rdata` section. You can control the placement of the heap and stack by manipulating BSP settings.

By default, the HAL performs no stack or heap checking. This makes function calls and memory allocation faster, but it means that `malloc()` (in C) and `new` (in C++) are unable to detect heap exhaustion. You can enable run-time stack checking by manipulating BSP settings. With stack checking on, `malloc()` and `new()` can detect heap exhaustion.

To specify the heap size limit, set the preprocessor symbol `ALT_MAX_HEAP_BYTES` to the maximum heap size in decimal. For example, the preprocessor argument `ALT_MAX_HEAP_BYTES=1048576` sets the heap size limit to 0x100000. You can specify this command-line option through a BSP setting.

For more information about manipulating BSP settings, refer to the "HAL BSP Settings" chapter.

Stack checking has performance costs. If you choose to leave stack checking turned off, you must code your program so as to ensure that it operates within the limits of available heap and stack memory.

For more information about selecting stack and heap placement, and setting up stack checking, refer to the "Nios II Software Build Tools" chapter.

For more information about how to control BSP settings, refer to the "HAL BSP Settings" chapter.

Related Information

- [HAL BSP Settings](#) on page 158
- [Nios II Software Build Tools Reference](#) on page 396
- [Nios II Embedded Software Projects](#) on page 90


7.15.4. Global Pointer Register

The global pointer register enables fast access to global data structures in Nios II programs. The Nios II compiler implements the global pointer, and determines which data structures to access with it. You do not need to do anything unless you want to change the default compiler behavior.

The global pointer register can access a single contiguous region of 64 KB. To avoid overflowing this region, the compiler only uses the global pointer with small global data structures. A data structure is considered "small" if its size is less than or equal to a specified threshold. By default, this threshold is 8 bytes.

The small data structures are allocated to the small global data sections, `.sdata`, `.sdata2`, `.sbss`, and `.sbss2`. The small global data sections are subsections of the `.rdata` and `.bss` sections.

Figure 13. Small Global Data Sections



If the total size of the small global data structures is more than 64 KB, these data structures overflow the global pointer region. The linker produces an error message saying "Unable to reach <variable name> ... from the global pointer ... because the offset ... is out of the allowed range, -32678 to 32767."

The best solution is to use fewer global variables of size 8 bytes or less. This is the default setting for the **-Gn** switch, perhaps by combining some into records. Another solution is to place only the frequently used global variables inside the **.sdata + .sbss**.

If the previous solution fails, a quick and easy solution is to use the **-mgpopt=none** switch. This removes the 64 KB limit on the size of the **.sdata + .sbss** sections addressed by the GP register. This is accomplished at the cost of using bigger, slower (typically 3-instruction) code sequences to address such values, in place of the typically single-instruction code sequences otherwise used.

When the size of the global variable is greater than 8 bytes, by default, it gets placed outside of the **.sdata + .sbss**, and takes longer to access it. You can improve space-time performance by placing only the frequently used global variables inside the **.sdata + .sbss** leaving space available to add global variables greater than 8 bytes; and by annotating the code to place these global variables inside the **.sdata + .sbss**.

Annotating the code is show in [#unique_428/unique_428_Connect_42_example_cnm_wbq_yy](#) on page 203.

For information about manipulating project settings, refer to "HAL BSP Settings".

Related Information

- [HAL BSP Settings](#) on page 158
- [GCC Nios II Options](#)

7.15.5. Boot Modes

The processor's boot memory is the memory that contains the reset vector. This device might be an external flash or an Intel FPGA EPCS serial configuration device, or it might be an on-chip RAM. Regardless of the nature of the boot memory, HAL-based systems are constructed so that all program and data sections are initially stored in it. The HAL provides a small boot loader program that copies these sections to their run time locations at boot time. You can specify run time locations for program and data memory by manipulating BSP settings.

If the runtime location of the **.text** section is outside of the boot memory, the Intel FPGA flash programmer places a boot loader at the reset address. This boot loader is responsible for loading all program and data sections before the call to **_start**. When booting from an EPCS device, this loader function is provided by the hardware.

You can boot a Nios II processor from Intel FPGA EPCQ flash memory (EPCQx1, EPCQx4) using an Intel FPGA serial flash controller. The Intel FPGA Serial Flash Controller with Avalon interface allows Nios II processor systems to access an Intel FPGA EPCQ flash memory, which supports standard, quad and single- or dual-I/O mode. The Nios II processor Software Build Tools (SBT) supports the Nios II booting from the Intel FPGA Serial Flash Controller. In addition, a Nios II hardware abstraction layer (HAL) driver is available for the Intel FPGA Serial Flash Controller that allows an application to read, write, or erase flash.

For more information about how to build a bootable system for a Nios II processor application executing in place (XIP) from EPCQ flash, refer to *AN736: Nios II Processor Booting From Intel FPGA Serial Flash (EPCQ)*.



However, if the runtime location of the `.text` section is in the boot memory, the system does not need a separate loader. Instead the `_reset` entry point in the HAL executable program is called directly. The function `_reset` initializes the instruction cache and then calls `_start`. This initialization sequence lets you develop applications that boot and execute directly from flash memory.

When running in this mode, the HAL executable program must take responsibility for loading any sections that require loading to RAM. The `.rwdata`, `.rodata`, and `.exceptions` sections are loaded before the call to `alt_main()`, as required. This loading is performed by the function `alt_load()`. To load these functions and data into memory manually; and to load any additional sections, use the `alt_load_section()` function.

For more information about `alt_load_section()`, refer to the "HAL API Reference" chapter.

Related Information

- [HAL API Reference](#) on page 315
- [Nios II Processor Booting From Altera Serial Flash \(EPCQ\)](#)

7.16. Working with HAL Source Files

You might wish to view files in the HAL, especially header files, for reference. This section describes how to find and use HAL source files.

7.16.1. Finding HAL Files

You determine the location of HAL source files when you create the BSP. HAL source files (and other BSP files) are copied to the BSP directory.

For more information, refer to "Nios II Software Build Tools Reference" of the *Nios II Software Developer's Handbook*.

Related Information

- [Nios II Software Build Tools Reference](#) on page 396
- [Nios II Embedded Software Projects](#) on page 90

7.16.2. Overriding HAL Functions

HAL source files are copied to your BSP directory when you create your BSP. If you regenerate a BSP, any HAL source files that differ from the installation files are copied. Avoid modifying BSP files. To override default HAL code, use BSP settings, or custom device drivers or software packages.

For more information about what happens when you regenerate a BSP, refer to "Revising your BSP" in the "Nios II Software Build Tools" section.


Note: Avoid modifying HAL source files. If you modify a HAL source file, you cannot regenerate the BSP without losing your changes. This makes it difficult to keep the BSP coordinated with changes to the underlying hardware system.



For more information, refer to "Nios II Embedded Software Projects" in the "Nios II Software Build Tools" section.

Related Information

- [Nios II Software Build Tools Reference](#) on page 396
- [Nios II Embedded Software Projects](#) on page 90



8. Developing Device Drivers for the Hardware Abstraction Layer

Embedded systems typically have application-specific hardware features that require custom device drivers. This chapter describes how to develop device drivers and integrate them with the hardware abstraction layer (HAL).

This chapter also describes how to develop software packages for use with HAL board support packages (BSPs). The process of integrating a software package with the HAL is nearly identical with the process for integrating a device driver.

Confine direct interaction with the hardware to device driver code. In general, the best practice is to keep most of your program code free of low-level access to the hardware. Wherever possible, use the high-level HAL application program interface (API) functions to access hardware. This makes your code more consistent and more portable to other Nios[®] II systems that might have different hardware configurations.

When you create a new driver, you can integrate the driver with the HAL framework at one of the following two levels:

- Integration in the HAL API
- Peripheral-specific API

Note:

As an alternative to creating a driver, you can compile the device-specific code as a user library, and link it with the application. This approach is workable if the device-specific code is independent of the BSP, and does not require any of the extra services offered by the BSP, such as the ability to add definitions to the `system.h` file.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer Revision History](#) on page 15

For details on the document revision history of this chapter

8.1. Driver Integration in the HAL API

Integration in the HAL API is the preferred option for a peripheral that belongs to one of the HAL generic device model classes, such as character-mode or direct memory access (DMA) devices.

For integration in the HAL API, you write device access functions as specified in this chapter, and the device becomes accessible to software through the standard HAL API. For example, if you have a new LCD screen device that displays ASCII characters, you write a character-mode device driver. With this driver in place, programs can call the familiar `printf()` function to stream characters to the LCD screen.

Related Information

[Overview of the Hardware Abstraction Layer](#) on page 152

For more information about the descriptions of the HAL generic device model classes.

8.2. The HAL Peripheral-Specific API

If the peripheral does not belong to one of the HAL generic device model classes, you need to provide a device driver with an interface that is specific to the hardware implementation. In this case, the API to the device is separate from the HAL API. Programs access the hardware by calling the functions you provide, not the HAL API.

The up-front effort to implement integration in the HAL API is higher, but you gain the benefit of the HAL and C standard library API to manipulate devices.

For details about integration in the HAL API, refer to the "Integrating a Device Driver in the HAL" chapter.

All the other sections in this chapter apply to integrating drivers in the HAL API and creating drivers with a peripheral-specific API.

Note: Although C++ is supported for programs based on the HAL, HAL drivers can not be written in C++. Restrict your driver code to either C or assembly language. C is preferred for portability.

Related Information

[Integrating a Device Driver in the HAL](#) on page 225

8.3. Preparing for HAL Driver Development

This chapter assumes that you are familiar with C programming for the HAL.

For more information, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.


Note: This chapter uses the variable <Intel FPGA installation> to represent the location where the Intel FPGA Complete Design Suite is installed. On a Windows system, by default, that location is **c:/intelfpga/**<version number>.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

8.4. Development Flow for Creating Device Drivers

The steps to develop a new driver for the HAL depend on your device details. However, the following generic steps apply to all device classes.



1. Create the device header file that describes the registers. This header file might be the only interface required.
2. Implement the driver functionality.
3. Test from `main()`.
4. Proceed to the final integration of the driver in the HAL environment.
5. Integrate the device driver in the HAL framework.

8.5. Nios II Hardware Design Concepts

This section discusses some basic concepts behind the Intel Platform Designer (Standard) system integration tools. These concepts can enhance your understanding of the driver development process. You do not normally need to use a system integration tool when developing Nios II device drivers.

8.5.1. The Relationship Between the `.sopcinfo` File and `system.h`

The system generation tool, Platform Designer, generates the Nios II processor system hardware. Hardware designers use the system generation tool to specify the architecture of the Nios II processor system and integrate the necessary peripherals and memory. Therefore, the definitions in `system.h`, such as the name and configuration of each peripheral, are a direct reflection of design choices made in the system generation tool. These design choices are encapsulated in the `.sopcinfo` file. `system.h` is derived from the `.sopcinfo` file.

For more information about the `system.h` header file, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

8.5.2. Using the System Generation Tool to Optimize Hardware

If you find less-than-optimal definitions in `system.h`, remember that you can modify the contents of `system.h` by changing the underlying hardware with the system generation tool, Platform Designer. Before you write a device driver to accommodate imperfect hardware, it is worth considering whether the hardware can be improved easily with the system generation tool.

8.5.3. Components, Devices, and Peripherals

The Platform Designer system generation tools use the term "component" to describe hardware modules included in the system. In the context of Nios II software development, components are devices, such as peripherals or memories. In the following sections, "component" is used interchangeably with "device" and "peripheral" when the context is closely related to the system generation tool.



8.6. Accessing Hardware

Software accesses the hardware with macros that abstract the memory-mapped interface to the device. This section describes the macros that define the hardware interface for each device.

All components provide a directory that defines the device hardware and software. For example, each component provided in the Intel Quartus Prime software has its own directory in the <Intel FPGA installation>/**ip/altera/sopc_builder_ip** directory. Many components provide a header file that defines their hardware interface. The header file is named <component name>_regs.h, included in the **inc** subdirectory for the specific component. For example, the Intel FPGA-provided JTAG UART component defines its hardware interface in the file <Intel FPGA installation>/ip/altera/sopc_builder_ip/altera_avalon_jtag_uart/inc/altera_avalon_jtag_uart_regs.h.



The `_regs.h` header file defines the following access macros for the component:

- Register access macros that provide either or both a read or write macro for each register in the component that supports the operation. The macros are:

- `IORD_<component name>_<register name> (<component base address>)`
- `IOWR_<component name>_<register name> (<component base address>, <data>)`

For example, `altera_avalon_jtag_uart_regs.h` defines the following macros:

- `IORD_ALTERA_AVALON_JTAG_UART_DATA()`
- `IOWR_ALTERA_AVALON_JTAG_UART_DATA()`
- `IORD_ALTERA_AVALON_JTAG_UART_CONTROL()`
- `IOWR_ALTERA_AVALON_JTAG_UART_CONTROL()`

- Register address macros that return the physical address for each register in a component. The address register returned is the component's base address + the specified register offset value. These macros are named **`IOADDR_<component name>_<register name> (<component base address>)`**.

For example, `altera_avalon_jtag_uart_regs.h` defines the following macros:

- `IOADDR_ALTERA_AVALON_JTAG_UART_DATA()`
- `IOADDR_ALTERA_AVALON_JTAG_UART_CONTROL()`

Use these macros only as parameters to a function that requires the specific address of a data source or destination. For example, a routine that reads a stream of data from a particular source register in a component might require the physical address of the register as a parameter.

- Bit-field masks and offsets that provide access to individual bit-fields in a register. These macros have the following names:

- `<component name>_<register name>_<name of field>_MSK`—A bit-mask of the field
- `<component name>_<register name>_<name of field>_OFST`—The bit offset of the start of the field

For example, `ALTERA_AVALON_UART_STATUS_PE_MSK` and `ALTERA_AVALON_UART_STATUS_PE_OFST` access the `pe` field of the status register.

Access a device's registers only with the macros defined in the `_regs.h` file. You must use the register access functions to ensure that the processor bypasses the data cache when reading and or writing the device. Do not use hard-coded constants, because they make your software susceptible to changes in the underlying hardware.

If you are writing the driver for a completely new hardware device, you must prepare the `_regs.h` header file.

For more information about a complete example of the `_regs.h` file, refer to the component directory for any of the Intel FPGA-supplied components, such as `<Intel FPGA installation>/ip/sopc_builder_ip/altera_avalon_jtag_uart/inc`.

Related Information

- [AN 459: Guidelines for Developing a Nios II HAL Device Driver](#)
For more information about developing device drivers for HAL BSPs.
- [Cache and Tightly-Coupled Memory](#) on page 283
For more information about the effects of cache management and device access.

8.7. Creating Embedded Drivers for HAL Device Classes

The HAL supports a number of generic device model classes. By writing a device driver as described in this section, you describe to the HAL an instance of a specific device that falls into one of its known device classes. This section defines a consistent interface for driver functions so that the HAL can access the driver functions uniformly.

The following sections define the API for the following classes of devices:

- Character-mode devices
- File subsystems
- DMA devices
- Timer devices used as system clock
- Timer devices used as timestamp clock
- Flash memory devices
- Ethernet devices

The following sections describe how to implement device drivers for each class of device, and how to register them for use in HAL-based systems.

Related Information

[Overview of the Hardware Abstraction Layer](#) on page 152

8.7.1. Character-Mode Device Drivers

8.7.1.1. Create a Device Instance

For a device to be made available as a character mode device, it must provide an instance of the `alt_dev` structure. The `alt_dev` structure, defined in `<Nios II EDS install path>/components/altera_hal/HAL/inc/sys/alt_dev.h`, is essentially a collection of function pointers. These functions are called in response to application accesses to the HAL file system. For example, if you call the function `open()` with a file name that corresponds to this device, the result is a call to the `open()` function provided in this structure.

Example 7–1. `alt_dev` Structure

```
typedef struct {  
    alt_llist llist; /* for internal use */  
    const char* name;  
    int (*open) (alt_fd* fd, const char* name, int flags, int mode);  
    int (*close) (alt_fd* fd);
```



```
int (*read) (alt_fd* fd, char* ptr, int len);  
int (*write) (alt_fd* fd, const char* ptr, int len);  
int (*lseek) (alt_fd* fd, int ptr, int dir);  
int (*fstat) (alt_fd* fd, struct stat* buf);  
int (*ioctl) (alt_fd* fd, int req, void* arg);  
} alt_dev;
```

For more information about `open()`, `close()`, `read()`, `write()`, `lseek()`, `fstat()`, and `ioctl()`, refer to the "HAL API Reference" section.

Related Information

[HAL API Reference](#) on page 315

8.7.1.1.1. Modifying the Global Error Status, `errno`

None of these functions directly modifies the global error status, `errno`. Instead, the return value is the negation of the appropriate error code provided in `errno.h`.

For example, the `ioctl()` function returns `-ENOTTY` if it cannot handle a request rather than set `errno` to `ENOTTY` directly. The HAL system routines that call these functions ensure that `errno` is set accordingly.

The function prototypes for these functions differ from their application level counterparts in that they each take an input file descriptor argument of type `alt_fd*` rather than `int`.

A new `alt_fd` structure is created on a call to `open()`. This structure instance is then passed as an input argument to all function calls made for the associated file descriptor.

The following code defines the `alt_fd` structure:

```
typedef struct  
{  
    alt_dev* dev;  
    void* priv;  
    int fd_flags;  
} alt_fd;
```

where:

- `dev` is a pointer to the device structure for the device being used.
- `fd_flags` is the value of `flags` passed to `open()`.
- `priv` is a reserved, implementation-dependent argument, defined by the driver. If the driver requires any special, non-HAL-defined values to be maintained for each file or stream, you can store them in a data structure, and use `priv` maintains a pointer to the structure. The HAL ignores `priv`.

Allocate storage for the data structure in your `open()` function (pointed to by the `alt_dev` structure). Free the storage in your `close()` function.

Note: To avoid memory leaks, ensure that the `close()` function is called when the file or stream is no longer needed.

8.7.1.1.2. Default Behavior for Functions Defined in `alt_dev`

A driver is not required to provide all of the functions in the `alt_dev` structure. If a given function pointer is set to `NULL`, a default action is used instead.

Table 37. Default Behavior for Functions Defined in `alt_dev`

Function	Default Behavior
<code>open</code>	Calls to <code>open()</code> for this device succeed, unless the device was previously locked by a call to <code>ioctl()</code> with <code>req = TIOCEXCL</code> .
<code>close</code>	Calls to <code>close()</code> for a valid file descriptor for this device always succeed.
<code>read</code>	Calls to <code>read()</code> for this device always fail.
<code>write</code>	Calls to <code>write()</code> for this device always fail.
<code>lseek</code>	Calls to <code>lseek()</code> for this device always fail.
<code>fstat</code>	The device identifies itself as a character mode device.
<code>ioctl</code>	<code>ioctl()</code> requests that cannot be handled without reference to the device fail.

In addition to the function pointers, the `alt_dev` structure contains two other fields: `llist` and `name`. `llist` is for internal use, and must always be set to the value `ALT_LLIST_ENTRY`. `name` is the location of the device in the HAL file system and is the name of the device as defined in `system.h`.

8.7.1.2. Register a Character Device

After you create an instance of the `alt_dev` structure, the device must be made available to the system by registering it with the HAL and by calling the following function:

```
int alt_dev_reg (alt_dev* dev)
```

This function takes a single input argument, which is the device structure to register. The return value is zero upon success. A negative return value indicates that the device cannot be registered.

After a device is registered with the HAL file system, you can access it through the HAL API and the ANSI C standard library. The node name for the device is the name specified in the `alt_dev` structure.


For more information, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

8.7.2. File Subsystem Drivers

A file subsystem device driver is responsible for handling file accesses beneath a specified mount point in the global HAL file system.



8.7.2.1. Create a Device Instance

Creating and registering a file system is very similar to creating and registering a character-mode device. To make a file system available, create an instance of the `alt_dev` structure.

For more information, refer to the "Character-Mode Device Drivers" chapter.

The only distinction is that the `name` field of the device represents the mount point for the file subsystem. Of course, you must also provide any necessary functions to access the file subsystem, such as `read()` and `write()`, similar to the case of the character-mode device.

Note: If you do not provide an implementation of `fstat()`, the default behavior returns the value for a character-mode device, which is incorrect behavior for a file subsystem.

Related Information

[Character-Mode Device Drivers](#) on page 214

8.7.2.2. Register a File Subsystem Device

You can register a file subsystem using the following function:

```
int alt_fs_reg (alt_dev* dev)
```

This function takes a single input argument, which is the device structure to register. A negative return value indicates that the file system cannot be registered.

After a file subsystem is registered with the HAL file system, you can access it through the HAL API and the ANSI C standard library. The mount point for the file subsystem is the `name` specified in the `alt_dev` structure.

For more information, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

8.7.3. Timer Device Drivers

8.7.3.1. System Clock Driver

A system clock device model requires a driver to generate the periodic clock tick. There can be only one system clock driver in a system. You implement a system clock driver as an interrupt service routine (ISR) for a timer peripheral that generates a periodic interrupt. The driver must provide periodic calls to the following function:

```
void alt_tick (void)
```

The expectation is that `alt_tick()` is called in exception context.

To register the presence of a system clock driver, call the following function:

```
int alt_sysclk_init (alt_u32 nticks)
```

The input argument `nticks` is the number of system clock ticks per second, which is determined by your system clock driver. The return value of this function is zero on success, and nonzero otherwise.

For more information about writing interrupt service routines, refer to the "Exception Handling" section.

Related Information

[Exception Handling](#) on page 244

8.7.3.2. Timestamp Driver

A timestamp driver provides implementations for the three timestamp functions: `alt_timestamp_start()`, `alt_timestamp()`, and `alt_timestamp_freq()`. The system can only have one timestamp driver.

For more information about using these functions, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

For more information about using these functions, refer to the "HAL API Reference" section.

Related Information

- [HAL API Reference](#) on page 315
- [Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

8.7.4. Flash Device Drivers

8.7.4.1. Create a Flash Driver

Flash device drivers must provide an instance of the `alt_flash_dev` structure, defined in `sys/alt_flash_dev.h`. The following code shows the structure:

```
struct alt_flash_dev
{
    alt_llist llist; // internal use only
    const char* name;
    alt_flash_open open;
    alt_flash_close close;
    alt_flash_write write;
    alt_flash_read read;
    alt_flash_get_flash_info get_info;
    alt_flash_erase_block erase_block;
    alt_flash_write_block write_block;
    void* base_addr;
    int length;
    int number_of_regions;
    flash_region region_info[ALT_MAX_NUMBER_OF_FLASH_REGIONS];
    alt_flash_lock lock;
};
```

The first parameter `llist` is for internal use, and must always be set to the value `ALT_LLIST_ENTRY`. `name` is the location of the device in the HAL file system and is the name of the device as defined in `system.h`.



The seven fields open to `write_block` are function pointers that implement the functionality behind the application API calls to the following functions:

- `alt_flash_open_dev()`
- `alt_flash_close_dev()`
- `alt_write_flash()`
- `alt_read_flash()`
- `alt_get_flash_info()`
- `alt_erase_flash_block()`
- `alt_write_flash_block()`
- `alt_flash_lock()`

where:

- the `base_addr` parameter is the base address of the flash memory
- `length` is the size of the flash in bytes
- `number_of_regions` is the number of erase regions in the flash
- `region_info` contains information about the location and size of the blocks in the flash device

For more information about the format of the `flash_region` structure, refer to "Using Flash Devices" in "Developing Programs Using the Hardware Abstraction Layer".

Some flash devices, such as common flash interface (CFI)-compliant devices, allow you to read out the number of regions and their configuration at run time. For all other flash devices, these two fields must be defined at compile time.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209

8.7.4.2. Register a Flash Device

After creating an instance of the `alt_flash_dev` structure, you must make the device available to the HAL system by calling the following function:

```
int alt_flash_device_register( alt_flash_fd* fd)
```

This function takes a single input argument, which is the device structure to register. The return value is zero upon success. A negative return value indicates that the device cannot be registered.

8.7.5. DMA Device Drivers

The HAL models a DMA transaction as being controlled by two endpoint devices: a receive channel and a transmit channel.

For more information about a complete description of the HAL DMA device model, refer to "Using DMA Devices" in the "Developing Programs Using the Hardware Abstraction Layer" section.

The DMA device driver interface is defined in `sys/alt_dma_dev.h`.



Related Information

Developing Device Drivers for the Hardware Abstraction Layer on page 209

8.7.5.1. DMA Transmit Channel

Example 7–2. alt_dma_txchan Structure

```
typedef struct alt_dma_txchan_dev_s alt_dma_txchan_dev;
struct alt_dma_txchan_dev_s
{
    alt_llist llist;
    const char* name;
    int (*space) (alt_dma_txchan dma);
    int (*send) (alt_dma_txchan dma,
    const void* from,
    alt_u32 len,
    alt_txchan_done* done,
    void* handle);
    int (*ioctl) (alt_dma_txchan dma, int req, void* arg);
};
```

8.7.5.2. DMA Receive Channel

Example 7–3. alt_dma_rxchan Structure

```
typedef alt_dma_rxchan_dev_s alt_dma_rxchan;
struct alt_dma_rxchan_dev_s
{
    alt_llist list;
    const char* name;
    alt_u32 depth;
    int (*prepare) (alt_dma_rxchan dma,
    void* data,
    alt_u32 len,
    alt_rxchan_done* done,
    void* handle);
    int (*ioctl) (alt_dma_rxchan dma, int req, void* arg);
};
```

The `prepare()` function must be defined. If the `ioctl` field is set to null, calls to `alt_dma_rxchan_ioctl()` return `-ENOTTY` for this device.

After creating an instance of the `alt_dma_rxchan` structure, you must register the device driver with the HAL system to make it available by calling the following function:

```
int alt_dma_rxchan_reg (alt_dma_rxchan_dev* dev)
```

The input argument `dev` is the device to register. The return value is zero on success, or negative if the device cannot be registered.

Table 38. Fields in the alt_dma_rxchan Structure

Field	Function
llist	This function is for internal use and must always be set to the value <code>ALT_LLIST_ENTRY</code> .
name	The name that refers to this channel in calls to <code>alt_dma_rxchan_open()</code> . <code>name</code> is the name of the device as defined in <code>system.h</code> .
<i>continued...</i>	



Field	Function
depth	The total number of receive requests that can be outstanding at any given time.
prepare	A pointer to a function that is called as a result of a call to the application API function <code>alt_dma_rxchan_prepare()</code> . This function posts a receive request to the DMA device. The parameters passed to <code>alt_dma_rxchan_prepare()</code> are passed directly to <code>prepare()</code> . For a description of parameters and return values, refer to the "HAL API Reference" section.
ioctl	This is a function that provides device specific I/O control. Refer to <code>sys/alt_dma_dev.h</code> for a list of the generic options that a device might wish to support.

Related Information

[HAL API Reference](#) on page 315


8.7.6. Ethernet Device Drivers

The HAL generic device model for Ethernet devices provides access to the NicheStack[®] TCP/IP Stack - Nios II Edition running on the MicroC/OS-II operating system. You can provide support for a new Ethernet device by supplying the driver functions that this section defines.

Before you consider writing a device driver for a new Ethernet device, you need a basic understanding of the Intel FPGA implementation of the NicheStack TCP/IP Stack and its usages.

8.7.6.1. Layered Software Model

Architectural Layers of a Nios II MicroC/OS-II software application



Each layer encapsulates the specific implementation details of that layer, abstracting the data for the next outer layer. However, the hierarchy of layers is not absolute. For example, the application makes system calls directly to the MicroC/OS-II or HAL API layers for services that do not require networking.

For more information, refer to the "Ethernet and the NicheStack TCP/IP Stack - Nios II Edition" section.

Related Information

[Ethernet and the NicheStack TCP/IP Stack](#) on page 296

8.7.6.2. Writing a New Ethernet Device Driver

The easiest way to write a new Ethernet device driver is to start with Intel FPGA's implementation for the Standard Microsystems Corporation (SMSC) lan91c111 device, and modify it to suit your Ethernet media access controller (MAC). This section assumes you take this approach. Starting from a known working example makes it easier for you to learn the most important details of the NicheStack TCP/IP Stack implementation.

The source code for the LAN91C111 10/100 Non-PCI Ethernet Single Chip MAC + PHY driver is provided with the Quartus Prime software.. For the sake of brevity, this section refers to this directory as *<SMSC path>*. The source files are in the *<SMSC path>/src/iniche* and *<SMSC path>/inc/iniche* directories.

A number of useful NicheStack TCP/IP Stack files are installed with the Nios II Embedded Design Suite (EDS), under the *<Nios II EDS install path>/components/altera_iniche/UCOSII* directory. For the sake of brevity, this chapter refers to this directory as *<iniche path>*.

For more information about the NicheStack TCP/IP Stack implementation, refer to the *NicheStack Technical Reference Manual*, available on the Intel FPGA website.

You need not edit the NicheStack TCP/IP Stack source code to implement a NicheStack-compatible driver because the source code is provided for your reference. The files are installed with the Nios II EDS in the *<iniche path>* directory. The Ethernet device driver interface is defined in *<iniche path>/inc/alt_iniche_dev.h*.

Related Information

- [NicheStack Technical Reference Manual](#)
For more information about the NicheStack TCP/IP Stack implementation, refer to the NicheStack Technical Reference Manual, available on the Nios II Processor Documentation website.
- [NicheStackRef.zip](#)
For access to the NicheStackRef.zip file.

8.7.6.3. Provide the NicheStack Hardware Interface Routines

The NicheStack TCP/IP Stack architecture requires several network hardware interface routines:



- Initialize hardware
- Send packet
- Receive packet
- Close
- Dump statistics

For more information about these routines, refer to "Porting Engineer Provided Functions" in the *NicheStack Technical Reference Manual*.

The NicheStack TCP/IP Stack system code uses the

Table 39. SMSC LAN91C111 Hardware Interface Routines

Prototype Function	LAN91C111 Function	File	Notes
n_init()	s91_init()	smsc91x.c	The initialization routine can install an ISR if applicable
pkt_send()	s91_pkt_send()	smsc91x.c	
Packet receive mechanism	s91_isr()	smsc91x.c	Packet receive includes three key actions: <ul style="list-style-type: none"> • pk_alloc()—Allocate a netbuf structure • putq()—Place netbuf structure on rcvq • SignalPktDemux()—Notify the Internet protocol (IP) layer that it can demux the packet
	s91_rcv()	smsc91x.c	
	s91_dma_rx_done()	smsc_mem.c	
n_close()	s91_close()	smsc91x.c	
n_stats()	s91_stats()	smsc91x.c	

net structure internally to define its interface to device drivers. The net structure is defined in net.h, in <niche path>/31src. . Among other things, the net structure contains the following things:

- A field for the IP address of the interface
- A function pointer to a low-level function to initialize the MAC device
- Function pointers to low-level functions to send packets

Typical NicheStack code refers to type NET, which is defined as *net.

Related Information

- [NicheStack Technical Reference Manual](#)
For more information about the NicheStack TCP/IP Stack implementation, refer to the NicheStack Technical Reference Manual, available on the Nios II Processor Documentation website.
- [NicheStackRef.zip](#)
For access to the NicheStackRef.zip file.

8.7.6.4. Provide *INSTANCE and *INIT Macros

To enable the HAL to use your driver, you must provide two HAL macros. The names of these macros are based on the name of your network interface component, according to the following templates:

- `<component name>_INSTANCE`
- `<component name>_INIT`

For examples, refer to `ALTERA_AVALON_LAN91C111_INSTANCE` and `ALTERA_AVALON_LAN91C111_INIT` in `<SMSC path>/inc/iniche/altera_avalon_lan91c111_iniche.h`, which is included in `<iniche path>/inc/altera_avalon_lan91c111.h`.

You can copy `altera_avalon_lan91c111_iniche.h` and modify it for your own driver. The HAL expects to find the `*INIT` and `*INSTANCE` macros in `<component name>.h`.

For more information, refer to the “Header Files and `alt_sys_init.c`” chapter. You can accomplish this with a `#include` directive as in `altera_avalon_lan91c111.h`, or you can define the macros directly in `<component name>.h`.

Your `*INSTANCE` macro declares data structures required by an instance of the MAC. These data structures must include an `alt_iniche_dev` structure. The `*INSTANCE` macro must initialize the first three fields of the `alt_iniche_dev` structure, as follows:

- The first field, `l1list`, is for internal use, and must always be set to the value `ALT_LLIST_ENTRY`.
- The second field, `name`, must be set to the device name as defined in `system.h`. For example, `altera_avalon_lan91c111_iniche.h` uses the C preprocessor’s `##` (concatenation) operator to reference the `LAN91C111_NAME` symbol defined in `system.h`.
- The third field, `init_func`, must point to your software initialization function. For more information, refer to the “Provide a Software Initialization Function” chapter. For example, `altera_avalon_lan91c111_iniche.h` inserts a pointer to `alt_avalon_lan91c111_init()`.

Your `*INIT` macro initializes the driver software. Initialization must include a call to the `alt_iniche_dev_reg()` macro, defined in `alt_iniche_dev.h`. This macro registers the device with the HAL by adding the driver instance to `alt_iniche_dev_list`.

When your driver is included in a Nios II BSP project, the HAL automatically initializes your driver by invoking the `*INSTANCE` and `*INIT` macros from its `alt_sys_init()` function. For more information about the `*INSTANCE` and `*INIT` macros, refer to the “Header Files and `alt_sys_init.c`” chapter.

Related Information

- [Header Files and `alt_sys_init.c`](#) on page 238
- [Provide a Software Initialization Function](#) on page 225



8.7.6.5. Provide a Software Initialization Function

The `*INSTANCE()` macro inserts a pointer to your initialization function in the `alt_iniche_dev` structure.

For more information, refer to the "Provide `*INSTANCE` and `*INIT` Macros" chapter.

Your software initialization function must perform at least the following three tasks:

- Initialize the hardware and verify its readiness
- Finish initializing the `alt_iniche_dev` structure
- Call `get_mac_addr()`

The initialization function must perform any other initialization your driver needs, such as creation and initialization of custom data structures and ISRs.

For more information about the `get_mac_addr()` function, refer to the "Ethernet and the NicheStack TCP/IP Stack - Nios II Edition" chapter.

For more information about an example of a software initialization function, refer to `alt_avalon_lan91c111_init()` in `<SMSC path>/src/iniche/smsc91x.c`.

Related Information

- [Provide `*INSTANCE` and `*INIT` Macros](#) on page 224
- [Ethernet and the NicheStack TCP/IP Stack](#) on page 296

8.8. Integrating a Device Driver in the HAL

The Nios II SBT can incorporate device drivers and software packages supplied by Intel FPGA, supplied by other third-party developers, or created by you. This section describes how to prepare device drivers and software packages so the BSP generator recognizes and adds them to a generated BSP.

You can take advantage of this service, whether you created a device driver for one of the HAL generic device models, or you created a peripheral-specific device driver.

Note: The process required to integrate a device driver is nearly identical to that required to develop a software package. The following sections describe the process for both. Certain steps are not needed for software packages, as noted in the text.

8.8.1. Overview

To publish a device driver or a software package, you provide the following items:

- A header file defining the package or driver interface
- A Tcl script specifying how to add the package or driver to a BSP

The header file and Tcl script are described in the following sections.

8.8.2. Assumptions and Requirements

Typically, you are developing a device driver or software package for eventual incorporation in a BSP. The driver or package is to be incorporated in the BSP by an end user who has limited knowledge of the driver or package internal implementation. To add your driver or package to a BSP, the end user must rely on the driver or package settings that you create with the tools described in this section.

For a device driver or software package to work with the Nios II SBT, it must meet the following criteria:

- It must have a defining Tcl script. The Tcl script for each driver or software package provides the Nios II SBT with a complete description of the driver or software. This description includes the following information:
 - Name—A unique name identifying the driver or software package
 - Source files—The location, name, and type of each C/C++ or assembly language source or header file
 - Associated hardware class (device drivers only)—The name of the hardware peripheral class the driver supports
 - Version and compatibility information—The driver or package version, and (for drivers) information about what device core versions it supports.
 - BSP type(s)—The supported operating system(s)
 - Settings—The visible parameters controlling software build and runtime configuration
- The Tcl script resides in the driver or software package root directory.
- The Tcl script's file name ends with **_sw.tcl**. Example: **custom_ip_block_sw.tcl**.
- The root directory of the driver or software package is located in a directory named **ip**, one level beneath the Intel Quartus Prime project directory containing the design your BSP targets. This approach is recommended if your driver or software package is used only once, in a specific hardware project.

For more information on how file names and directory structures conform to certain conventions, refer to the "File Names and Locations" chapter.

If your driver or software package uses the HAL auto initialization mechanism (`alt_sys_init()`), certain macros must be defined in a header file.

For more information about this header file, refer to the "Header Files and `alt_sys_init.c`" chapter.

For more information about integrating a HAL device driver, refer to *AN 459: Guidelines for Developing a Nios II HAL Device Driver*.

For more information about the commands you can use in a driver Tcl script, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

- [File Names and Locations](#) on page 228
- [Header Files and `alt_sys_init.c`](#) on page 238
- [AN 459: Guidelines for Developing a Nios II HAL Device Driver](#)
- [Nios II Software Build Tools Reference](#) on page 396



8.8.3. The Nios II BSP Generator

This section describes the process by which the Nios II BSP generator adds device drivers and software packages to your BSP. The Nios II BSP generator, a subset of the Nios II SBT, is a combination of command utilities and scripts that enable you to create and manage BSPs and their settings.

For more information about the Nios II SBT, refer to the "Overview of Nios II Embedded Development" chapter.

For more information about the Nios II SBT, refer to the "Getting Started from the Command Line" chapter.

Related Information

- [Overview of Nios II Embedded Development](#) on page 18
- [Getting Started from the Command Line](#) on page 73

8.8.3.1. Component Discovery

When you run any BSP generator utility, a library of available drivers and software packages is populated.

The BSP generator locates software packages and drivers by inspecting a list of known locations determined by the Intel FPGA Nios II EDS, Quartus Prime software, and IP core[®] IP Library installers, as well as searching locations specified in certain system environment variables.

The Nios II BSP tools identify drivers and software packages by locating and sourcing Tcl scripts with file names ending in `_sw.tcl` in these locations.

Note: For run-time efficiency, the BSP generator only looks at driver files that conform to the criteria listed in this section.

After locating each driver and software package, the Nios II SBT searches for a suitable driver for each hardware module in the hardware system (mastered by the Nios II processor that the BSP is generated for), as well as software packages that the BSP creator requested.

8.8.3.2. Device Driver Versions

In the case of device drivers, the highest version of driver that is compatible with the associated hardware peripheral is added to the BSP, unless specified otherwise by the device driver management commands.

For more information, refer to the "Nios II Software Build Tools Reference" section.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.3.3. Device Driver and Software Package Inclusion

8.8.3.3.1. Specific Requests

The BSP generator adds software packages to the BSP if they are specifically requested during BSP generation, with the `enable_sw_package` command.

For more information, refer to "Software Build Tools Tcl Commands" in the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.3.3.2. No Specific Requests

If no specific device driver is requested, and no compatible device driver is located for a particular hardware module, the BSP generator issues an informative message visible in either the `debug` or `verbose` generation output. This behavior is normal for many types of hardware, such as memory devices, that do not have device drivers. If a software package or specific driver is requested and cannot be located, an error is generated and BSP generation or settings update halts.

Creating a Tcl script allows you to add extra definitions in the `system.h` file, enable automatic driver initialization through the `alt_sys_init.c` structure, and enable the Nios II SBT to control any extra parameters that might exist.

With the Tcl software definition files in place, the SBT reads in the Tcl file and populate the makefiles and other support files accordingly.

When the Nios II SBT adds each driver or software package to the system, it uses the data in the Tcl script defining the driver or software package to control each file copied in to the BSP. This rule also affects generated BSP files such as the BSP **Makefile**, `public.mk`, `system.h`, and the BSP settings and summary HTML files.

When you create a new software project, the Nios II SBT generates the contents of `alt_sys_init.c` to match the specific hardware contents of the system.

8.8.4. File Names and Locations

The Nios II build tools find a device driver or software package by locating a Tcl script with the file name ending in `_sw.tcl`, and sourcing it.

For more information, refer to the "The Nios II BSP Generator" chapter.

Each peripheral in a Nios II system is associated with a specific component directory. This directory contains a file defining the software interface to the peripheral.

For more information, refer to the "Accessing Hardware" chapter.

To enable the SBT to find your component device driver, place the Tcl script in a directory named **ip** under your hardware project directory.

The file hierarchy that is suitable for the Nios II SBT is located in the *<Intel FPGA installation>/ip/altera/sopc_builder_ip* directory. This example assumes a device driver supporting a hardware component named `custom_component`.

Related Information

- [The Nios II BSP Generator](#) on page 227
- [Accessing Hardware](#) on page 212



8.8.4.1. Source Code Discovery

You use Tcl scripts to specify the location of driver source files.

For more information, refer to the "The Nios II BSP Generator" chapter.

Related Information

[The Nios II BSP Generator](#) on page 227

8.8.5. Driver and Software Package Tcl Script Creation

This section discusses writing a Tcl script to describe your software package or driver. The exact contents of the Tcl script depends on the structure and complexity of your driver or software. For many simple device drivers, you need only include a few commands. For more complex software, the Nios II SBT provides powerful features that give the BSP end user control of your software or driver's operation.

The Tcl command and argument descriptions in this section are not exhaustive. For a detailed explanation of each command and all arguments, refer to the "Nios II Software Build Tools Reference" section.


Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.5.1. Example Device Driver File Hierarchy and Naming

For a reference in creating your own driver or software Tcl files, you can also view the driver and software package Tcl scripts included with the Nios II EDS and the IP core IP library. These scripts are in the *<Nios II EDS install path>/components* and *<IP core IP library install path>/sopc_builder_ip* folders, respectively.

Figure 14. Example Device Driver File Hierarchy and Naming



Note: **"inc"** - Contains header file(s) that define the device hardware interfaces. Contents in this directory are not HAL-specific and apply to a driver, regardless of whether it is based on the HAL, MicroC/OS-II, or any other RTOS environment.

Note: **"HAL"** - Contains software files required to integrate the device with the Nios II hardware abstraction layer. Files in this directory pertain specifically to the HAL.

8.8.5.2. Tcl Command Walkthrough for a Typical Driver or Software Package

The Tcl script excerpts in this section describe a typical device driver or software package.

The example in this section creates a device driver for a hardware peripheral whose component class name is `my_custom_component`. The driver supports both HAL and MicroC/OS-II BSP types. It has a single C source file (`.c`) and two C header files (`.h`).



8.8.5.2.1. Creating and Naming the Driver or Package

The first command in any driver or software package Tcl script must be the `create_driver` or `create_sw_package` command. The remaining commands can be in any order. Use the appropriate **create** command only once per Tcl file. Choose a unique driver or package name. For drivers, Intel FPGA recommends appending `_driver` to the associated hardware class name. The following example illustrates this convention:

```
create_driver my_custom_component_driver
```

8.8.5.2.2. Identifying the Hardware Component Class

Each driver must identify the hardware component class the driver is associated with in the `set_sw_property` command's `hw_class_name` argument. The following example associates the driver with a hardware class called `my_custom_component`:

```
set_sw_property hw_class_name my_custom_component
```

Note: The `set_sw_property` command accepts several argument types. Each call to `set_sw_property` sets or overwrites a property to the value specified in the second argument.

For more information about the `set_sw_property` command, refer to the "Nios II Software Build Tools Reference" chapter.

The `hw_class_name` argument does not apply to software packages.

If you are creating your own driver to use in place of an existing one (for example, a custom UART driver for the `altera_avalon_uart` component), specify a driver name different from the standard driver. The Nios II SBT uses your driver only if you specify it explicitly.

For more information, refer to the "Nios II Software Build Tools Reference" chapter.

Choose a name for your driver or software package that does not conflict with other Intel FPGA-supplied software or IP, or any third-party software or IP installed on your host system. The BSP generator uses the name you specify to look up the software package or driver during BSP creation. If the Nios II SBT finds multiple compatible drivers or software packages with the same name, it might pick any of them.

If you intend to distribute your driver or software package, Intel FPGA recommends prefixing all names with your organization's name.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.5.2.3. Setting the BSP Type

You must specify each operating system (or BSP type) that your driver or software package supports. Use the `add_sw_property` command's `supported_bsp_type` argument to specify each compatible operating system. In most cases, a driver or software package supports both Intel FPGA HAL (`hal`) and Micrium MicroC/OS-II (`ucosii`) BSP types, as in the following example:

```
add_sw_property supported_bsp_type hal
add_sw_property supported_bsp_type ucousii
```

Note: The `add_sw_property` command accepts several argument types. Each call to `add_sw_property` adds the final argument to the property specified in the second argument.

Note: Support for additional operating system and BSP types is not present in this release of the Nios II SBT.

8.8.5.2.4. Specifying an Operating System

Many drivers and software packages do not require any particular operating system. However, you can structure your software to provide different source files depending on the operating system used.

If your driver or software has different source files, paths, or settings that depend on the operating system used, write a Tcl script for each variant of the driver or software package. Each script must specify the same software package or driver name in the `create_driver` or `create_sw_package` command, and same `hw_class_name` in the case of device drivers. Each script must specify only the files, paths, and other settings that pertain to that operating system. During BSP generation, only drivers or software packages that specify compatibility with the selected operating system (OS) type are eligible to add to the BSP.

8.8.5.2.5. Specifying Source Files

Using the Tcl command interface, you must specify each source file in your driver or software package that you want in the generated BSP. The commands discussed in this section add driver source files and specify their location in the file system and generated BSP.

The `add_sw_property` command's `c_source` and `asm_source` arguments add a single `.c` or Nios II assembly language source file (`.s` or `.S`) to your driver or software package. You must express path information to the source relative to the driver root (the location of the Tcl file). `add_sw_property` copies source files to BSPs that incorporate the driver, using the path information specified, and adds them to source file list in the generated BSP makefile. When you build the BSP using `make`, the driver source files are compiled as follows:


```
add_sw_property c_source HAL/src/my_driver.c
```

The `add_sw_property` command's `include_source` argument adds a single header file in the path specified to the driver. The paths are relative to the driver root. `add_sw_property` copies header files to the BSP during generation, using the path information specified at generation time. It does not include header files in the makefile.

```
add_sw_property include_source inc/my_custom_component_regs.h
add_sw_property include_source HAL/inc/my_custom_component.h
```

8.8.5.2.6. Specifying a Subdirectory

You can optionally specify a subdirectory in the generated BSP for your driver or software package files using the `bsp_subdirectory` argument to `set_sw_property`. All driver source and header files are copied to this directory,



along with any path or hierarchy information specified with each source or header file. If no `bsp_subdirectory` is specified, your driver or software package is placed under the **drivers** folder of the generated BSP. Set the subdirectory as follows:

```
set_sw_property bsp_subdirectory my_driver
```

Note: If the path begins with the BSP type (e.g `HAL` or `UCOSII`), the BSP type is removed and replaced with the value of the `bsp_subdirectory` property.

8.8.5.2.7. Enabling Software Initialization

If your driver or software package uses the HAL auto-initialization mechanism, your source code includes `INSTANCE` and `INIT` macros, to create storage for each driver instance, and to call any initialization routines. The generated `alt_sys_init.c` file invokes these macros, which must be defined in a header file named `<hardware component class>.h`.

For more information, refer to the “Provide `*INSTANCE` and `*INIT` Macros” chapter.

To support this functionality in Nios II BSPs, you must set the `set_sw_property` command's `auto_initialize` argument to `true` using the following Tcl command:

```
set_sw_property auto_initialize true
```

If you do not turn on this attribute, `alt_sys_init.c` does not invoke the `INIT` and `INSTANCE` macros.

Related Information

[Provide `*INSTANCE` and `*INIT` Macros](#) on page 224

8.8.5.2.8. Adding Include Paths

By default, the generated BSP **Makefile** and `public.mk` add include paths to find header files in `/inc` or `<BSP type>/inc` folders.

You might need to set up a header file directory hierarchy to logically organize your code. You can add additional include paths to your driver or software package using the `add_sw_property` command's `include_directory` argument as follows:

```
add_sw_property include_directory UCOSII/inc/protocol/h
```

Note: If the path begins with the BSP type (e.g `HAL` or `UCOSII`), the BSP type is removed and replaced with the value of the `bsp_subdirectory` property.

Additional include paths are added to the preprocessor flags in the BSP `public.mk` file. These preprocessor flags allow BSP source files, as well as application and user library source files that reference the BSP, to find the include path while each source file is compiled.

Note: Adding additional include paths is not required if your source code includes header files with explicit path names. You can also specify the location of the header files with a `#include` directive similar to the following:

```
#include "protocol/h/<filename>"
```

8.8.5.2.9. Version Compatibility

Your device driver or software package can optionally specify versioning information through the Tcl command interface. The driver and software package Tcl commands specifying versioning information allow the following functionality:

- You can request a specific version of your driver or software package with BSP settings.
- You can make updates to your device driver and specify that the driver is still compatible with a minimum hardware class version, or specific hardware class versions. This facility is especially useful in situations in which a hardware design is stable and you foresee making software updates over time.

The <version> argument in each of the following versioning-related commands can be a string containing numbers and characters. Examples of version strings are 8.0, 5.1.1, 6.1, and 6.1spl. The "." character is a separator. The BSP generator compares versions against each other to determine if one is more recent than the other, or if two are equal, by successively comparing the strings between each separator. Thus, 2.1 is greater than 2.0, and 2.1spl is greater than 2.1. Two versions are equal if their version assignment strings are identical.

Use the `version` argument of `set_sw_property` to assign a version to your driver or software package. If you do not assign a version to your software or device driver, the version of the Nios II EDS installation (containing the Nios II BSP commands being executed) is set for your driver or software package:

```
set_sw_property version 7.1
```

Device drivers (but not software packages) can use the `min_compatible_hw_version` and `specific_compatible_hw_version` arguments to establish compatibility with their associated hardware class, as follows:

```
set_sw_property min_compatible_hw_version 5.0.1
add_sw_property specific_compatible_hw_version 6.1spl
```

You can add multiple specific compatible versions. This functionality allows you to roll out a new version of a device driver that tracks changes supporting a hardware peripheral change.

For device drivers, if no compatible version information is specified, the version of the device driver must be equal to the associated hardware class. Thus, if you do not wish to use this feature, Intel FPGA recommends setting the `min_compatible_hw_version` of your driver to the lowest version of the associated hardware class your driver is compatible with.

8.8.5.3. Creating Settings for Device Drivers and Software Packages

The BSP generator allows you to publish settings for individual device drivers and software packages. These settings are visible and can be modified by the BSP user, if the BSP includes your driver or software package. Use the Tcl command interface to create settings.

The Tcl command that publishes settings is especially useful if your driver or software package has build or runtime options that are normally specified with `#define` statements or makefile definitions at software build time. Settings can also add custom variable declarations to the BSP **Makefile**.



8.8.5.3.1. How Settings Affect the Generated BSP

Settings affect the generated BSP in several ways:

- Settings are added either to the BSP `system.h` or `public.mk`, or to the BSP makefile as a variable.
- Settings are stored in the BSP settings file, named with hierarchy information to prevent namespace collision.
- A default value of your choice is assigned to the setting so that the end user of the driver or package does not need to explicitly specify the setting when creating or updating a BSP.
- Settings are displayed in the BSP `summary.html` document, along with description text of your choice.

Arguments for `add_sw_setting`

Use the `add_sw_setting` Tcl command to add a setting. To specify the details, `add_sw_setting` requires each of the following arguments, in the order shown:

- `type` - The data type, which controls formatting of the setting's value assignment in the appropriate generated file.
- `destination` - The destination file in the BSP.
- `displayName` - The name that is used to identify the setting when changing BSP settings or viewing the BSP `summary.html` document.
- `identifier` - Conceptually, this argument is the macro defined in a C language definition (the text immediately following `#define`), or the name of a variable in a makefile.
- `value` - A default value assigned to the setting if the BSP user does not manually change it.
- `description` - Descriptive text, shown in the BSP `summary.html` document.

8.8.5.3.2. Data Types

Several setting data types are available, controlled by the `type` argument to `add_sw_setting`. They correspond to the data types you can express as `#define` statements or values concatenated to makefile variables. The specific setting type depends on your software's structure or BSP build needs.

Table 40. Data Type Settings

Data Type	Setting Value	Notes
Boolean definition	<code>boolean_define_only</code>	A definition that is generated when true, and absent when false. Use a boolean definition in your C source files with the <code>#ifdef <setting> ... #endif</code> construct.
Boolean assignment	<code>boolean</code>	A definition assigned to 1 when true, 0 when false. Use a boolean assignment in your C source files with the <code>#if <setting> ... #else ...</code> construct.
Character	<code>character</code>	A definition with one character surrounded by single quotation marks (')
<i>continued...</i>		

Data Type	Setting Value	Notes
Decimal number	decimal_number	A definition with an unquoted, unformatted decimal number, such as 123. Useful for defining values in software that, for example, might have a configurable buffer size, such as <code>int buffer[SIZE];</code>
Double precision number	double	A definition with a double-precision floating point number such as 123.4
Floating point number	float	A definition with a single-precision floating point number such as 234.5
Hexadecimal number	hex_number	A definition with a number prefixed with 0x, such as 0x1000. Useful for specifying memory addresses or bit masks
Quoted string	quoted_string	A definition with a string in quotes, such as "Buffer"
Unquoted string	unquoted_string	A definition with a string not in quotes, such as BUFFER

8.8.5.3.3. Setting Destination Files

The `destination` argument of `add_sw_setting` specifies settings and their assigned values. This argument controls the file to which the setting is saved in the BSP. The BSP generator formats the setting's assigned value based on the definition file and type of setting.

Table 41. Destination File Settings

Destination File	Setting Value	Notes
<code>system.h</code>	<code>system_h_define</code>	This destination file is recommended in most cases. Your source code must use a <code>#include <system.h></code> statement to make the setting definitions available. Settings appear as <code>#define</code> statements in <code>system.h</code> .
<code>public.mk</code>	<code>public_mk_define</code>	Definitions appear as <code>-D</code> statements in <code>public.mk</code> , in the C preprocessor flags assembly. This setting type is passed directly to the compiler during build and is visible during compilation of application and libraries referencing the BSP.
BSP makefile	<code>makefile_variable</code>	Settings appear as makefile variable assignments in the BSP makefile.

Note: Certain setting types are not compatible with the `public.mk` or **Makefile** destination file types.

For more information, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.5.3.4. Setting Display Name

The setting `displayName` controls what the end user of the driver or package (the BSP developer) types to control the setting in their BSP. BSPs append the `displayName` text after a . (dot) separator to your driver or software package's name (as defined in the `create_driver` or `create_sw_package` command). For example, if your driver is named `my_peripheral_driver` and your setting's



displayName is `small_driver`, BSPs with your driver have a setting `my_peripheral_driver.small_driver`. Thus each driver and software package has its own settings namespace.

8.8.5.3.5. Setting Generation Name

The setting `generationName` of `add_sw_setting` controls the physical name of the setting in the generated BSP files. The physical name corresponds to the definition being created in `public.mk` and `system.h`, or the make variable created in the BSP **Makefile**. The `generationName` is commonly the text that your software uses in conditionally-compiled code. For example, suppose your software creates a buffer as follows:

```
unsigned int driver_buffer[MY_DRIVER_BUFFER_SIZE];
```

You can enter the exact text, `MY_DRIVER_BUFFER_SIZE`, in the `generationName` argument.

8.8.5.3.6. Setting Default Value

The value argument of `add_sw_setting` holds the default value of your setting. This value propagates to the generated BSP unless the end user of the driver or package (the BSP developer) changes the setting's assignment before BSP generation.

Note: The value assigned to any setting, whether it is the default value in the driver or software package Tcl script, or entered by the user configuring the BSP, must be compatible with the selected setting.

For more information, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.8.5.3.7. Setting Description

The `description` argument of `add_sw_setting` contains a brief description of the setting. The `description` argument is required. Place quotation marks (" ") around the text of the description. The description text appears in the generated BSP `summary.html` document.

8.8.5.3.8. Setting Creation Example

```
#include "system.h"
#ifdef MY_CUSTOM_DRIVER_SMALL
int send_data( <args> )
{
    // Small implementation
}
#else
int send_data( <args> )
{
    // fast implementation
}
#endif
```

Note: This example implements a setting for a driver that has two variants of a function, one implementing a small driver (minimal code footprint) and the other a fast driver (efficient execution).

A simple Boolean definition setting is added to your driver Tcl file. This feature allows BSP users to control your driver through the BSP settings interface. When users set the setting to true or 1, the BSP defines MY_CUSTOM_DRIVER_SMALL in either system.h or the BSP public.mk file. When the user compiles the BSP, your driver is compiled with the appropriate routine incorporated in the object file. When a user disables the setting, MY_CUSTOM_DRIVER_SMALL is not defined.

You add the MY_CUSTOM_DRIVER_SMALL setting to your driver as follows using the add_sw_setting Tcl command:

```
add_sw_setting boolean_define_only system_h_define small_driver
MY_CUSTOM_DRIVER_SMALL false
"Enable the small implementation of the driver for my_peripheral"
```

Note: Each Tcl command must reside on a single line of the Tcl file. This example is wrapped due to space constraints.

Each argument has several variants.

For more information about detailed usage and restrictions, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.9. Creating a Custom Device Driver for the HAL

This section describes how to provide appropriate files to integrate your device driver in the HAL.

For more information about the correct locations for the files, refer to the "Integrating a Device Driver in the HAL" chapter.

Related Information

[Integrating a Device Driver in the HAL](#) on page 225

8.9.1. Header Files and alt_sys_init.c

At the heart of the HAL is the autogenerated source file, alt_sys_init.c. This file contains the source code that the HAL uses to initialize the device drivers for all supported devices in the system. In particular, this file defines the alt_sys_init() function, which is called before main() to initialize device drivers software packages, and make them available to the program.

When you create the driver or software package, you specify in a Tcl script whether you want the alt_sys_init() function to invoke your INSTANCE and INIT macros.

For more information, refer to the "Enabling Software Initialization" chapter.



Note: The remainder of this section assumes that you are using the `alt_sys_init()` HAL initialization mechanism.

Related Information

[Enabling Software Initialization](#) on page 233

8.9.1.1. Creating `alt_sys_init.c` Based on Associated Header Files

The Software Build Tools (SBT) creates `alt_sys_init.c` based on the header files associated with each device driver and software package. For a device driver, the header file must define the macros `<component name>_INSTANCE` and `<component name>_INIT`.

Like a device driver, a software package provides an `INSTANCE` macro, which `alt_sys_init()` invokes once. A software package header file can optionally provide an `INIT` macro.

Example 7-4. Excerpt from an `alt_sys_init.c` File Performing Driver Initialization

```
#include "system.h"
#include "sys/alt_sys_init.h"
/*
 * device headers
 */
#include "altera_avalon_timer.h"
#include "altera_avalon_uart.h"
/*
 * Allocate the device storage
 */
ALTERA_AVALON_UART_INSTANCE( UART1, uart1 );
ALTERA_AVALON_TIMER_INSTANCE( SYSCLK, sysclk );
/*
 * Initialize the devices
 */
void alt_sys_init( void )
{
    ALTERA_AVALON_UART_INIT( UART1, uart1 );
    ALTERA_AVALON_TIMER_INIT( SYSCLK, sysclk );
}
```

8.9.1.2. `altera_avalon_jtag_uart.h` Defining Macros

For example, `altera_avalon_jtag_uart.h` must define the macros `ALTERA_AVALON_JTAG_UART_INSTANCE` and `ALTERA_AVALON_JTAG_UART_INIT`. The purpose of these macros is as follows:

- The `*_INSTANCE` macro performs any required static memory allocation. For drivers, `*_INSTANCE` is invoked once per device instance, so that memory can be initialized on a per-device basis. For software packages, `*_INSTANCE` is invoked once.
- The `*_INIT` macro performs runtime initialization of the device driver or software package.

In the case of a device driver, both macros take two input arguments:

- The first argument, `name`, is the capitalized name of the device instance.
- The second argument, `dev`, is the lower case version of the device name. `dev` is the name given to the component at system generation time.

You can use these input parameters to extract device-specific configuration information from the `system.h` file.

The name of the header file must be as follows:

- Device driver: `<hardware component class>.h`. For example, if your driver targets the **altera_avalon_uart** component, the file name is `altera_avalon_uart.h`.
- Software packages `<package name>.h`. For example, if you create the software package with the following command:

```
create_sw_package my_sw_package
```

the header file is called `my_sw_package.h`.

For more information about a complete example, refer to any of the Intel FPGA-supplied device drivers, such as the JTAG UART driver in `<Intel FPGA installation>/ip/sopc_builder_ip/altera_avalon_jtag_uart`.

Note: For optimal project rebuild time, do not include the peripheral header in `system.h`. It is included in `alt_sys_init.c`.

8.9.2. Device Driver Source Code

In addition to the header file, the component driver might need to provide compilable source code, to be incorporated in the BSP. This source code is specific to the hardware component, and resides in one or more C files (or assembly language files).

8.10. Reducing Code Footprint in HAL Embedded Drivers

The HAL provides several options for reducing the size, or footprint, of the BSP code. Some of these options require explicit support from device drivers. If you need to minimize the size of your software, consider using one or both of the following techniques in your custom device driver:

- Provide reduced footprint drivers. This technique usually reduces driver functionality.
- Support the lightweight device driver API. This technique reduces driver overhead. It need not reduce functionality, but it might restrict your flexibility in using the driver.

These techniques are discussed in the following sections.

8.10.1. Provide Reduced Footprint Drivers

The HAL defines a C preprocessor macro named `ALT_USE_SMALL_DRIVERS` that you can use in driver source code to provide alternate behavior for systems that require a minimal code footprint. If `ALT_USE_SMALL_DRIVERS` is not defined, driver source code implements a fully featured version of the driver. If the macro is defined, the source code might provide a driver with restricted functionality. For example a driver might implement interrupt-driven operation by default, but polled (and presumable smaller) operation if `ALT_USE_SMALL_DRIVERS` is defined.

When writing a device driver, if you choose to ignore the value of `ALT_USE_SMALL_DRIVERS`, the same version of the driver is used regardless of the definition of this macro.



You can enable `ALT_USE_SMALL_DRIVERS` in a BSP with the `hal.enable_reduced_device_drivers` BSP setting.

For more information, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.10.2. Support the Lightweight Device Driver API

8.10.2.1. Using Character-Mode Functions

The lightweight device driver API allows you to minimize the overhead of character-mode device drivers. It does this by removing the need for the `alt_fd` file descriptor table, and the `alt_dev` data structure required by each driver instance.

If you want to support the lightweight device driver API on a character-mode device, you need to write at least one of the lightweight character-mode functions listed in the "Driver Functions for Lightweight Device Driver API" table (Table 7-7). Implement the functions needed by your software. For example, if you only use the device for `stdout`, you only need to implement the `<component class>_write()` function.

Table 42. Driver Functions for Lightweight Device Driver API

Function	Purpose	Example ⁽⁷⁾
<code><component class>_read()</code>	Implements character-mode read functions	<code>altera_avalon_jtag_uart_read()</code>
<code><component class>_write()</code>	Implements character-mode write functions	<code>altera_avalon_jtag_uart_write()</code>
<code><component class>_ioctl()</code>	Implements device-dependent functions	<code>altera_avalon_jtag_uart_ioctl()</code>

8.10.2.2. Using Macros

When you build your BSP with `ALT_USE_DIRECT_DRIVERS` enabled, instead of using file descriptors, the HAL accesses your drivers with the following macros:

- `ALT_DRIVER_READ(instance, buffer, len, flags)`
- `ALT_DRIVER_WRITE(instance, buffer, len, flags)`
- `ALT_DRIVER_IOCTL(instance, req, arg)`

These macros are defined in `<Nios II EDS install path>/components/altera_hal/HAL/inc/sys/alt_driver.h`.

These macros, together with the system-specific macros that the Nios II SBT creates in `system.h`, generate calls to your driver functions. For example, with lightweight drivers turned on, `printf()` calls the HAL `write()` function, which directly calls your driver's `<component class>_write()` function, bypassing file descriptors.

⁽⁷⁾ Based on component `altera_avalon_jtag_uart`.

You can enable `ALT_USE_DIRECT_DRIVERS` in a BSP with the `hal.enable_lightweight_device_driver_api` BSP setting.

For more information, refer to the "Nios II Software Build Tools Reference" chapter.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

8.10.2.3. Invoking Macros in Your Application Software

You can also take advantage of the lightweight device driver API by invoking `ALT_DRIVER_READ()`, `ALT_DRIVER_WRITE()` and `ALT_DRIVER_IOCTL()` in your application software. To use these macros, include the header file `sys/alt_driver.h`. Replace the `instance` argument with the device instance name macro from `system.h`; or if you are confident that the device instance name never changes, you can use a literal string, for example `custom_uart_0`.

8.10.2.4. Calling Direct Without Macros

Another way to use your driver functions is to call them directly, without macros. If your driver includes functions other than `<component class>_read()`, `<component class>_write()` and `<component class>_ioctl()`, you must call those functions directly from your application.

8.11. HAL Namespace Allocation

To avoid conflicting names for symbols defined by devices in the hardware system, all global symbols need a defined prefix. Global symbols include global variable and function names. For device drivers, the prefix is the name of the component followed by an underscore. Because this naming can result in long strings, an alternate short form is also permitted. This short form is based on the vendor name, for example `alt_` is the prefix for components published by Intel FPGA. It is expected that vendors test the interoperability of all components they supply.

For example, for the `altera_avalon_jtag_uart` component, the following function names are valid:

- `altera_avalon_jtag_uart_init()`
- `alt_jtag_uart_init()`

The following names are invalid:


- `avalon_jtag_uart_init()`
- `jtag_uart_init()`

As source files are located using search paths, these namespace restrictions also apply to file names for device driver source and header files.

8.12. Overriding the HAL Default Device Drivers

All components can elect to provide a HAL device driver.

For more information, refer to ["Integrating a Device Driver in the HAL"](#) on page 7–17.



However, if the driver supplied with a component is inappropriate for your application, you can override the default driver by supplying a different driver.

In the Nios II SBT for Eclipse, you can use the BSP Editor to specify a custom driver.

For more information about selecting device drivers, refer to "Using the BSP Editor" in the "Getting Started with the Graphical User Interface" chapter.

On the command line, you specify a custom driver with the following BSP Tcl command:


```
set_driver <driver name> <component name>
```

For example, if you are using the **nios2-bsp** command, you replace the default driver for `uart0` with a driver called `custom_driver` as follows:

```
nios2-bsp hal my_bsp --cmd set_driver custom_driver uart0r
```

Related Information

- [Integrating a Device Driver in the HAL](#) on page 225
- [Getting Started with the Graphical User Interface](#) on page 26



9. Exception Handling

This chapter discusses how to write programs to handle exceptions in the Nios® II processor architecture. Emphasis is placed on how to process hardware interrupt requests by registering a user-defined interrupt service routine (ISR) with the hardware abstraction layer (HAL). This information applies to embedded software projects created with the Nios II Software Build Tools (SBT), either in Eclipse or on the command line.

For more information and low-level details about handling exceptions and hardware interrupts on the Nios II architecture, refer to the "Programming Model" chapter.

Related Information

- [Programming Model](#)
- [Exception Handling Revision History](#) on page 15
For details on the document revision history of this chapter

9.1. Nios II Exception Handling Overview

The Nios II processor provides the following exception types:

- Hardware interrupts
- Software exceptions, which fall into the following categories:
 - Unimplemented instructions
 - Software traps
 - Miscellaneous exceptions

The Nios II processor offers two distinct approaches to handling hardware interrupts:

- The internal interrupt controller (IIC)
- The external interrupt controller (EIC) interface

The interrupt controllers are discussed in detail in the "Interrupt Controllers" chapter.

Related Information

[Interrupt Controllers](#) on page 246

9.1.1. Exception Handling Terminology

The following list of HAL terms outlines basic exception handling concepts:



- Application context—The status of the Nios II processor and the HAL during normal program execution, outside of exception funnels and handlers.
- Context switch—The process of saving the Nios II processor's registers on a software exception or hardware interrupt, and restoring them on return from the exception handling routine or ISR.
- Exception—A transfer of control away from a program's normal flow of execution, caused by an event, either internal or external to the processor, which requires immediate attention. Exceptions include software exceptions and hardware interrupts.
- Exception context—The status of the Nios II processor and the HAL after a software exception or hardware interrupt, when funnel code, a software exception handler, or an ISR is executing.
- Exception handling system—The complete system of software routines that service all exceptions, including hardware interrupts, and pass control to software exception handlers and ISRs as necessary.
- Exception (or interrupt) latency—The time elapsed between the event that causes the exception (such as an unimplemented instruction or interrupt request) and the execution of the first instruction at the exception (or interrupt vector) address.
- Exception (or interrupt) response time—The time elapsed between the event that causes the exception and the execution of the handler.
- Exception overhead—Additional processing required to service a software exception or hardware interrupt, including HAL-specific processing and RTOS-specific processing if applicable.
- Funnel code—HAL-provided code that sets up the correct processor environment for an exception-specific handler, such as an ISR.
- Handler—Code specific to the exception type. The handler code is distinct from the funnel code, which takes care of general exception overhead tasks.
- Hardware interrupt—An exception caused by an explicit hardware request signal from an external device. A hardware interrupt diverts the processor's execution flow to a ISR, to ensure that a hardware condition is handled in a timely manner.
- Implementation-dependent instruction—A Nios II processor instruction that is not supported on all implementations of the Nios II core. For example, the `mul` and `div` instructions are implementation-dependent, because they are not supported on the Nios II/e core.
- Interrupt—Hardware interrupt.
- Interrupt controller—Hardware enabling the Nios II processor to respond to an interrupt by transferring control to an ISR.
- Interrupt request (IRQ)—Hardware interrupt.
- Interrupt service routine (ISR)—A software routine that handles an individual hardware interrupt.
- Invalid instruction—An instruction that is not defined for any implementation of the Nios II processor.
- Maskable exceptions—Exceptions that can be disabled with the `status.PIE` flag, including internal hardware interrupts, maskable external hardware interrupts, and software exceptions, but not including nonmaskable external interrupts.
- Maximum disabled time—The maximum amount of continuous time that the system spends with maskable exceptions disabled.

- Maximum masked time—The maximum amount of continuous time that the system spends with a single interrupt masked.
- Miscellaneous exception—A software exception which is neither an unimplemented instruction nor a `trap` instruction.
For more information, refer to the “Miscellaneous Exceptions” chapter.
- Nested interrupts—See pre-emption.
- Pre-emption—The process of a high-priority interrupt taking control when a lower-priority ISR is already running. Also: nested interrupts.
- Software exception—An exception caused by a software condition; that is, any exception other than a hardware interrupt. This includes unimplemented instructions and `trap` instructions.
- Unimplemented instruction—An implementation-dependent instruction that is not supported on the particular Nios II core implementation that is in your system. For example, in the Nios II/e core, `mul` and `div` are unimplemented.
- Worst-case exception (or interrupt) latency—The value of the exception (or interrupt) latency, including the maximum disabled time or maximum masked time. Including the maximum disabled or masked time accounts for the case when the exception (or interrupt) occurs at the beginning of the masked or disabled time.

Related Information

[Miscellaneous Exceptions](#) on page 278

9.1.2. Interrupt Controllers

The configuration of Nios II exception processing depends on the type of hardware interrupt controller. You select the hardware interrupt controller when you instantiate the Nios II processor in the system integration tool, Platform Designer.

For more information and details about selecting a hardware interrupt controller, refer to the “Instantiating the Nios II Processor” chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Instantiating the Nios II Processor](#)

For more information and details about selecting a hardware interrupt controller.

9.1.2.1. Internal Interrupt Concepts

With the IIC, Nios II exception handling is implemented in classic RISC fashion. All exception types, including hardware interrupts, are dispatched through a single top-level exception funnel. This means that all exceptions (hardware and software) are handled by code residing at a single location, the exception address.

The IIC is a simple, nonvectored hardware interrupt controller. Upon receipt of an interrupt request, the IIC transfers control to the general exception address. The hardware indicates which IRQ is currently asserted, and allows software to mask individual interrupts.

With the IIC, the HAL interrupt funnel identifies the hardware interrupt cause in software, and dispatches the registered ISR.



The IIC is available in all revisions of the Nios II processor.

9.1.2.2. External Interrupt Concepts

The EIC interface enables the Nios II processor to work with a separate external interrupt controller component. An EIC can be a custom component that you provide. Intel FPGA provides an example of an EIC, the vectored interrupt controller (VIC).

For more information about the VIC, refer to the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

With an EIC, hardware interrupts are handled separately from software exceptions. Hardware interrupts have separate vectors and funnels. Each interrupt can have its own handler, or handlers can be shared. Software exception handling is the same as with the IIC.

The EIC interface provides extensive capabilities for customizing your interrupt hardware. You can design, connect and configure an interrupt controller that is optimal for your application.

When an external hardware interrupt occurs, the Nios II processor transfers control to an individual vector address, which can be unique for each interrupt. The HAL provides the following services:

- Registering ISRs
- Setting up the vector table
- Transferring control from the vector table to your ISR

An EIC can be used with shadow register sets. A shadow register set is a complete alternate set of Nios II general-purpose registers, which can be used to maintain a separate runtime context for an ISR.

An EIC provides the following information about each hardware interrupt:

Related Information

[Vectored Interrupt Controller Core](#)

9.1.2.2.1. Requested Handler Address

The requested handler address (RHA) specifies the address of the funnel associated with the hardware interrupt. The availability of an RHA for each interrupt allows the Nios II processor to jump directly to the interrupt funnel specific to the interrupting device, reducing interrupt latency.

9.1.2.2.2. Requested Interrupt Level

The Nios II processor uses the requested interrupt level (RIL) to prioritize the hardware interrupt request versus any interrupt it is currently processing. While handling an interrupt, the Nios II processor normally only takes higher-level interrupts.

9.1.2.2.3. Requested Register Set

If shadow register sets are implemented on the Nios II core, an EIC specifies a requested register set (RRS) when it asserts an interrupt request. When the Nios II processor takes the hardware interrupt, the processor switches to the requested register set. When an interrupt has a dedicated register set, the ISR avoids the overhead of saving registers for a context switch.

Multiple hardware interrupts can be configured to share a register set. However, at run time, the Nios II processor does not allow pre-emption between interrupts assigned to the same register set unless this feature is specifically enabled. In this case, the ISRs must be written so as to avoid register corruption.

For more information, refer to an example of a driver that manages pre-emption within a register set in the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Related Information

[Vectored Interrupt Controller Core](#)

9.1.2.2.4. Requested NMI Mode

If the interrupt is configured as a nonmaskable interrupt (NMI), the EIC asserts requested NMI (RNMI). Any hardware interrupt can be nonmaskable, depending on the configuration of the EIC. An NMI typically signals a critical system event requiring immediate handling, to ensure either system stability or deterministic real-time performance.

9.1.2.2.5. Shadow Register Sets

Although shadow register sets can be implemented independently of the EIC interface, typically the two features are used together. Combining shadow register sets with an appropriate EIC, you can minimize or eliminate the context switch overhead for critical hardware interrupts.

9.1.3. Latency and Response Time

Exception (interrupt) latency, as defined in the previous section, is the time required for the hardware to respond to an exception. Response time, in contrast, is the time required to begin executing code specific to the exception cause, such as a particular ISR. Response time includes latency plus the time required for the HAL to carry out some or all of the following overhead tasks:

- Context save—Saving registers on the stack
- RTOS context switch—Calling context-switch function(s) if an RTOS is implemented
- Dispatch handler—Determining the cause of the exception, and transferring control to a specific handler or ISR

If you are concerned with system performance, response time is the more important than latency, because it reflects the time elapsed between the physical event and the system's specific response to that event.



9.1.3.1. Internal or External Interrupt Controller

The Nios II IIC is nonvectored, requiring the processor to dispatch ISRs with a software routine. An EIC, by contrast, can be vectored. With a vectored EIC, such as the Intel FPGA[®] VIC, ISR dispatch is managed by hardware, eliminating the processing time required for ISR dispatch, and substantially reducing hardware interrupt response time.

An EIC has no impact on software exception latency or response time.

9.1.3.2. Shadow Register Sets

In conjunction with an EIC, shadow register sets speed up hardware interrupt response by making it unnecessary to save registers on the stack. This feature has no impact on interrupt latency, but significantly reduces interrupt response time.

Shadow register sets have no impact on software exception response time.

9.1.3.2.1. How the Hardware Works

The Nios II processor can respond to exceptions including software exceptions and hardware interrupts. When the Nios II processor responds to an exception, it performs the following tasks:

- Saves the `status` register in `estatus`. This means that if hardware interrupts are enabled, the `PIE` bit of `estatus` is set.
- Disables hardware interrupts.
- Saves the next execution address in `ea` (`r29`).
- Transfers control to the appropriate exception address, as follows:
 - Software exception or internal hardware interrupt—Nios II processor general exception address
 - External hardware interrupt—Device-specific interrupt address

All Nios II exception types are precise. This means that after an exception is handled, the Nios II processor can re-execute the instruction that caused the exception.

The Nios II processor always re-executes the instruction after the software exception handler or ISR has completed, when the exception processing system returns to the application context.

Several exception types, such as the advanced exceptions, are optional in the Nios II processor core. The presence of these exception types depends on how the hardware designer configures the Nios II core at the time of hardware generation.

The processor's response to hardware interrupts depends on which interrupt controller is implemented. The following sections describe the hardware behavior with each interrupt controller.

For more information about the Nios II processor exception controller and hardware interrupt controllers, including a list of optional exception types, refer to the "Processor Architecture" chapter of the *Nios II Processor Reference Handbook*.

Related Information

- [Invalid Instructions](#) on page 279

- [Processor Architecture](#)

9.1.3.3. How the Internal Interrupt Controller Works

With the IIC, 32 independent hardware interrupt signals are available. These interrupt signals allow software to prioritize interrupts, although the interrupt signals themselves have no inherent priority.

Note: With the IIC, Nios II exceptions are not vectored. Therefore, the same exception address receives control for all types of exceptions. The general exception funnel at that address must determine the type of software exception or hardware interrupt.

9.1.3.4. How an External Interrupt Controller Works

With an EIC, the Nios II processor supports an arbitrary number of independent hardware interrupt signals. Interrupts are typically vectored, with interrupt priority levels associated in hardware. Vectoring allows the Nios II processor to transfer control directly to each ISR. Hardware interrupt levels allow the most critical interrupts to pre-empt lower-priority interrupts. Because both of these features are implemented in hardware, the system can handle an interrupt without executing general exception funnel code.

Note: The details of hardware interrupt vectoring and prioritization are specific to the EIC implementation.

For more information, refer to an example of an EIC implementation in the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Note: The HAL supports external interrupt controllers only if they are connected in one of the following ways:

- Directly to the Nios II EIC interface
- Through the daisy-chain port on another EIC

Related Information

[Vectored Interrupt Controller Core](#)

9.2. Nios II Interrupt Service Routines

Software often communicates with peripheral devices using hardware interrupts. When a peripheral asserts its IRQ, it diverts the processor's normal execution flow. When such an interrupt occurs, an appropriate ISR must handle this interrupt and return the processor to its pre-interrupt state on completion.

When you create a board support package (BSP) project, the build tools include all needed device drivers. You do not need to write HAL ISRs unless you are interfacing to a custom peripheral. For reference purposes, this section describes the framework provided by HAL BSPs for handling hardware interrupts.

For examples of HAL ISRs, refer to existing handlers for Intel FPGA components.

For more information about the Intel FPGA-provided HAL handlers, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.



Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

9.2.1. HAL APIs for Hardware Interrupts

The HAL provides an enhanced application program interface (API) for writing, registering and managing ISRs. This API is compatible with both internal and external hardware interrupt controllers.

Intel FPGA also supports a legacy hardware interrupt API. This API supports only the IIC. If you have a custom driver written prior to Nios II version 9.1, it uses the legacy API.

Both interrupt APIs include the following types of routines:

- Routines to be called by a device driver to register an ISR
- Routines to be called by an ISR to manage its environment
- Routines to be called by BSP or application code to control ISR behavior

Both interrupt APIs support the following types of BSPs:

- HAL BSP without an RTOS
- HAL-based RTOS BSP, such as a MicroC/OS-II BSP

Note: The legacy API is deprecated. Write new drivers using the enhanced API, even if they are only intended to support the IIC. Drivers for devices supporting an EIC must use the enhanced API. Existing legacy drivers continue to be supported until further notice. Make plans to port them to the enhanced API.

When an EIC is present, the controller's driver provides driver settings for the BSP, which can be used to configure the driver. The number and types of the settings depends on the EIC implementation and the number of EICs present.

For more information, refer to an example of EIC driver settings in the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Related Information

- [Vectored Interrupt Controller Core](#)
- [The Enhanced HAL Interrupt API](#) on page 252

9.2.1.1. Selecting an Interrupt API

When the SBT creates a BSP, it determines whether the BSP must implement the legacy interrupt API. Each driver that supports the enhanced API publishes this capability to the SBT through its `<driver name>_sw.tcl` file. The BSP implements the enhanced API if all drivers support it. It implements the legacy API only if required by the drivers.

In determining the interrupt API to use, the SBT ignores any devices whose interrupts are not connected to the Nios II processor associated with the BSP.



A driver can publish its interrupt API support by way of a software property. The driver's `<driver name>_sw.tcl` file uses the `set_sw_property` command to set `supported_interrupt_apis` to either `legacy_interrupt_api`, `enhanced_interrupt_api`, or both.

Drivers supporting the enhanced API always publish that support. If `supported_interrupt_apis` is undefined, the SBT assumes that the driver only supports the legacy API.

Starting in 9.1, all Intel FPGA device drivers support both APIs. These drivers can be used in a BSP along with legacy drivers. The SBT determines whether the legacy API is required, and implements it only if it is required. If there are no drivers requiring the legacy API, the BSP implements the enhanced API.

A driver can be written to support only the enhanced API. However, you cannot combine such a driver with legacy drivers.

For more information and details about writing a driver to support both APIs, refer to the "Supporting Multiple Interrupt APIs" chapter.

Related Information

[Supporting Multiple Interrupt APIs](#) on page 254

9.2.1.2. The Enhanced HAL Interrupt API

Table 43. Enhanced HAL Interrupt API Functions that Manage Hardware Interrupt Processing

Function Name	Implemented By
<code>alt_ic_isr_register()</code>	Interrupt controller driver ()
<code>alt_ic_irq_enable()</code>	Interrupt controller driver ()
<code>alt_ic_irq_disable()</code>	Interrupt controller driver ()
<code>alt_ic_irq_enabled()</code>	Interrupt controller driver ()
<code>alt_irq_disable_all()</code>	HAL
<code>alt_irq_enable_all()</code>	HAL
<code>alt_irq_enabled()</code>	HAL

Note: If the system is based on an EIC, these functions must be implemented by the EIC driver. If the system is based in the IIC, the functions are implemented by the HAL. For more information about each function, refer to the "HAL API Reference" section.

Related Information

[HAL API Reference](#) on page 315

9.2.1.3. Using the Enhanced HAL Interrupt API to Implement ISRs

Using the enhanced HAL API to implement ISRs requires that you perform the following steps:



1. Write your ISR that handles hardware interrupts for a specific device.
2. Ensure that your program registers the ISR with the HAL by calling the `alt_ic_isr_register()` function. `alt_ic_isr_register()` enables hardware interrupts for you.

The SBT inserts the following symbol definitions in `system.h`, indicating the configuration of the processor's interrupt-related hardware options:

- `NIOS2_EIC_PRESENT`—If defined, indicates that one or more EICs are present
- `NIOS2_NUM_OF_SHADOW_REG_SETS`—Indicates how many shadow register sets are present. The maximum value is 63. If there are no shadow register sets, the value is 0.

9.2.1.3.1. The External Interrupt Controller Driver

To be compliant with the HAL enhanced interrupt API, the driver for an EIC must support the functions listed under "The Enhanced HAL Interrupt API" chapter.

For more information, refer to the "The Enhanced HAL Interrupt API" chapter.

In addition, it can provide functions to support any special hardware features.

For more information, refer to the "Using the HAL Interrupt API with the VIC" chapter.

Related Information

- [The Enhanced HAL Interrupt API](#) on page 252
- [Using the HAL Interrupt API with the VIC](#) on page 253

9.2.1.3.2. Using the HAL Interrupt API with the VIC

The Intel FPGA driver for the VIC component supports the HAL enhanced interrupt API.

The VIC driver provides support for multiple, daisy chained VIC devices. It also includes support for shadow register sets. A BSP driver setting allows you to enable automatic pre-emption (fast nested interrupts). Automatic pre-emption means that the Nios II processor leaves maskable exceptions enabled when accepting a hardware interrupt.

For more information about fast nested interrupts, refer to "Exception Processing" in the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

The VIC device driver also provides the following device-specific functions:

- `int alt_vic_sw_interrupt_set(alt_u32 ic_id, alt_u32 irq);`
- `int alt_vic_sw_interrupt_clear(alt_u32 ic_id, alt_u32 irq);`
- `alt_u32 alt_vic_sw_interrupt_status(alt_u32 ic_id, alt_u32 irq);`
- `int alt_vic_irq_set_level(alt_u32 ic_id, alt_u32 irq, alt_u32 level);`

For more information, refer to a detailed discussion of the VIC device-specific driver routines in the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

The EIC driver controls where hardware interrupt vector tables are located. For example, the Intel FPGA VIC driver locates the vector table in the `.text` section by default, but allows you to position the vector table in a different section with a driver setting.

Note: The memory in which you place the vector table must be connected to both instruction and data master ports on the Nios II processor.

Related Information

- [Programming Model](#)
- [Vectored Interrupt Controller Core](#)

9.2.1.4. The Legacy HAL Interrupt API

The legacy HAL interrupt API defines the following functions to manage hardware interrupt processing:

- `alt_irq_register()`
- `alt_irq_disable()`
- `alt_irq_enable()`
- `alt_irq_disable_all()`
- `alt_irq_enable_all()`
- `alt_irq_interruptible()`
- `alt_irq_non_interruptible()`
- `alt_irq_enabled()`

For more information about these functions, refer to the "HAL API Reference" chapter.

Legacy drivers do not define the `supported_interrupt_apis` property. The absence of this property indicates to the SBT that they require the legacy interrupt API.

9.2.1.4.1. Using the Legacy HAL API to Implement ISRs

Using the legacy HAL API to implement ISRs requires that you perform the following steps:

1. Write your ISR that handles hardware interrupts for a specific device.
2. Ensure that your program registers the ISR with the HAL by calling the `alt_irq_register()` function. `alt_irq_register()` enables hardware interrupts for you, by calling `alt_irq_enable_all()`.

9.2.1.5. Supporting Multiple Interrupt APIs

When you write or update a custom device driver, Intel FPGA recommends that you write it in one of two ways:



- Write it to support the enhanced HAL interrupt API—Write the driver this way if you intend to use it only in combination with other drivers supporting the enhanced API.
- Write it to support both the enhanced and the legacy API—Write the driver this way if you need to use it in combination with legacy drivers supporting only the legacy API.

Note: Intel FPGA recommends using the enhanced API even if your Nios II processor implements the IIC. The enhanced API supports both types of interrupt controller, and the legacy API is deprecated.

When the SBT selects the interrupt API, it defines one of the following symbols in `system.h`, to identify which interrupt API is available:

- `ALT_ENHANCED_INTERRUPT_API_PRESENT`—Defined if the enhanced API is implemented
- `ALT_LEGACY_INTERRUPT_API_PRESENT`—Defined if the legacy API is implemented

In your driver code, use these symbols to determine which API calls to make.

To support both APIs, your driver must publish its interrupt API support by way of a software property. In your driver's `<driver name>_sw.tcl` file, use the `set_sw_property` command to set `supported_interrupt_apis` to both `legacy_interrupt_api` and `enhanced_interrupt_api`.

For more information about the `set_sw_property` command, refer to the "Software Build Tools Tcl Commands" section of the "Nios II Software Build Tools Reference" section.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

9.2.2. HAL ISR Restrictions

When your system has an EIC, the HAL interrupt support imposes the following restrictions:

- Nonmaskable hardware interrupts must use a shadow register set.
- Nonmaskable hardware interrupts cannot share a register set with a maskable hardware interrupt.

9.2.3. Writing an ISR

The ISR you write must match the prototype that `alt_ic_isr_register()` expects. The prototype for your ISR function must match the following prototype:

```
void (*alt_isr_func) (void* isr_context)
```

The parameter definition of `context` is the same as for the `alt_ic_isr_register()` function.

From the point of view of the HAL exception handling system, the most important function of an ISR is to clear the associated peripheral's interrupt condition. The procedure for clearing an hardware interrupt condition is specific to the peripheral.

For more information, refer to the relevant chapter in the "Embedded Peripherals IP User Guide".

When the ISR has finished servicing the hardware interrupt, it must return to the HAL interrupt funnel that called it.

Note: If you write your ISR in assembly language, use `ret` to return. The HAL interrupt funnel issues an `eret` after restoring the application context.

Related Information

[Embedded Peripherals IP User Guide](#)

9.2.3.1. Using Interrupt Funnels

The HAL creates a vector table for each EIC connected to the Nios II processor. In the vector table, the HAL inserts a branch to the correct funnel for each interrupt-driven device supported by the BSP, depending on the device driver characteristics and pre-emption settings. Funnels can be shared by multiple hardware interrupts, if the drivers have compatible characteristics.

The funnel code receives control from the general exception or interrupt vector, depending on which interrupt controller is implemented. The funnel performs tasks such as switching the stack pointer, saving registers and calling RTOS context-switch routines, and transfers control to the handler. When the handler returns, the funnel code performs tasks such as calling RTOS process-dispatch routines and restoring registers, and transfers control to the appropriate foreground task.

The HAL includes the following interrupt funnels:

- Shadow register set, pre-emption disabled—Hardware interrupt assigned to a shadow register set, with pre-emption within the register set disabled. This funnel does not preserve register context. Hardware guarantees that only one ISR runs with the shadow register set at any time.
- Shadow register set, pre-emption enabled—Hardware interrupt assigned to a shadow register set. An interrupt can pre-empt another interrupt using the same register set. This funnel preserves register context, so that handlers assigned to the same register set do not corrupt one another's context.
- Nonmaskable interrupt—Nonmaskable hardware interrupt assigned to a shadow register set, with pre-emption within the register set disabled. This funnel does not preserve register context. Hardware guarantees that only one ISR runs in the shadow register set at any time.

The HAL funnel code is called from the vector table.

9.2.3.2. Running in a Restricted Environment

ISRs run in a restricted environment. A large number of the HAL API calls are not available from ISRs. For example, accesses to the HAL file system are not permitted. As a general rule, when writing your own ISR, never include function calls that can block for any reason (such as waiting for a hardware interrupt).



For more information about identifying these API functions that are not available to ISRs, refer to the "HAL API Reference" chapter.

Be careful when calling ANSI C standard library functions inside of an ISR. Avoid using the C standard library I/O API, because calling these functions can result in deadlock within the system, that is, the system can become permanently blocked in the ISR.

In particular, do not call `printf()` from within an ISR unless you are certain that `stdout` is mapped to a non-interrupt-based device driver. Otherwise, `printf()` can deadlock the system, waiting for a hardware interrupt that never occurs because interrupts are disabled.

Related Information

[HAL API Reference](#) on page 315

9.2.3.3. Managing Pre-Emption

The HAL enhanced interrupt API supports interrupt pre-emption. When pre-emption is enabled, a higher-level interrupt can take control even if an ISR is already running. A device driver must be specifically written to function correctly under pre-emption. When a device driver supports pre-emption, it publishes this capability through the `isr_preemption_supported` driver setting. When constructing the BSP, the SBT checks each device driver to determine whether it supports pre-emption. If all drivers in the BSP support pre-emption, it is enabled.

Legacy device drivers do not publish the `isr_preemption_supported` property. Therefore the SBT assumes that they do not support pre-emption. If your legacy custom driver supports pre-emption, and you want to allow pre-emption in the BSP, you must update the driver to use the enhanced interrupt API.

Note: To enable the enhanced interrupt API, ensure that all drivers in the system are updated to use the enhanced interrupt API.

For more information and details about the `isr_preemption_supported` driver setting, refer to the `set_sw_property` command in the "Software Build Tools Tcl Commands" section of the "Nios II Software Build Tools Reference" chapter.

Operating systems can also publish the `isr_preemption_supported` property.

The HAL enhanced interrupt API supports automatic pre-emption. Automatic pre-emption means that maskable exceptions remain enabled when the processor accepts the hardware interrupt. This means that your ISR can immediately be pre-empted by a higher-level ISR, without any need to execute the `eret` instruction.

Automatic pre-emption can only take place when the pre-empting hardware interrupt uses a different register set from the interrupt being pre-empted.

Automatic pre-emption is only available if you enable it in the BSP settings.

Related Information

[Nios II Software Build Tools Reference](#) on page 396

9.2.4. Registering an ISR with the Enhanced Interrupt API

Before the software can use an ISR, you must register it by calling `alt_ic_isr_register()`. The prototype for `alt_ic_isr_register()` is:

```
int alt_ic_isr_register(alt_u32 ic_id,
    alt_u32 irq,
    alt_isr_func isr,
    void *isr_context,
    void* flags)
```

The function has the following parameters:

- `ic_id` is the interrupt controller identifier (ID) as defined in `system.h`. With daisy-chained EICs, `ic_id` identifies the EIC in the daisy chain. With the IIC, `ic_id` is not significant.
- `irq` is the hardware interrupt number for the device, as defined in `system.h`.
 - For the IIC, `irq` is the IRQ number. Interrupt priority corresponds inversely to the IRQ number. Therefore, `IRQ0` represents the highest priority interrupt and `IRQ31` is the lowest.
 - For an EIC, `irq` is the interrupt port ID.
- `isr_context` points to a data structure associated with the device driver instance. `isr_context` is passed as the input argument to the `isr` function. It is used to pass context-specific information to the ISR, and can point to any ISR-specific information. The context value is opaque to the HAL; it is provided entirely for the benefit of the user-defined ISR.
- `isr` is a pointer to the ISR function that is called in response to IRQ number `irq`. The ISR function prototype is:
`void (void* isr_context);`
 The input argument provided to this function is the `isr_context`.

Note: Registering a null pointer for `isr` results in the interrupt being disabled.

- `flags` is reserved.

Related Information

[The Enhanced HAL Interrupt API](#) on page 252

9.2.4.1. Methods the HAL Uses to Register the ISR

The HAL registers the ISR by one of the following methods:

- For the IIC, by storing the function pointer, `isr`, in a lookup table.
- For an EIC, by configuring the vector table with the appropriate funnel code
 For more information, refer to the “Using Interrupt Funnels” chapter.

The return code from `alt_ic_isr_register()` is zero if the function succeeded, and nonzero if it failed.

If the HAL registers your ISR successfully, the associated Nios II hardware interrupt (as defined by `irq`) is enabled on return from `alt_ic_isr_register()`.



Note: Hardware-specific initialization might also be required.

When a specific interrupt occurs, the HAL code ensures that the registered ISR is correctly dispatched.

For more information and details about hardware interrupt initialization specific to your peripheral, refer to the relevant chapter of the *Embedded Peripherals IP User Guide*.

For more information about `alt_ic_isr_register()`, refer to the "HAL API Reference" chapter.

Note: The HAL legacy interrupt API provides a different function for registering hardware interrupts. For all new and updated drivers, Intel FPGA recommends using the enhanced API described in this section.

For more information about the legacy API function, `alt_irq_register()`, refer to the "HAL API Reference" chapter.

Related Information

- [Using Interrupt Funnels](#) on page 256
- [HAL API Reference](#) on page 315
- [Embedded Peripherals IP User Guide](#)

9.2.5. Enabling and Disabling Interrupts

The HAL enhanced interrupt API provides the functions `alt_ic_irq_disable()`, `alt_ic_irq_enable()`, `alt_ic_irq_enabled()`, `alt_irq_disable_all()`, `alt_irq_enable_all()`, and `alt_irq_enabled()` to allow a program to disable hardware interrupts for certain sections of code, and reenable them later.

`alt_ic_irq_disable()` and `alt_ic_irq_enable()` allow you to disable and enable individual interrupts. `alt_irq_disable_all()` disables all interrupts, and returns a context value. To reenable hardware interrupts, you call `alt_irq_enable_all()` and pass in the context parameter. In this way, interrupts are returned to their state prior to the call to `alt_irq_disable_all()`. `alt_irq_enabled()` returns nonzero if maskable exceptions are enabled. `alt_ic_irq_enabled()` determines whether a specified interrupt is enabled.

Note: Disable hardware interrupts for as short a time as possible. Maximum interrupt latency increases with the longest amount of time interrupts are disabled.

For more information about disabled interrupts, refer to the "Keep Interrupts Enabled" chapter.

For more information about these functions, refer to the "HAL API Reference" chapter.

Note: The HAL legacy interrupt API provides different functions for enabling and disabling individual interrupts. For all new and updated drivers, Intel FPGA recommends using the enhanced API described in this section.

For more information about the legacy API functions, `alt_irq_disable()` and `alt_irq_enable()`, refer to the "HAL API Reference" chapter.

Related Information

- [Keep Interrupts Enabled](#) on page 263
- [HAL API Reference](#) on page 315

9.2.6. Configuring an External Interrupt Controller

The driver for an EIC provides specialized driver settings that are created at the time you generate the BSP. These settings customize the driver to the EIC configuration found in the Nios II system. The number and type of settings depends on the EIC implementation, as well as on the number and configuration of EICs in the hardware system. The SBT creates the BSP with default values, selected to ensure useful system performance. You can optimize these settings at the time you create the BSP. For details of how to manipulate the EIC driver settings, refer to the documentation for your specific EIC.

The driver for an EIC can provide specialized functions to manage any implementation-specific features of the EIC. An example would be modifying interrupt priority levels at runtime.

For more information, refer to the examples in the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Related Information

[Vectored Interrupt Controller Core](#)


9.2.7. C Example

9.2.7.1. An ISR to Service a Button PIO Interrupt

This example is based on a Nios II system with a 4-bit PIO peripheral connected to push buttons. An IRQ is generated any time a button is pushed. The ISR code reads the PIO peripheral's edge capture register and stores the value to a global variable. The address of the global variable is passed to the ISR in the context pointer.

Example 2. Example 8–1. An ISR to Service a Button PIO Interrupt

```
#include "system.h"
#include "altera_avalon_pio_regs.h"
#include "alt_types.h"
#ifdef ALT_ENHANCED_INTERRUPT_API_PRESENT
static void handle_button_interrupts(void* context)
#else
static void handle_button_interrupts(void* context, alt_u32 id)
#endif
{
    /* Cast context to edge_capture's type. It is important that this
    be declared volatile to avoid unwanted compiler optimization. */
    volatile int* edge_capture_ptr = (volatile int*) context;
    /*
    * Read the edge capture register on the button PIO.
    * Store value.
    */
    *edge_capture_ptr =
    IORD_ALTERA_AVALON_PIO_EDGE_CAP(BUTTON_PIO_BASE);
    /* Write to the edge capture register to reset it. */
    IOWR_ALTERA_AVALON_PIO_EDGE_CAP(BUTTON_PIO_BASE, 0);
    /* Read the PIO to delay ISR exit. This is done to prevent a
    spurious interrupt in systems with high processor -> pio
```



```
latency and fast interrupts. */
IORD_ALTERA_AVALON_PIO_EDGE_CAP(BUTTON_PIO_BASE);
}
```

9.2.7.2. Registering the Button PIO ISR with the HAL

Based on the code in the example, the following execution flow is possible:

- Button is pressed, generating an IRQ.
- The ISR gains control.
 - With the IIC, the HAL general exception funnel gains control of the processor, and dispatches the `handle_button_interrupts()` ISR.
 - With an EIC, the processor branches to the address in the vector table, which transfers control to the `handle_button_interrupts()` ISR.
- `handle_button_interrupts()` services the hardware interrupt and returns.
- Normal program operation continues with an updated value of `edge_capture`.

Example 3. Example 8–2. Registering the Button PIO ISR with the HAL

```
#include "sys/alt_irq.h"
#include "system.h"
...
/* Declare a global variable to hold the edge capture value. */
volatile int edge_capture;
...
/* Initialize the button_pio. */
static void init_button_pio()
{
    /* Recast the edge_capture pointer to match the
    alt_irq_register() function prototype. */
    void* edge_capture_ptr = (void*) &edge_capture;
    /* Enable all 4 button interrupts. */
    IOWR_ALTERA_AVALON_PIO_IRQ_MASK(BUTTON_PIO_BASE, 0xf);
    /* Reset the edge capture register. */
    IOWR_ALTERA_AVALON_PIO_EDGE_CAP(BUTTON_PIO_BASE, 0x0);
    /* Register the ISR. */
    #ifdef ALT_ENHANCED_INTERRUPT_API_PRESENT
    alt_ic_isr_register(BUTTON_PIO_IRQ_INTERRUPT_CONTROLLER_ID,
        BUTTON_PIO_IRQ,
        handle_button_interrupts,
        edge_capture_ptr, 0x0);
    #else
    alt_irq_register( BUTTON_PIO_IRQ,
        edge_capture_ptr,
        handle_button_interrupts );
    #endif
}
```

Note: Additional software examples that demonstrate implementing ISRs, such as the `count_binary` example project template, are installed with the Nios II Embedded Design Suite (EDS).

9.2.8. Upgrading to the Enhanced HAL Interrupt API

If you have custom device drivers, Intel FPGA recommends that you upgrade them to use the enhanced HAL interrupt API. The enhanced API maintains compatibility with the IIC, while supporting external interrupt controllers. The legacy HAL interrupt API is deprecated.

If you plan to use an EIC, you must upgrade your custom driver to the enhanced HAL interrupt API.

Upgrading your device driver is very simple, requiring only minor changes to some function calls.

For more information and details of the API functions, refer to the "HAL API Reference" chapter.

Table 44. HAL Interrupt Legacy and Enhanced API Functions to

Legacy API Function	Enhanced API Function
<code>alt_irq_register()</code>	<code>alt_ic_isr_register()</code>
<code>alt_irq_disable()</code>	<code>alt_ic_irq_disable()</code>
<code>alt_irq_enable()</code>	<code>alt_ic_irq_enable()</code>

If your upgraded driver might need to function in a BSP with legacy drivers, code it to support both APIs.

For more information, refer to the "Supporting Multiple Interrupt APIs" chapter.

Related Information

- [Supporting Multiple Interrupt APIs](#) on page 254
- [HAL API Reference](#) on page 315

9.3. Improving Nios II ISR Performance

If your software uses hardware interrupts extensively, the performance of ISRs is probably the most critical determinant of your overall software performance.

9.3.1. Software Performance Improvements

In improving your ISR performance, you probably consider software changes first. However, in some cases it might require less effort to implement hardware design changes that increase system efficiency.

For more information about hardware optimizations, refer to the "Hardware Performance Improvements" chapter.

The following sections describe changes you can make in the software design to improve ISR performance.

Related Information

[Hardware Performance Improvements](#) on page 268

9.3.1.1. Execute Time-Intensive Algorithms in the Application Context

ISRs provide rapid, low latency response to changes in the state of hardware. They do the minimum necessary work to clear the hardware interrupt condition and then return. If your ISR performs lengthy, noncritical processing, it can interfere with more critical tasks in the system.



If your ISR requires lengthy processing, design your software to perform this processing outside of the exception context. The ISR can use a message-passing mechanism to notify the application code to perform the lengthy processing tasks.

Deferring a task is simple in systems based on an RTOS such as MicroC/OS-II. In this case, you can create a thread to handle the processor-intensive operation, and the ISR can communicate with this thread using any of the RTOS communication mechanisms, such as event flags or message queues.

You can emulate this approach in a single-threaded HAL-based system. The main program polls a global variable managed by the ISR to determine whether it needs to perform the processor-intensive operation.

9.3.1.2. Implement Time-Intensive Algorithms in Hardware

Processor-intensive tasks must often transfer large amounts of data to and from peripherals. A general-purpose processor such as the Nios II processor is not the most efficient way to do this. Use direct memory access (DMA) hardware if it is available.

For more information about programming with DMA hardware, refer to "Using DMA Devices" in the "Developing Programs Using the Hardware Abstraction Layer chapter".

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

9.3.1.3. Increase Buffer Size

If you are using DMA to transfer large data buffers, the buffer size can affect performance. Small buffers imply frequent interrupts, which lead to high overhead.

Increase the size of the transaction data buffer(s).

9.3.1.4. Use Double Buffering

Using DMA to transfer large data buffers might not provide a large performance increase if the Nios II processor must wait for DMA transactions to complete before it can perform the next task.

Double buffering allows the Nios II processor to process one data buffer while the hardware is transferring data to or from another.

9.3.1.5. Keep Interrupts Enabled

When interrupts are disabled, the Nios II processor cannot respond quickly to hardware interrupt events. Buffers and queues can fill or overflow. Even in the absence of overflow, maximum interrupt processing time can increase after interrupts are re-enabled, because the ISRs must process data backlogs.

Disable interrupts as infrequently as possible, and for the briefest time possible.

Instead of disabling all interrupts, call `alt_ic_irq_disable()` and `alt_ic_irq_enable()` to enable and disable individual interrupts.

To protect shared data structures, use RTOS structures such as semaphores.

Disable all interrupts only during critical system operations. In the code where interrupts are disabled, perform only the bare minimum of critical operations, and reenable interrupts immediately.

9.3.1.6. Use Fast Memory

ISR performance depends on memory speed.

For best performance, place the ISRs and the stack in the fastest available memory: preferably tightly-coupled memory (if available), or on-chip memory.

If it is not possible to place the main stack in fast memory, consider using a separate exception stack, mapped to a fast memory section, as described in the next section.

For more information about mapping memory, refer to "Memory Usage" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

For more information about tightly-coupled memory, refer to the "Cache and Tightly-Coupled Memory" chapter.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [Cache and Tightly-Coupled Memory](#) on page 283

9.3.1.7. Use a Separate Exception Stack

The HAL implements two types of separate exception stack. Their availability depends on the interrupt controller, as described in this section. The "Separate Exception Stack Usage" table ([Table 8-3](#)) outlines the availability of separate exception stacks, and how they can be used with each type of interrupt controller.

Note: Using a separate exception stack entails a slight additional overhead. When processing a software exception or hardware interrupt, the processor must execute an additional instruction on entry and exit, to change the stack pointer. Take this additional processing time into account if your interrupt response requirements are extremely strict.

9.3.1.7.1. Separate General Exception Stack

The separate general exception stack is available with either the internal or the external interrupt controller.

Use the `hal.linker.enable_exception_stack` BSP setting to enable a separate general exception stack.

The HAL general exception funnel code takes care of correctly changing the stack pointer on entry to and exit from an exception handler.

9.3.1.7.2. Separate Hardware Interrupt Stack

The separate hardware interrupt stack is available with the EIC interface. The separate hardware interrupt stack is not applicable to the IIC. With the IIC, hardware interrupts and software exceptions use the same stack. The following BSP settings enable you to control the separate hardware interrupt stack:



- `hal.linker.enable_interrupt_stack` enables a separate hardware interrupt stack.
- `hal.linker.interrupt_stack_size` controls the size of the hardware interrupt stack.
- `hal.linker.interrupt_stack_memory_region_name` enables you to control where the hardware interrupt stack is positioned in memory.

The HAL funnel code takes care of correctly changing the stack pointer on entry to and exit from an ISR.

Table 45. Separate Exception Stack Usage

Interrupt Controller	BSP Settings		Application Stack	General Exception Stack	Hardware Interrupt Stack
	Separate General Exception Stack Enabled	Separate Hardware Interrupt Stack Enabled			
Internal	No	—	<ul style="list-style-type: none"> • Application • Software exceptions • Hardware interrupts 	—	—
	Yes	—	Application	<ul style="list-style-type: none"> • Software exceptions • Hardware interrupts 	—
External	No	No	<ul style="list-style-type: none"> • Application • Software exceptions • Hardware interrupts 	—	—
		Yes	<ul style="list-style-type: none"> • Application • Software exceptions 	—	Hardware interrupts
	Yes	No	<ul style="list-style-type: none"> • Application • Hardware interrupts 	Software exceptions	—
		Yes	Application	Software exceptions	Hardware interrupts

Note: If your ISR is located in a vector table, the HAL does not provide funnel code. In this case, your code must manage the stack pointer, as well as all other funnel code functions.

For more information about implementing a separate hardware interrupt stack, refer to *AN595: Vectored Interrupt Controller Applications and Usage*.

Related Information

[AN595: Vectored Interrupt Controller Usage and Applications](#)

9.3.1.8. Use Nested Hardware Interrupts

By default, the HAL disables interrupts when it dispatches an ISR. This means that only one ISR can execute at any time, and ISRs are executed on a first-come first-served basis. This reduces the system overhead associated with interrupt processing, and simplifies ISR development. The ISR does not need to be reentrant. ISRs can use and modify any global or static data structures or hardware registers that are not shared with application code.

However, first-come first-served execution means that the HAL hardware interrupt priorities only have an effect if two IRQs are active at the same time. A low-priority interrupt occurring before a higher-priority interrupt can prevent the higher-priority ISR from executing. This is a form of priority inversion, and it can have a significant impact on ISR performance in systems that generate frequent interrupts.

A software system can achieve full hardware interrupt prioritization by using nested ISRs. With nested ISRs, higher-priority interrupts are allowed to interrupt lower-priority ISRs.

This technique can improve the response time for higher-priority interrupts.

Note: Nested ISRs increase the processing time for lower-priority hardware interrupts.

If your ISR is very short, it might not be worth the overhead to enable nested hardware interrupts. Enabling nested interrupts for a short ISR can actually increase the response time for higher-priority interrupts.

Note: If you use a separate exception stack with the IIC, you cannot nest hardware interrupts.

For more information about separate exception stacks, refer to [“Use a Separate Exception Stack”](#).

Related Information

[Use a Separate Exception Stack](#) on page 264

9.3.1.8.1. Nested Hardware Interrupts with the Internal Interrupt Controller

To implement nested hardware interrupts with the IIC, use the `alt_irq_interruptible()` and `alt_irq_non_interruptible()` legacy functions to bracket code in a processor-intensive ISR.

Note: The legacy API is deprecated. Write new drivers using the enhanced API, even if they are only intended to support the IIC. Drivers for devices supporting an EIC must use the enhanced API. Existing legacy drivers continue to be supported until further notice. Make plans to port them to the enhanced API.

If you choose to continue using the legacy APIs, you must first comment out `#define ALT_ENHANCED_INTERRUPT_API_PRESENT` in `system.h`.

The call to `alt_irq_interruptible()` adjusts the interrupt mask so that higher-priority interrupts can take control from the running ISR. When your ISR calls `alt_irq_non_interruptible()`, the interrupt mask is returned to its previous state.



Note: If your ISR calls `alt_irq_interruptible()`, it must call `alt_irq_non_interruptible()` before returning. Otherwise, the HAL exception handling system might lock up.

9.3.1.8.2. Nested Hardware Interrupts with an External Interrupt Controller

The HAL enhanced interrupt API supports nested hardware interrupts, also known as interrupt pre-emption. A device driver must be specifically written to function correctly under pre-emption.

Legacy device drivers do not publish the `isr_preemption_supported` property. Therefore the SBT assumes that they do not support pre-emption. If your legacy custom driver supports pre-emption, and you want to allow pre-emption in the BSP, you must update the driver to use the enhanced HAL interrupt API.

The HAL enhanced interrupt API also supports automatic pre-emption. Automatic pre-emption means that maskable exceptions remain enabled when the processor accepts the hardware interrupt.

For more information about pre-emption with an EIC, refer to the “Managing Pre-Emption” chapter.

In the vector table, the HAL inserts a branch to the correct funnel for each hardware interrupt, depending on the pre-emption settings.

Related Information

[Managing Pre-Emption](#) on page 257

9.3.1.9. Locate ISR Body in Vector Table

If you are using a vectored EIC, and you have a critical ISR of small size, you might achieve a performance improvement by positioning the ISR code directly in the vector table. In this way, you eliminate the overhead of branching from the vector table through the HAL funnel to your ISR.

The EIC’s driver provides a default vector table entry size. For example, with the Intel FPGA VIC, the default size is 16 bytes. To accommodate your ISR, adjust the entry size with a driver setting when you create the BSP.

Note: Positioning an ISR in a vector table is an advanced and error-prone technique, not directly supported by the HAL. You must exercise great caution to ensure that the ISR code fits in the vector table entry. If your ISR overflows the vector table entry, it corrupts other entries in the vector table, and your entire interrupt handling system. When your ISR is located in the vector table, it does not need to be registered. Do not call `alt_ic_isr_register()`, because it overwrites the contents of the vector table. The HAL does not provide funnel code. Therefore, your code must manage all funnel code functions.

For more information about locating an ISR in a vector table, refer to *AN595: Vectored Interrupt Controller Usage and Applications*.

Related Information

[AN595: Vectored Interrupt Controller Usage and Applications](#)

9.3.1.10. Use Compiler Optimization

For the best performance both in exception context and application context, use compiler optimization level -O3. Level -O2 also produces good results. Removing optimization altogether significantly increases exception response time.

For more information about compiler optimizations, refer to "Reducing Code Footprint in Embedded Systems" in the "Developing Programs Using the Hardware Abstraction Layer chapter".

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

9.3.2. Hardware Performance Improvements

Several simple hardware changes can provide a substantial improvement in ISR performance. These changes involve editing and regenerating the hardware component, and recompiling the Quartus II design.

In some cases, these changes also require changes in the software architecture or implementation.

For more information about these and other software optimizations, refer to the "Software Performance Improvements" chapter.

The following sections describe changes you can make in the hardware design to improve ISR performance.

Related Information

[Software Performance Improvements](#) on page 262

9.3.2.1. Use Vectored Hardware Interrupts

By default, the Nios II processor has a nonvectored IIC. The HAL provides software to dispatch each hardware interrupt to its specific ISR. By contrast, vectoring allows the processor to transfer control directly to the ISR with minimal software intervention.

The options available for hardware interrupt vectoring depend on the interrupt controller configured in the Nios II hardware, as described in this section.

9.3.2.1.1. Using the Interrupt Vector Custom Instruction

The Nios II processor core offers an interrupt vector custom instruction that accelerates hardware interrupt vector dispatch in the HAL. You can include this custom instruction to improve your program's interrupt response time.

When the interrupt vector custom instruction is present in the Nios II processor, the HAL source detects it at compile time and generates code using the custom instruction.

When using an interrupt vector custom instruction, you cannot use a separate exception stack.

Note: The interrupt vector custom instruction is only available in hardware systems generated by SOPC Builder.



For more information about the interrupt vector custom instruction, refer to "Interrupt Vector Custom Instruction" in the "Instantiating the Nios II Processor" chapter of the *Nios II Processor Reference Handbook*.

Related Information

- [Using Tightly Coupled Memory with the Nios II Processor Tutorial](#)
- [Instantiating the Nios II Processor](#)

9.3.2.1.2. Using an External Interrupt Controller

The Nios II EIC port allows you to connect a customizable external interrupt controller component. An EIC can be vectored. An example is the Intel FPGA VIC.

For more information about the VIC, refer to the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Related Information

[Vectored Interrupt Controller Core](#)

9.3.2.2. Add Fast Memory

Increase the amount of fast on-chip memory available for data buffers. Ideally, implement tightly-coupled memory that the software can use for buffers.

For more information about tightly-coupled memory, refer to the "Cache and Tightly-Coupled Memory" chapter.

For more information about tightly-coupled memory, refer to the "Using Tightly Coupled Memory with the Nios II Processor Tutorial".

Related Information

- [Cache and Tightly-Coupled Memory](#) on page 283
- [Using Tightly Coupled Memory with the Nios II Processor Tutorial](#)
- [Instantiating the Nios II Processor](#)

9.3.2.3. Add a DMA Controller

A DMA controller performs bulk data transfers, reading data from a source address range and writing the data to a different address range. Add DMA controllers to move large data buffers. This allows the Nios II processor to carry out other tasks while data buffers are being transferred.

For more information about DMA controllers, refer to the "DMA Controller Core" and "Scatter-Gather DMA Controller Core" chapters in the *Embedded Peripherals IP User Guide*.

Related Information

[Embedded Peripherals IP User Guide](#)

9.3.2.4. Place the Handler in Fast Memory

For the fastest execution of exception handler code, place the handler in a fast memory device. For example, an on-chip RAM with zero wait states is preferable to a slow SDRAM. For best performance, store exception handling code and data in tightly-coupled memory.

9.3.2.5. Use a Fast Nios II Core

For processing in both the exception context and the application context, the Nios II/f core is the fastest, and the Nios II/e core (designed for small size) is the slowest.

9.3.2.6. Select Hardware Interrupt Priorities

Hardware interrupt priority levels can have a significant impact on system performance. If two interrupts can be asserted at the same time, it is important to assign a higher priority level to the more critical interrupt, so that it runs in preference to the less critical interrupt.

9.3.2.6.1. Hardware Interrupt Priorities with the Internal Interrupt Controller

When selecting the IRQ for each peripheral, remember that the HAL hardware interrupt funnel treats IRQ₀ as the highest priority. Assign each peripheral's interrupt priority based on its need for fast servicing in the overall system. Avoid assigning multiple peripherals to the same IRQ.

9.3.2.6.2. Hardware Interrupt Priorities with an External Interrupt Controller

With an EIC, the hardware interrupt priority level can be more flexible than with the IIC. The method of assigning priority levels to IRQs depends on the specific EIC implementation.

For example, with the Intel FPGA VIC, you can adjust hardware interrupt priority levels at runtime, with the `alt_vic_irq_set_level()` function.

For more information about the VIC, refer to the "Vectored Interrupt Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Related Information

[Vectored Interrupt Controller Core](#)

9.4. Debugging Nios II ISRs

You can debug an ISR by setting breakpoints in the ISR. The debugger completely halts the processor on reaching a breakpoint. In the meantime, however, the other hardware in your system continues to operate. Therefore, it is inevitable that other interrupts are ignored while the processor is halted. You can use the debugger to step through the ISR code, but the status of other interrupt-driven device drivers is generally invalid by the time you return the processor to normal execution. You must reset the processor to return the system to a valid state.

With the IIC, the `ipending` register (`ctl14`) is masked to all zeros during single-stepping. This masking prevents the processor from servicing interrupts that are asserted while you single-step through code. As a result, if you try to single-step through a part of the exception handling system that reads the `ipending` register, such as `alt_irq_entry()` or `alt_irq_handler()`, the code does not detect any



pending interrupts. This issue does not affect debugging software exceptions. You can set breakpoints in your ISR code (and single-step through it), because the interrupt funnel has already used `ipending` to determine which device caused the hardware interrupt.

9.5. HAL Exception Handling System Implementation

The exception handling system implementation is one of many possible implementations of an exception handling system for the Nios II processor. Some features of the HAL exception handling system are constrained by the Nios II hardware, while others provide generally useful services.

You can take advantage of the HAL exception handling system without a complete understanding of the HAL implementation.

For more information about how to install ISRs using the HAL API, refer to the “Nios II Interrupt Service Routines” chapter.

Related Information

[Nios II Interrupt Service Routines](#) on page 250

9.5.1. Exception Handling System Structure

The exception handling system consists of the following components:

- The general exception funnel
- The software exception funnel
- The hardware interrupt funnel(s)
- An ISR for each peripheral that generates hardware interrupts

With the IIC, there is a single hardware interrupt funnel. This funnel manages processor context switch and RTOS overhead (if any). It determines the source of the IRQ, and dispatches the correct ISR.

With an EIC, hardware interrupt funnels are configured by the EIC driver. With a vectored EIC, such as the Intel FPGA VIC, there are multiple hardware interrupt funnels. Each funnel manages processor context switch if necessary, and RTOS overhead if any. ISR dispatch is managed by hardware.

With the IIC, when the Nios II processor generates an exception, the general exception funnel receives control. The general exception funnel passes control to either the hardware interrupt funnel or the software exception funnel. The hardware interrupt funnel passes control to one or more ISRs.

Each time an exception occurs, the exception handling system services either a software exception or hardware interrupts, with hardware interrupts having a higher priority. The HAL IIC support does not include nested exceptions, but can handle multiple hardware interrupts per context switch.

For more information, refer to the “Hardware Interrupt Funnel” chapter.

With an EIC, the general exception funnel handles only software exceptions. An IRQ causes the processor to transfer control to one of the interrupt funnels, which branches directly to the ISR.

Related Information

[Hardware Interrupt Funnel](#) on page 273

9.5.2. General Exception Funnel

The general exception funnel provided with the HAL is located at the Nios II processor's exception address. When a software exception or internal hardware interrupt occurs, and control transfers to the general exception funnel, it does the following:

- Switches to the separate exception stack (if enabled)
- Stores register values onto the stack
- Determines the type of exception, and passes control to the software exception funnel or the hardware interrupt funnel

9.5.2.1. Hardware Interrupt Dispatch with the Internal Interrupt Controller

With the IIC, the general exception funnel dispatches hardware interrupts as well as software exceptions.

The general exception funnel looks at the `estatus` register to determine the interrupt enable status. If the `PIE` bit is set, hardware interrupts were enabled at the time the exception happened. If so, the general exception funnel transfers control to the hardware interrupt funnel. The hardware interrupt funnel looks at the `IRQ` bits in `ipending`. If any `IRQs` are asserted, the interrupt funnel calls the appropriate hardware interrupt handler.

If hardware interrupts are not enabled at the time of the exception, it is not necessary to look at `ipending`.

If no `IRQs` are active, there is no hardware interrupt, and the exception is a software exception. In this case, the general exception funnel calls the software exception funnel.

All hardware interrupts are higher priority than software exceptions.

Note: With an EIC, `IRQs` are dispatched by hardware. The HAL general exception funnel only handles software exceptions.

For more information about the Nios II processor `estatus` and `ipending` registers, refer to the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Programming Model](#)

9.5.2.2. Returning from Exceptions


After returning from the ISR or software exception handler, the general exception funnel performs the following tasks:

- Restores the stack pointer, if a separate exception stack is used
- Restores the registers from the stack
- Exits by issuing an `eret` (exception return) instruction

9.5.3. Hardware Interrupt Funnel

The configuration of the HAL hardware interrupt funnel depends on the interrupt controller implemented in the Nios II processor core.

Figure 15. HAL Exception Handling System with the Internal Interrupt Controller



Note: This figure shows the algorithm that the HAL general exception funnel uses to distinguish between hardware interrupts and software exceptions.

9.5.3.1. Interrupt Funnel for the Internal Interrupt Controller

With the IIC, the Nios II processor supports 32 hardware interrupts. In the HAL funnel, hardware interrupt 0 has the highest priority, and 31 the lowest. This prioritization is a feature of the HAL funnel, and is not inherent in the Nios II interrupt controller.

The hardware interrupt funnel calls the user-registered ISRs. It goes through the IRQs in `ipending` starting at 0, and finds the first (highest priority) active IRQ. Then it calls the corresponding registered ISR. After this ISR executes, the funnel begins

scanning the IRQs again, starting at IRQ₀. In this way, higher-priority interrupts are always processed before lower-priority interrupts. When all IRQs are clear, the hardware interrupt funnel returns to the top level.

When the interrupt vector custom instruction is present in the Nios II processor, the HAL source detects it at compile time and generates code using the custom instruction.

For more information, refer to the “Using the Interrupt Vector Custom Instruction” chapter.

Related Information

[Using the Interrupt Vector Custom Instruction](#) on page 268

9.5.3.2. Interrupt Funnels for External Interrupt Controllers

With the EIC interface, the Nios II processor supports a potentially unlimited number of hardware interrupts on daisy-chained EICs. The interrupt priority level can be software-configurable. Details of setting interrupt priorities depend on the particular EIC implementation. The hardware ensures that the highest-priority interrupt is always serviced first.

You register ISRs at system initialization time. Interrupt dispatch is handled by hardware.


For more information, refer to the “Exception Handling System Structure” chapter.

Related Information

[Exception Handling System Structure](#) on page 271

9.5.3.3. Interrupt Funnels for Internal Interrupt Controllers

HAL Hardware Interrupt Funnel for the Internal Interrupt Controller





The HAL provides the following interrupt funnels:

- Shadow register set, pre-emption disabled
- Shadow register set, pre-emption enabled
- Nonmaskable interrupt

For more information, refer to the “Using Interrupt Funnels” chapter.

Related Information

[Using Interrupt Funnels](#) on page 256

9.5.4. Software Exception Funnel

Software exceptions can include unimplemented instructions, traps, and miscellaneous exceptions.

Software exception handling depends on options selected in the BSP. If you have enabled unimplemented instruction emulation, the software exception funnel first checks whether an unimplemented instruction caused the exception. If so, it emulates the instruction. Otherwise, it handles traps and miscellaneous exceptions.

9.5.4.1. Unimplemented Instructions

You can include a handler to emulate unimplemented instructions. The Nios II processor architecture defines the following implementation-dependent instructions:

- `mul`
- `muli`
- `mulxss`
- `mulxsu`
- `mulxuu`
- `div`
- `divu`

For more information about unimplemented instructions, refer to “Unimplemented Instructions” in the “Processor Architecture” chapter of the *Nios II Processor Reference Handbook*.

For more information about how unimplemented instructions are different from invalid instructions, refer to the “Invalid Instructions” chapter.

Related Information

- [Invalid Instructions](#) on page 279
- [Processor Architecture](#)

9.5.4.1.1. When to Use the Unimplemented Instruction Handler

You do not normally need the unimplemented instruction handler, because the HAL includes software emulation for unimplemented instructions from its run-time libraries if you are compiling for a Nios II processor that does not support the instructions.

You might need the unimplemented instruction handler under the following circumstances:

- You are running a Nios II program on an implementation of the Nios II processor other than the one you compiled for. The best solution is to build your program for the correct Nios II processor implementation. Resort to the unimplemented instruction handler only if it is not possible to determine the processor implementation at compile time.
- You have assembly language code that uses an implementation-dependent instruction.

If unimplemented instruction emulation is disabled, but the processor encounters an unimplemented instruction, the software exception funnel treats the exception as a miscellaneous exception.

For more information about miscellaneous exceptions, refer to the “Miscellaneous Exceptions” chapter.

Otherwise, if instruction emulation is not enabled, this logic is omitted.

Related Information


[Miscellaneous Exceptions](#) on page 278

9.5.4.1.2. Using the Unimplemented Instruction Handler

To include the unimplemented instruction handler, turn on the `hal.enable_mul_div_emulation` BSP property. The emulation routines occupy less than $\frac{3}{4}$ kilobyte(KB) of memory.

Note: An exception handler must never execute an unimplemented instruction. The HAL exception handling system does not support nested software exceptions.

Figure 16. HAL Software Exception Funnel Including the Optional Instruction Emulation Logic



9.5.4.2. Instruction-Related Exceptions

If the cause of the software exception is not an unimplemented instruction, the HAL software exception funnel checks for a registered instruction-related exception handler. If no instruction-related exception handler is registered, the exception is handled.

For more information, refer to the "Software Trap Handling" chapter. If a handler is registered, the HAL software exception funnel calls it, then restores context and returns.

For more information, refer to the "The Nios II Instruction-Related Exception Handler" chapter for a description of the instruction-related exception handler and how to register it.

Related Information

- [The Nios II Instruction-Related Exception Handler](#) on page 279
- [Software Trap Handling](#) on page 278

9.5.4.3. Software Trap Handling

If no instruction-related exception handler is registered, the HAL software exception funnel checks for a `trap` instruction. If the exception is caused by a `trap` instruction, the trap exception handler executes a `break` instruction. The `break` instruction transfers control to a hardware debug core, if one is available. If the exception is not caused by a `trap` instruction, it is treated as a miscellaneous exception.

9.5.4.4. Miscellaneous Exceptions

If the software exception is not caused by an unimplemented instruction or a trap, it is a miscellaneous exception.

If a debug core is present in the Nios II processor, traps and miscellaneous exceptions are handled identically, by executing a `break` instruction.

For more information about the flowchart of the HAL software exception funnel, including the optional trap logic, refer to the "HAL Software Exception Funnel Including the Optional Instruction Emulation Logic" figure ([Figure 8-3](#)).

If a debug core is present in the Nios II processor, the trap logic is omitted.

In a debugging environment, the processor executes a `break`, allowing the debugger to take control. In a nondebugging environment, the processor enters an infinite loop.

For more information about the Nios II processor `break` instruction, refer to the "Programming Model" chapter.

For more information about the Nios II processor `break` instruction, refer to the "Instruction Set Reference" chapter of the *Nios II Processor Reference Handbook*.

Miscellaneous exceptions can occur for these reasons:

- Advanced exceptions, the memory protection unit (MPU), or the memory management unit (MMU) are implemented in the Nios II processor core.
- You need to include the unimplemented instruction handler.
- A peripheral is generating spurious hardware interrupts. This is a symptom of a serious hardware problem. A peripheral might generate spurious hardware interrupts if it deasserts its interrupt output before an ISR has explicitly serviced it.

For more information about how to handle advanced and MPU exceptions, refer to the "The Nios II Instruction-Related Exception Handler" chapter.



For more information about how you need to implement a full-featured operating system to handle MMU exceptions, refer to the "Programming Model" chapter.

For more information about the unimplemented instruction handler, refer to the "Unimplemented Instructions" chapter.

Related Information

- [The Nios II Instruction-Related Exception Handler](#) on page 279
- [Unimplemented Instructions](#) on page 275
- [Instruction Set Reference](#)
- [Programming Model](#)

9.5.5. Invalid Instructions

An invalid instruction word contains invalid codes in the OP or OPX field. For normal Nios II core implementations, the result of executing an invalid instruction is undefined; processor behavior is dependent on the Nios II core.

Therefore, the software exception funnel cannot detect or respond to an invalid instruction.

For more information about how invalid instructions are different from unimplemented instructions, refer to the "Unimplemented Instructions" chapter.

For more information, refer to the "Nios II Core Implementation Details" chapter of the *Nios II Processor Reference Handbook*.

Related Information

- [Unimplemented Instructions](#) on page 275
- [Nios II Core Implementation Details](#)

9.6. The Nios II Instruction-Related Exception Handler

The software exception funnel lets you handle instruction-related exceptions, such as the advanced exceptions. The instruction-related exception handler is a custom handler. Your software registers the instruction-related exception handler with the HAL at startup time.

Note: The `hal.enable_instruction_related_exceptions_api` setting must be enabled in the BSP in order for you to register an instruction-related exception handler.

For more information about the Nios II instruction-related exceptions, refer to the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

For more information about enabling instruction-related exception handlers, refer to "Settings Managed by the Software Build Tools" in the "Nios II Software Build Tools Reference" section.

When you register an instruction-related exception handler, it takes the place of the break/optional trap logic.

When you remove the instruction-related exception handler, the HAL restores the default break/optional trap logic.

Related Information

- [Programming Model](#)
- [Nios II Software Build Tools Reference](#) on page 396

9.6.1. Writing an Instruction-Related Exception Handler

The prototype for an instruction-related exception handler is as follows:

```
alt_exception_result handler (  
    alt_exception_cause cause,  
    alt_u32 addr,  
    alt_u32 bad_addr );
```

The instruction-related exception handler's return value is a flag requesting that the HAL either re-execute the instruction, or skip it.

The HAL exception funnel calls the instruction-related exception handler with the following arguments:

- `cause`—A value representing the exception type, as shown in the "Nios II Exception Cause Codes" table ([Table 8-4](#))
- `addr`—Instruction address at which exception occurred
- `bad_addr`—Bad address register (if implemented)

Include the following header file in your instruction-related exception handler code:

```
#include "sys/alt_exceptions.h"
```

`alt_exceptions.h` provides type macro definitions required to interface your instruction-related exception handler to the HAL, including the cause codes shown in the "Nios II Exception Cause Codes" table ([Table 8-4](#)).

The API function `alt_exception_cause_generated_bad_addr()` is provided by the HAL, for the use of the instruction-related exception handler. This function parses the `cause` argument and determines if `bad_addr` contains the exception-causing address.

For more information about Nios II processor exception causes, refer to "Exception Processing" in the "Programming Model" chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Programming Model](#)



9.6.1.1. Exception Cause Codes

Table 46. Nios II Exception Cause Codes

Exception	Cause Code	Cause Symbol ⁽⁸⁾
Reset	0	NIOS2_EXCEPTION_RESET
Processor-only Reset Request	1	NIOS2_EXCEPTION_CPU_ONLY_RESET_REQUEST
Hardware Interrupt	2	NIOS2_EXCEPTION_INTERRUPT
Trap Instruction	3	NIOS2_EXCEPTION_TRAP_INST
Unimplemented Instruction	4	NIOS2_EXCEPTION_UNIMPLEMENTED_INST
Illegal Instruction	5	NIOS2_EXCEPTION_ILLEGAL_INST
Misaligned Data Address	6	NIOS2_EXCEPTION_MISALIGNED_DATA_ADDR
Misaligned Destination Address	7	NIOS2_EXCEPTION_MISALIGNED_TARGET_PC
Division Error	8	NIOS2_EXCEPTION_DIVISION_ERROR
Supervisor-only Instruction Address	9	NIOS2_EXCEPTION_SUPERVISOR_ONLY_INST_ADDR
Supervisor-only Instruction	10	NIOS2_EXCEPTION_SUPERVISOR_ONLY_INST
Supervisor-only Data Address	11	NIOS2_EXCEPTION_SUPERVISOR_ONLY_DATA_ADDR
Translation lookaside buffer (TLB) Miss	12	NIOS2_EXCEPTION_TLB_MISS
TLB Permission Violation (execute)	13	NIOS2_EXCEPTION_TLB_EXECUTE_PERM_VIOLATION
TLB Permission Violation (read)	14	NIOS2_EXCEPTION_TLB_READ_PERM_VIOLATION
TLB Permission Violation (write)	15	NIOS2_EXCEPTION_TLB_WRITE_PERM_VIOLATION
MPU Region Violation (instruction)	16	NIOS2_EXCEPTION_MPU_INST_REGION_VIOLATION
MPU Region Violation (data)	17	NIOS2_EXCEPTION_MPU_DATA_REGION_VIOLATION
Cause unknown ⁽⁹⁾	-1	NIOS2_EXCEPTION_CAUSE_NOT_PRESENT

If there is an instruction-related exception handler, it is called at the end of the software exception funnel (if the funnel has not recognized a hardware interrupt, unimplemented instruction or trap). It takes the place of the break or infinite loop. Therefore, to support debugging, execute a break on a trap instruction.

Note: It is possible for an instruction-related exception to occur during execution of an ISR.

9.6.2. Registering an Instruction-Related Exception Handler

The HAL API function `alt_instruction_exception_register()` registers a single instruction-related exception handler.

⁽⁸⁾ Cause symbols are defined in `sys/alt_exceptions.h`.

⁽⁹⁾ This value is passed to the instruction-related exception handler if the `cause` argument if the cause is not known; for example, if the cause register not implemented in the Nios II processor core.

The function prototype is as follows:

```
alt_instruction_exception_register (  
alt_exception_result (*handler)  
( alt_exception_cause, alt_u32, alt_u32 ));
```

The `handler` argument is a pointer to the instruction-related exception handler.

To use `alt_instruction_exception_register()`, include the following header file:

```
#include "sys/alt_exceptions.h"
```

Note: The `hal.enable_instruction_related_exceptions_api` setting must be enabled in the BSP in order for you to register an instruction-related exception handler.

For more information, refer to "Settings Managed by the Software Build Tools" in the "Nios II Software Build Tools Reference" section.

Note: Register the instruction-related exception handler as early as possible in function `main()`. This allows you to handle abnormal condition during startup. You register an exception handler from the `alt_main()` function.

For more information about `alt_main()`, refer to "Boot Sequence and Entry Point" in the "Developing Programs Using the Hardware Abstraction Layer" section.

Related Information


- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [Nios II Software Build Tools Reference](#) on page 396

9.6.3. Removing an Instruction-Related Exception Handler

To remove a registered instruction-related exception handler, your C code must call the `alt_instruction_exception_register()` function, as follows:

```
alt_instruction_exception_register ( null, null );
```

When the HAL removes the instruction-related exception handler, it restores the default break/optional trap logic.



10. Cache and Tightly-Coupled Memory

Nios II embedded processor cores can contain instruction and data caches. This chapter discusses cache-related issues that you need to consider to guarantee that your program executes correctly on the Nios II processor. Fortunately, most software based on the Nios II hardware abstraction layer (HAL) works correctly without any special accommodations for caches. However, some software must manage the cache directly.

For code that needs direct control over the cache, the Nios II architecture provides facilities to perform the following actions:

- Initialize lines in the instruction and data caches
- Flush lines in the instruction and data caches
- Bypass the data cache during load and store instructions

This chapter discusses the following common cases in which you must manage the cache:

- Initializing cache after reset
- Writing device drivers
- Writing program loaders
- Managing cache in multi-master or multi-processor systems

This chapter covers cache management issues that affect Nios II programmers. It does not discuss the fundamental operation of caches. Refer to *The Cache Memory Book* by Jim Handy for a discussion of general cache management issues.

Related Information

- [Cache and Tightly-Coupled Memory Revision History](#) on page 15
For details on the document revision history of this chapter
- [The Cache Memory Book by Jim Handy](#)

10.1. Nios II Cache Implementation

Depending on the Nios II core implementation, a Nios II processor system might or might not have data or instruction caches. You can write programs generically so that they function correctly on any Nios II processor, regardless of whether it has cache memory. For a Nios II core without one or both caches, cache management operations are benign and have no effect.

The current Nios II cores have no hardware cache coherency mechanism. Therefore, if multiple masters can access shared memory, software must explicitly maintain coherency across all masters.

For more information about the features of each Nios II core implementation, refer to the "Nios II Core Implementation Details" chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Nios II Core Implementation Details](#)

10.1.1. Defining Cache Properties

The details for a particular Nios II processor system are defined in the `system.h` file.

Example 9–1. An Excerpt from `system.h` that Defines the Cache Structure

```
#define NIOS2_ICACHE_SIZE 4096
#define NIOS2_DCACHE_SIZE 0
#define NIOS2_ICACHE_LINE_SIZE 32
#define NIOS2_DCACHE_LINE_SIZE 0
```

This system has a 4 KB instruction cache with 32 byte lines, and no data cache.

10.2. HAL API Functions for Managing Cache

The HAL application program interface (API) provides the following functions for managing cache memory:

- `alt_dcache_flush()`
- `alt_dcache_flush_no_writeback()`
- `alt_dcache_flush_all()`
- `alt_icache_flush()`
- `alt_icache_flush_all()`
- `alt_uncached_malloc()`
- `alt_uncached_free()`
- `alt_remap_uncached()`
- `alt_remap_cached()`

For more information about API functions, refer to the "HAL API Reference" section.

Related Information

[HAL API Reference](#) on page 315

10.3. Initializing the Nios II Cache after Reset

After reset, the contents of the instruction cache and data cache are unknown. They must be initialized at the start of the software reset handler for correct operation.

The Nios II caches cannot be disabled by software; they are always enabled. To allow proper operation, a processor reset causes the instruction cache to invalidate the one instruction cache line that corresponds to the reset handler address. This forces the instruction cache to fetch instructions corresponding to this cache line from memory. The reset handler address must be aligned to the size of the instruction cache line.



It is the responsibility of the first eight instructions of the reset handler to initialize the remainder of the instruction cache. The Nios II `init_i` instruction initializes a single instruction cache line. Do not use the `flush_i` instruction because it might cause undesired effects when used to initialize the instruction cache in future Nios II implementations.

10.3.1. Assembly Code to Initialize the Instruction Cache

Place the `init_i` instruction in a loop that executes `init_i` for each instruction cache line address.

Example 9–2. Assembly Code to Initialize the Instruction Cache

```
mov r4, r0
movhi r5, %hi(NIOS2_ICACHE_SIZE)
ori r5, r5, %lo(NIOS2_ICACHE_SIZE)
icache_init_loop:
init_i r4
addi r4, r4, NIOS2_ICACHE_LINE_SIZE
bltu r4, r5, icache_init_loop
```

After the instruction cache is initialized, the data cache must also be initialized. The Nios II `init_d` instruction initializes a single data cache line. Do not use the `flush_d` instruction for this purpose, because it writes dirty lines back to memory. The data cache is undefined after reset, including the cache line tags. Using `flush_d` can cause unexpected writes of random data to random addresses. The `init_d` instruction does not write back dirty data.

10.3.2. Assembly Code to Initialize the Data Cache

Example 9–3. Assembly Code to Initialize the Data Cache

```
mov r4, r0
movhi r5, %hi(NIOS2_DCACHE_SIZE)
ori r5, r5, %lo(NIOS2_DCACHE_SIZE)
dcache_init_loop:
init_d 0(r4)
addi r4, r4, NIOS2_DCACHE_LINE_SIZE
bltu r4, r5, dcache_init_loop
```

Note: Place the `init_d` instruction in a loop that executes `init_d` for each data cache line address.

It is legal to execute instruction and data cache initialization code on Nios II cores that do not implement one or both of the caches. The `init_i` and `init_d` instructions are simply treated as `nop` instructions if there is no cache of the corresponding type present.

10.3.3. HAL Behavior for Initializing the Nios II Cache after Reset

Programs based on the HAL need not manage the initialization of cache memory. The HAL C run-time code (`crt0.S`) provides a default reset handler that performs cache initialization before `alt_main()` or `main()` is called.

10.4. Nios II Device Driver Cache Considerations

Device drivers typically access control registers associated with their device. These registers are mapped into the Nios II address space. When accessing device registers, the data cache must be bypassed to ensure that accesses are not lost or deferred due to the data cache.

When writing a device driver, bypass the data cache with the `ldio/stio` family of instructions. On Nios II cores without a data cache, these instructions behave just like their corresponding `ld/st` instructions, and therefore are benign.

Note: Declaring a C pointer `volatile` does not make pointer accesses bypass the data cache. The `volatile` keyword merely prevents the compiler from optimizing out accesses using the pointer. This `volatile` behavior is different from the methodology for the first-generation Nios processor.


10.4.1. HAL Behavior for Nios II Device Driver Cache Considerations

The HAL provides the C-language macros `IORD` and `IOWR` that expand to the appropriate assembly instructions to bypass the data cache. The `IORD` macro expands to the `ldwio` instruction, and the `IOWR` macro expands to the `stwio` instruction. These macros are provided to enable HAL device drivers to access device registers.

All of these macros bypass the data cache when they perform their operation. In general, your program passes values defined in `system.h` as the `BASE` and `REGNUM` parameters. These macros are defined in the file `<Nios II EDS install path>/components/altera_nios2/HAL/inc/io.h`.

Table 47. HAL I/O Macros to Bypass the Data Cache

Macro	Use
<code>IORD(BASE, REGNUM)</code>	Read the value of the register at offset <code>REGNUM</code> in a device with base address <code>BASE</code> . Registers are assumed to be offset by the address width of the bus.
<code>IOWR(BASE, REGNUM, DATA)</code>	Write the value <code>DATA</code> to the register at offset <code>REGNUM</code> in a device with base address <code>BASE</code> . Registers are assumed to be offset by the address width of the bus.
<code>IORD_32DIRECT(BASE, OFFSET)</code>	Make a 32-bit read access at the location with address <code>BASE + OFFSET</code> .
<code>IORD_16DIRECT(BASE, OFFSET)</code>	Make a 16-bit read access at the location with address <code>BASE + OFFSET</code> .
<code>IORD_8DIRECT(BASE, OFFSET)</code>	Make an 8-bit read access at the location with address <code>BASE + OFFSET</code> .
<code>IOWR_32DIRECT(BASE, OFFSET, DATA)</code>	Make a 32-bit write access to write the value <code>DATA</code> at the location with address <code>BASE + OFFSET</code> .
<code>IOWR_16DIRECT(BASE, OFFSET, DATA)</code>	Make a 16-bit write access to write the value <code>DATA</code> at the location with address <code>BASE + OFFSET</code> .
<code>IOWR_8DIRECT(BASE, OFFSET, DATA)</code>	Make an 8-bit write access to write the value <code>DATA</code> at the location with address <code>BASE + OFFSET</code> .



10.5. Cache Considerations for Writing Program Loaders

Software that writes instructions to memory, such as program loaders, needs to ensure that old instructions are flushed from the instruction cache and processor pipeline. This flushing is accomplished with the `flushi` and `flushp` instructions, respectively. Additionally, if new instruction(s) are written to memory using store instructions that do not bypass the data cache, you must use the `flushd` instruction to flush the new instruction(s) from the data cache to memory.

Example 9–4. Assembly Code That Writes a New Instruction to Memory

```
/*
 * Assume new instruction in r4 and
 * instruction address already in r5.
 */
stw r4, 0(r5)
flushd 0(r5)
flushi r5
flushp
```

Note: Notice that this example uses the `stw/flushd` pair instead of the `stwi` instruction. The `stwi` instruction does not flush the data cache, and therefore might leave stale data in the data cache.

The `stw` instruction writes the new instruction in `r4` to the instruction address specified by `r5`. If a data cache is present, the instruction is written just to the data cache and the associated line is marked dirty. The `flushd` instruction writes the data cache line associated with the address in `r5` to memory and invalidates the corresponding data cache line. The `flushi` instruction invalidates the instruction cache line associated with the address in `r5`. Finally, the `flushp` instruction ensures that the processor pipeline has not prefetched the old instruction at the address specified by `r5`.

This code sequence is correct for all Nios II implementations. If a Nios II core does not have a particular kind of cache, the corresponding flush instruction (`flushd` or `flushi`) is executed as a `nop`.

10.5.1. HAL Behavior for Cache Considerations for Writing Program Loaders

The HAL API does not provide functions for this cache management case.

10.6. Managing Cache in Multi-Master and Multi-Processor Systems

The Nios II architecture does not provide hardware cache coherency. Instead, software cache coherency must be provided when communicating through shared memory. The data cache contents of all processors accessing the shared memory must be managed by software to ensure that all masters read the most recent values and do not overwrite new data with stale data. This management is done by using the data cache flushing and bypassing facilities to move data between the shared memory and the data cache(s) as needed.

Uncached data and cached data can no longer be allocated on the same line in the data cache because the Nios II core does not update the cache in an uncached line. This is the behavior for Nios II Classic. If you have existing Nios II code and use a Nios II/f with a data cache, then you have to check your software to ensure that it does not mix cacheable and uncachable data on the same cache line.

Nios II provides two options for data cache bypass:

- Bit-31 cache bypass is set by default for compatibility
- If 32-bit addressing is selected, then any code/drivers that rely on bit-31 cache bypass needs modification to use cache bypass macros/instructions or the peripheral memory region.

10.6.1. Cache Implementation

When using the Nios II core, the peripheral region is introduced, where there is a 32-bit address option. With Nios II, for an uncached write, where bit 31 is set or in the peripheral memory region, the cache is bypassed. This behavior is the industry standard.

10.6.2. Bit-31 Cache Bypass

The `ldio/stio` family of instructions explicitly bypass the data cache. Bit-31 provides an alternate method to bypass the data cache. Using the bit-31 cache bypass, the normal `ld/st` family of instructions can be used to bypass the data cache if the most significant bit of the address (bit 31) is set to one. The value of bit 31 is only used internally to the processor; bit 31 is forced to zero in the actual address accessed. This limits the maximum byte address space to 31 bits.

Using bit 31 to bypass the data cache is a convenient mechanism for software because the cacheability of the associated address is contained in the address. This usage allows the address to be passed to code that uses the normal `ld/st` family of instructions, while still guaranteeing that all accesses to that address consistently bypass the data cache.

Bit-31 cache bypass is only provided in the Nios II/f core, and must not be used with other Nios II cores. The other Nios II cores limit their maximum byte address space to 31 bits to ease migration of code from one implementation to another. They effectively ignore the value of bit 31, which allows code written for a Nios II/f core using bit 31 cache bypass to run correctly on other current Nios II implementations. In general, this feature depends on the Nios II core implementation.

For more information, refer to the "Nios II Core Implementation Details" chapter of the *Nios II Processor Reference Handbook*.

Related Information

[Nios II Core Implementation Details](#)

10.6.3. HAL Behavior for Managing Cache in Multi-Master and Multi-Processor Systems

The HAL provides the C-language `IORD_*DIRECT` macros that expand to the `ldio` family of instructions and the `IOWR_*DIRECT` macros that expand to the `stio` family of instructions.



For more information, refer to the "HAL I/O Macros to Bypass the Data Cache" table (Table 9–1 on page 9–4).

These macros are provided to access noncacheable memory regions.

The HAL provides the `alt_uncached_malloc()`, `alt_uncached_free()`, `alt_remap_uncached()`, and `alt_remap_cached()` routines to allocate and manipulate regions of uncached memory. These routines are available on Nios II cores with or without a data cache—code written for a Nios II core with a data cache is completely compatible with a Nios II core without a data cache.

The `alt_uncached_malloc()` routine guarantees that the allocated memory region is not in the data cache and that all subsequent accesses to the allocated memory regions bypass the data cache. In the case there is no data cache implemented the `alt_uncached_malloc()` routine simply calls `malloc()`. If data cache is implemented, but bit 31 is not set to be used as a cache bypass then the following link error results when building the code: `ALT_LINK_ERROR("alt_uncached_malloc() is not available because CPU is not configured to use bit 31 of address to bypass data cache");`.

The `alt_remap_uncached()` routine is not available with Nios II cores with data caches because mixing cacheable and uncachable data on the same line is not supported. This function results in a link error when used with Nios II cores.

In the case there is no data cache implemented the `alt_uncached_free()` routine simply calls `free()`. If data cache is implemented, but bit 31 is not set to be used as a cache bypass then a link error results when building the code.

10.7. Nios II Tightly-Coupled Memory


If you want the performance of cache all the time, place your code or data in a tightly-coupled memory. Tightly-coupled memory is fast on-chip memory that bypasses the cache and has guaranteed low latency. Tightly-coupled memory gives the best memory access performance. You assign code and data to tightly-coupled memory partitions in the same way as other memory sections.

Cache instructions do not affect tightly-coupled memory. However, cache-management instructions become NOPs, which might result in unnecessary overhead.

For more information, refer to "Memory Usage" in the "Developing Programs Using the Hardware Abstraction Layer" section.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158



11. MicroC/OS-II Real-Time Operating System

Related Information

[MicroC/OS-II Real-Time Operating System Revision History](#) on page 15

For details on the document revision history of this chapter

11.1. Overview of the MicroC/OS-II RTOS

MicroC/OS-II is a popular real-time kernel produced by Micrium® Inc. in 1992. MicroC/OS-II is a portable, ROMable, scalable, pre-emptive, real-time, multitasking kernel. MicroC/OS-II is used in hundreds of commercial applications. It is implemented on more than 40 different processor architectures in addition to the Nios II processor.

MicroC/OS-II provides the following services:

- Tasks (threads)
- Event flags
- Message passing
- Memory management
- Semaphores
- Time management

The MicroC/OS-II kernel operates on top of the hardware abstraction layer (HAL) board support package (BSP) for the Nios II processor. Because of this architecture, MicroC/OS-II development for the Nios II processor has the following advantages:

- Programs are portable to other Nios II hardware systems.
- Programs are resistant to changes in the underlying hardware.
- Programs can access all HAL services, calling the UNIX-like HAL application program interface (API).
- ISRs are easy to implement.

Note: MicroC/OS-II is not compatible with external interrupt controllers on the External Interrupt Controller (EIC) interface; and can only run on systems using the internal interrupt controller.

For more information about MicroC/OS-II features and usage, refer to *MicroC/OS-II - The Real-Time Kernel* by Jean J. Labrosse (CMP Books).

Related Information

[Micrium website](#)



11.1.1. Licensing

Intel distributes MicroC/OS-II in the Nios II Embedded Design Suite (EDS) for evaluation purposes only.

If you plan on using MicroC/OS-II in a commercial product, you must obtain a license from the Micrium Licensing Website.

Note: Micrium offers free licensing for universities and students. Contact Micrium for details.

Related Information

[Micrium Licensing Website](#)

11.2. Other RTOS Providers

Intel FPGA distributes MicroC/OS-II to provide you with immediate access to an easy-to-use RTOS. In addition to MicroC/OS-II, many other RTOSs are available from third-party vendors.

Related Information

Embedded Software

For more information, refer to the complete list of RTOSs that support the Nios II processor.

11.3. The Nios II Implementation of MicroC/OS-II

Intel FPGA has ported MicroC/OS-II to the Nios II processor. Intel FPGA distributes MicroC/OS-II in the Nios II EDS, and supports the Nios II implementation of the MicroC/OS-II kernel. Ready-made, working examples of MicroC/OS-II programs are installed with the Nios II EDS. In addition, Intel FPGA development boards are preprogrammed with a web server reference design based on MicroC/OS-II and the NicheStack TCP/IP Stack - Nios II Edition.

The Intel FPGA implementation of MicroC/OS-II is designed to be easy to use. Using the Nios II project settings, you can control the configuration for all the RTOS's modules.

You need not modify source files directly to enable or disable kernel features. Nonetheless, Intel FPGA provides the Nios II processor-specific source code in case you wish to examine it. The MicroC/OS-II source code is located in the following directories:


- Processor-specific code: `<Nios II EDS install path>/components/altera_nios2/UCOSII`
- Processor-independent code: `<Nios II EDS install path>/components/micrium_uc_osii`

The MicroC/OS-II software package behaves like the drivers for hardware components: When MicroC/OS-II is included in a Nios II project, the header and source files from `components/micrium_uc_osii` are included in the project path, causing the MicroC/OS-II kernel to compile and link as part of the project.

11.3.1. MicroC/OS-II Architecture

The Intel FPGA implementation of MicroC/OS-II for the Nios II processor extends the single-threaded HAL environment to include the MicroC/OS-II scheduler and the associated MicroC/OS-II API. The complete HAL API is available to all MicroC/OS-II projects.

Figure 17. Architecture of MicroC/OS-II Programs in Relation to the HAL API



The multi-threaded environment affects certain HAL functions.

Related Information

HAL API Reference

For more information about the consequences of calling a particular HAL function in a multi-threaded environment.

11.3.2. MicroC/OS-II Device Drivers

Each peripheral (that is, each hardware component) can provide include files and source files in the `inc` and `src` subdirectories of the component's HAL directory.

In addition to the HAL directory, a component can optionally provide a UCOSII directory that contains code specific to the MicroC/OS-II environment. Similar to the HAL directory, the UCOSII directory contains `inc` and `src` subdirectories.

When you create a MicroC/OS-II project, these directories are added to the search paths for source and include files.

The Nios II Software Build Tools (SBT) copies the files to your BSP `obj` subdirectory.

You can use the UCOSII directory to provide code that is used only in a multi-threaded environment. Other than these additional search directories, the mechanism for providing MicroC/OS-II device drivers is identical to the process for any other device driver.



The HAL system initialization process calls the MicroC/OS-II function `OSInit()` before `alt_sys_init()`, which instantiates and initializes each device in the system. Therefore, the complete MicroC/OS-II API is available to device drivers, although the system is still running in single-threaded mode until the program calls `OSStart()` from within `main()`.

Related Information

- [Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209
For more information about developing device drivers.
- [Nios II Software Build Tools](#) on page 87
For more information about specifying file paths with the Nios II SBT, refer to "Nios II Embedded Software Projects".

11.3.3. Thread-Safe HAL Drivers

To enable a driver to be ported between the HAL and MicroC/OS-II environments, Intel FPGA defines a set of operating system-independent macros that provide access to operating system facilities. These macros implement functionality that is only relevant to a multi-threaded environment. When compiled for a MicroC/OS-II project, the macros expand to MicroC/OS-II API calls. When compiled for a single-threaded HAL project, the macros expand to benign empty implementations. These macros are used in Intel FPGA-provided device driver code, and you can use them if you need to write a device driver with similar portability.

For more information about the functionality in the MicroC/OS-II environment, refer to *MicroC/OS-II: The Real-Time Kernel*.

The path listed for the header file is relative to the `<Nios II EDS install path>/components/micrium_uc_osii/UCOSII/inc` directory.

Table 48. OS-Independent Macros for Thread-Safe HAL Drivers

Macro	Defined in Header	MicroC/OS-II Implementation	Single-Threaded HAL Implementation
<code>ALT_FLAG_GRP(group)</code>	<code>os/alt_flag.h</code>	Create a pointer to a flag group with the name <code>group</code> .	Empty statement
<code>ALT_EXTERN_FLAG_GRP(group)</code>	<code>os/alt_flag.h</code>	Create an external reference to a pointer to a flag group with name <code>group</code> .	Empty statement
<code>ALT_STATIC_FLAG_GRP(group)</code>	<code>os/alt_flag.h</code>	Create a static pointer to a flag group with the name <code>group</code> .	Empty statement
<code>ALT_FLAG_CREATE(group, flags)</code>	<code>os/alt_flag.h</code>	Call <code>OSFlagCreate()</code> to initialize the flag group pointer, <code>group</code> , with the flags value <code>flags</code> . The error code is the return value of the macro.	Return 0 (success)
<code>ALT_FLAG_PEND(group, flags, wait_type, timeout)</code>	<code>os/alt_flag.h</code>	Call <code>OSFlagPend()</code> with the first four input arguments set to <code>group</code> , <code>flags</code> , <code>wait_type</code> , and <code>timeout</code> respectively. The error code is the return value of the macro.	Return 0 (success)
<i>continued...</i>			



Macro	Defined in Header	MicroC/OS-II Implementation	Single-Threaded HAL Implementation
ALT_FLAG_POST(group, flags, opt)	os/ alt_flag.h	Call OSFlagPost() with the first three input arguments set to group, flags, and opt respectively. The error code is the return value of the macro.	Return 0 (success)
ALT_SEM(sem)	os/ alt_sem.h	Create an OS_EVENT pointer with the name sem.	Empty statement
ALT_EXTERN_SEM(sem)	os/ alt_sem.h	Create an external reference to an OS_EVENT pointer with the name sem.	Empty statement
ALT_STATIC_SEM(sem)	os/ alt_sem.h	Create a static OS_EVENT pointer with the name sem.	Empty statement
ALT_SEM_CREATE(sem, value)	os/ alt_sem.h	Call OSSemCreate() with the argument value to initialize the OS_EVENT pointer sem. The return value is zero on success, or negative otherwise.	Return 0 (success)
ALT_SEM_PEND(sem, timeout)	os/ alt_sem.h	Call OSSemPend() with the first two argument set to sem and timeout respectively. The error code is the return value of the macro.	Return 0 (success)
ALT_SEM_POST(sem)	os/ alt_sem.h	Call OSSemPost() with the input argument sem.	Return 0 (success)

11.3.4. The newlib ANSI C Standard Library

Programs based on MicroC/OS-II can also call the ANSI C standard library functions. Some consideration is necessary in a multi-threaded environment to ensure that the C standard library functions are thread-safe. The newlib C library stores all global variables in a single structure referenced through the pointer `_impure_ptr`. However, the Intel FPGA MicroC/OS-II implementation creates a new instance of the structure for each task. During a context switch, the value of `_impure_ptr` is updated to point to the current task's version of this structure. In this way, the contents of the structure pointed to by `_impure_ptr` are treated as thread local. For example, through this mechanism each task has its own version of `errno`.

This thread-local data is allocated at the top of the task's stack. You must make allowance for thread-local data storage when allocating memory for stacks. In general, the `_reent` structure consumes approximately 900 bytes of data for the normal C library, or 90 bytes for the reduced-footprint C library.

For more information about the contents of the `_reent` structure, refer to the newlib documentation. On the Windows **Start** menu, click **Programs > Intel FPGA > Nios II > Nios II Documentation**.

In addition, the MicroC/OS-II implementation provides appropriate task locking to ensure that heap accesses (calls to `malloc()` and `free()`) are also thread-safe.



11.3.5. Interrupt Service Routines for MicroC/OS-II

Implementing ISRs for MicroC/OS-II normally involves some housekeeping details, as described in *MicroC/OS-II: The Real-Time Kernel*. However, because the Nios II implementation of MicroC/OS-II is based on the HAL, several of these details are taken care of for you. The HAL performs the following housekeeping tasks for your interrupt service routine (ISR):

- Saves and restores processor registers
- Calls `OSIntEnter()` and `OSIntExit()`

The HAL also allows you to write your ISR in C, rather than assembly language.

Related Information

[Exception Handling](#) on page 244

For more information about writing ISRs with the HAL.


11.4. Implementing MicroC/OS-II Projects for the Nios II Processor

To create a program based on MicroC/OS-II, start by setting the BSP properties so that it is a MicroC/OS-II project. You can control the configuration of the MicroC/OS-II kernel using BSP settings with the Nios II SBT for Eclipse, or on the Nios II command line.

- You do not need to edit header files (such as `OS_CFG.h`) or source code to configure the MicroC/OS-II features. The project settings are reflected in the BSP's `system.h` file; `OS_CFG.h` simply includes `system.h`.
- MicroC/OS-II settings are identified by the prefix `ucosii`.
- The meaning of each setting is defined fully in *MicroC/OS-II: The Real-Time Kernel*.

Related Information

- [Getting Started with the Graphical User Interface](#) on page 26
- [Nios II Software Build Tools](#) on page 87
For more information about how to configure MicroC/OS-II with BSP settings
- [Nios II Software Build Tools Reference](#) on page 396
For more information, refer to a list of available MicroC/OS-II BSP settings in "Settings Managed by the Software Build Tools".



12. Ethernet and the NicheStack TCP/IP Stack

For the Nios II processor, the NicheStack TCP/IP Stack is a small footprint implementation of the TCP/IP suite. The focus of the NicheStack TCP/IP Stack implementation is to reduce resource usage while providing a full-featured TCP/IP stack. The NicheStack TCP/IP Stack is designed for use in embedded systems with small memory footprints, making it suitable for Nios II processor systems.

The NicheStack TCP/IP Stack is a software package that you can add to your board support package (BSP), available through the Nios II Software Build Tools (SBT). The NicheStack TCP/IP Stack includes these features:

- Internet Protocol (IP) including packet forwarding over multiple network interfaces
- Internet control message protocol (ICMP) for network maintenance and debugging
- User datagram protocol (UDP)
- Transmission Control Protocol (TCP) with congestion control, round trip time (RTT) estimation, and fast recovery and retransmit
- Dynamic host configuration protocol (DHCP)
- Address resolution protocol (ARP) for Ethernet
- Standard sockets application program interface (API)

Related Information

[Ethernet and the NicheStack TCP/IP Stack - Nios II Edition Revision History](#) on page 16

For details on the document revision history of this chapter

12.1. Prerequisites for Understanding the NicheStack TCP/IP Stack

To make the best use of information in this chapter, you should be familiar with these topics:

- Sockets
- Nios II Embedded Design Suite (EDS)
- MicroC/OS-II RTOS

For more information about the several books available on the topic of programming with sockets, refer to *Unix Network Programming* by Richard Stevens.

For more information about the several books available on the topic of programming with sockets, refer to *Internetworking with TCP/IP Volume 3* by Douglas Comer.



Related Information

- [Overview of Nios II Embedded Development](#)
For more information about the Nios II Embedded Design Suite (EDS).
- [MicroC/OS-II Real-Time Operating System](#)
For more information about MicroC/OS-II.
- [Using MicroC/OS-II RTOS with the Nios II Processor Tutorial](#)
For more information about MicroC/OS-II and a Nios II processor tutorial.

12.2. Introduction to the NicheStack TCP/IP Stack - Nios II Edition

Intel FPGA provides the Nios II implementation of the NicheStack TCP/IP Stack, including source code, in the Nios II EDS. The NicheStack TCP/IP Stack provides you with immediate access to a stack for Ethernet connectivity for the Nios II processor. Intel FPGA's implementation of the NicheStack TCP/IP Stack includes an API wrapper, providing the standard, well documented socket API.

The NicheStack TCP/IP Stack uses the MicroC/OS-II RTOS multithreaded environment. Therefore, to use the NicheStack TCP/IP Stack with the Nios II EDS, you must base your C/C++ project on the MicroC/OS-II RTOS. The Nios II processor system must also contain an Ethernet interface, or media access control (MAC). The Intel FPGA-provided NicheStack TCP/IP Stack includes driver support for the following two MACs:

- The SMSC LAN91C111 device
- The Intel FPGA Triple Speed Ethernet IP core

The Nios II Embedded Design Suite includes hardware for both MACs. The NicheStack TCP/IP Stack driver is interrupt-based, so you must ensure that interrupts for the Ethernet component are connected.

Intel FPGA's implementation of the NicheStack TCP/IP Stack is based on the hardware abstraction layer (HAL) generic Ethernet device model. In the generic device model, you can write a new driver to support any target Ethernet MAC, and maintain the consistent HAL and sockets API to access the hardware.

Related Information

[Developing Device Drivers for the Hardware Abstraction Layer](#) on page 209
For more information about writing an Ethernet device driver.

12.2.1. The NicheStack TCP/IP Stack Files and Directories

Intel provides the source code for your reference. By default the files are installed with the Nios II EDS in the *<Nios II EDS install path>/components/altera_iniche/UCOSII* directory. For the sake of brevity, this chapter refers to this directory as *<iniche path>*. You need not edit the NicheStack TCP/IP Stack source code to use the stack in a Nios II C/C++ program.

Under *<iniche path>*, the original code is maintained; as much as possible; under the *<iniche path>* directory. This organization facilitates upgrading to more recent versions of the NicheStack TCP/IP Stack. The directory contains the original NicheStack TCP/IP Stack source code and documentation specific to the Nios II implementation of the NicheStack TCP/IP Stack, including source code supporting MicroC/OS-II.



Intel FPGA's implementation of the NicheStack TCP/IP Stack is based on version 3.1 of the protocol stack, with wrappers around the code to integrate it with the HAL.

Related Information

[Nios II Processor Documentation Page](#)

12.2.2. Support and Licensing

The NicheStack TCP/IP Stack is a TCP/IP protocol stack created by InterNiche Technologies, Inc. The version provided by Intel is supplied as example code only and is supplied without product support. If you require a supported TCP/IP stack you should license a product from a third-party software vendor.

You can license a newer version of the NicheStack TCP/IP Stack and other protocol stacks directly from InterNiche Technologies, Inc.

Related Information

[InterNiche Technologies, Inc.](#)

12.3. Other TCP/IP Stack Providers for the Nios II Processor

Other third party vendors also provide Ethernet support for the Nios II processor. Notably, third party RTOS vendors often offer Ethernet modules for their particular RTOS frameworks.

Related Information

[Embedded Software](#)

For more information about products available from third party providers.

12.4. Using the NicheStack TCP/IP Stack - Nios II Edition

The primary interface to the NicheStack TCP/IP Stack is the standard sockets interface. In addition, you call the following functions to initialize the stack and drivers:

- `alt_iniche_init()`
- `netmain()`

You also use the global variable `iniche_net_ready` in the initialization process.

You must provide the following simple functions, which the HAL system code calls to obtain the MAC address and IP address:

- `get_mac_addr()`
- `get_ip_addr()`

12.4.1. Nios II System Requirements

To use the NicheStack TCP/IP Stack, your Nios II system must meet the following requirements:



- The system hardware must include an Ethernet interface with interrupts enabled.
- The BSP must be based on MicroC/OS-II.
- The MicroC/OS-II RTOS must be configured to have the following settings:
 - TimeManagement / OSTimeTickHook must be enabled.
 - Maximum Number of Tasks must be four or less.
- The system clock timer must be set to point to an appropriate timer device.

12.4.2. The NicheStack TCP/IP Stack Tasks

The NicheStack TCP/IP Stack, in its standard Nios II configuration, consists of two fundamental tasks. Each of these tasks consumes a MicroC/OS-II thread resource, along with some memory for the thread's stack. In addition to the tasks your program creates, the following tasks run continuously:

- **The NicheStack main task, `tk_netmain()`**—After initialization, this task sleeps until a new packet is available for processing. Packets are received by an interrupt service routine (ISR). When the ISR receives a packet, it places it in the receive queue, and wakes up the main task.
- **The NicheStack tick task, `tk_nettick()`**—This task wakes up periodically to monitor for time-out conditions.

These tasks are started when the initialization process succeeds in the `netmain()` function.

Note: You can modify the task priority and stack sizes using `#define` statements in the configuration file `ipport.h`. You can create additional system tasks by enabling other options in the NicheStack TCP/IP Stack by editing `ipport.h`.

Related Information

[netmain\(\)](#) on page 300

12.4.3. Initializing the Stack

Before you initialize the stack, start the MicroC/OS-II scheduler by calling `OSStart()` from `main()`. Perform stack initialization in a high priority task, to ensure that your code does not attempt further initialization until the RTOS is running and I/O drivers are available.

To initialize the stack, call the functions `alt_iniche_init()` and `netmain()`. Global variable `iniche_net_ready` is set `true` when stack initialization is complete.

Note: Ensure that your code does not use the sockets interface before `iniche_net_ready` is set to `true`.

Related Information

[iniche_net_ready](#) on page 300

For more information and example, call `alt_iniche_init()` and `netmain()` from the highest priority task, and wait for `iniche_net_ready` before allowing other tasks to run.

12.4.3.1. alt_iniche_init()

`alt_iniche_init()` initializes the stack for use with the MicroC/OS-II operating system.

The prototype for `alt_iniche_init()` is:

```
void alt_iniche_init(void)
```

When used this way, `alt_iniche_init()` returns nothing and has no parameters.

12.4.3.2. netmain()

`netmain()` is responsible for initializing and launching the NicheStack tasks. The prototype for `netmain()` is:

```
void netmain(void)
```

`netmain()` returns nothing and has no parameters.

12.4.3.3. iniche_net_ready

When the NicheStack stack has completed initialization, it sets the global variable `iniche_net_ready` to a non-zero value.

Note: Do not call any NicheStack API functions (other than for initialization) until `iniche_net_ready` is true.

Example 4. Instantiating the NicheStack TCP/IP Stack Using `iniche_net_ready`

```
void SSSInitialTask(void *task_data)
{
    INT8U error_code;
    alt_iniche_init();
    netmain();

    while (!iniche_net_ready)
        TK_SLEEP(1);
    /* Now that the stack is running, perform the application
       initialization steps */
    .
    .
    .
}
```

Macro `TK_SLEEP()` is part of the NicheStack TCP/IP Stack operating system (OS) porting layer.

12.4.3.4. get_mac_addr() and get_ip_addr()

The NicheStack TCP/IP Stack system code calls `get_mac_addr()` and `get_ip_addr()` during the device initialization process. These functions are necessary for the system code to set the MAC and IP addresses for the network interface, which you select with the `altera_iniche.iniche_default_if` BSP setting.



Because you write these functions yourself, your system has the flexibility to store the MAC address and IP address in an arbitrary location, rather than a fixed location hard-coded in the device driver. For example, some systems might store the MAC address in flash memory, while others might have the MAC address in on-chip embedded memory.

Both functions take as parameters device structures used internally by the NicheStack TCP/IP Stack. However, you do not need to know the details of the structures. You only need to know enough to fill in the MAC and IP addresses.

12.4.3.4.1. Prototype for `get_mac_addr()`

The prototype for `get_mac_addr()` is:

```
int get_mac_addr(NET net, unsigned char mac_addr[6]);
```

You must implement the `get_mac_addr()` function to assign the MAC address to the `mac_addr` argument. Leave the `net` argument untouched.

The prototype for `get_mac_addr()` is in the header file `<niche path><iniche path>/inc/alt_iniche_dev.h`. The `NET` structure is defined in the `<iniche path>/src/h/net.h` file.

For demonstration purposes only, the MAC address is stored at address `CUSTOM_MAC_ADDR` in this example. There is no error checking in this example. In a real application, if there is an error, `get_mac_addr()` must return -1.

Example 5. An Implementation of `get_mac_addr()`

```
#include <alt_iniche_dev.h>
#include "includes.h"
#include "ipport.h"
#include "tcpport.h"
#include <io.h>
int get_mac_addr(NET net, unsigned char mac_addr[6])
{
    int ret_code = -1;
    /* Read the 6-byte MAC address from wherever it is stored */
    mac_addr[0] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 4);
    mac_addr[1] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 5);
    mac_addr[2] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 6);
    mac_addr[3] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 7);
    mac_addr[4] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 8);
    mac_addr[5] = IORD_8DIRECT(CUSTOM_MAC_ADDR, 9);
    ret_code = ERR_OK;
    return ret_code;
}
```

12.4.3.4.2. Prototype for `get_ip_addr()`

You must write the function `get_ip_addr()` to assign the IP address of the protocol stack. Your program can either assign a static address, or request the DHCP to find an IP address. The function prototype for `get_ip_addr()` is:

```
int get_ip_addr(alt_iniche_dev* p_dev,
    ip_addr* ipaddr,
    ip_addr* netmask,
    ip_addr* gw,
    int* use_dhcp);
```

`get_ip_addr()` sets the return parameters as follows:

```
IP4_ADDR(&ipaddr, IPADDR0, IPADDR1, IPADDR2, IPADDR3);
IP4_ADDR(&gw, GWADDR0, GWADDR1, GWADDR2, GWADDR3);
IP4_ADDR(&netmask, MSKADDR0, MSKADDR1, MSKADDR2, MSKADDR3);
```

For the dummy variables `IP_ADDR0-3`, substitute expressions for bytes 0-3 of the IP address. For `GWADDR0-3`, substitute the bytes of the gateway address. For `MSKADDR0-3`, substitute the bytes of the network mask. For example, the following statement sets `ip_addr` to IP address 137.57.136.2:

```
IP4_ADDR ( ip_addr, 137, 57, 136, 2 );
```

To enable DHCP, include the line:

```
*use_dhcp = 1;
```

The NicheStack TCP/IP stack attempts to get an IP address from the server. If the server does not provide an IP address within 30 seconds, the stack times out and uses the default settings specified in the `IP4_ADDR()` function calls.

To assign a static IP address, include the lines:

```
*use_dhcp = 0;
```

The prototype for `get_ip_addr()` is in the header file `<iniche path>/inc/alt_iniche_dev.h`.

`INICHE_DEFAULT_IF`, defined in `system.h`, identifies the network interface that you defined at system generation time. You can control `INICHE_DEFAULT_IF` through the `iniche_default_if` BSP setting.

`DHCP_CLIENT`, also defined in `system.h`, specifies whether to use the DHCP client application to obtain an IP address. You can set or clear this property with the `altera_iniche.dhcp_client` setting.

12.4.4. Calling the Sockets Interface

After you initialize your Ethernet device, use the sockets API in the remainder of your program to access the IP stack.

To create a new task that talks to the IP stack using the sockets API, you must use the function `TK_NEWTASK()`. The `TK_NEWTASK()` function is part of the NicheStack TCP/IP Stack operating system (OS) porting layer. `TK_NEWTASK()` calls the MicroC/OS-II `OSTaskCreate()` function to create a thread, and performs some other actions specific to the NicheStack TCP/IP Stack.

The prototype for `TK_NEWTASK()` is:

```
int TK_NEWTASK(struct inet_task_info* nettask);
```

Example 6. An Implementation of `get_ip_addr()`

```
#include <alt_iniche_dev.h>
#include "includes.h"
#include "ipport.h"
#include "tcpport.h"
int get_ip_addr(alt_iniche_dev* p_dev,
               ip_addr* ipaddr,
               ip_addr* netmask,
               ip_addr* gw,
```



```
int* use_dhcp)
{
    int ret_code = -1;
    /*
     * The name here is the device name defined in system.h
     */
    if (!strcmp(p_dev->name, "/dev/" INICHE_DEFAULT_IF))
    {
        /* The following is the default IP address if DHCP
         fails, or the static IP address if DHCP_CLIENT is
         undefined. */
        IP4_ADDR(&ipaddr, 10, 1, 1, 3);
        /* Assign the Default Gateway Address */
        IP4_ADDR(&gw, 10, 1, 1, 254);
        /* Assign the Netmask */
        IP4_ADDR(&netmask, 255, 255, 255, 0);
#ifdef DHCP_CLIENT
        *use_dhcp = 1;
#else
        *use_dhcp = 0;
#endif /* DHCP_CLIENT */
        ret_code = ERR_OK;
    }
    return ret_code;
}
```

Note: There is no error checking in this example. In a real application, you might need to return -1 on error.

The prototype is defined in `<iniche path>/src/nios2/osport.h`. You can include this header file as follows:

```
#include "osport.h"
```

You can find other details of the OS porting layer in the `osport.c` file in the NicheStack TCP/IP Stack component directory, `<iniche path>/src/nios2/`.

Related Information

[Using the NicheStack TCP/IP Stack - Nios II Edition Tutorial](#)

For more information about how to use `TK_NEWTASK()` in an application.

12.5. Configuring the NicheStack TCP/IP Stack in a Nios II Program

The NicheStack TCP/IP Stack has many options that you can configure using `#define` directives in the file `ipport.h`. The Nios II EDS allows you to configure certain options (that is, modify the `#defines` in `system.h`) without editing source code. The most commonly accessed options are available through a set of BSP options, identifiable by the prefix `altera_iniche`.

Some less-frequently-used options are not accessible through the BSP settings. If you need to modify these options, you must edit the `ipport.h` file manually.

You can find `ipport.h` in the `debug/system_description` directory for your BSP project.

The following sections describe the features that you can configure using the Nios II SBT. Both development flows provide a default value for each feature. In general, these values provide a good starting point, and you can later fine-tune the values to meet the needs of your system.

12.5.1. NicheStack TCP/IP Stack General Settings

The ARP, UDP, and IP protocols are always enabled.

Table 49. Protocol Options

Option	Description
TCP	Enables and disables the TCP.

Table 50. Global Options

Option	Description
Use DHCP to automatically assign IP address	If this option is turned on, the component uses DHCP to acquire an IP address. If this option is turned off, you must assign a static IP address.
Enable statistics	If this option is turned on, the stack keeps counters of packets received, errors, etc. The counters are defined in <code>mib</code> structures defined in various header files in directory <code><niche path>/31src/h</code> . For details about <code>mib</code> structures, refer to the NicheStack documentation.
MAC interface	If the IP stack has more than one network interface, this parameter indicates which interface to use.

For more information about BSP settings for the NicheStack, refer to the "Nios II Software Build Tools Reference" section.

Related Information

[Known Limitations](#) on page 305

12.5.2. IP Options

Table 51. IP Options

Option	Description
Forward IP packets	If there is more than one network interface, this option is turned on, and the IP stack for one interface receives packets that are not addressed to it, the stack forwards the packet out of the other interface.
Reassemble IP packet fragments	If this option is turned on, the NicheStack TCP/IP Stack reassembles IP packet fragments as full IP packets. Otherwise, it discards IP packet fragments. This topic is explained in <i>Unix Network Programming</i> by Richard Stevens.

Related Information

[Known Limitations](#) on page 305

12.5.3. TCP Options

Table 52. TCP Zero Copy Options Available When Enabled

Option	Description
Use TCP zero copy	This option enables the NicheStack zero copy TCP API. This option allows you to eliminate buffer-to-buffer copies when using the NicheStack TCP/IP Stack. For details, refer to the NicheStack reference manual. You must modify your application code to take advantage of the zero copy API.



12.6. Further Information

The tutorial provides in-depth information about the NicheStack TCP/IP Stack, and illustrates how to use it in a networking application.


Related Information

[Using the NicheStack TCP/IP Stack - Nios II Edition Tutorial](#)

For more information about the NicheStack implementation

12.7. Known Limitations

Although the NicheStack code contains features intended to support multiple network interfaces, these features are not tested in the Nios II edition. Refer to the NicheStack TCP/IP Stack reference manual and source code for information about multiple network interface support.



13. Read-Only Zip File System

Intel FPGA provides a read-only zip file system for use with the hardware abstraction layer (HAL). The read-only zip file system provides access to a simple file system stored in flash memory. This file system is suitable for embedded software use. The drivers take advantage of the HAL generic device driver framework for file subsystems. Therefore, you can access the zip file subsystem using the ANSI C standard library I/O functions, such as `fopen()` and `fread()`.

The Intel FPGA read-only zip file system is provided as a software package. All source and header files for the HAL drivers are located in the directory `<Nios II EDS install path>/components/altera_ro_zipfs/HAL/`.

Related Information

[Read-Only Zip File System Revision History](#) on page 16

For details on the document revision history of this chapter

13.1. Using the Read-Only Zip File System in a Project

The read-only zip file system is supported by both Nios II software development flows. You need not edit any source code to include and configure the file system. To use the zip file system, you use the Nios II development tools to include it as a software package for the board support package (BSP) project.

You must specify the following four parameters to configure the file system:

- The name of the flash device where you wish to program the file system.
- The offset in the address space of this flash device.
- The name of the mount point for this file subsystem in the HAL file system. For example, if you name the mount point `/mnt/zipfs`, the following code opens a file in the zip file:

```
fopen("/mnt/zipfs/hello", "r");
```

This code, called from within a HAL-based program, opens the file `hello` for reading.

- The name of the zip file you wish to use.

The next time you build your project after you make these settings, the Nios II development tools include and link the file subsystem in the project. After you rebuild the project, the `system.h` file reflects the presence of this software package in the system.



13.1.1. Preparing the Zip File

The zip file must be uncompressed. The read-only zip file system uses the zip format only for bundling files together; it does not provide the file decompression features for which zip utilities are known.

Creating a zip file with no compression is straightforward using the WinZip GUI. Alternately, use the `-e0` option to disable compression when using either `winzip` or `pkzip` from a command line.

13.1.2. Programming the Zip File to Flash

For your program to access files in the zip file subsystem, you must first program the zip data to flash. As part of the project build process, the Nios II development tools create a Motorola S-record file (`.flash`) that includes the data for the zip file system.

You then use the Nios II Flash Programmer to program the zip file system data to flash memory on the board.

Related Information

[Nios II Flash Programmer User Guide](#)

For more information about programming flash.

14. Publishing Component Information to Embedded Software

This document describes how to publish hardware component information for embedded software tools. You can publish component information for use by software, such as a C compiler and a board support package (BSP) generator. Information used by a C compiler might be a set of `#define` statements that describe some aspect of a component. Information used by a BSP generator might be the identification of memory components, so that the BSP generator can create a linker script.


Related Information

[Publishing Component Information to Embedded Software Revision History](#) on page 16
For details on the document revision history of this chapter

14.1. Embedded Component Information Flow

14.1.1. Embedded Component Information Flow Diagram

Embedded Component Information Flow





14.1.2. Tcl Assignment Statements

A component publishes information by including Tcl assignment statements in its component description file, `<component_name>_hw.tcl`. Each assignment is a name-value pair that can be associated with the entire component, or with a single interface. When the assignment statement applies to the entire component, it is set using the `set_module_assignment` command. Assignment statements that apply to an interface are set using the `set_interface_assignment` command.

```
# These assignments apply to the entire component
# This is the syntax for the set_module_assignment command:
# set_module_assignment <assignment_name> <value>
# Here are 3 examples
set_module_assignment embeddedsw.CMacro.colorSpace "CMYK"
set_module_assignment embeddedsw.configuration.cpuArchitecture "My processor"
set_module_assignment embeddedsw.memoryInfo.IS_FLASH 1
# This is the syntax of the set_interface_assignment command:
# set_interface_assignment <interface_name> <assignment_name> <value>
# Here is an example
set_interface_assignment lcd0 embeddedsw.configuration.isPrintableDevice 1
```

When you generate a hardware system, the system integration tool, Platform Designer, creates an `<sopc_builder_system>.sopcinfo` file that includes all of the assignments for your component. The embedded software tools use these assignments for further processing. The system integration tool does not require any of the information included in these assignments to build the hardware representation of the component. The tool simply passes the assignments from the `_hw.tcl` file to the (`.sopcinfo`).

Related Information

[Quartus Prime Standard Edition Handbook Volume 1: Design and Synthesis](#)

For more information about the `_hw.tcl` file and using Tcl to define hardware components, refer to the

14.2. Embedded Software Assignments

Embedded software assignments are organized in a period-separated namespace. All of the assignments for embedded software tools have the prefix `embeddedsw`. The `embeddedsw` namespace is further divided into the following three sub-namespaces:

- C Macro—Assignment name prefix `embeddedsw.CMacro`
- Configuration—Assignment name prefix `embeddedsw.configuration`
- Memory Initialization—Assignment name prefix `embeddedsw.memoryInfo`

14.2.1. C Macro Namespace

You can use the C macro namespace to publish information about your component that is converted to `#define`'s in a C or C++ `system.h` file. C macro assignments are associated with the entire hardware component, not with individual interfaces.

The name of an assignment in the C macro namespace is `embeddedsw.CMacro.<assignmentName>`. You must format the value as a legal C or C++ expression.

Example 13–2. Assignment Statement for the BAUD_RATE of uart_0 in a Hardware System

```
# Tcl assignment statement included in the _hw.tcl file
add_parameter BAUD_RATE_PARAM integer 9600 "This is the default baud rate."
# Dynamically reassign the baud rate based on the parameter value
set_module_assignment embeddedsw.CMacro.BAUD_RATE \
[get_parameter_value BAUD_RATE_PARAM]
```

14.2.1.1. Generated Macro in system.h

Example 13–3. Generated Macro in system.h After Dynamic Reassignment

```
/* Generated macro in the system.h file after dynamic reassignment */
#define UART_0_BAUD_RATE 15200
```

For more information about formatting constants, refer to the [GNU web page](#).

Related Information

- [GCC, the GNU Compiler Collection](#)
For more information about formatting constants, refer to the GNU webpage.
- [GNU web page](#)
For more information about formatting constants

14.2.1.2. GCC C/C++ 32-bit Processor Constants

Table 53. Examples of How to Format GCC C/C++ 32-bit Processor Constants

C Data Type	Examples
boolean (char, short, int)	1, 0
32-bit signed integer (int, long)	123, -50
32-bit unsigned integer (unsigned int, unsigned long)	123u, 0xef8472a0
64-bit signed integer (long long int)	4294967296LL, -4294967296LL
64-bit unsigned integer (unsigned long long int)	4294967296ULL, 0xac458701fd64ULL
32-bit floating-point (float)	3.14f
64-bit floating-point (double)	2.78, 314e-2
character (char)	'x'
string (const char*)	"Hello World!"

14.2.2. Configuration Namespace

You can use the configuration namespace to pass configuration information to embedded software tools. You can associate configuration namespace assignments with the entire component or with a single interface.

The assignment name for the configuration namespace is `embeddedsw.configuration.<name>`. Intel FPGA's embedded software tools already have definitions for the data types of the configuration names listed in this section.



14.2.2.1. Configuration Data Types

Table 54. Configuration Data Types and Corresponding Format

Configuration Data Type	Format
boolean	1, 0
32-bit integer	123, -50
64-bit integer	4294967296, -4294967296
32-bit floating-point	3.14
64-bit floating-point	2.78, 314e-2
string	ABC

14.2.2.2. Component Configuration Information

Table 55. Component Configuration Information - Assign with `set_module_assignment`

Configuration Name	Type	Default	Meaning	Example
cpuArchitecture	string	—	Processor instruction set architecture. Provide this assignment if you want your component to be considered a processor.	My 8051
requiredDriver	boolean	0	If this configuration is 1 (true), the component requires a software driver. Software tools are expected to generate a warning if no driver is found.	1

14.2.2.3. Memory-Mapped Slave Information

Table 56. Avalon Memory-Mapped Slave Information - Assign with `set_interface_assignment`

Configuration Name	Type	Default	Meaning	Examples
isMemoryDevice	boolean	0	The slave port provides access to a memory device.	Intel FPGA® On-Chip Memory Component, DDR Controller, erasable programmable configurable serial (EPCS) Controller
isPrintableDevice	boolean	0	The slave port provides access to a character-based device.	Intel FPGA UART, Intel FPGA JTAG UART, Intel FPGA LCD
isTimerDevice	boolean	0	The slave port provides access to a timer device.	Intel FPGA Timer
<i>continued...</i>				



Configuration Name	Type	Default	Meaning	Examples
isEthernetMacDevice	boolean	0	The slave port provides access to an Ethernet media access control (MAC).	Intel FPGA Triple-Speed Ethernet
isNonVolatileStorage ⁽¹⁰⁾	boolean	0	The memory device is a non-volatile memory device. The contents of a non-volatile memory device are fixed and always present. In normal operation, you can only read from this memory. If this property is true, you must also set <code>isMemoryDevice</code> to true.	Common flash interface (CFI) Flash, EPCS Flash, on-chip FPGA memory configured as a ROM
isFlash	boolean	0	The memory device is a flash memory device. If <code>isFlash</code> is true, you must also set <code>isMemoryDevice</code> and <code>isNonVolatileStorage</code> to true.	CFI Flash, EPCS Flash
hideDevice	boolean	0	Do not make this slave port visible to the embedded software tools.	Nios II debug slave port
affectsTransactionsOnMasters	string	empty string	<p>A list of master names delimited by spaces, for example <code>m1 m2</code>. Used when the slave port provides access to Avalon-MM control registers in the component. The control registers control transfers on the specified master ports.</p> <p>The slave port can configure the control registers for master ports on the listed components. The address space for this slave port is composed of the address spaces of the named master ports.</p> <p>Nios II embedded software tools use this information to generate <code>#define</code></p>	Intel FPGA direct memory access (DMA), Intel FPGA Scatter/Gather DMA

⁽¹⁰⁾ Some FPGA RAMs support initialization at power-up from the SRAM Object File (**.sof**) or programmer object file (**.pof**), but are not considered non-volatile because this ability might not be used.



Configuration Name	Type	Default	Meaning	Examples
			directives describing the address space of these master ports.	

Note:

14.2.2.4. Streaming Source Information

Table 57. Avalon Streaming Slave Interface Source Information - Assign with set_interface_assignment

Configuration Name	Type	Default	Meaning	Examples
isInterruptControllerSender ⁽¹¹⁾	boolean	0	The interface sends interrupts to an interrupt controller receiver interface.	Intel FPGA Vectored Interrupt Controller
transportsInterruptsFromReceivers ⁽¹²⁾	string	empty string	A list of interrupt receiver interface names delimited by spaces. Used when the interrupt controller sender interface can transport daisy-chained interrupts from one or more interrupt controller receiver ports on the same module.	Intel FPGA Vectored Interrupt Controller daisy-chain input

14.2.2.5. Streaming Sink Information

Table 58. Streaming Sink Information - Assign with set_interface_assignment

Configuration Name	Type	Default	Meaning	Examples
isInterruptControllerReceiver ⁽¹³⁾	boolean	0	The interface receives interrupts (optionally daisy-chained) from an interrupt controller sender interface.	Intel FPGA Vectored Interrupt Controller, Intel FPGA Nios II

14.2.3. Memory Initialization Namespace


You use the memory initialization namespace to pass memory initialization information to embedded software tools. Use this namespace to create memory initialization files, including **.flash**, **.hex**, **.dat**, and **.sym** files. You use memory initialization files for the following tasks:

- Flash programming
- RTL simulation
- Creating initialized FPGA RAMs for Quartus Prime compilation

⁽¹¹⁾ An interrupt sender interface is an Avalon-ST source providing interrupt information according to the external interrupt controller (EIC) protocol.

⁽¹²⁾ An interrupt receiver interface is an Avalon-ST sink receiving interrupt information from an EIC.

⁽¹³⁾ An interrupt controller receiver interface is an Avalon-ST sink receiving interrupt information from an EIC.



You only need to provide these assignments if your component is a memory device that you want to initialize.

The assignment name for the memory initialization namespace is `embeddedsd.memoryInfo.<name>`. The embedded software tools already have definitions for the data types of the possible values.


Table 59. Memory Initialization Data Types and Corresponding Format

Memory Initialization Data Type	Format
boolean	1, 0
32-bit integer	123, -50
string	ABC

Note: Quotation marks are not required.

Table 60. Memory Initialization Information - Assign with `set_module_assignment` Command

Memory Initialization Name	Type	Default	Meaning
HAS_BYTE_LANE	boolean	0	Create a memory initialization file for each byte.
IS_FLASH	boolean	0	Component is a flash device.
IS_EPCS	boolean	0	If IS_FLASH and IS_EPCS are both 1, component is an EPCS flash device. If IS_FLASH is 1 and IS_EPCS is 0, the component is a CFI flash device. If IS_EPCS is 1, IS_FLASH must also be 1.
GENERATE_HEX	boolean	0	Create an Intel hexadecimal file (.hex).
GENERATE_DAT_SYM	boolean	0	Create a .dat and a .sym file.
GENERATE_FLASH	boolean	0	Create a Motorola S-record File (.flash).
INCLUDE_WARNING_MSG	string	empty string	Display a warning message when creating memory initialization files.
MEM_INIT_FILENAME	string	Module instance name	Name of the memory initialization file, without any file type suffix.
MEM_INIT_DATA_WIDTH	32-bit integer	none (mandatory)	Width of memory initialization file in bits. May be different than the slave port data width.



15. HAL API Reference

This chapter provides an alphabetically ordered list of all the functions in the hardware abstraction layer (HAL) application program interface (API). Each function is listed with its C prototype and a short description. Each listing provides information about whether the function is thread-safe when running in a multi-threaded environment, and whether it can be called from an interrupt service routine (ISR).

This chapter only lists the functionality provided by the HAL. The complete newlib API is also available from within HAL systems. For example, newlib provides `printf()`, and other standard I/O functions, which are not described here.

Note:

Each function description lists the C header file that your code must include to access the function. Because header files include other header files, the function prototype might not be defined in the listed header file. However, you must include the listed header file in order to include all definitions on which the function depends.

For more information about the newlib API, refer to the newlib documentation. On the Windows **Start** menu, click **Programs > Intel FPGA > Nios II <version> > Nios II <version> > Documentation**.

Related Information

[HAL API Reference Revision History](#) on page 17

For details on the document revision history of this chapter

15.1. HAL API Functions

15.1.1. `_exit()`

Prototype

```
void _exit (int exit_code)
```

Commonly Called By

newlib C library

Thread-safe

Yes.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The newlib `exit()` function calls the `_exit()` function to terminate the current process. Typically, `exit()` calls this function when `main()` completes. Because there is only a single process in HAL systems, the HAL implementation blocks forever.

Interrupts are not disabled, so ISRs continue to execute.

The input argument, `exit_code`, is ignored.

Return

--

Related Information

[newlib Library Documentation](#)

15.1.2. `_rename()`**Prototype**

```
int _rename(char *existing, char* new)
```

Commonly Called By

newlib C library

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<stdio.h>
```

Description

The `_rename()` function is provided for newlib compatibility.

Return

It always fails with return code `-1`, and with `errno` set to `ENOSYS`.

Related Information

[newlib Library Documentation](#)

15.1.3. `alt_dcache_flush()`**Prototype**

```
void alt_dcache_flush (void* start, alt_u32 len)
```

Commonly Called By

C/C++ programs

Device drivers



Thread-safe

Yes.

Available from ISR

Yes.

Include

<sys/alt_cache.h>

Description

The `alt_dcache_flush()` function flushes the data cache for a memory region of length `len` bytes, starting at address `start`. Flushing the cache consists of writing back dirty data and then invalidating the cache.

In processors without data caches, it has no effect.

Return

--

Related Information

- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319
- [alt_uncached_malloc\(\)](#) on page 319

15.1.4. alt_dcache_flush_all()

Prototype

```
void alt_dcache_flush_all (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

<sys/alt_cache.h>

Description

The `alt_dcache_flush_all()` function flushes, that is, writes back dirty data and then invalidates, the entire contents of the data cache.

In processors without data caches, it has no effect.

Return

--

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319
- [alt_uncached_malloc\(\)](#) on page 319

15.1.5. alt_dcache_flush_no_writeback()

Prototype

```
void alt_dcache_flush_no_writeback (void* start, alt_u32 len)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_cache.h>
```

Description

The `alt_dcache_flush_no_writeback()` is called to flush the data cache for a memory region of length "len" bytes, starting at address "start". Any dirty lines in the data cache are NOT written back to memory. The cache becomes invalidated.

Return

--



15.1.6. alt_uncached_malloc()

Prototype

```
volatile void* alt_uncached_malloc (size_t size)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_cache.h>
```

Description

The `alt_uncached_malloc()` routine guarantees that the allocated memory region is not in the data cache and that all subsequent accesses to the allocated memory regions bypass the data cache. In the case there is no data cache implemented the `alt_uncached_malloc()` routine simply calls `malloc()`. If data cache is implemented, but bit 31 is not set to be used as a cache bypass then the following link error results when building the code: `ALT_LINK_ERROR("alt_uncached_malloc() is not available because CPU is not configured to use bit 31 of address to bypass data cache")`.

Return

If sufficient memory cannot be allocated, this function returns null, otherwise a pointer to the allocated space is returned.

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319

15.1.7. alt_uncached_free()

Prototype

```
void alt_uncached_free (volatile void* ptr)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

`<sys/alt_cache.h>`

Description

In the case there is no data cache implemented the `alt_uncached_free()` routine simply calls `free()`. If data cache is implemented, but bit 31 is not set to be used as a cache bypass then a link error results when building the code.

Return

--

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_malloc\(\)](#) on page 319

15.1.8. `alt_remap_uncached()`

Prototype

```
volatile void* alt_remap_uncached (void* ptr,  
alt_u32 len);
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.



Include

`<sys/alt_cache.h>`

Description

The `alt_remap_uncached()` routine is not available with Nios II cores with data caches because mixing cacheable and uncachable data on the same line is not supported. This function results in a link error when used with Nios II cores.

Return

The return value for this function is the remapped memory region.

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_uncached_free\(\)](#) on page 319
- [alt_uncached_malloc\(\)](#) on page 319

15.1.9. alt_remap_cached()

Prototype

```
void* alt_remap_cached (volatile void* ptr,  
alt_u32 len);
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

`<sys/alt_cache.h>`

Description

The `alt_remap_cached()` function remaps a region of memory for cached access. The memory to map is `len` bytes, starting at address `ptr`.

Processors that do not have a data cache return uncached memory.

Return

The return value for this function is the remapped memory region.

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319
- [alt_uncached_malloc\(\)](#) on page 319

15.1.10. alt_icache_flush_all()

Prototype

```
void alt_icache_flush_all (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_cache.h>
```

Description

The `alt_icache_flush_all()` function invalidates the entire contents of the instruction cache.

In processors without instruction caches, it has no effect.

Return

--

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush\(\)](#) on page 323
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319



- [alt_uncached_malloc\(\)](#) on page 319

15.1.11. alt_icache_flush()

Prototype

```
void alt_icache_flush (void* start, alt_u32 len)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_cache.h>
```

Description

The `alt_icache_flush()` function invalidates the instruction cache for a memory region of length `len` bytes, starting at address `start`.

In processors without instruction caches, it has no effect.

Return

--

Related Information

- [alt_dcache_flush\(\)](#) on page 316
- [alt_dcache_flush_all\(\)](#) on page 317
- [alt_icache_flush_all\(\)](#) on page 322
- [alt_remap_cached\(\)](#) on page 321
- [alt_remap_uncached\(\)](#) on page 320
- [alt_uncached_free\(\)](#) on page 319
- [alt_uncached_malloc\(\)](#) on page 319

15.1.12. alt_alarm_start()

Prototype

```
int alt_alarm_start  
( alt_alarm* alarm,  
  alt_u32 nticks,  
  alt_u32 (*callback) (void* context),
```

```
void* context )
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_alarm.h>
```

Description

The `alt_alarm_start()` function schedules an alarm callback.

For more information, refer to "Using Timer Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

The HAL waits `nticks` system clock ticks before calling the `callback()` function. When the HAL calls `callback()`, it passes it the input argument `context`. The HAL does not use the `context` parameter. It only passes it as a parameter to the `callback()` function.

The `alarm` argument is a pointer to a structure that represents this alarm. You must create it, and it must have a lifetime that is at least as long as that of the alarm. However, you are not responsible for initializing the contents of the structure pointed to by `alarm`. This action is done by the call to `alt_alarm_start()`.

One alarm is created for each call to `alt_alarm_start()`. Multiple alarms can run simultaneously.

Return

The return value for `alt_alarm_start()` is zero on success, and negative otherwise. This function fails if there is no system clock available.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380



- [usleep\(\)](#) on page 383

15.1.13. alt_alarm_stop()

Prototype

```
void alt_alarm_stop (alt_alarm* alarm)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_alarm.h>
```

Description

You can call the `alt_alarm_stop()` function to cancel an alarm previously registered by a call to `alt_alarm_start()`. The input argument is a pointer to the alarm structure in the previous call to `alt_alarm_start()`.

On return the alarm is canceled, if it is still active.

Return

--

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_ticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.14. alt_dma_rxchan_depth()

Prototype

```
alt_u32 alt_dma_rxchan_depth(alt_dma_rxchan dma)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

<sys/alt_dma.h>

Description

The `alt_dma_rxchan_depth()` function returns the maximum number of receive requests that can be posted to the specified DMA transmit channel, `dma`.

Whether this function is thread-safe, or can be called from an ISR, depends on the underlying device driver. In general it safest to assume that it is not thread-safe.

Return

Returns the maximum number of receive requests that can be posted.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.15. alt_dma_rxchan_close()

Prototype

```
int alt_dma_rxchan_close (alt_dma_rxchan rxchan)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.



Available from ISR

No.

Include

<sys/alt_dma.h>

Description

The `alt_dma_rxchan_close()` function notifies the system that the application has finished using the direct memory access (DMA) receive channel, `rxchan`. The current implementation always succeeds.

Return

The return value is zero on success and negative otherwise.

Related Information

- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.16. alt_dev_reg()

Prototype

```
int alt_dev_reg(alt_dev* dev)
```

Commonly Called By

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_dev.h>

Description

The `alt_dev_reg()` function registers a device with the system. After it is registered, you can access a device using the standard I/O functions.

For more information, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

The system behavior is undefined in the event that a device is registered with a name that conflicts with an existing device or file system.

The `alt_dev_reg()` function is not thread-safe in the sense that no other thread can use the device list at the time that `alt_dev_reg()` is called. Call `alt_dev_reg()` only in the following circumstances:

- When running in single-threaded mode.
- From a device initialization function called by `alt_sys_init()`.
`alt_sys_init()` may only be called by the single-threaded C startup code.

Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_fs_reg\(\)](#) on page 341

15.1.17. alt_dma_rxchan_open()

Prototype

```
alt_dma_rxchan alt_dma_rxchan_open (const char* name)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_rxchan_open()` function obtains an `alt_dma_rxchan` descriptor for a DMA receive channel. The input argument, `name`, is the name of the associated physical device, for example, `/dev/dma_0`.

Return

The return value is null on failure and non-null otherwise. If an error occurs, `errno` is set to `ENODEV`.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326



- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.18. alt_dma_rxchan_prepare()

Prototype

```
int alt_dma_rxchan_prepare (alt_dma_rxchan dma,  
void* data,  
alt_u32 length,  
alt_rxchan_done* done,  
void* handle)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

See description.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_rxchan_prepare()` posts a receive request to a DMA receive channel. The input arguments are: `dma`, the channel to use; `data`, a pointer to the location that data is to be received to; `length`, the maximum length of the data to receive in bytes; `done`, callback function that is called after the data is received; `handle`, an opaque value passed to `done`.

Whether this function is thread-safe, or can be called from an ISR, depends on the underlying device driver. In general it safest to assume that it is not thread-safe.

Return

The return value is zero upon success. A negative return value indicates that the request cannot be posted.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.19. alt_dma_rxchan_reg()**Prototype**

```
int alt_dma_rxchan_reg (alt_dma_rxchan_dev* dev)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_dma_dev.h>
```

Description

The `alt_dma_rxchan_reg()` function registers a DMA receive channel with the system.

After it is registered, a device can be accessed using the functions described in "Using DMA Devices" in the "Developing Programs Using the Hardware Abstraction Layer" section.

System behavior is undefined in the event that a channel is registered with a name that conflicts with an existing channel.

The `alt_dma_rxchan_reg()` function is not thread-safe if other threads are using the channel list at the time that `alt_dma_rxchan_reg()` is called. Call `alt_dma_rxchan_reg()` only in the following circumstances:

- When running in single-threaded mode.
- From a device initialization function called by `alt_sys_init()`.
`alt_sys_init()` may only be called by the single-threaded C startup code.



Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.20. alt_dma_txchan_close()

Prototype

```
int alt_dma_txchan_close (alt_dma_txchan txchan)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_txchan_close` function notifies the system that the application has finished using the DMA transmit channel, `txchan`. The current implementation always succeeds.

Return

The return value is zero on success and negative otherwise.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325

- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.21. alt_dma_txchan_ioctl()

Prototype

```
int alt_dma_txchan_ioctl (alt_dma_txchan dma,  
int req,  
void* arg)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

See description.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_txchan_ioctl()` function performs device specific I/O operations on the DMA transmit channel, `dma`. For example, some drivers support options to control the width of the transfer operations. The input argument, `req`, is an enumeration of the requested operation; `arg` is an additional argument for the request. The interpretation of `arg` is request dependent.

For more information, refer to the "Generic Requests DMA Might Support" table ([Table 14–1 on page 14–11](#)) for the generic requests a device might support.

Whether a call to `alt_dma_txchan_ioctl()` is thread-safe, or can be called from an ISR, is device dependent. In general it safest to assume that it is not thread-safe.

Do not call the `alt_dma_txchan_ioctl()` function while DMA transfers are pending, or unpredictable behavior could result.

Return

A negative return value indicates failure; otherwise the interpretation of the return value is request specific.



Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.22. alt_dma_txchan_open()

Prototype

```
alt_dma_txchan alt_dma_txchan_open (const char* name)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_txchan_open()` function obtains an `alt_dma_txchan()` descriptor for a DMA transmit channel. The input argument, `name`, is the name of the associated physical device, for example, `/dev/dma_0`.

Return

The return value is null on failure and non-null otherwise. If an error occurs, `errno` is set to `ENODEV`.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330

- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.23. alt_dma_txchan_reg()

Prototype

```
int alt_dma_txchan_reg (alt_dma_txchan_dev* dev)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_dma_dev.h>
```

Description

The `alt_dma_txchan_reg()` function registers a DMA transmit channel with the system.

After it is registered, a device can be accessed using the functions described in "Using DMA Devices" in the "Developing Programs Using the Hardware Abstraction Layer" section.

System behavior is undefined in the event that a channel is registered with a name that conflicts with an existing channel.

The `alt_dma_txchan_reg()` function is not thread-safe if other threads are using the channel list at the time that `alt_dma_txchan_reg()` is called. Call `alt_dma_txchan_reg()` only in the following circumstances:

- When running in single-threaded mode.
- From a device initialization function called by `alt_sys_init()`.
`alt_sys_init()` may only be called by the single-threaded C startup code.

Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_dma_rxchan_close\(\)](#) on page 326



- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_send\(\)](#) on page 340
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.24. alt_flash_close_dev()

Prototype

```
void alt_flash_close_dev(alt_flash_fd* fd)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_flash.h>
```

Description

The `alt_flash_close_dev()` function closes a flash device. All subsequent calls to `alt_write_flash()`, `alt_read_flash()`, `alt_get_flash_info()`, `alt_erase_flash_block()`, or `alt_write_flash_block()` for this flash device fail.

Call the `alt_flash_close_dev()` function only when operating in single-threaded mode.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

--

Related Information

- [alt_flash_open_dev\(\)](#) on page 341
- [alt_get_flash_info\(\)](#) on page 342

- [alt_read_flash\(\)](#) on page 360
- [alt_write_flash\(\)](#) on page 365
- [alt_write_flash_block\(\)](#) on page 366

15.1.25. [alt_exception_cause_generated_bad_addr\(\)](#)

Prototype

```
int alt_exception_cause_generated_bad_addr ( alt_exception_cause
cause )
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

--

Available from ISR

--

Include

```
<sys/alt_exceptions.h>
```

Description

This function validates the `bad_addr` argument to an instruction-related exception handler. The function parses the handler's `cause` argument to determine whether the `bad_addr` register contains the exception-causing address.

If the exception is of a type that generates a valid address in `bad_addr`, this function returns a nonzero value. Otherwise, it returns zero.

If the `cause` register is unimplemented in the Nios II processor core, this function always returns zero.

Return

A nonzero value means `bad_addr` contains the exception-causing address.

Zero means the value of `bad_addr` is to be ignored.

Related Information

[alt_instruction_exception_register\(\)](#) on page 348

15.1.26. [alt_erase_flash_block\(\)](#)

Prototype

```
int alt_erase_flash_block(alt_flash_fd* fd,
int offset,
```




int length)

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_flash.h>

Description

The `alt_erase_flash_block()` function erases an individual flash erase block. The parameter `fd` specifies the flash device; `offset` is the offset within the flash of the block to erase; `length` is the size of the block to erase. No error checking is performed to check that this is a valid block, or that the length is correct.

For more information, refer to "Using Flash Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

Call the `alt_erase_flash_block()` function only when operating in single-threaded mode.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

[Developing Programs Using the Hardware Abstraction Layer](#) on page 158

15.1.27. `alt_dma_rxchan_ioctl()`

Prototype

```
int alt_dma_rxchan_ioctl (alt_dma_rxchan dma,  
  
int req,  
  
void* arg)
```

Commonly Called By

C/C++ programs



Device drivers

Thread-safe

See description.

Available from ISR

See description.

Include

<sys/alt_dma.h>

Description

The `alt_dma_rxchan_ioctl()` function performs DMA I/O operations on the DMA receive channel, `dma`. The I/O operations are device specific. For example, some DMA drivers support options to control the width of the transfer operations. The input argument, `req`, is an enumeration of the requested operation; `arg` is an additional argument for the request. The interpretation of `arg` is request dependent.

Whether a call to `alt_dma_rxchan_ioctl()` is thread-safe, or can be called from an ISR, is device dependent. In general it safest to assume that it is not thread-safe.

Do not call the `alt_dma_rxchan_ioctl()` function while DMA transfers are pending, or unpredictable behavior could result.

For device-specific information about the Intel FPGA DMA controller core, refer to the "DMA Controller Core" chapter in the *Embedded Peripherals IP User Guide*.

Return

A negative return value indicates failure. The interpretation of nonnegative return values is request specific.

Table 61. Generic Requests DMA Might Support

Request	Meaning
ALT_DMA_SET_MODE_8	Transfer data in units of 8 bits. The value of <code>arg</code> is ignored.
ALT_DMA_SET_MODE_16	Transfer data in units of 16 bits. The value of <code>arg</code> is ignored.
ALT_DMA_SET_MODE_32	Transfer data in units of 32 bits. The value of <code>arg</code> is ignored.
ALT_DMA_SET_MODE_64	Transfer data in units of 64 bits. The value of <code>arg</code> is ignored.
ALT_DMA_SET_MODE_128	Transfer data in units of 128 bits. The value of <code>arg</code> is ignored.
ALT_DMA_GET_MODE	Return the transfer width. The value of <code>arg</code> is ignored.
ALT_DMA_TX_ONLY_ON	The <code>ALT_DMA_TX_ONLY_ON</code> request causes a DMA channel to operate in a mode in which only the transmitter is under software control. The other side writes continuously from a single location. The address to which to write is the argument to this request.
ALT_DMA_TX_ONLY_OFF	Return to the default mode, in which both the receive and transmit sides of the DMA can be under software control.
ALT_DMA_RX_ONLY_ON	The <code>ALT_DMA_RX_ONLY_ON</code> request causes a DMA channel to operate in a mode in which only the receiver is under software control. The other side reads continuously from a single location. The address to read is the argument to this request.
ALT_DMA_RX_ONLY_OFF	Return to the default mode, in which both the receive and transmit sides of the DMA can be under software control.



Related Information

DMA Controller Core

For more information, refer to the "DMA Controller Core" section of the *Embedded Peripherals IP User Guide*.

15.1.28. alt_dma_txchan_space()

Prototype

```
int alt_dma_txchan_space (alt_dma_txchan dma)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

See description/

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_txchan_space()` function returns the number of transmit requests that can be posted to the specified DMA transmit channel, `dma`. A negative value indicates that the value cannot be determined.

Whether this function is thread-safe, or can be called from an ISR, depends on the underlying device driver. In general it safest to assume that it is not thread-safe.

Return

Returns the number of transmit requests that can be posted.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333
- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_send\(\)](#) on page 340

15.1.29. alt_dma_txchan_send()

Prototype

```
int alt_dma_txchan_send (alt_dma_txchan dma,  
const void* from,  
alt_u32 length,  
alt_txchan_done* done,  
void* handle)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

See description.

Include

```
<sys/alt_dma.h>
```

Description

The `alt_dma_txchan_send()` function posts a transmit request to a DMA transmit channel. The input arguments are: `dma`, the channel to use; `from`, a pointer to the start of the data to send; `length`, the length of the data to send in bytes; `done`, a callback function that is called after the data is sent; and `handle`, an opaque value passed to `done`.

Whether this function is thread-safe, or can be called from an ISR, depends on the underlying device driver. In general it safest to assume that it is not thread-safe.

Return

The return value is negative if the request cannot be posted, and zero otherwise.

Related Information

- [alt_dma_rxchan_close\(\)](#) on page 326
- [alt_dma_rxchan_depth\(\)](#) on page 325
- [alt_dma_rxchan_open\(\)](#) on page 328
- [alt_dma_rxchan_prepare\(\)](#) on page 329
- [alt_dma_rxchan_reg\(\)](#) on page 330
- [alt_dma_txchan_close\(\)](#) on page 331
- [alt_dma_txchan_ioctl\(\)](#) on page 332
- [alt_dma_txchan_open\(\)](#) on page 333



- [alt_dma_txchan_reg\(\)](#) on page 334
- [alt_dma_txchan_space\(\)](#) on page 339

15.1.30. alt_flash_open_dev()

Prototype

```
alt_flash_fd* alt_flash_open_dev(const char* name)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_flash.h>
```

Description

The `alt_flash_open_dev()` function opens a flash device. After it is opened, you can perform the following operations:

- Write to a flash device using `alt_write_flash()`
- Read from a flash device using `alt_read_flash()`
- Control individual flash blocks using `alt_get_flash_info()`, `alt_erase_flash_block()`, or `alt_write_flash_block()`.

Call the `alt_flash_open_dev` function only when operating in single-threaded mode.

Return

The return value is zero upon failure. Any other value indicates success.

Related Information

- [alt_flash_close_dev\(\)](#) on page 335
- [alt_get_flash_info\(\)](#) on page 342
- [alt_read_flash\(\)](#) on page 360
- [alt_write_flash\(\)](#) on page 365
- [alt_write_flash_block\(\)](#) on page 366

15.1.31. alt_fs_reg()

Prototype

```
int alt_fs_reg (alt_dev* dev)
```

Commonly Called By

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_dev.h>

Description

The `alt_fs_reg()` function registers a file system with the HAL. After it is registered, a file system can be accessed using the standard I/O functions.

For more information, refer to the "Developing Programs Using the Hardware Abstraction Layer" section.

System behavior is undefined in the event that a file system is registered with a name that conflicts with an existing device or file system.

`alt_fs_reg()` is not thread-safe if other threads are using the device list at the time that `alt_fs_reg()` is called. Call `alt_fs_reg()` only in the following circumstances:

- When running in single-threaded mode.
- From a device initialization function called by `alt_sys_init()`.
`alt_sys_init()` may only be called by the single-threaded C startup code.

Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_dev_reg\(\)](#) on page 327

15.1.32. alt_get_flash_info()**Prototype**

```
int alt_get_flash_info(alt_flash_fd* fd,  
flash_region** info,  
int* number_of_regions)
```

Commonly Called By

C/C++ programs

Device drivers



Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_flash.h>

Description

The `alt_get_flash_info()` function gets the details of the erase region of a flash part. The flash part is specified by the descriptor `fd`, a pointer to the start of the `flash_region` structures is returned in the `info` parameter, and the number of flash regions are returned in number of regions.

Call this function only when operating in single-threaded mode.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

The return value is zero upon success. A negative return value indicates failure.

Related Information

- [alt_flash_close_dev\(\)](#) on page 335
- [alt_flash_open_dev\(\)](#) on page 341
- [alt_read_flash\(\)](#) on page 360
- [alt_write_flash\(\)](#) on page 365
- [alt_write_flash_block\(\)](#) on page 366

15.1.33. alt_ic_irq_disable()

Prototype

```
int alt_ic_irq_disable (alt_u32 ic_id, alt_u32 irq)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

<sys/alt_irq.h>

Description

The `alt_ic_irq_disable()` function disables a single interrupt.

The function arguments are as follows:

- `ic_id` is the interrupt controller identifier (ID) as defined in `system.h`, identifying the external interrupt controller in the daisy chain. This argument is ignored if the external interrupt controller interface is not implemented.
- `irq` is the interrupt request (IRQ) number, as defined in `system.h`, identifying the interrupt to enable.
- A driver for an external interrupt controller (EIC) must implement this function.

Return

This function returns zero if successful, or nonzero otherwise. The function fails if the `irq` parameter is greater than the maximum interrupt port number supported by the external interrupt controller.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.34. alt_ic_irq_enabled()

Prototype

```
int alt_ic_irq_enabled (alt_u32 ic_id, alt_u32 irq)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.



Include

`<sys/alt_irq.h>`

Description

This function determines whether a specified interrupt is enabled.

The function arguments are as follows:

- `ic_id` is the interrupt controller ID as defined in `system.h`, identifying the external interrupt controller in the daisy chain. This argument is ignored if the external interrupt controller interface is not implemented.
- `irq` is the IRQ number, as defined in `system.h`, identifying the interrupt to enable.
- A driver for an EIC must implement this function.

Return

Returns zero if the specified interrupt is disabled, and nonzero otherwise.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.35. alt_ic_isr_register()

Prototype

```
int alt_ic_isr_register (alt_u32 ic_id,  
                        alt_u32 irq,  
  
                        alt_isr_func isr,  
                        void* isr_context,  
  
                        void* flags)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

<sys/alt_irq.h>

Description

The `alt_ic_isr_register()` function registers an ISR. If the function is successful, the requested interrupt is enabled on return, and `isr` and `isr_context` are inserted in the vector table.

The function arguments are as follows:

- `ic_id` is the interrupt controller ID as defined in `system.h`, identifying the external interrupt controller in the daisy chain. This argument is ignored if the external interrupt controller interface is not implemented.
- `irq` is the IRQ number, as defined in `system.h`, identifying the interrupt to register.
- `isr` is the function that is called when the interrupt is accepted.
- `isr_context` is the input argument to `isr`. `isr_context` points to a data structure associated with the device driver instance.
- `flags` is reserved.

The ISR function prototype is defined as follows:

```
typedef void (*alt_isr_func) (void* isr_context);
```

Calls to `alt_ic_isr_register()` replace previously registered handlers for interrupt `irq`.

If `isr` is set to null, the interrupt is disabled.

- A driver for an EIC must implement this function.

Return

This function returns zero if successful, or nonzero otherwise. The function fails if the `irq` parameter is greater than the maximum interrupt port number supported by the external interrupt controller.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_irq_cpu_enable_interrupts\(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349



- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.36. alt_ic_irq_enable()

Prototype

```
int alt_ic_irq_enable (alt_u32 ic_id, alt_u32 irq)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_irq.h>
```

Description

The `alt_ic_irq_enable()` function enables a single interrupt.

The function arguments are as follows:

- `ic_id` is the interrupt controller ID as defined in `system.h`, identifying the external interrupt controller in the daisy chain. This argument is ignored if the external interrupt controller interface is not implemented.
- `irq` is the IRQ number, as defined in `system.h`, identifying the interrupt to enable.
- A driver for an EIC must implement this function.

Return

This function returns zero if successful, or nonzero otherwise. The function fails if the `irq` parameter is greater than the maximum interrupt port number supported by the external interrupt controller.

Related Information

- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350

- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.37. alt_instruction_exception_register()

Prototype

```
void alt_instruction_exception_register (  
alt_exception_result (*handler)  
( alt_exception_cause cause,  
alt_u32 exception_pc,  
alt_u32 bad_addr ))
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

Yes.

Include

```
<sys/alt_exceptions.h>
```

Description

The HAL API function `alt_instruction_exception_register()` registers an instruction-related exception handler. The `handler` argument is a pointer to the instruction-related exception handler.

You can only use this API function if you have enabled the `hal.enable_instruction_related_exceptions_api` setting in the board support package (BSP).

For more information, refer to "Settings Managed by the Software Build Tools" in the "Nios II Software Build Tools Reference" chapter.

Register the instruction-related exception handler as early as possible in function `main()`. This allows you to handle abnormal conditions during startup.



You can register an exception handler from the `alt_main()` function.

A call to `alt_instruction_exception_register()` replaces the previously registered exception handler, if any. If `handler` is set to null, the instruction-related exception handler is removed.

For more information about usage, refer to the "Exception Handling" section.

Return

--

Related Information

- [alt_exception_cause_generated_bad_addr\(\)](#) on page 336
- [alt_irq_register\(\)](#) on page 356

15.1.38. alt_irq_disable()

Prototype

```
int alt_irq_disable (alt_u32 id)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<priv/alt_legacy_irq.h>
```

Description

The `alt_irq_disable()` function disables a single interrupt.

This function is part of the legacy HAL interrupt API, which is deprecated. Intel FPGA recommends using the enhanced HAL interrupt API.

For more information about using the enhanced HAL interrupt API, refer to "Nios II Interrupt Service Routines" in the "Exception Handling" chapter.

Return

The return value is zero.

Related Information

- [Nios II Interrupt Service Routines](#) on page 250
- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344

- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.39. alt_irq_cpu_enable_interrupts ()

Prototype

```
void alt_irq_cpu_enable_interrupts ()
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_irq.h>
```

Description

The `alt_irq_cpu_enable_interrupts ()` function enables the CPU to start taking interrupts.

Return

--

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353



- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.40. alt_irq_disable_all()

Prototype

```
alt_irq_context alt_irq_disable_all (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<sys/alt_irq.h>
```

Description

The `alt_irq_disable_all()` function disables all maskable interrupts. Nonmaskable interrupts (NMIs) are unaffected.

Return

Pass the return value as the input argument to a subsequent call to `alt_irq_enable_all()`.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.41. alt_irq_enable()

Prototype

```
int alt_irq_enable (alt_u32 id)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<priv/alt_legacy_irq.h>
```

Description

The `alt_irq_enable()` function enables a single interrupt.

This function is part of the legacy HAL interrupt API, which is deprecated. Intel FPGA recommends using the enhanced HAL interrupt API.

Return

The return value is zero.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.42. alt_irq_enable_all()

Prototype

```
void alt_irq_enable_all (alt_irq_context context)
```




Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

<sys/alt_irq.h>

Description

The `alt_irq_enable_all()` function enables all interrupts that were previously disabled by `alt_irq_disable_all()`. The input argument, `context`, is the value returned by a previous call to `alt_irq_disable_all()`. Using `context` allows nested calls to `alt_irq_disable_all()` and `alt_irq_enable_all()`. As a result, `alt_irq_enable_all()` does not necessarily enable all interrupts, such as interrupts explicitly disabled by `alt_irq_disable()`.

Return

--

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.43. alt_irq_enabled()

Prototype

```
int alt_irq_enabled (void)
```

Commonly Called By

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_irq.h>
```

Description

Determines whether maskable exceptions (`status.PIE`) are enabled.

For more information about using the enhanced HAL interrupt API, refer to "Nios II Interrupt Service Routines" in the "Exception Handling" chapter.

Return

Returns zero if interrupts are disabled, and non-zero otherwise.

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.44. alt_irq_init()

Prototype

```
void alt_irq_init (void* base)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.



Include

<sys/alt_irq.h>

Description

The `alt_irq_init ()` function calls the initialization macros for all interrupt controllers in the system at config time, before any other non-interrupt controller driver is initialized. The "base" parameter is ignored and only present for backwards-compatibility. It is recommended that NULL is passed in for the "base" parameter.

Return

--

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_pending \(\)](#) on page 355
- [alt_irq_register\(\)](#) on page 356

15.1.45. alt_irq_pending ()

Prototype

```
void alt_irq_pending (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

<sys/alt_irq.h>

Description

The `alt_irq_pending()` function returns a bit list of the current pending interrupts. This is used by `alt_irq_handler()` to determine which registered interrupt handlers should be called. This routine is only available for the Nios II internal interrupt controller.

Return

--

Related Information

- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts\(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_register\(\)](#) on page 356

15.1.46. alt_irq_register()

Prototype

```
int alt_irq_register (alt_u32 id,  
  
void* context,  
void (*isr)(void*, alt_u32))
```

Commonly Called By

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<priv/alt_legacy_irq.h>
```



Description

The `alt_irq_register()` function registers an ISR. If the function is successful, the requested interrupt is enabled on return.

The input argument `id` is the interrupt to enable. `isr` is the function that is called when the interrupt is active. `context` and `id` are the two input arguments to `isr`.

Calls to `alt_irq_register()` replace previously registered handlers for interrupt `id`.

If `irq_handler` is set to null, the interrupt is disabled.

1 This function is part of the legacy HAL interrupt API, which is deprecated. Intel recommends using the enhanced HAL interrupt API.

For more information about using the enhanced HAL interrupt API, refer to "Nios II Interrupt Service Routines" in the "Exception Handling" section.

Return

The `alt_irq_register()` function returns zero if successful, or non-zero otherwise.

Related Information

- [Nios II Interrupt Service Routines](#) on page 250
- [alt_ic_irq_enable\(\)](#) on page 347
- [alt_ic_irq_enabled\(\)](#) on page 344
- [alt_ic_isr_register\(\)](#) on page 345
- [alt_irq_cpu_enable_interrupts \(\)](#) on page 350
- [alt_irq_disable\(\)](#) on page 349
- [alt_irq_disable_all\(\)](#) on page 351
- [alt_irq_enable\(\)](#) on page 352
- [alt_irq_enable_all\(\)](#) on page 352
- [alt_irq_enabled\(\)](#) on page 353
- [alt_irq_init\(\)](#) on page 354
- [alt_irq_pending \(\)](#) on page 355

15.1.47. alt_llist_insert()

Prototype

```
void alt_llist_insert(alt_llist* list,  
alt_llist* entry)
```

Commonly Called By

C/C++ programs

Device drivers



Thread-safe

No.

Available from ISR

Yes.

Include

<sys/alt_llist.h>

Description

The `alt_llist_insert()` function inserts the doubly linked list entry `entry` in the list `list`. This operation is not reentrant. For example, if a list can be manipulated from different threads, or from within both application code and an ISR, some mechanism is required to protect access to the list. Interrupts can be locked, or in MicroC/OS-II, a `mutex` can be used.

Return

--

Related Information

[alt_llist_remove\(\)](#) on page 358

15.1.48. alt_llist_remove()

Prototype

```
void alt_llist_remove(alt_llist* entry)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

Yes.

Include

<sys/alt_llist.h>

Description

The `alt_llist_remove()` function removes the doubly linked list entry `entry` from the list it is currently a member of. This operation is not reentrant. For example if a list can be manipulated from different threads, or from within both application code and an ISR, some mechanism is required to protect access to the list. Interrupts can be locked, or in MicroC/OS-II, a `mutex` can be used.

Return

--



Related Information

[alt_llist_insert\(\)](#) on page 357

15.1.49. alt_load_section()

Prototype

```
void alt_load_section(alt_u32* from,  
alt_u32* to,  
alt_u32* end)
```

Commonly Called By

C/C++ programs

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_load.h>
```

Description

When operating in run-from-flash mode, the sections `.exceptions`, `.rodata`, and `.rwdata` are automatically loaded from the boot device to RAM at boot time. However, if there are any additional sections that require loading, the `alt_load_section()` function loads them manually before these sections are used.

It is recommended to call below the macro `ALT_LOAD_SECTION_BY_NAME` and before `alt_dcache_flush_all()` and `alt_icache_flush_all()`.

The input argument `from` is the start address in the boot device of the section; `to` is the start address in RAM of the section, and `end` is the end address in RAM of the section.

To load one of the additional memory sections provided by the default linker script, use the macro `ALT_LOAD_SECTION_BY_NAME` rather than calling `alt_load_section()` directly. For example, to load the section `.onchip_ram`, use the following code:

```
ALT_LOAD_SECTION_BY_NAME(onchip_ram);
```

The leading `'.'` is omitted in the section name. This macro is defined in the header `sys/alt_load.h`.

Return

--

15.1.50. alt_nticks()

Prototype

```
alt_u32 alt_nticks (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_alarm.h>
```

Description

The `alt_nticks()` function.

Return

Returns the number of elapsed system clock tick since reset. It returns zero if there is no system clock available.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.51. alt_read_flash()

Prototype

```
int alt_read_flash(alt_flash_fd* fd,  
int offset,  
void* dest_addr,  
int length)
```




Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_flash.h>

Description

The `alt_read_flash()` function reads data from flash. `length` bytes are read from the flash `fd`, starting `offset` bytes from the beginning of the flash and are written to the location `dest_addr`.

Call this function only when operating in single-threaded mode.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [alt_flash_close_dev\(\)](#) on page 335
- [alt_flash_open_dev\(\)](#) on page 341
- [alt_get_flash_info\(\)](#) on page 342
- [alt_write_flash\(\)](#) on page 365
- [alt_write_flash_block\(\)](#) on page 366

15.1.52. alt_tick()

Prototype

```
void alt_tick (void)
```

Commonly Called By

Device drivers

Thread-safe

No.

Available from ISR

Yes.

Include

```
<sys/alt_alarm.h>
```

Description

Only the system clock driver may call the `alt_tick()` function. The driver is responsible for making periodic calls to this function at the rate specified in the call to `alt_sysclk_init()`. This function provides notification to the system that a system clock tick has occurred. This function runs as a part of the ISR for the system clock driver.

Return

--

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.53. alt_ticks_per_second()

Prototype

```
alt_u32 alt_ticks_per_second (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/alt_alarm.h>
```

Description

The `alt_ticks_per_second()` function returns the number of system clock ticks that elapse per second. If there is no system clock available, the return value is zero.



Return

Returns the number of system clock ticks that elapse per second.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.54. alt_timestamp()

Prototype

```
alt_u32 alt_timestamp (void)
```

Commonly Called By

C/C++ programs

Thread-safe

See description.

Available from ISR

See description.

Include

```
<sys/alt_timestamp.h>
```

Description

The `alt_timestamp()` function returns the current value of the timestamp counter.

For more information, refer to "Using Timer Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

The implementation of this function is provided by the timestamp driver. Therefore, whether this function is thread-safe and or available at interrupt level depends on the underlying driver.

Always call the `alt_timestamp_start()` function before any calls to `alt_timestamp()`. Otherwise the behavior of `alt_timestamp()` is undefined.

Return

Returns the current value of the timestamp counter.

Related Information

- [alt_timestamp_freq\(\)](#) on page 364
- [alt_timestamp_start\(\)](#) on page 364

15.1.55. alt_timestamp_freq()

Prototype

```
alt_u32 alt_timestamp_freq (void)
```

Commonly Called By

C/C++ programs

Thread-safe

See description.

Available from ISR

See description.

Include

```
<sys/alt_timestamp.h>
```

Description

The `alt_timestamp_freq()` function returns the rate at which the timestamp counter increments.

For more information, refer to "Using Timer Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

The implementation of this function is provided by the timestamp driver. Therefore, whether this function is thread-safe and or available at interrupt level depends on the underlying driver.

Return

The returned value is the number of counter ticks per second.

Related Information

- [alt_timestamp\(\)](#) on page 363
- [alt_timestamp_start\(\)](#) on page 364

15.1.56. alt_timestamp_start()

Prototype

```
int alt_timestamp_start (void)
```

Commonly Called By

C/C++ programs

Thread-safe

See description.



Available from ISR

See description.

Include

<sys/alt_timestamp.h>

Description

The `alt_timestamp_start()` function starts the system timestamp counter.

For more information, refer to "Using Timer Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

The implementation of this function is provided by the timestamp driver. Therefore, whether this function is thread-safe and or available at interrupt level depends on the underlying driver.

This function resets the counter to zero, and starts the counter running.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [alt_timestamp\(\)](#) on page 363
- [alt_timestamp_freq\(\)](#) on page 364

15.1.57. alt_write_flash()

Prototype

```
int alt_write_flash(alt_flash_fd* fd,  
  
int offset,  
  
const void* src_addr,  
  
int length)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

<sys/alt_flash.h>

Description

The `alt_write_flash()` function writes data to flash. The data to be written is at address `src_addr`. `length` bytes are written to the flash `fd`, `offset` bytes from the beginning of the flash device address space.

Call this function only when operating in single-threaded mode. This function does not preserve any unwritten areas of any flash sectors affected by this write.

For more information, refer to "Using Flash Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_flash_close_dev\(\)](#) on page 335
- [alt_flash_open_dev\(\)](#) on page 341
- [alt_get_flash_info\(\)](#) on page 342
- [alt_read_flash\(\)](#) on page 360
- [alt_write_flash_block\(\)](#) on page 366

15.1.58. alt_write_flash_block()

Prototype

```
int alt_write_flash_block(alt_flash_fd* fd,  
int block_offset,  
int data_offset,  
  
const void *data,  
int length)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.



Include

<sys/alt_flash.h>

Description

The `alt_write_flash_block()` function writes one block of data of flash. The data to be written is at address `data`. `length` bytes are written to the flash `fd`, into the block starting at offset `block_offset` from the beginning of the flash address space. The data starts at offset `data_offset` from the beginning of the flash address space.

No check is performed on any of the parameters.

For more information, refer to "Using Flash Devices" in the "Developing Programs Using the Hardware Abstraction Layer" chapter.

Call this function only when operating in single-threaded mode.

The only valid values for the `fd` parameter are those returned from the `alt_flash_open_dev` function. If any other value is passed, the behavior of this function is undefined.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [Developing Programs Using the Hardware Abstraction Layer](#) on page 158
- [alt_flash_close_dev\(\)](#) on page 335
- [alt_flash_open_dev\(\)](#) on page 341
- [alt_get_flash_info\(\)](#) on page 342
- [alt_read_flash\(\)](#) on page 360
- [alt_write_flash\(\)](#) on page 365

15.1.59. close()

Prototype

```
int close (int fd)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

<unistd.h>

Description

The `close()` function is the standard UNIX-style `close()` function, which closes the file descriptor `fd`.

Calls to `close()` are thread-safe only if the implementation of `close()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.

Return

The return value is zero on success, and `-1` otherwise. If an error occurs, `errno` is set to indicate the cause.

Related Information

[newlib Library Documentation](#)

15.1.60. fstat()**Prototype**

```
int fstat (int fd, struct stat *st)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<sys/stat.h>
```

Description

The `fstat()` function obtains information about the capabilities of an open file descriptor. The underlying device driver fills in the input `st` structure with a description of its functionality. Refer to the header file `sys/stat.h` provided with the compiler for the available options.

By default, file descriptors are marked as character devices, unless the underlying driver provides its own implementation of the `fstat()` function.

Calls to `fstat()` are thread-safe only if the implementation of `fstat()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.



Return

The return value is zero on success, or -1 otherwise. If the call fails, `errno` is set to indicate the cause of the error.

Related Information

- [fcntl\(\)](#) on page 369
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.61. fork()

Prototype

```
pid_t fork (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The `fork()` function is only provided for compatibility with newlib.

Return

Calls to `fork()` always fails with the return code -1 and `errno` set to `ENOSYS`.

Related Information

[newlib Library Documentation](#)

15.1.62. fcntl()

Prototype

```
int fcntl(int fd, int cmd)
```

Commonly Called By

C/C++ programs

Thread-safe

No.

Available from ISR

No.

Include

```
<unistd.h>  
<fcntl.h>
```

Description

The `fcntl()` function is a limited implementation of the standard `fcntl()` system call, which can change the state of the flags associated with an open file descriptor. Normally these flags are set during the call to `open()`. The main use of this function is to change the state of a device from blocking to nonblocking (for device drivers that support this feature).

The input argument `fd` is the file descriptor to be manipulated. `cmd` is the command to execute, which can be either `F_GETFL` (return the current value of the flags) or `F_SETFL` (set the value of the flags).

Return

If `cmd` is `F_SETFL`, the argument `arg` is the new value of flags, otherwise `arg` is ignored. Only the flags `O_APPEND` and `O_NONBLOCK` can be updated by a call to `fcntl()`. All other flags remain unchanged. The return value is zero on success, or `-1` otherwise.

If `cmd` is `F_GETFL`, the return value is the current value of the flags. If an error occurs, `-1` is returned.

In the event of an error, `errno` is set to indicate the cause.

Related Information

- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)



15.1.63. `execve()`

Prototype

```
int execve(const char *path,  
char *const argv[],  
char *const envp[])
```

Commonly Called By

C/C++ programs

Thread-safe

Yes.

Available from ISR

Yes.

Include

<unistd.h>

Description

The `execve()` function is only provided for compatibility with newlib.

Return

Calls to `execve()` always fail with the return code `-1` and `errno` set to `ENOSYS`.

Related Information

[newlib Library Documentation](#)

15.1.64. `getpid()`

Prototype

```
pid_t getpid (void)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

<unistd.h>

Description

The `getpid()` function is provided for newlib compatibility and obtains the current process ID.

Return

Because HAL systems cannot contain multiple processes, `getpid()` always returns the same ID number.

Related Information

[newlib Library Documentation](#)

15.1.65. kill()**Prototype**

```
int kill(int pid, int sig)
```

Commonly Called By

newlib C library

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<signal.h>
```

Description

The `kill()` function is used by newlib to send signals to processes. The input argument `pid` is the ID of the process to signal, and `sig` is the signal to send. As there is only a single process in the HAL, the only valid values for `pid` are either the current process ID, as returned by `getpid()`, or the broadcast values, that is, `pid` must be less than or equal to zero.

The following signals result in an immediate shutdown of the system, without call to `exit()`: `SIGABRT`, `SIGALRM`, `SIGFPE`, `SIGILL`, `SIGKILL`, `SIGPIPE`, `SIGQUIT`, `SIGSEGV`, `SIGTERM`, `SIGUSR1`, `SIGUSR2`, `SIGBUS`, `SIGPOLL`, `SIGPROF`, `SIGSYS`, `SIGTRAP`, `SIGVTALRM`, `SIGXCPU`, and `SIGXFSZ`.

The following signals are ignored: `SIGCHLD` and `SIGURG`.

All the remaining signals are treated as errors.

Return

The return value is zero on success, or `-1` otherwise. If the call fails, `errno` is set to indicate the cause of the error.

Related Information

[newlib Library Documentation](#)



15.1.66. stat()

Prototype

```
int stat(const char *file_name,  
struct stat *buf);
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

<sys/stat.h>

Description

The `stat()` function is similar to the `fstat()` function—It obtains status information about a file. Instead of using an open file descriptor, like `fstat()`, `stat()` takes the name of a file as an input argument.

Calls to `stat()` are thread-safe only if the implementation of `stat()` provided by the driver that is manipulated is thread-safe.

Internally, the `stat()` function is implemented as a call to `fstat()`.

Return

--

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.67. settimeofday()

Prototype

```
int settimeofday (const struct timeval *t,  
const struct timezone *tz)
```

Commonly Called By

C/C++ programs

Thread-safe

No.

Available from ISR

Yes.

Include

```
<sys/time.h>
```

Description

If the `settimeofday()` function is called concurrently with a call to `gettimeofday()`, the value returned by `gettimeofday()` is unreliable.

Return

The return value is zero on success. If no system clock is available, the return value is -1, and `errno` is set to `ENOSYS`.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.68. wait()

Prototype

```
int wait(int *status)
```

Commonly Called By

newlib C library



Thread-safe

Yes.

Available from ISR

Yes.

Include

`<sys/wait.h>`

Description

`newlib` uses the `wait()` function to wait for all child processes to exit. Because the HAL does not support spawning child processes, this function returns immediately.

Return

On return, the content of `status` is set to zero, which indicates there is no child processes.

The return value is always `-1` and `errno` is set to `ECHILD`, which indicates that there are no child processes to wait for.

Related Information

[newlib Library Documentation](#)

15.1.69. `unlink()`

Prototype

```
int unlink(char *name)
```

Commonly Called By

`newlib` C library

Thread-safe

Yes.

Available from ISR

Yes.

Include

`<unistd.h>`

Description

The `unlink()` function is only provided for compatibility with `newlib`.

Return

Calls to `unlink()` always fails with the return code `-1` and `errno` set to `ENOSYS`.

Related Information

[newlib Library Documentation](#)

15.1.70. sbrk()

Prototype

```
caddr_t sbrk(int incr)
```

Commonly Called By

newlib C library

Thread-safe

No.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The `sbrk()` function dynamically extends the data segment for the application. The input argument `incr` is the size of the block to allocate. Do not call `sbrk()` directly. If you wish to dynamically allocate memory, use the newlib `malloc()` function.

Return

--

Related Information

[newlib Library Documentation](#)

15.1.71. link()

Prototype

```
int link(const char *_path1,  
const char *_path2)
```

Commonly Called By

newlib C library

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<unistd.h>
```

Description

The `link()` function is only provided for compatibility with newlib.



Return

Calls to `link()` always fails with the return code `-1` and `errno` set to `ENOSYS`.

Related Information

[newlib Library Documentation](#)

15.1.72. lseek()

Prototype

```
off_t lseek(int fd, off_t ptr, int whence)
```

Commonly Called By

C/C++ programs

newlib C library

Thread-safe

See description.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The `lseek()` function moves the read/write pointer associated with the file descriptor `fd`. `lseek()` is wrapper function that passes control directly to the `lseek()` function registered for the driver associated with the file descriptor. If the driver does not provide an implementation of `lseek()`, an error is reported.

`lseek()` corresponds to the standard UNIX `lseek()` function.

You can use the following values for the input parameter, `whence`:

- `SEEK_SET`—The offset is set to `ptr` bytes.
- `SEEK_CUR`—The offset is incremented by `ptr` bytes.
- `SEEK_END`—The offset is set to the end of the file plus `ptr` bytes.

Calls to `lseek()` are thread-safe only if the implementation of `lseek()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.

Return

On success, the return value is a nonnegative file pointer. The return value is `-1` in the event of an error. If the call fails, `errno` is set to indicate the cause of the error.

Related Information

- `fcntl()` on page 369

- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.73. [alt_sysclk_init\(\)](#)

Prototype

```
int alt_sysclk_init (alt_u32 nticks)
```

Commonly Called By

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_alarm.h>
```

Description

The `alt_sysclk_init()` function registers the presence of a system clock driver. The input argument is the number of ticks per second at which the system clock is run.

The expectation is that this function is only called from within `alt_sys_init()`, that is, while the system is running in single-threaded mode. Concurrent calls to this function might lead to unpredictable results.

Return

This function returns zero on success; otherwise it returns a negative value. The call can fail if a system clock driver is already registered, or if no system clock device is available.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362



- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383

15.1.74. open()

Prototype

```
int open (const char* pathname, int flags, mode_t mode)
```

Commonly Called By

C/C++ programs

Thread-safe

See description.

Available from ISR

No.

Include

```
<unistd.h>  
<fcntl.h>
```

Description

The `open()` function opens a file or device and returns a file descriptor (a small, nonnegative integer for use in read, write, etc.)

`flags` is one of: `O_RDONLY`, `O_WRONLY`, or `O_RDWR`, which request opening the file in read-only, write-only, or read/write mode, respectively.

You can also bitwise-OR `flags` with `O_NONBLOCK`, which causes the file to be opened in nonblocking mode. Neither `open()` nor any subsequent operation on the returned file descriptor causes the calling process to wait.

Not all file systems/devices recognize this option.

`mode` specifies the permissions to use, if a new file is created. It is unused by current file systems, but is maintained for compatibility.

Calls to `open()` are thread-safe only if the implementation of `open()` provided by the driver that is manipulated is thread-safe.

Return

The return value is the new file descriptor, and `-1` otherwise. If an error occurs, `errno` is set to indicate the cause.

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386

- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.75. times()

Prototype

```
clock_t times (struct tms *buf)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

Yes.

Include

```
<sys/times.h>
```

Description

This `times()` function is provided for compatibility with newlib. It returns the number of clock ticks since reset. It also fills in the structure pointed to by the input parameter `buf` with time accounting information. The definition of the `tms` structure is:

```
typedef struct
{
    clock_t tms_utime;
    clock_t tms_stime;
    clock_t tms_cutime;
    clock_t tms_cstime;
};
```



The structure has the following elements:

- `tms_untime`: the processor time charged for the execution of user instructions
- `tms_stime`: the processor time charged for execution by the system on behalf of the process
- `tms_cutime`: the sum of the values of `tms_untime` and `tms_cutime` for all child processes
- `tms_cstime`: the sum of the values of `tms_stime` and `tms_cstime` for all child processes

In practice, all elapsed time is accounted as system time. No time is ever attributed as user time. In addition, no time is allocated to child processes, as child processes cannot be spawned by the HAL.

Return

If there is no system clock available, the return value is zero, and `errno` is set to `ENOSYS`.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [usleep\(\)](#) on page 383
- [newlib Library Documentation](#)

15.1.76. read()

Prototype

```
int read(int fd, void *ptr, size_t len)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The `read()` function reads a block of data from a file or device. `read()` is wrapper function that passes control directly to the `read()` function registered for the device driver associated with the open file descriptor `fd`. The input argument, `ptr`, is the location to place the data read and `len` is the length of the data to read in bytes.

Calls to `read()` are thread-safe only if the implementation of `read()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.

Return

The return argument is the number of bytes read, which might be less than the requested length

The return value is `-1` upon an error. In the event of an error, `errno` is set to indicate the cause.

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.77. write()

Prototype

```
int write(int fd, const void *ptr, size_t len)
```

Commonly Called By

C/C++ programs

newlib C library

Thread-safe

See description.

Available from ISR

No.

Include

```
<unistd.h>
```



Description

The `write()` function writes a block of data to a file or device. `write()` is wrapper function that passes control directly to the `write()` function registered for the device driver associated with the file descriptor `fd`. The input argument `ptr` is the data to write and `len` is the length of the data in bytes.

Calls to `write()` are thread-safe only if the implementation of `write()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.

Return

The return argument is the number of bytes written, which might be less than the requested length.

The return value is `-1` upon an error. In the event of an error, `errno` is set to indicate the cause.

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [newlib Library Documentation](#)

15.1.78. `usleep()`

Prototype

```
int usleep (unsigned int us)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

Yes.

Available from ISR

No.

Include

```
<unistd.h>
```

Description

The `usleep()` function blocks until at least `us` microseconds have elapsed.

Return

The `usleep()` function returns zero on success, or `-1` otherwise. If an error occurs, `errno` is set to indicate the cause. The current implementation always succeeds.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_ticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [gettimeofday\(\)](#) on page 385
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380

15.1.79. alt_lock_flash()

Prototype

```
int alt_lock_flash(alt_flash_dev * flash_info,  
alt_u32 sectors_to_lock)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_flash.h>
```




Description

Locking to range of the flash memory sectors, which protected from writing and erasing by passing the uninteger 32 bits value to the `sectors_to_lock` argument, where this argument depends on the specific flash device being used, and this argument value can be found in the flash device datasheet. The flash devices can be supported are shown as below:

EPCQ16, EPCQ32, EPCQ64, EPCQ128, EPCQ256, N25Q512, EPCQ512,
EPCQL512, EPCQL1024

More Micron flash devices are supported in future, and being updated into this document.

Arguments

- `*flash_info`: Pointer to general flash device structure.
- `sectors_to_lock`: Block protection bits, including the top/bottom (TB) bit in the EPCQ or QSPI, according to the device. For example, in the EPCQ128 device, the bits are Bit4=TB Bit3=BP3 Bit2=BP2 Bit1=BP1 Bit0=BP0.

Return

- ***0 > Success**
- **-EINVL > Invalid arguments**
- **-ETIME > Time out and skipping the looping after 0.7 sec**
- **-ENOLCK > Sectors lock failed**

15.1.80. `gettimeofday()`

Prototype

```
int gettimeofday(struct timeval *ptimeval,  
struct timezone *ptimezone)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

Yes.

Include

<sys/time.h>

Description

The `gettimeofday()` function obtains a time structure that indicates the current time. This time is calculated using the elapsed number of system clock ticks, and the current time value set by the most recent call to `settimeofday()`.

If this function is called concurrently with a call to `settimeofday()`, the value returned by `gettimeofday()` is unreliable; however, concurrent calls to `gettimeofday()` are legal.

Return

The return value is zero on success. If no system clock is available, the return value is `-ENOTSUP`.

Related Information

- [alt_alarm_start\(\)](#) on page 323
- [alt_alarm_stop\(\)](#) on page 325
- [alt_nticks\(\)](#) on page 360
- [alt_sysclk_init\(\)](#) on page 378
- [alt_tick\(\)](#) on page 361
- [alt_ticks_per_second\(\)](#) on page 362
- [settimeofday\(\)](#) on page 374
- [times\(\)](#) on page 380
- [usleep\(\)](#) on page 383
- [newlib Library Documentation](#)

15.1.81. ioctl()

Prototype

```
int ioctl (int fd, int req, void* arg)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<sys/ioctl.h>
```



Description

The `ioctl()` function allows application code to manipulate the I/O capabilities of a device driver in driver-specific ways. This function is equivalent to the standard UNIX `ioctl()` function. The input argument `fd` is an open file descriptor for the device to manipulate, `req` is an enumeration defining the operation request, and the interpretation of `arg` is request specific.

For file subsystems, `ioctl()` is wrapper function that passes control directly to the appropriate device driver's `ioctl()` function (as registered in the driver's `alt_dev` structure).

For devices, `ioctl()` handles `TIOCEXCL` and `TIOCNXCL` requests internally, without calling the device driver. These requests lock and release a device for exclusive access. For requests other than `TIOCEXCL` and `TIOCNXCL`, `ioctl()` passes control to the device driver's `ioctl()` function.

Calls to `ioctl()` are thread-safe only if the implementation of `ioctl()` provided by the driver that is manipulated is thread-safe.

Valid values for the `fd` parameter are: `stdout`, `stdin`, and `stderr`, or any value returned from a call to `open()`.

Return

The interpretation of the return value is request specific. If the call fails, `errno` is set to indicate the cause of the error.

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [isatty\(\)](#) on page 387
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.1.82. isatty()

Prototype

```
int isatty(int fd)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.



Available from ISR

No.

Include

<unistd.h>

Description

The `isatty()` function determines whether the device associated with the open file descriptor `fd` is a terminal device. This implementation uses the driver's `fstat()` function to determine its reply.

Calls to `isatty()` are thread-safe only if the implementation of `fstat()` provided by the driver that is manipulated is thread-safe.

Return

The return value is 1 if the device is a character device, and zero otherwise. If an error occurs, `errno` is set to indicate the cause.

Related Information

- [fcntl\(\)](#) on page 369
- [fstat\(\)](#) on page 368
- [ioctl\(\)](#) on page 386
- [lseek\(\)](#) on page 377
- [open\(\)](#) on page 379
- [read\(\)](#) on page 381
- [stat\(\)](#) on page 373
- [write\(\)](#) on page 382
- [newlib Library Documentation](#)

15.2. HAL Standard Types

In the interest of portability, the HAL uses a set of standard type definitions in place of the ANSI C built-in types. The Table below describes these types, which are defined in the header file `alt_types.h`.

Table 62. HAL Standard Types

Type	Description
<code>alt_8</code>	Signed 8-bit integer.
<code>alt_u8</code>	Unsigned 8-bit integer.
<code>alt_16</code>	Signed 16-bit integer.
<code>alt_u16</code>	Unsigned 16-bit integer.
<code>alt_32</code>	Signed 32-bit integer.
<code>alt_u32</code>	Unsigned 32-bit integer.
<code>alt_64</code>	Signed 64-bit integer.
<code>alt_u64</code>	Unsigned 64-bit integer.



15.2.1. alt_getchar()

Prototype

alt_getchar()

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<sys/alt_driver.h>  
<sys/alt_stdio.h>  
<priv/alt_file.h>  
<unistd.h>
```

Description

The alt_getchar() function uses the ALT_DRIVER_READ() macro to call directly to the driver, if available; otherwise, it uses the newlib provided getchar() routine.

Return

--

Related Information

- [alt_putchar\(\)](#) on page 390
- [alt_putstr\(\)](#) on page 389
- [alt_printf\(\)](#) on page 391
- [newlib Library Documentation](#)

15.2.2. alt_putstr()

Prototype

alt_putstr(const char* str)

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<sys/alt_driver.h>  
<sys/alt_stdio.h>
```

Description

The `alt_putstr()` function uses the `ALT_DRIVER_WRITE()` macro to call directly to the driver, if available; otherwise, it uses the newlib provided `fputs()` routine.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [alt_putchar\(\)](#) on page 390
- [alt_getchar\(\)](#) on page 389
- [alt_printf\(\)](#) on page 391
- [newlib Library Documentation](#)

15.2.3. alt_putchar()

Prototype

```
alt_putchar(int c)
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

See description.

Available from ISR

No.

Include

```
<sys/alt_driver.h>  
<sys/alt_stdio.h>
```

Description

The `alt_putchar()` function uses the `ALT_DRIVER_WRITE()` macro to call directly to the driver, if available; otherwise, it uses the newlib provided `putchar()` routine.

Return

The return value is zero on success and nonzero otherwise.

Related Information

- [alt_putstr\(\)](#) on page 389
- [alt_getchar\(\)](#) on page 389
- [alt_printf\(\)](#) on page 391



- [newlib Library Documentation](#)

15.2.4. alt_printf()

Prototype

```
alt_printf(const char* fmt, ... )
```

Commonly Called By

C/C++ programs

Device drivers

Thread-safe

No.

Available from ISR

No.

Include

```
<sys/alt_stdio.h>
```

Description

The `alt_printf()` function provides a very minimal `printf` implementation for use with very small applications. Only the following format strings are supported: `%x`, `%s`, `%c`, and `%%`.

Return

--

Related Information

- [alt_putchar\(\)](#) on page 390
- [alt_putstr\(\)](#) on page 389
- [alt_getchar\(\)](#) on page 389

15.3. ADC HAL Device Driver

The Intel FPGA Modular ADC IP core provides a HAL device driver. You can integrate the device driver into the HAL system library for Nios II systems.

15.3.1. adc_stop

Prototype

```
void adc_stop(int sequencer_base)
```

Arguments

`sequencer_base`: Sequencer base value.

Description

This function writes 0 to the sequencer CMD register RUN bit; and then it polls the RUN bit until it is 0.

Return

—

15.3.2. adc_start**Prototype**

```
void adc_start(int sequencer_base)
```

Arguments

sequencer_base: Sequencer base value.

Description

This function sets the sequencer CMD register RUN bit.

Return

—

15.3.3. adc_set_mode_run_once**Prototype**

```
void adc_set_mode_run_once(int sequencer_base)
```

Arguments

sequencer_base: Sequencer base value.

Description

This function sets the sequencer CMD register MODE bits to once.

Note: Stop the ADC before calling this function, changing ADC mode while RUN bit is set has no effect.

Return

—

15.3.4. adc_set_mode_run_continuously**Prototype**

```
void adc_set_mode_run_continuously(int sequencer_base)
```

Arguments

sequencer_base: Sequencer base value.



Description

This function sets the sequencer CMD register MODE bits to continuous.

Note: Stop the ADC before calling this function, changing ADC mode while RUN bit is set has no effect.

Return

—

15.3.5. adc_recalibrate

Prototype

```
void adc_recalibrate(int sequencer_base)
```

Arguments

sequencer_base: Sequencer base value.

Description

- Backup CMD register, because some values can be overwritten.
- Stop the ADC Sequencer Core.
- Set the recalibration request bits.
- Start the ADC Sequencer Core.
- Poll for RUN bit to be clear.
- Restore CMD register

Return

—

15.3.6. adc_interrupt_enable

Prototype

```
void adc_interrupt_enable(int )
```

Arguments

sample_store_base: Base address of sample store core.

Description

This function sets the IRQ enable bit in the ADC Sample Storage IRQ register.

Return

—

15.3.7. `adc_interrupt_disable`

Prototype

```
void adc_interrupt_disable(int sample_store_base)
```

Arguments

`sample_store_base`: Base address of sample store core.

Description

This function clears the IRQ enable bit in the ADC Sample Storage IRQ register.

Return

—

15.3.8. `adc_clear_interrupt_status`

Prototype

```
void adc_clear_interrupt_status(int sample_store_base)
```

Arguments

`sample_store_base`: Base address of sample store core.

Description

This function clears the W1C bits in the ADC sample Storage Status register.

Return

—

15.3.9. `adc_wait_for_interrupt` - ADC Sample Storage Status Register

Prototype

```
void adc_wait_for_interrupt(int sample_store_base)
```

Arguments

`sample_store_base`: Base address of sample store core.

Description

This function waits while the ADC sample storage status register is 0.

Return

—



15.3.10. adc_interrupt_asserted

Prototype

```
int adc_interrupt_asserted(int sample_store_base)
```

Arguments

sample_store_base: Base address of sample store core.

Description

This function reads the sample storage irq status register.

Return

-1 if 1, else returns 0

15.3.11. adc_wait_for interrupt - IRQ Status Register

Prototype

```
void adc_wait_for_interrupt(int sample_store_base)
```

Arguments

sample_store_base: Base address of sample store core.

Description

This function waits while the sample storage IRQ status register is 0.

Return

—

15.3.12. alt_adc_word_read

Prototype

```
int alt_adc_word_read (alt_u32 sample_store_base, alt_u32*  
dest_ptr, alt_u32 len)
```

Arguments


- sample_store_base: Base address of sample store core.
- *dest_ptr: destination buffer
- len: number of 32-bit reads

Description

Reads words from the sample store

Return

—



16. Nios II Software Build Tools Reference

This chapter provides a complete reference of all available commands, options, and settings for the Nios II Software Build Tools (SBT). This reference is useful for developing your own embedded software projects, packages, or device drivers.

Related Information

- [Getting Started from the Command Line](#) on page 73
For more information about what you should read before using this chapter.
- [Nios II Software Build Tools](#) on page 87
For more information about familiarizing yourself with its parts.
- [Nios II Software Build Tools Reference Revision History](#) on page 17
For details on the document revision history of this chapter

16.1. Nios II Software Build Tools Utilities

The build tools utilities are an entry point to the Nios II SBT. Everything you can do with the tools, such as specifying settings, creating makefiles, and building projects, is made available by the utilities.

All Nios II SBT utilities share the following behavior:

- Sends error messages and warning messages to `stderr`.
- Sends normal messages (other than errors and warnings) to `stdout`.
- Displays one error message for each error.
- Returns an exit value of 1 if it detects any errors.
- Returns an exit value of 0 if it does not detect any errors. (Warnings are not errors.)
- If the `help` or `version` command-line option is specified, returns an exit value of 0, and takes no other action. Sends the output (help or version number) to `stdout`.
- When an error is detected, suppresses all subsequent operations (such as writing files).

16.1.1. Logging Levels

All the utilities support multiple status-logging levels. You specify the logging level on the command line. At each level, the utilities report the status as listed under **Description**. Each level includes the messages from all lower levels.

**Table 63. Nios II SBT Logging Levels**

Logging Level	Description
silent (lowest)	No information is provided except for errors and warnings (sent to <code>stderr</code>).
default	Minimal information is provided (for example, start and stop operation of SBT phases).
verbose	Detailed information is provided (for example, lists of files written).
debug (highest)	Debug information is provided (for example, stack backtraces on errors). This level is for reporting problems.

Only one logging level is possible at a time, so these options are all mutually exclusive.

Table 64. Command-Line Options to Select Each Logging Level

Command-Line Option	Logging Level	Comments
none	default	If there is no command-line option, the default level is selected.
<code>--silent</code>	silent	Selects silent level of logging.
<code>--verbose</code>	verbose	Selects verbose level of logging.
<code>--debug</code>	debug	Selects debug level of logging.
<code>--log <fname></code>	debug	All information is written to <code><fname></code> in addition to being sent to the <code>stdout</code> and <code>stderr</code> devices.

For Nios II, there is full error correction code (ECC) support:

- Register file
- Instruction cache
- Data cache
- Tightly-Coupled Memory (TCM)

16.1.2. Setting Values

The value of a setting is specified with the `--set` command-line option to **nios2-bsp-create-settings** or **nios2-bsp-update-settings**, or with the `set_setting` Tcl command. The value of a setting is obtained with the `--get` command-line option to **nios2-bsp-query-settings** or with the `get_setting` Tcl command.

Related Information

[Settings Managed by the Software Build Tools](#) on page 423

16.1.3. Utility and Script Summary

The following command-line utilities and scripts are available:

Related Information

- [nios2-app-generate-makefile](#) on page 398
- [nios2-bsp-create-settings](#) on page 400

- [nios2-bsp-generate-files](#) on page 402
- [nios2-bsp-query-settings](#) on page 403
- [nios2-bsp-update-settings](#) on page 404
- [nios2-lib-generate-makefile](#) on page 405
- [nios2-bsp-editor](#) on page 407
- [nios2-app-update-makefile](#) on page 407
- [nios2-lib-update-makefile](#) on page 410
- [nios2-swexample-create](#) on page 412
- [nios2-elf-insert](#) on page 413
- [nios2-elf-query](#) on page 414
- [nios2-bsp](#) on page 74
- [nios2-bsp-console](#) on page 419

16.1.4. nios2-app-generate-makefile

Usage: `nios2-app-generate-makefile --bsp-dir <directory> [<options>]`

Description: The `nios2-app-generate-makefile` command generates an application makefile (called Makefile). The path to a BSP created by `nios2-bsp-generate-files` is a mandatory command line option.

Required Arguments:

`--bsp-dir <directory>`: Specifies the path to the BSP generated files directory (populated using the `nios2-bsp-generate-files` command).

Optional Arguments:

- `--app-dir <directory>`: Directory to place the application makefile and executable and linking format file (.elf). If omitted, it defaults to the current directory.
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to `stdout`.
- `--elf-name <filename>`: Name of the .elf file to create. If omitted, it defaults to the first source file specified with the file name extension replaced with .elf and placed in the application directory.
- `--extended-help`: Displays full information about this command and its options.
- `--help`: Displays basic information about this command and its options.
- `--inc-dir <directory>`: Searches for source include files in <filepath>. Use "." to look in the current directory. Multiple `--inc-dir` options are allowed.
- `--inc-rdir <directory>`: Same as `--inc-dir` option but recursively search for source include files in or under <filepath>. Multiple `--inc-rdir` options are allowed.



- `--jvm-max-heap-size <value>` Optional. The maximum memory size to be used for allocations when running this tool. This value is specified as `<size><unit>` where unit can be m (or M) for multiples of megabytes or g (or G) for multiples of gigabytes. The default value is 512m.
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.
- `--no-src`: Allows no sources files to be set in the Makefile. You must add source files in manually before compiling
- `--set <name> <value>`: Set the makefile variable called `<name>` to `<value>`. If the variable exists in the managed section of the makefile, `<value>` replaces the default settings. If the variable does not already exist, it is added. Multiple `--set` options are allowed.
- `--silent`: Suppress information about the command's operation normally sent to `stdout`.
- `--src-dir <directory>`: Searches for source files in `<directory>`. Use `.` to look in the current directory. Multiple `--src-dir` options are allowed.
- `--src-files <filenames>`: Adds a list of space-separated source file names to the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--src-rdir <directory>`: Same as `--src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--use-lib-dir <directory>`: Specifies the path to a dependent user library directory. The user library directory must contain a makefile fragment called `public.mk`. Multiple `--use-lib-dir` options are allowed.
- `--verbose`: Output verbose, and default information about the command's operation to `stdout`.
- `--version`: Displays the version of this command and exits with a zero exit status.

Examples:

Example:

```
> 'nios2-app-generate-makefile --bsp-dir ../my_bsp --src-files  
hello_world.c'
```

Generates a Makefile setup to compile one source file in the current directory.

```
> 'make'
```

Recursively makes the BSP and then compiles and links the application to create `hello_world.elf`.

Example:

```
> 'nios2-app-generate-makefile --bsp-dir ../my_bsp --app-dir /tmp/  
my_dir/release --elf foo --src-rdir /data/jball/src/foo --src-files  
extra1.c extra2.c'
```

Generates a Makefile in `/tmp/my_dir/release` that builds an ELF called `/tmp/my_dir/release/foo.elf`. The source files are all those recursively found under `/data/jball/src/foo` and extra files called `extra1.c` and `extra2.c` in the current directory.

16.1.5. nios2-bsp-create-settings

Usage

```
nios2-bsp-create-settings [--bsp-dir <directory>]
  [--cmd <tcl command>] [--cpu-name <cpu name>]
  [--debug] [--extended-help] [--get-cpu-arch]
  [--help] [--jdi <filename>]
  [--librarian-factory-path <directory>]
  [--librarian-path <directory>] [--log <filename>]
  [--script <filename>] [--set <name> <value>]
  --settings <filename> [--silent]
  --sopc <filename> --type <OS name> [--type-version <version>] [--verbose] [--version]
```

Options

- `--bsp-dir <directory>`: Path to the directory where the BSP files are generated. Use `.` for the current directory. The directory `<directory>` must exist. This command overwrites preexisting files in `<directory>` without warning.
- `--cmd <tcl command>`: Runs the specified Tcl command. Multiple `--cmd` options are allowed.
- `--cpu-name <cpu name>`: The name of the Nios II processor that the BSP supports. Optional for a single-processor system. Use `?` to list available Nios II processor names.
- `--debug`: Sends debug information, exception traces, verbose output, and default information about the command's operation, to `stdout`.
- `--extended-help`: Displays full information about this command and its options. Also displays Tcl command help for the `--cmd` and `--script` options.
- `--get-cpu-arch`: Queries for processor architecture from the processor specified. Does not create a BSP.
- `--help`: Displays basic information about this command and its options.
- `--jdi <filename>`: The location of the JTAG Debugging Information File (`.jdi`) generated by the Quartus Prime software. The `.jdi` file specifies the name-to-node mappings for the JTAG chain elements. The tool inserts the JTAG Debugging Information File (`.jdi`) path in `public.mk`. If no `.jdi` path is specified, the command searches the directory containing the SOPC Information File (`.sopcinfo`), and uses the first `.jdi` file found.
- `--librarian-factory-path<directory>` : Comma-separated librarian search path. Use `$` for default factory search path.



- `--librarian-path<directory>` : Comma-separated librarian search path. Use `$` for default search path.
- `--log <filename>`: Creates a debug log and write to specified file. Also logs debug information to `stdout`.
- `--script <filename>`: Run the specified Tcl script with optional arguments. Multiple `--script` options are allowed.
- `--set <name> <value>`: Sets the setting called `<name>` to `<value>`. Multiple `--set` options are allowed.
- `--settings <filename>`: File name of the BSP settings file to create. This file is created with a `.bsp` file extension. It overwrites any existing settings file.
- `--silent`: Suppresses information about the command's operation normally sent to `stdout`.
- `--sopc <filename>`: The `.sopcinfo` file used to create the BSP.
- `--type <OS name>`: BSP type. Use `?` or `types` to list available BSP types for this option. Use `names` to list the display names of available BSP types. For a Nios II DPX system, always set this argument to `lwhal`.
- `--type-version <version>`: BSP software component version. By default the latest version is used. `default` value can be used to reset to this default behavior. Use `?` to list available BSP types and versions.
- `--verbose`: Sends verbose output, and default information about the command's operation, to `stdout`.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

If you use **nios2-bsp-create-settings** to create a settings file without any command-line options, Tcl commands, or Tcl scripts to modify the default settings, it creates a settings file that fails when running **nios2-bsp-generate-files**. Failure occurs because the **nios2-bsp-create-settings** command is able to create reasonable defaults for most settings, but the command requires additional information for system-dependent settings. The default Tcl scripts set the required system-dependent settings. Therefore it is better to use default Tcl scripts when calling **nios2-bsp-create-settings** directly. For an example of how to use the default Tcl scripts, refer to the **nios2-bsp** script.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

Example

```
nios2-bsp-create-settings --settings my_settings.bsp --sopc \  
../my_sopc.sopcinfo --type hal --script default_settings.tcl
```

Related Information

[Tcl Commands for BSP Settings](#) on page 466

16.1.6. nios2-bsp-generate-files

Usage

```
nios2-bsp-generate-files --bsp-dir <directory>
[--debug] [--extended-help] [--help]
[--librarian-factory-path <directory>]
[--librarian-path <directory>] [--log <filename>]
--settings <filename> [--silent] [--verbose]
[--version]
```

Options

- **--bsp-dir <directory>**: Path to the directory where the BSP files are generated. Use . for the current directory. The directory <directory> must exist. This command overwrites preexisting files in <directory> without warning.
- **--debug**: Sends debug, exception trace, verbose, and default information about the command's operation to stdout.
- **--extended-help**: Displays full information about this command and its options.
- **--help**: Displays basic information about this command and its options.
- **--librarian-factory-path <directory>**: Comma-separated librarian search path. Use \$ for default factory search path.
- **--librarian-path <directory>**: Comma-separated librarian search path. Use \$ for default search path.
- **--log <filename>**: Creates a debug log and writes to specified file. Also logs debug information to stdout.
- **--settings <filename>**: File name of an existing BSP Settings File (.bsp) to generate files from.
- **--silent**: Suppresses information about the command's operation normally sent to stdout.
- **--verbose**: Sends verbose and default information about the command's operation to stdout.
- **--version**: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-bsp-generate-files** command populates the files in a BSP directory. The path to an existing .bsp file and the path to the BSP directory are mandatory command-line options. Files are written to the specified BSP directory. Generated files are created unconditionally. Copied files are copied from the Nios II EDS installation folder only if they are not present in the BSP directory, or if the existing files differ from the installation files.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to stderr.

Note: For more information about this command, use the --extended-help option to display comprehensive usage information.



16.1.7. nios2-bsp-query-settings

Usage

```
nios2-bsp-query-settings [--cmd <tcl command>]
[--debug] [--extended-help] [--get <name>]
[--get-all] [--help]
[--librarian-factory-path <directory>]
[--librarian-path <directory>] [--log <filename>]
[--script <filename>] --settings <filename>
[--show-descriptions] [--show-names] [--silent]
[--verbose] [--version]
```

Options

- `--cmd <tcl command>`: Run the specified Tcl command. Multiple `--cmd` options are allowed.
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to `stdout`.
- `--extended-help`: Displays full information about this command and its options.
- `--get <name>`: Display the value of the setting called `<name>`. Multiple `--get` options are allowed. Each value appears on its own line in the order the `--get` options are specified. Mutually exclusive with the `--get-all` option.
- `--get-all`: Display the value of all BSP settings in order sorted by option name. Each option appears on its own line. Mutually exclusive with the `--get` option.
- `--help`: Displays basic information about this command and its options.
- `--librarian-factory-path <directory>`: Comma-separated librarian search path. Use `$` for default factory search path.
- `--librarian-path <directory>`: Comma-separated librarian search path. Use `$` for default search path.
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.
- `--script <filename>`: Run the specified Tcl script with optional arguments. Multiple `--script` options are allowed.
- `--settings <filename>`: File name of an existing BSP settings file to query settings from.
- `--show-descriptions`: Displays the description of each option after the value.
- `--show-names`: Displays the name of each option before the value.
- `--silent`: Suppress information about the command's operation normally sent to `stdout`.
- `--verbose`: Output verbose, and default information about the command's operation to `stdout`.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-bsp-query-settings** command provides information from a .bsp file. The path to an existing .bsp file is a mandatory command-line option. The command does not modify the settings file. Only requested information is displayed on `stdout`; no informational messages are displayed.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

16.1.8. nios2-bsp-update-settings

Usage

```
nios2-bsp-update-settings [--bsp-dir <directory>]
  [--cmd <tcl command>] [--cpu-name <cpu name>]
  [--debug] [--extended-help] [--help] [--jdi <filename>]
  [--librarian-factory-path <directory>]
  [--librarian-path <directory>] [--log <filename>]
  [--script <filename>] [--set <name> <value>]
  [--settings <filename>] [--silent]
  [--sopc <filename>] [--verbose] [--version]
```

Options

- `--bsp-dir <directory>`: Path to the directory where the BSP files are generated. Use `.` for the current directory. The directory `<directory>` must exist.
- `--cmd <tcl command>`: Run the specified Tcl command. Multiple `--cmd` options are allowed.
- `--cpu-name <cpu name>`: The name of the Nios II processor that the BSP supports. This argument is useful if the hardware design contains multiple Nios II processors. Optional for a single-processor design.
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to `stdout`.
- `--extended-help`: Displays full information about this command and its options.
- `--help`: Displays basic information about this command and its options.
- `--jdi <filename>`: The location of the .jdi file generated by the Quartus Prime software. The .jdi file specifies the name-to-node mappings for the JTAG chain elements. The tool inserts the .jdi path in `public.mk`. If no .jdi path is specified, the command searches the directory containing the `.sopcinfo` file, and uses the first .jdi file found.
- `--librarian-factory-path <directory>`: Comma-separated librarian search path. Use `$` for default factory search path.
- `--librarian-path <directory>`: Comma-separated librarian search path. Use `$` for default search path.
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.



- `--script <filename>`: Run the specified Tcl script with optional arguments. Multiple `--script` options are allowed.
- `--set <name> <value>`: Set the setting called `<name>` to `<value>`. Multiple `--set` options are allowed.
- `--settings <filename>`: File name of an existing BSP settings file to update.
- `--silent`: Suppress information about the command's operation normally sent to stdout.
- `--sopc <filename>`: The `.sopcinfo` file to update the BSP with. It is recommended to create a new BSP if the design has changed significantly. This argument is useful if the path to the original `.sopcinfo` file has changed.
- `--verbose`: Output verbose, and default information about the command's operation to stdout.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-bsp-update-settings** command updates an existing Nios II **.bsp** file. The path to an existing **.bsp** file is a mandatory command-line option. The command modifies the settings file so the file must have write permissions. You might want to use the `--script` option to pass the default Tcl script to the **nios2-bsp-update-settings** command to make sure that your BSP is consistent with your system (this is what the **nios2-bsp** command does).

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to stderr.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

16.1.9. nios2-lib-generate-makefile

Usage

```
nios2-lib-generate-makefile [--bsp-dir <directory>]
  [--debug] [--extended-help] [--help]
  [--lib-dir <directory>] [--lib-name <filename>]
  [--log <filename>] [--no-src]
  [--public-inc-dir <directory>] [--set <name> <value>]
  [--silent] [--src-dir <directory>]
  [--src-files <filenames>] [--src-rdir <directory>]
  [--use-lib-dir <directory>] [--verbose]
  [--version]
```

Options

- `--bsp-dir <directory>`: Path to the BSP generated files directory (populated using the **nios2-bsp-generate-files** command).
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to stdout.
- `--extended-help`: Displays full information about this command and its options.
- `--help`: Displays basic information about this command and its options.

- `--lib-dir <directory>`: Destination directory for the user library archive file (.a), the user library makefile, and `public.mk`. If omitted, it defaults to the current directory.
- `--lib-name <filename>`: Name of the user library being created. The user library file name is the user library name with a `lib` prefix and `.a` suffix added. Do not include these in the user library name itself. If the user library name option is omitted, the user library name defaults to the name of the first source file with its extension removed.
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.
- `--no-src`: Allows no sources files to be set in the Makefile. You must add source files manually before compiling.
- `--public-inc-dir <directory>`: Path to a directory that contains C header files (.h) that are to be made available (that is, public) to users of the user library. This directory is added to the appropriate variable in `public.mk`. Multiple `--public-inc-dir` options are allowed.
- `--set <name> <value>`: Set the makefile variable called `<name>` to `<value>`. If the variable exists in the managed section of the makefile, `<value>` replaces the default settings. It adds the makefile variable if it does not already exist. Multiple `--set` options are allowed.
- `--silent`: Suppress information about the command's operation normally sent to `stdout`.
- `--src-dir <directory>`: Search for source files in `<directory>`. Use `.` to look in the current directory. Multiple `--src-dir` options are allowed.
- `--src-files <filenames>`: A list of space-separated source file names added to the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--src-rdir <directory>`: Same as `--src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--use-lib-dir <directory>`: Path to a dependent user library directory. The user library directory must contain a makefile fragment called `public.mk`. Multiple `--use-lib-dir` options are allowed.
- `--verbose`: Output verbose, and default information about the command's operation to `stdout`.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-lib-generate-makefile** command generates a user library makefile (called Makefile). The path to a BSP created by **nios2-bsp-generate-files** is an optional command-line option.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.



Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

16.1.10. nios2-bsp-editor

Usage

```
nios2-bsp-editor [--extended-help]
[--fontsize <point size>] [--help]
[--librarian-factory-path <directory>]
[--librarian-path <directory>] [--log <filename>]
[--settings <filename>] [--version]
```

Options

- `--extended-help`: Displays full information about this command and its options.
- `--fontsize <point size>`: The default point size for GUI fonts is 11. Use this option to adjust the point size.
- `--help`: Displays basic information about this command and its options.
- `--librarian-factory-path <directory>`: Comma-separated librarian search path. Use \$ for default factory search path.
- `--librarian-path <directory>`: Comma-separated librarian search path. Use \$ for default search path.
- `--log <filename>`: Create a debug log and write to specified file.
- `--settings <filename>`: File name of an existing BSP settings file to update.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-bsp-editor** command is a GUI application for creating and editing board support packages for Nios II designs.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

16.1.11. nios2-app-update-makefile


Usage

```
nios2-app-update-makefile --app-dir <directory>
[--add-lib-dir <directory>] [--add-src-dir <directory>]
[--add-src-files <filenames>] [--add-src-rdir <directory>] [--debug]
[--extended-help] [--force] [--get <name>] [--get-all]
[--get-asflags] [--get-bsp-dir] [--get-debug-level]
[--get-defined-symbols] [--get-elf-name] [--get-optimization]
[--get-undefined-symbols] [--get-user-flags] [--get-warnings]
[--help] [--list-lib-dir] [--list-src-files] [--lock]
[--log <filename>] [--no-src] [--remove-lib-dir <directory>]
[--remove-src-dir <directory>] [--remove-src-files <filenames>]
[--remove-src-rdir <directory>] [--set <name>]
[--set-asflags <value>] [--set-bsp-dir <directory>]
[--set-debug-level <value>] [--set-defined-symbols <value>]
[--set-elf-name <name>] [--set-optimization <value>]
```

```
[--set-undefined-symbols <value>] [--set-user-flags <value>]
[--set-warnings <value>] [--show-managed-section] [--show-names]
[--silent] [--unlock] [--verbose] [--version]
```

Options

- `--app-dir <directory>`: Path to the Application Directory with the generated makefile.
- `--add-lib-dir <directory>`: Add a path to dependent user library directory
- `--add-src-dir <directory>`: Add source files in `<directory>`. Use `.` to look in the current directory. Multiple `--add-src-dir` options are allowed.
- `--add-src-files <filenames>`: A list of space-separated source file names to be added to the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--add-src-rdir <directory>`: Same as `--add-src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--add-src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to `stdout`.
- `--extended-help`: Displays full information about this command and its options.
- `--force`: Update the Makefile even if it's locked
- `--get <name>`: Get the values of Makefile variables
- `--get-all`: Get all variables in the managed section of the Makefile
- `--get-asflags`: Get user assembler flags
- `--get-bsp-dir`: Get the BSP generated files directory
- `--get-debug-level`: Get debug level flag
- `--get-defined-symbols`: Get defined symbols flag
- `--get-elf-name`: Get the name of `.elf` file
- `--get-optimization`: Get optimization flag
- `--get-undefined-symbols`: Get undefined symbols flag
- `--get-user-flags`: Get user flags
- `--get-warnings`: Get warnings flag
- `--help`: Displays basic information about this command and its options.
- `--list-lib-dir`: List all paths to dependent user library directories
- `--list-src-files`: List all source files in the makefile.
- `--lock`: Lock the Makefile to prevent it from being updated
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.
- `--no-src`: Remove all source files in the makefile
- `--remove-lib-dir <directory>`: Remove a path to dependent user library directory



- `--remove-src-dir <directory>`: Remove source files in `<directory>`. Use `.` to look in the current directory. Multiple `--remove-src-dir` options are allowed.
- `--remove-src-files <filenames>`: A list of space-separated source file names to be removed from the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--remove-src-rdir <directory>`: Same as `--remove-src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--remove-src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--set <name> <value>`: Set the value of a Makefile variable called `<name>`
- `--set-asflags <value>`: Set user assembler flags
- `--set-bsp-dir <directory>`: Set the BSP generated files directory
- `--set-debug-level <value>`: Set debug level flag
- `--set-defined-symbols <value>`: Set defined symbols flag
- `--set-elf-name <name>`: Set the name of `.elf` file
- `--set-optimization <value>`: Set optimization flag
- `--set-undefined-symbols <value>`: Set undefined symbols flag
- `--set-user-flags <value>`: Set user flags
- `--set-warnings <value>`: Set warnings flag
- `--show-managed-section`: Show the managed section in the Makefile
- `--show-names`: Show name of the variables
- `--silent`: Suppress information about the command's operation normally sent to stdout.
- `--unlock`: Unlock the Makefile
- `--verbose`: Output verbose, and default information about the command's operation to stdout.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-app-update-makefile** command updates an application makefile to add or remove source files.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

Note: The `--add-src-dir`, `--add-src-rdir`, `--remove-src-dir`, and `--remove-src-rdir` options add and remove files found in `<directory>` at the time the command is executed. Files subsequently added to or removed from the directory are not reflected in the makefile.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.


16.1.12. nios2-lib-update-makefile

Usage

```
nios2-lib-update-makefile --lib-dir <directory>
  [--add-lib-dir <directory>] [--add-public-inc-dir <directory>]
  [--add-src-dir <directory>] [--add-src-files <filenames>]
  [--add-src-rdir <directory>] [--debug] [--extended-help] [--force]
  [--get <name>] [--get-all] [--get-asflags] [--get-bsp-dir]
  [--get-debug-level] [--get-defined-symbols] [--get-lib-name]
  [--get-optimization] [--get-undefined-symbols] [--get-user-flags]
  [--get-warnings] [--help] [--list-lib-dir] [--list-public-inc-dir]
  [--list-src-files] [--lock] [--log <filename>] [--no-src]
  [--remove-lib-dir <directory>] [--remove-public-inc-dir <directory>]
  [--remove-src-dir <directory>] [--remove-src-files <filenames>]
  [--remove-src-rdir <directory>] [--set <name> <value>]
  [--set-asflags <value>] [--set-bsp-dir <directory>]
  [--set-debug-level <value>] [--set-defined-symbols <value>]
  [--set-lib-name <name>] [--set-optimization <value>]
  [--set-undefined-symbols <value>] [--set-user-flags <value>]
  [--set-warnings <value>] [--show-managed-section] [--show-names]
  [--silent] [--unlock] [--verbose] [--version]
```

Options

- `--add-lib-dir <directory>`: Add a path to dependent user library directory
- `--add-public-inc-dir <directory>`: Add a directory that contains C-language header files
- `--add-src-dir <directory>`: Add source files in `<directory>`. Use `.` to look in the current directory. Multiple `--add-src-dir` options are allowed.
- `--add-src-files <filenames>`: A list of space-separated source file names to be added to the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--add-src-rdir <directory>`: Same as `--add-src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--add-src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--debug`: Output debug, exception traces, verbose, and default information about the command's operation to `stdout`.
- `--extended-help`: Displays full information about this command and its options.
- `--force`: Update the Makefile even if it is locked



- `--get <name>`: Get the values of Makefile variables
- `--get-all`: Get all variables in the managed section of the Makefile
- `--get-asflags`: Get user assembler flags
- `--get-bsp-dir`: Get the BSP generated files directory
- `--get-debug-level`: Get debug level flag
- `--get-defined-symbols`: Get defined symbols flag
- `--get-lib-name`: Get the name of user library
- `--get-optimization`: Get optimization flag
- `--get-undefined-symbols`: Get undefined symbols flag
- `--get-user-flags`: Get user flags
- `--get-warnings`: Get warnings flag
- `--help`: Displays basic information about this command and its options.
- `--list-lib-dir`: List all paths to dependent user library directories
- `--list-public-inc-dir`: List all public include directories
- `--list-src-files`: List all source files in the makefile.
- `--lock`: Lock the Makefile to prevent it from being updated
- `--log <filename>`: Create a debug log and write to specified file. Also logs debug information to `stdout`.
- `--no-src`: Remove all source files
- `--remove-lib-dir <directory>`: Remove a path to dependent user library directory
- `--remove-public-inc-dir <directory>`: Remove a include directory
- `--remove-src-dir <directory>`: Remove source files in `<directory>`. Use `.` to look in the current directory. Multiple `--remove-src-dir` options are allowed.
- `--remove-src-files <filenames>`: A list of space-separated source file names to be removed from the makefile. The list of file names is terminated by the next option or the end of the command line. Multiple `--src-files` options are allowed.
- `--remove-src-rdir <directory>`: Same as `--remove-src-dir` option but recursively search for source files in or under `<directory>`. Multiple `--remove-src-rdir` options are allowed and can be freely mixed with `--src-dir` options.
- `--set <name> <value>`: Set the value of a Makefile variable called `<name>`
- `--set-asflags <value>`: Set user assembler flags
- `--set-bsp-dir <directory>`: Set the BSP generated files directory
- `--set-debug-level <value>`: Set debug level flag
- `--set-defined-symbols <value>`: Set defined symbols flag
- `--set-lib-name <name>`: Set the name of user library
- `--set-optimization <value>`: Set optimization flag

- `--set-undefined-symbols <value>`: Set undefined symbols flag
- `--set-user-flags <value>`: Set user flags
- `--set-warnings <value>`: Set warnings flag
- `--show-managed-section`: Show the managed section in the Makefile
- `--show-names`: Show name of the variables
- `--silent`: Suppress information about the command's operation normally sent to stdout.
- `--unlock`: Unlock the Makefile
- `--verbose`: Output verbose, and default information about the command's operation to stdout.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-lib-update-makefile** command updates a user library makefile to add or remove source files.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to stderr.

Note: The `--add-src-dir`, `--add-src-rdir`, `--remove-src-dir`, and `--remove-src-rdir` options add and remove files found in *<directory>* at the time the command is executed. Files subsequently added to or removed from the directory are not reflected in the makefile.

Note: For more information about this command, use the `--extended-help` option to display comprehensive usage information.

16.1.13. nios2-swexample-create

Usage

```
nios2-create-swexample [Options]
```

Options

- `--name`: Specify the name of the software project to create.
- `--sopc-dir` Specify the SOPC builder directory [deprecated].
- `--sopc-file` Specify the SOPC builder file [required].
- `--type`: Specify the software design example template type. Required.
- `--list` List all valid software design example template types.
- `--app-dir` Specify the application directory to create. Default: *<sopc-dir>/software_examples/app/<name>*
- `--bsp-dir` Specify the bsp directory to create. Default: *<sopc-dir>/software_examples/bsp/<bsp-type>*
- `--no-app` Do not generate the **create-this-app** script



- `--no-bsp` Do not generate the **create-this-bsp** script
- `--elf-name` Name of the .elf file to create.
- `--describe` Describe the software example type specified and exit.
- `--describeX` Verbosely describe the software example type specified and exit.
- `--describeAll` Describe all the software example types and exit.
- `--search` Search for software example templates in the specified directory.
Default: `$SOPC_KIT_NIOS2/examples/software`.
- `--help` Print this message and exit.
- `--silent` Do not echo commands.
- `--version` Print the version number of `nios2-create-swexample` and exit.
- `--cpu-name` Create the software example using the `cpuName` specified.
- `--jvm-max-heap-size` The maximum memory size to be used for allocations when running this tool. This value is specified as `<size><unit>` where unit can be `m` (or `M`) for multiples of megabytes or `g` (or `G`) for multiples of gigabytes. The default value is `512m`. [Optional]

Description

This utility creates a template software example for a given SOPC system.

16.1.14. nios2-elf-insert

Usage

Simple ELF 'fattening' tool used to inject additional sections into an ELF intended for the Nios II soft-core processor. The main purpose of this tool is to insert extra information into ELF files so that downstream tools can extract that information. The main motivation for this tool is to make the ELF file the single handoff file that all downstream embedded tools can agree on.

For example, the Nios II SBT build flow uses `nios-elf-insert` to insert the `cpu` name and the `sysid` information into the ELF file at build time. Later on downstream, the eclipse debugger can use `nios2-elf-query` to extract this information to auto-populate all the various GUI settings with the correct default values.

The first argument is the ELF filename: (`nios2-elf-insert <filename>`).

Valid Additional Arguments

```
--qsys <qsysFabricModeEnabled>
--cpu_name <cpuName>
--stderr_dev <stderrDev>
--stdin_dev <stdinDev>
--stdout_dev <stdoutDev>
--sidp <sysidBase>
--id <sysidHash>
--timestamp <sysidTime>
--sof <sofFile>
--sopcinfo <sopcinfoFile>
--jar <jarFile>
--jdi <jdiFile>
```

```
--quartus_project_dir <quartusProjectDir>
--sopc_system_name <sopcSystemName>
--profiling_enabled <profilingEnabled>
--simulation_enabled <simulationEnabled>
--thread_model <threadModel>
```

Advanced Options

--jvm-max-heap-size=<value>—Optional. The maximum memory size to be used for allocations when running this tool. This value is specified as <size><unit> where unit can be m (or M) for multiples of megabytes or g (or G) for multiples of gigabytes. The default value is 512m.

Related Information

[nios2-elf-query](#) on page 414

16.1.15. nios2-elf-query

Usage

Simple ELF 'querying' tool used to extract metadata inserted into an ELF intended for the Nios II soft-core processor. The main purpose of this tool is so that downstream tools can extract information from an ELF that was inserted using `nios2-elf-insert`. The main motivation for this tool is to make the ELF file the single handoff file that all downstream embedded tools can agree on.

For example, the Nios II SBT build flow uses `nios-elf-insert` to insert the cpu name and the sysid information into the ELF file at build time. Later on downstream, the eclipse debugger can use `nios2-elf-query` to extract this information to auto-populate all the various GUI settings with the correct default values.

The first argument is the ELF filename: (`nios2-elf-query <filename>`).

Valid Additional Arguments

```
--qsys
--cpu_name
--stderr_dev
--stdin_dev
--stdout_dev
--sidp
--id
--timestamp
--sof
--sopcinfo
--jar
--jdi
--quartus_project_dir
--sopc_system_name
--profiling_enabled
--simulation_enabled
--thread_model
```

Advanced Options

--jvm-max-heap-size=<value>—Optional. The maximum memory size to be used for allocations when running this tool. This value is specified as <size><unit> where unit can be m (or M) for multiples of megabytes or g (or G) for multiples of gigabytes. The default value is 512m.



Related Information

[nios2-elf-insert](#) on page 413

16.1.16. nios2-flash-programmer-generate

Usage

```
nios2-flash-programmer-generate [--accept-bad-sysid]
[--add-bin <fname> <flash-slave-desc> <offset>]
[--add-elf <fname> <flash-slave-desc> <extra-elf2flash-arguments>]
[--add-sof <fname> <flash-slave-desc> <offset>]
<extra-sof2flash-arguments>]
[--cable <cable name>] [--cpu <processor_name>] [--debug]
[--device <device name>] [--erase-first] [--extended-help]
--flash-dir <directory> [--go] [--help] [--id <address>]
[--instance <instance value>] [--log <filename>] [--mmu]
[--program-flash] [--script-dir <directory>] [--sidp <address>]
[--silent] --sopcinfo <filename> [--verbose] [--version]
```

Options

- `--accept-bad-sysid`: Continue even if the system identifier (ID) comparison fails.
- `--add-bin <fname> <flash-slave-desc> <offset>`: Specify a binary file to convert and program. The filename, target flash slave descriptor, and target offset amount are required. This option can be used multiple times for SRAM Object Files (.sof).
- `--add-elf <fname> <flash-slave-desc> <extra-elf2flash-arguments>`: Specify a .elf file to convert and program. The filename and target flash slave descriptor are required. This option can be used multiple times for .elf files. `<extra-elf2flash-arguments>` can be any of the following options supported by **elf2flash**:

- save
- sim_optimize

The following **elf2flash** options have default values computed, but are also supported as `<extra-elf2flash-arguments>` for manual override of those defaults:

- base
- boot
- end
- reset

- `--add-sof <fname> <flash-slave-desc> <offset> <extra-sof2flash-arguments>`: Specify a .sof file to convert and program. The filename, target flash slave descriptor, and target offset arguments are required. This option can be used multiple times for .sof files. `<extra-sof2flash-arguments>` can be any of the following options supported by **sof2flash**:
 - `activeparallel`
 - `compress`
 - `save`
 - `timestamp`
 - `options`
- `--cable <cable name>`: Specifies which JTAG cable to use (not needed if you only have one cable). Not used without `--program-flash` option.
- `--cpu <processor_name>`: The Nios II processor name from the .sopcinfo file. Not required if only one Nios II processor in the system.
- `--debug`: Sends debug information, exception traces, verbose output, and default information about the command's operation, to stdout.
- `--device <device name>`: Specifies in which device you want to look for the Nios II debug core. Device 1 is the device nearest TDI. Not used without `--program-flash` option.
- `--erase-first`: Erase entire flash targets before programming them. Not used without `--program-flash` option.
- `--extended-help`: Displays full information about this command and its options.
- `--flash-dir <directory>`: Path to the directory where the flash files are generated. Use . for the current directory. This command overwrites pre-existing files in `<directory>` without warning.
- `--go`: Run processor from reset vector after program.
- `--help`: Displays basic information about this command and its options.
- `--id <address>`: Unique ID code for target system. Not used without `--program-flash` option.
- `--instance <instance value>`: Specifies the INSTANCE value of the debug core (not needed if there is exactly one on the chain). Not used without `--program-flash` option.
- `--log <filename>`: Creates a debug log and write to specified file. Also logs debug information to stdout.
- `--mmu`: Specifies if the processor with the corresponding INSTANCE value has an MMU (not needed if there is exactly one processor in the system). Not used without `--program-flash` option.
- `--program-flash`: Providing this flag causes calls to **nios2-flash-programmer** to be generated and executed. This results in flash targets being programmed.



- `--script-dir <directory>`: Path to the directory where a shell script of this tool's executed command lines is generated. This script can be used in place of this **nios2-flash-programmer-generate** command. Use `.` for the current directory. This command overwrites pre-existing files in `<directory>` without warning.
- `--sidp <address>`: Base address of system ID peripheral on the target. Not used without `--program-flash` option.
- `--silent`: Suppresses information about the command's operation normally sent to stdout.
- `--sopcinfo <filename>`: The **.sopcinfo** file.
- `--verbose`: Sends verbose output, and default information about the command's operation, to stdout.
- `--version`: Displays the version of this command and exits with a zero exit status.

Description

The **nios2-flash-programmer-generate** command converts multiple files to a **.flash** in Motorola S-record format, and programs them to the designated target flash devices (`--program-flash`). This is a convenience utility that manages calls to the following command line utilities

- **bin2flash**
- **elf2flash**
- **sof2flash**
- **nios2-flash-programmer**

This utility also generates a script that captures the sequence of conversion and flash programmer commands.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

Example

```
nios2-flash-programmer-generate --sopcinfo=C:\my_design.sopcinfo \  
--flash-dir=. \  
--add-sof C:\my_design\test.sof 0x0C000000 memory_0 compress save \  
--add-elf C:\my_app\my_app.elf 0x08000000 memory_0 \  
--program-flash
```

16.1.17. nios2-bsp

Usage

```
nios2-bsp <bsp-type> <bsp-dir> [<sopc>] [<override>]...
```

Options

- `<bsp-type>`: hal or ucosii.
- `<bsp-dir>`: Path to the BSP directory.
- `<sopc>`: The path to the .sopcinfo file or its directory.
- `<override>`: Options to override defaults.

Description

The **nios2-bsp** script calls **nios2-bsp-create-settings** or **nios2-bsp-update-settings** to create or update a BSP settings file, and the **nios2-bsp-generate-files** command to create the BSP files. The Nios II Embedded Design Suite (EDS) supports the following BSP types:

- hal
- ucosii

BSP type names are case-insensitive.

This utility produces a BSP of `<bsp-type>` in `<bsp-dir>`. If the BSP does not exist, it is created. If the BSP already exists, it is updated to be consistent with the associated hardware system.

The default Tcl script is used to set the following system-dependent settings:

- `stdio` character device
- System timer device
- Default linker memory
- Boot loader status (enabled or disabled)

If the BSP already exists, **nios2-bsp** overwrites these system-dependent settings.

The default Tcl script is installed at `<Nios II EDS install path>/sdk2/bin/bsp-set-defaults.tcl`

When creating a new BSP, this utility runs **nios2-bsp-create-settings**, which creates `settings.bsp` in `<bsp-dir>`.

When updating an existing BSP, this utility runs **nios2-bsp-update-settings**, which updates `settings.bsp` in `<bsp-dir>`.

After creating or updating the `settings.bsp` file, this utility runs **nios2-bsp-generate-files**, which generates files in `<bsp-dir>`

Required arguments:

- `<bsp-type>`: Specifies the type of BSP. This argument is ignored when updating a BSP. This argument is case-insensitive. The **nios2-bsp** script supports the following values of `<bsp-type>`:
 - hal
 - ucosii
- `<bsp-dir>`: Path to the BSP directory. Use "." to specify the current directory.



Optional arguments:

- `<sopc>`: The path name of the `.sopcinfo` file. Alternatively, specify a directory containing a `.sopcinfo` file. In the latter case, the tool finds a file with the extension `.sopcinfo`. This argument is ignored when updating a BSP. If you omit this argument, it defaults to the current directory.
- `<override>`: Options to override defaults. The **nios2-bsp** script passes most overrides to **nios2-bsp-create-settings** or **nios2-bsp-update-settings**. It also passes the `--silent`, `--verbose`, `--debug`, and `--log` options to **nios2-bsp-generate-files**.

nios2-bsp passes the following overrides to the default Tcl script:

- `--default_stdio <device>|none|DONT_CHANGE`
Specifies stdio device.
- `--default_sys_timer <device>|none|DONT_CHANGE`
Specifies system timer device.
- `--default_memory_regions DONT_CHANGE`
Suppresses creation of new default memory regions when updating a BSP. Do not use this option when creating a new BSP.
- `--default_sections_mapping <region>|DONT_CHANGE`
Specifies the memory region for the default sections.
- `--use_bootloader 0|1|DONT_CHANGE`
Specifies whether a boot loader is required.
On a preexisting BSP, the value `DONT_CHANGE` prevents associated settings from changing their current value.

Note: The "--" prefix is stripped when the option is passed to the underlying utility.

If no command-line arguments are specified, this command returns an exit value of 1 and sends a help message to `stderr`.

16.1.18. nios2-bsp-console

Usage

```
nios2-bsp-console [--cmd <tcl> <command>] [--extended-help] [--gui]  
[--help] [--script <filename>] [--version]
```

Options

- `--cmd <tcl> <command>`: Runs the specified Tcl command. Multiple `--cmd` options are allowed.
- `--extended-help`: Displays full information about this command and its options. Lists BSP Tcl command help for the `--cmd` and `--script` options
- `--gui`: This option opens a Tcl console for creating, editing, and generating BSPs.
- `--help`: Displays basic information about this command and its options.
- `--script <filename>`: Run the specified Tcl script with optional arguments. Multiple `--script` options are allowed.

- `--version`: Displays the version of this command and exits with a zero exit status.

Description

When invoked with no arguments, **nios2-bsp-console** starts an interactive command-line Tcl interpreter for creating, editing, and generating BSPs.

Related Information

[Tcl Commands for BSP Settings](#) on page 466

16.1.19. alt-file-convert (BETA)

Description

alt-file-convert (BETA): General file conversion tool. For Nios II, it is primarily used for generating a Nios II application image for Max Onchip Flash and EPCQ.

Usage

```
alt-file-convert -I <input_type> -O <output_type> [option(s)] --
input=<input_file> --output=<output_file>
```

For Nios II, the BETA version is limited to the following uses:

- Convert between Intel HEX (byte addressed) and Quartus HEX (word addressed)
- Convert between Quartus HEX files of various widths
- Convert an `.elf` file to a HEX file and append a bootcopier (used for application flash image for Max On-chip Flash and EPCQ)

Options

```
-h, --help - prints usage
-I - input type
-O - output type
--base - base address (in hex) of target memory (default 0x0)
--end - end address (in hex) of target memory (default 0xFFFFFFFF)
--reset - reset address (in hex) of target memory (default None)
--input - path to input file
--output - path to output file
--in-data-width - data width of inputfile [8, 16, 32, 64, 128, 256] (default 8)
--out-data-width - data width of target memory [8, 16, 32, 64, 128, 256]
(default None)
--boot - location of boot file to be appended (srec format)
```

Examples

Converting from Intel Hex (IHEX) to a Quartus Hex (HEX) for a memory with a 32-bit data width:

```
alt-file-convert -I ihex -O
hex out-data-width 32 in.ihex out.hex
```

Converting from an `.elf` file to a flash and appending a bootcopier given as a srec file:

```
alt-file-convert -I elf32-littlenios2 -O flash in.elf out.flash --have-boot-
copier --boot boot.elf
```



16.2. Nios II Design Example Scripts

The Nios II SBT includes commands that allow you to create sample BSPs and applications. In this example, `nios2-swexample-create` is used to create the `create_helloworld.sh` script.

Example 7. `create_helloworld.sh`

```
# Define user definitions

PROJECT_NAME=test
SAMPLE_TYPE=hello_world_small
SOPCINFO_DIR=./Bemicro_nios_v2_sample
SOPCINFO_FILE=qsys.sopcinfo
CPU_NAME=CPU

# Define internal symbols

BSP_STR=_bsp
APP_NAME=$PROJECT_NAME
BSP_NAME=$PROJECT_NAME$BSP_STR
APP_DIR=$SOPCINFO_DIR/software/$APP_NAME
BSP_DIR=$SOPCINFO_DIR/software/$BSP_NAME

# Create create-this-app and create-this-bsp script

nios2-swexample-create --name=$PROJECT_NAME \
                      --type=$SAMPLE_TYPE \
                      --sopc-file=$SOPCINFO_DIR/$SOPCINFO_FILE \
                      --app-dir=$APP_DIR \
                      --bsp-dir=$BSP_DIR

# Build BSP and Application

cd $APP_DIR
./create-this-app
```

Related Information

[nios2-swexample-create](#) on page 412

16.2.1. `create-this-bsp`

Each BSP subdirectory contains a **create-this-bsp** script. The **create-this-bsp** script calls the **nios2-bsp** script to create a BSP in the current directory. The **create-this-bsp** script has a relative path to the directory containing the **.sopcinfo** file.

The **.sopcinfo** file resides two directory levels above the directory containing the **create-this-bsp** script.

The **create-this-bsp** script takes no command-line arguments. Your current directory must be the same directory as the **create-this-bsp** script. The exit value is zero on success and one on error.

16.2.2. `create-this-app`

Each application subdirectory contains a **create-this-app** script. The **create-this-app** script copies the C/C++ application source code to the current directory, runs **nios2-app-generate-makefile** to create a makefile (named **Makefile**), and then runs **make** to build the Executable and Linking Format File (**.elf**) for your application. Each **create-this-app** script uses a particular example BSP. For further information,

refer to the script to determine the associated example BSP. If the BSP does not exist when **create-this-app** runs, **create-this-app** calls the associated **create-this-bsp** script to create the BSP.

The **create-this-app** script takes no command-line arguments. Your current directory must be the same directory as the **create-this-app** script. The exit value is zero on success and one on error.

16.2.3. Finding create-this-app and create-this-bsp


The **create-this-app** and **create-this-bsp** scripts are installed with your Nios II design examples. You can easily find them from the following information:

- Where the Nios II EDS is installed
- Which Intel FPGA development board you are using
- Which HDL you are using
- Which Nios II hardware design example you are using
- The name of the Nios II software example

The **create-this-app** script for each software design example is in <Nios II EDS install path>/**examples**/**<HDL>/niosII_<board type>/<design name>/software_examples/app/<example name>**. For example, the **create-this-app** script for the **Hello World** software example running on the triple-speed ethernet design example for the Stratix® IV GX FPGA Development Kit might be located in **c:/altera/100/nios2eds/examples/verilog/niosII_stratixIV_4sgx230/triple_speed_ethernet_design/software_examples/app/hello_world**.

Similarly, the **create-this-bsp** script for each software design example is in <Nios II EDS install path>/**examples**/**<HDL>/niosII_<board type>/<design name>/software_examples/bsp/<BSP_type>**. For example, the **create-this-bsp** script for the basic HAL BSP to run on the triple-speed ethernet design example for the Stratix IV GX FPGA Development Kit might be located in **c:/altera/100/nios2eds/examples/verilog/niosII_stratixIV_4sgx230/triple_speed_ethernet_design/software_examples/bsp/hal_default**.

Figure 18. Software Design Example Directory Structure



16.3. Settings Managed by the Software Build Tools

Settings are central to how you create and work with BSPs, software packages, and device drivers. You control the characteristics of your project by controlling the settings. The settings determine things like whether or not an operating system is supported, and the device drivers and other packages that are included.

Sometimes these settings are specified automatically, by scripts such as **create-this-bsp**, and sometimes explicitly, with Tcl commands. Either way, settings are always involved.

This section contains a complete list of available settings for BSPs and for Intel FPGA-supported device drivers and software packages. It does not include settings for device drivers or software packages furnished by Intel FPGA partners or other third parties. If you are using a third-party driver or component, refer to the supplier's documentation.

Settings used in the Nios II SBT are organized hierarchically, for logical grouping and to avoid name conflicts. Each setting's position in the hierarchy is indicated by one or more prefixes. A prefix is an identifier followed by a dot (.). For example, `hal.enable_c_plus_plus` is a hardware abstraction layer (HAL) setting, while `ucosii.event_flag.os_flag_accept_en` is a member of the event flag subgroup of MicroC/OS-II settings.

Setting names are case-insensitive.

Related Information

- [Getting Started from the Command Line](#) on page 73

- [Nios II Software Build Tools](#) on page 87
For more information, refer to the examples about specifying or manipulating settings.

16.3.1. Overview of BSP Settings

A BSP setting consists of a name/value pair.

The format in which you specify the setting value depends on the setting type. Several settings types are supported.

Table 67. Allowed Formats for each Setting Type

Setting Type	Format When Setting	Format When Getting
boolean	0/1 or false/true	0/1
number	0x prefix for hexadecimal or no prefix for a decimal number	decimal
string	Quoted string Use "none" to set empty string. In the SBT command line, to specify a string value with embedded spaces, surround the string with a backslash-double-quote sequence (\"). For example: <code>--set APP_INCLUDE_DIRS \"lcd board\"</code>	Quoted string

Table 68. BSP Setting Contexts

Setting Context	Description
Intel FPGA LWHAL	Settings available with the Intel FPGA Lightweight HAL BSP or any BSP based on it.
Intel FPGA HAL	Settings available with the Intel FPGA HAL BSP or any BSP based on it (for example, Micrium MicroC/OS-II).
Micrium MicroC/OS-II	Settings available if using the Micrium MicroC/OS-II BSP. All Intel FPGA HAL BSP settings are also available because MicroC/OS-II is based on the Intel FPGA HAL BSP.
Intel FPGA BSP Makefile Generator	Settings available if using the Intel FPGA BSP makefile generator (generates the Makefile and <code>public.mk</code> files). These settings control the contents of makefile variables. This generator is always present in Intel FPGA HAL BSPs or any BSPs based on the Intel FPGA HAL.
Intel FPGA BSP Linker Script Generator	Settings available if using the Intel FPGA BSP linker script generator (generates the <code>linker.x</code> and <code>linker.h</code> files). This generator is always present in Intel FPGA HAL BSPs or any BSPs based on the Intel FPGA HAL.

Do not confuse BSP settings with BSP Tcl commands. This section covers BSP settings, including their types, meanings, and legal values.

Related Information

[Tcl Commands for BSP Settings](#) on page 466



16.3.2. Overview of Component and Driver Settings

The Nios II EDS includes a number of standard software packages and device drivers. All of the software packages, and several drivers, have settings that you can manipulate when creating a BSP. This section lists the packages and drivers that have settings.

You can enable a software package or driver in the Nios II BSP Editor.

Related Information

[Tcl Commands for BSP Settings](#) on page 466

16.3.2.1. Intel FPGA Host-Based File System Settings

The Intel FPGA host-based file system has one setting. If the Intel FPGA host-based file system is enabled, you must debug (not run) applications based on the BSP for the host-based file system to function. The host-based file system relies on the GNU debugger running on the host to provide host-based file operations.

The host-based file system enables debugging information in your project, by setting `APP_CFLAGS_OPTIMIZATION` to `-g` in the makefile.

To include the host-based file system in your BSP, enable the `altera_hostfs` software package.

16.3.2.2. Intel FPGA Read-Only Zip File System Settings

The Intel FPGA read-only zip file system has several settings. If the read-only zip file system is enabled, it adds `-DUSE_RO_ZIPFS` to `ALT_CPPFLAGS` in `public.mk`.

To include the read-only zip file system in your BSP, enable the `altera_ro_zipfs` software package.

16.3.2.3. Intel FPGA NicheStack TCP/IP - Nios II Edition Stack Settings

The Intel FPGA NicheStack TCP/IP Network Stack - Nios II Edition has several settings. The stack is only available in MicroC/OS-II BSPs. If the NicheStack TCP/IP stack is enabled, it adds `-DALT_INICHE` to `ALT_CPPFLAGS` in `public.mk`.

To include the NicheStack TCP/IP networking stack in your BSP, enable the `altera_iniche` software package.

16.3.2.4. Intel FPGA Avalon-MM JTAG UART Driver Settings

The Intel FPGA Avalon Memory-Mapped® (Avalon-MM) JTAG UART driver settings are available if the `altera_avalon_jtag_uart` driver is present. By default, this driver is used if your hardware system has an `altera_avalon_jtag_uart` module connected to it.

16.3.2.5. Intel FPGA Avalon-MM UART Driver Settings

The Intel FPGA Avalon-MM UART driver settings are available if the `altera_avalon_uart` driver is present. By default, this driver is used if your hardware system has an `altera_avalon_uart` module connected to it.

16.3.3. Settings Reference

This section lists all settings for BSPs, software packages, and device drivers.

hal.enable_instruction_related_exceptions_api

- **Identifier:** none
- **Type:** Boolean definition
- **Default Value:** false
- **Destination File:** none
- **Description:** Enables application program interface (API) for registering handlers to service instruction-related exceptions. These exception types can be generated if various processor options are enabled, such as the memory management unit (MMU), memory protection unit (MPU), or other advanced exception types. Enabling this setting increases the size of the exception entry code.
- **Restrictions:** none

hal.max_file_descriptors

- **Identifier:** none
- **Type:** Decimal number
- **Default Value:** 32
- **Destination File:** none
- **Description:** Determines the number of file descriptors statically allocated.
- **Restriction:** If `hal.enable_lightweight_device_driver_api` is true, there are no file descriptors so this setting is ignored. If `hal.enable_lightweight_device_driver_api` is false, this setting must be at least 4 because HAL needs a file descriptor for `/dev/null`, `/dev/stdin`, `/dev/stdout`, and `/dev/stderr`. This setting defines the value of `ALT_MAX_FD` in `system.h`.

hal.disable_startup_thread_sync

- **Identifier:** `ALT_DISABLE_STARTUP_THREAD_SYNC`
- **Type:** Boolean definition
- **Default Value:** false
- **Destination File:** `system.h`



- **Description:** Disables thread synchronization checking on startup. By default, startup code in **crt0.S** assumes that the `.rdata` section must be reloaded every time the system is reset. Thread 0 waits until the `.rdata` section is reloaded before executing initialization code.
- The `hal.disable_startup_thread_sync` setting allows you to disable this restriction in your BSP, if your software is written without initialized global or static variables. This setting might be useful if you develop assembly language, and want to take advantage of initialization code in **crt0.S**.
- **Restriction:** Do not disable startup thread synchronization under the following circumstances:
 - Your code uses initialized global or static variables
 - Your application uses memory management functions such as `alt_malloc()`, `alt_free()` and `alt_calloc()`

`hal.enable_small_stack`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** `lwhal.enable_small_stack` turns off a build warning that indicates the setting '`lwhal.thread_stack_size`' might be too small (< 384 for `printf`) for your application.
- **Restriction:** none

`hal.exclude_default_exception`

- **Identifier:** `ALT_EXCLUDE_DEFAULT_EXCEPTION`
- **Type:** Boolean definition
- **Default Value:** false
- Destination File: `system.h`
- **Description:** Excludes default exception vector. If true, this setting defines the macro `ALT_EXCLUDE_DEFAULT_EXCEPTION` in `system.h`.
- **Restriction:** none

`hal.sys_clk_timer`

- **Identifier:** none
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: none
- **Description:** Slave descriptor of the system clock timer device. This device provides a periodic interrupt ("tick") and is typically required for RTOS use. This setting defines the value of `ALT_SYS_CLK` in `system.h`.
- **Restriction:** none

hal.timestamp_timer

- Identifier: none
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: none
- **Description:** Slave descriptor of timestamp timer device. This device is used by Intel FPGA HAL timestamp drivers for high-resolution time measurement. This setting defines the value of ALT_TIMESTAMP_CLK in `system.h`.
- **Restriction:** none

ucosii.os_max_tasks

- Identifier: OS_MAX_TASKS
- **Type:** Decimal number
- **Default Value:** 10
- Destination File: `system.h`
- **Description:** Maximum number of tasks
- **Restriction:** none

ucosii.os_lowest_prio

- **Identifier:** OS_LOWEST_PRIO
- **Type:** Decimal number
- **Default Value:** 20
- Destination File: `system.h`
- **Description:** Lowest assignable priority
- **Restriction:** none

ucosii.os_thread_safe_newlib

- **Identifier:** OS_THREAD_SAFE_NEWLIB
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Thread safe C library
- **Restriction:** none

ucosii.miscellaneous.os_arg_chk_en

- **Identifier:** OS_ARG_CHK_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable argument checking
- **Restriction:** none



ucosii.miscellaneous.os_cpu_hooks_en

- **Identifier:** OS_CPU_HOOKS_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable MicroC/OS-II hooks
- **Restriction:** none

ucosii.miscellaneous.os_debug_en

- **Identifier:** OS_DEBUG_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable debug variables
- **Restriction:** none

ucosii.miscellaneous.os_sched_lock_en

- **Identifier:** OS_SCHED_LOCK_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSSchedLock() and OSSchedUnlock()
- **Restriction:** none

ucosii.miscellaneous.os_task_stat_en

- **Identifier:** OS_TASK_STAT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable statistics task
- **Restriction:** none

ucosii.miscellaneous.os_task_stat_stk_chk_en

- **Identifier:** OS_TASK_STAT_STK_CHK_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Check task stacks from statistics task
- **Restriction:** none

ucosii.miscellaneous.os_tick_step_en

- **Identifier:** OS_TICK_STEP_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable tick stepping feature for uCOS-View
- **Restriction:** none

ucosii.miscellaneous.os_event_name_size

- **Identifier:** OS_EVENT_NAME_SIZE
- **Type:** Decimal number
- **Default Value:** 32
- Destination File: `system.h`
- **Description:** Size of name of Event Control Block groups
- **Restriction:** none

ucosii.miscellaneous.os_max_events

- **Identifier:** OS_MAX_EVENTS
- **Type:** Decimal number
- **Default Value:** 60
- Destination File: `system.h`
- **Description:** Maximum number of event control blocks
- **Restriction:** none

ucosii.miscellaneous.os_task_idle_stk_size

- **Identifier:** OS_TASK_IDLE_STK_SIZE
- **Type:** Decimal number
- **Default Value:** 512
- Destination File: `system.h`
- **Description:** Idle task stack size
- **Restriction:** none

ucosii.miscellaneous.os_task_stat_stk_size

- **Identifier:** OS_TASK_STAT_STK_SIZE
- **Type:** Decimal number
- **Default Value:** 512
- Destination File: `system.h`
- **Description:** Statistics task stack size
- **Restriction:** none



ucosii.task.os_task_change_prio_en

- **Identifier:** OS_TASK_CHANGE_PRIO_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSTaskChangePrio()
- **Restriction:** none

ucosii.task.os_task_create_en

- **Identifier:** OS_TASK_CREATE_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSTaskCreate()
- **Restriction:** none

ucosii.task.os_task_create_ext_en

- **Identifier:** OS_TASK_CREATE_EXT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSTaskCreateExt()
- **Restriction:** none

ucosii.task.os_task_del_en

- **Identifier:** OS_TASK_DEL_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSTaskDel()
- **Restriction:** none

ucosii.task.os_task_name_size

- **Identifier:** OS_TASK_NAME_SIZE
- **Type:** Decimal number
- **Default Value:** 32
- **Destination File:** system.h
- **Description:** Size of task name
- **Restriction:** none

[ucosii.task.os_task_profile_en](#)

- **Identifier:** OS_TASK_PROFILE_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include data structure for run-time task profiling
- **Restriction:** none

[ucosii.task.os_task_query_en](#)

- **Identifier:** OS_TASK_QUERY_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTaskQuery
- **Restriction:** none

[ucosii.task.os_task_suspend_en](#)

- **Identifier:** OS_TASK_SUSPEND_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTaskSuspend() and OSTaskResume()
- **Restriction:** none

[ucosii.task.os_task_sw_hook_en](#)

- **Identifier:** OS_TASK_SW_HOOK_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTaskSwHook()
- **Restriction:** none

[ucosii.time.os_time_tick_hook_en](#)

- **Identifier:** OS_TIME_TICK_HOOK_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTimeTickHook()
- **Restriction:** none

**ucosii.time.os_time_dly_resume_en**

- **Identifier:** OS_TIME_DLY_RESUME_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTimeDlyResume()
- **Restriction:** none

ucosii.time.os_time_dly_hmsm_en

- **Identifier:** OS_TIME_DLY_HMSM_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTimeDlyHMSM()
- **Restriction:** none

ucosii.time.os_time_get_set_en

- **Identifier:** OS_TIME_GET_SET_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Include code for OSTimeGet and OSTimeSet()
- **Restriction:** none

ucosii.os_flag_en

- **Identifier:** OS_FLAG_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** `system.h`
- **Description:** Enable code for Event Flags. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

ucosii.event_flag.os_flag_wait_clr_en

- **Identifier:** OS_FLAG_WAIT_CLR_EN
- **Type:** Boolean assignment
- **Default Value:** 1

- Destination File: `system.h`
- **Description:** Include code for Wait on Clear Event Flags. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.event_flag.os_flag_accept_en`

- **Identifier:** `OS_FLAG_ACCEPT_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSFlagAccept()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.event_flag.os_flag_del_en`

- **Identifier:** `OS_FLAG_DEL_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSFlagDel()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.event_flag.os_flag_query_en`

- **Identifier:** `OS_FLAG_QUERY_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSFlagQuery()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.event_flag.os_flag_name_size`

- **Identifier:** `OS_FLAG_NAME_SIZE`
- **Type:** Decimal number
- **Default Value:** 32



- Destination File: `system.h`
- **Description:** Size of name of Event Flags group. CAUTION: This is required by the HAL and many Intel FPGA device drivers; use caution in reducing this value.
- **Restriction:** none

`ucosii.event_flag.os_flags_nbits`

- **Identifier:** `OS_FLAGS_NBITS`
- **Type:** Decimal number
- **Default Value:** 16
- Destination File: `system.h`
- **Description:** Event Flag bits (8,16,32). CAUTION: This is required by the HAL and many Intel FPGA device drivers; use caution in changing this value.
- **Restriction:** none

`ucosii.event_flag.os_max_flags`

- **Identifier:** `OS_MAX_FLAGS`
- **Type:** Decimal number
- **Default Value:** 20
- Destination File: `system.h`
- **Description:** Maximum number of Event Flags groups. CAUTION: This is required by the HAL and many Intel FPGA device drivers; use caution in reducing this value.
- **Restriction:** none

`ucosii.os_mutex_en`

- **Identifier:** `OS_MUTEX_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable code for Mutex Semaphores
- **Restriction:** none

`ucosii.mutex.os_mutex_accept_en`

- **Identifier:** `OS_MUTEX_ACCEPT_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSMutexAccept()`
- **Restriction:** none

ucosii.mutex.os_mutex_del_en

- **Identifier:** OS_MUTEX_DEL_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMutexDel()
- **Restriction:** none

ucosii.mutex.os_mutex_query_en

- **Identifier:** OS_MUTEX_QUERY_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMutexQuery
- **Restriction:** none

ucosii.os_sem_en

- **Identifier:** OS_SEM_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable code for semaphores. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

ucosii.semaphore.os_sem_accept_en

- **Identifier:** OS_SEM_ACCEPT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSSemAccept(). This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

ucosii.semaphore.os_sem_set_en

- **Identifier:** OS_SEM_SET_EN
- **Type:** Boolean assignment
- **Default Value:** 1



- Destination File: `system.h`
- **Description:** Include code for `OSSemSet()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.semaphore.os_sem_del_en`

- **Identifier:** `OS_SEM_DEL_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSSemDel()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.semaphore.os_sem_query_en`

- **Identifier:** `OS_SEM_QUERY_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSSemQuery()`. This setting is enabled by default in MicroC-OS/II BSPs, because it is required for correct functioning of Intel FPGA device drivers and the HAL in a multithreaded environment. Avoid disabling it.
- **Restriction:** none

`ucosii.os_mbox_en`

- **Identifier:** `OS_MBOX_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable code for mailboxes
- **Restriction:** none

`ucosii.mailbox.os_mbox_accept_en`

- **Identifier:** `OS_MBOX_ACCEPT_EN`
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for `OSMboxAccept()`
- **Restriction:** none

ucosii.mailbox.os_mbox_del_en

- **Identifier:** OS_MBOX_DEL_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMboxDel()
- **Restriction:** none

ucosii.mailbox.os_mbox_post_en

- **Identifier:** OS_MBOX_POST_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMboxPost()
- **Restriction:** none

ucosii.mailbox.os_mbox_post_opt_en

- **Identifier:** OS_MBOX_POST_OPT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMboxPostOpt()
- **Restriction:** none

ucosii.mailbox.os_mbox_query_en

- **Identifier:** OS_MBOX_QUERY_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSMboxQuery()
- **Restriction:** none

ucosii.os_q_en

- **Identifier:** OS_Q_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Enable code for Queues
- **Restriction:** none



ucosii.queue.os_q_accept_en

- **Identifier:** OS_Q_ACCEPT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSQAccept()
- **Restriction:** none

ucosii.queue.os_q_del_en

- **Identifier:** OS_Q_DEL_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSQDel()
- **Restriction:** none

ucosii.queue.os_q_flush_en

- **Identifier:** OS_Q_FLUSH_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSQFlush()
- **Restriction:** none

ucosii.queue.os_q_post_en

- **Identifier:** OS_Q_POST_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code of OSQFlush()
- **Restriction:** none

ucosii.queue.os_q_post_front_en

- **Identifier:** OS_Q_POST_FRONT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: `system.h`
- **Description:** Include code for OSQPostFront()
- **Restriction:** none

ucosii.queue.os_q_post_opt_en

- **Identifier:** OS_Q_POST_OPT_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSQPostOpt()
- **Restriction:** none

ucosii.queue.os_q_query_en

- **Identifier:** OS_Q_QUERY_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSQQuery()
- **Restriction:** none

ucosii.queue.os_max_qs

- **Identifier:** OS_MAX_QS
- **Type:** Decimal number
- **Default Value:** 20
- **Destination File:** system.h
- **Description:** Maximum number of Queue Control Blocks
- **Restriction:** none

ucosii.os_mem_en

- **Identifier:** OS_MEM_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Enable code for memory management
- **Restriction:** none

ucosii.memory.os_mem_query_en

- **Identifier:** OS_MEM_QUERY_EN
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** system.h
- **Description:** Include code for OSMemQuery()
- **Restriction:** none

**ucosii.memory.os_mem_name_size**

- **Identifier:** OS_MEM_NAME_SIZE
- **Type:** Decimal number
- **Default Value:** 32
- **Destination File:** `system.h`
- **Description:** Size of memory partition name
- **Restriction:** none

ucosii.memory.os_max_mem_part

- **Identifier:** OS_MAX_MEM_PART
- **Type:** Decimal number
- **Default Value:** 60
- **Destination File:** `system.h`
- **Description:** Maximum number of memory partitions
- **Restriction:** none

ucosii.os_tmr_en

- **Identifier:** OS_TMR_EN
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** `system.h`
- **Description:** Enable code for timers
- **Restriction:** none

ucosii.timer.os_task_tmr_stk_size

- **Identifier:** OS_TASK_TMR_STK_SIZE
- **Type:** Decimal number
- **Default Value:** 512
- **Destination File:** `system.h`
- **Description:** Stack size for timer task
- **Restriction:** none

ucosii.timer.os_task_tmr_prio

- **Identifier:** OS_TASK_TMR_PRIO
- **Type:** Decimal number
- **Default Value:** 2
- **Destination File:** `system.h`
- **Description:** Priority of timer task (0=highest)
- **Restriction:** none

ucosii.timer.os_tmr_cfg_max

- **Identifier:** OS_TMR_CFG_MAX
- **Type:** Decimal number
- **Default Value:** 16
- Destination File: `system.h`
- **Description:** Maximum number of timers
- **Restriction:** none

ucosii.timer.os_tmr_cfg_name_size

- **Identifier:** OS_TMR_CFG_NAME_SIZE
- **Type:** Decimal number
- **Default Value:** 16
- Destination File: `system.h`
- **Description:** Size of timer name
- **Restriction:** none

ucosii.timer.os_tmr_cfg_ticks_per_sec

- **Identifier:** OS_TMR_CFG_TICKS_PER_SEC
- **Type:** Decimal number
- **Default Value:** 10
- Destination File: `system.h`
- **Description:** Rate at which timer management task runs (Hz)
- **Restriction:** none

ucosii.timer.os_tmr_cfg_wheel_size

- **Identifier:** OS_TMR_CFG_WHEEL_SIZE
- **Type:** Decimal number
- **Default Value:** 2
- Destination File: `system.h`
- **Description:** Size of timer wheel (number of spokes)
- **Restriction:** none

altera_avalon_uart_driver.enable_small_driver

- **Identifier:** ALTERA_AVALON_UART_SMALL
- **Type:** Boolean definition
- **Default Value:** false
- Destination File: `public.mk`
- **Description:** Small-footprint (polled mode) driver
- **Restriction:** none



altera_avalon_uart_driver.enable_ioctl

- **Identifier:** ALTERA_AVALON_UART_USE_IOCTL
- **Type:** Boolean definition
- **Default Value:** false
- **Destination File:** `public.mk`
- **Description:** Enable driver `ioctl()` support. This feature is not compatible with the small driver; `ioctl()` support is not compiled if either the UART `enable_small_driver` or the HAL `enable_reduced_device_drivers` setting is enabled.
- **Restriction:** none

altera_avalon_jtag_uart_driver.enable_small_driver

- **Identifier:** ALTERA_AVALON_JTAG_UART_SMALL
- **Type:** Boolean definition
- **Default Value:** false
- **Destination File:** `public.mk`
- **Description:** Small-footprint (polled mode) driver
- **Restriction:** none

altera_hostfs.hostfs_name

- **Identifier:** ALTERA_HOSTFS_NAME
- **Type:** Quoted string
- **Default Value:** `/mnt/host`
- **Destination File:** `system.h`
- **Description:** Mount point
- **Restriction:** none

altera_iniche.iniche_default_if

- **Identifier:** INICHE_DEFAULT_IF
- **Type:** Quoted string
- **Default Value:** `NOT_USED`
- **Destination File:** `system.h`
- **Description:** Deprecated setting: Default media access control (MAC) interface. This setting is used in some legacy Intel FPGA networking examples. It is not needed in new projects. If this setting appears in an existing project, Intel FPGA recommends that you make any necessary changes to remove it. This setting might be removed in a future release.
- **Restriction:** none

altera_iniche.enable_dhcp_client

- **Identifier:** DHCP_CLIENT
- **Type:** Boolean definition
- **Default Value:** true

- Destination File: `system.h`
- **Description:** Use dynamic host configuration protocol (DHCP) to automatically assign Internet protocol (IP) address
- **Restriction:** none

`altera_iniche.enable_ip_fragments`

- **Identifier:** `IP_FRAGMENTS`
- **Type:** Boolean definition
- **Default Value:** `true`
- Destination File: `system.h`
- **Description:** Reassemble IP packet fragments
- **Restriction:** none

`altera_iniche.enable_include_tcp`

- **Identifier:** `INCLUDE_TCP`
- **Type:** Boolean definition
- **Default Value:** `true`
- Destination File: `system.h`
- **Description:** Enable Transmission Control Protocol (TCP)
- **Restriction:** none

`altera_iniche.enable_tcp_zerocopy`

- **Identifier:** `TCP_ZEROCOPY`
- **Type:** Boolean definition
- **Default Value:** `false`
- Destination File: `system.h`
- **Description:** Use TCP zero-copy
- **Restriction:** none

`altera_iniche.enable_net_stats`

- **Identifier:** `NET_STATS`
- **Type:** Boolean definition
- **Default Value:** `false`
- Destination File: `system.h`
- **Description:** Enable statistics
- **Restriction:** none

`altera_ro_zipfs.ro_zipfs_name`

- **Identifier:** `ALTERA_RO_ZIPFS_NAME`
- **Type:** Quoted string
- **Default Value:** `/mnt/rozipfs`



- Destination File: `system.h`
- **Description:** Mount point
- **Restriction:** none

`altera_ro_zipfs.ro_zipfs_offset`

- **Identifier:** `ALTERA_RO_ZIPFS_OFFSET`
- **Type:** Hexadecimal number
- **Default Value:** `0x100000`
- Destination File: `system.h`
- **Description:** Offset of file system from base of flash
- **Restriction:** none

`altera_ro_zipfs.ro_zipfs_base`

- **Identifier:** `ALTERA_RO_ZIPFS_BASE`
- **Type:** Hexadecimal number
- **Default Value:** `0x0`
- Destination File: `system.h`
- **Description:** Base address of flash memory device
- **Restriction:** none

`hal.linker.allow_code_at_reset`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: none
- **Description:** Indicates if initialization code is allowed at the reset address. If true, defines the macro `ALT_ALLOW_CODE_AT_RESET` in `linker.h`.
- **Restriction:** This setting is typically false if an external bootloader (e.g. flash bootloader) is present.

`hal.linker.enable_alt_load`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 1
- Destination File: none
- **Description:** Enables the `alt_load()` facility. The `alt_load()` facility copies sections from the `.text` memory into RAM. If true, this setting sets up the VMA/LMA (virtual memory address/low memory address) of sections in `linker.x` to allow them to be loaded into the `.text` memory.
- **Restriction:** This setting is typically false if an external bootloader (e.g. flash bootloader) is present.

hal.linker.enable_alt_load_copy_exceptions

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** none
- **Description:** Causes the alt_load() facility to copy the .exceptions section. If true, this setting defines the macro ALT_LOAD_COPY_EXCEPTIONS in linker.h.
- **Restriction:** none

hal.linker.enable_alt_load_copy_rodata

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** none
- **Description:** Causes the alt_load() facility to copy the .rodata section. If true, this setting defines the macro ALT_LOAD_COPY_RODATA in linker.h.
- **Restriction:** none

hal.linker.enable_alt_load_copy_rwdata

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** none
- **Description:** Causes the initialization code to copy the .rwdata section. If true, this setting defines the macro ALT_LOAD_COPY_RWDATA in linker.h.
- **Restriction:** none

hal.linker.enable_exception_stack

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** none
- **Description:** Enables use of a separate exception stack. If true, defines the macro ALT_EXCEPTION_STACK in linker.h, adds a memory region called exception_stack to linker.x, and provides the symbols __alt_exception_stack_pointer and __alt_exception_stack_limit in linker.x.
- **Restriction:** The hal.linker.exception_stack_size and hal.linker.exception_stack_memory_region_name settings must also be valid. This setting must be false for MicroC/OS-II BSPs. The exception stack can be used to improve interrupt and other exception performance if an EIC is not implemented.



hal.linker.exception_stack_memory_region_name

- **Identifier:** none
- **Type:** Unquoted string
- **Default Value:** none
- **Destination File:** none
- **Description:** Name of the existing memory region to be divided up to create the `exception_stack` memory region. The selected region name is adjusted automatically when the BSP is generated to create the `exception_stack` memory region.
- **Restriction:** Only used if `hal.linker.enable_exception_stack` is true.

hal.linker.exception_stack_size

- **Identifier:** none
- **Type:** Decimal number
- **Default Value:** 1024
- **Destination File:** none
- **Description:** Size of the exception stack in bytes.
- **Restriction:** Only used if `hal.linker.enable_exception_stack` is true. none

hal.linker.enable_interrupt_stack

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** none
- **Description:** Enables use of a separate interrupt stack. If true, defines the macro `ALT_INTERRUPT_STACK` in `linker.h`, adds a memory region called `interrupt_stack` to `linker.x`, and provides the symbols `__alt_interrupt_stack_pointer` and `__alt_interrupt_stack_limit` in `linker.x`.
- **Restriction:** The `hal.linker.interrupt_stack_size` and `hal.linker.interrupt_stack_memory_region_name` settings must also be valid. This setting must be false for MicroC/OS-II BSPs. Only enable this setting for systems with an EIC. If an EIC is not implemented, use the separate exception stack to improve interrupt and other exception performance.

.linker.interrupt_stack_memory_region_name

- **Identifier:** none
- **Type:** Unquoted String
- **Default Value:** none

- Destination File: none
- **Description:** Name of the existing memory region that is divided up to create the `interrupt_stack` memory region. The selected region name is adjusted automatically when the BSP is generated to create the `interrupt_stack` memory region.
- **Restriction:** Only used if `hal.linker.enable_interrupt_stack` is true.
none

`hal.linker.interrupt_stack_size`

- **Identifier:** none
- **Type:** Decimal Number
- **Default Value:** 1024
- Destination File: none
- **Description:** Size of the interrupt stack in bytes.
- **Restriction:** Only used if `hal.linker.enable_interrupt_stack` is true.

`hal.make.ar`

- **Identifier:** AR
- **Type:** Unquoted string
- **Default Value:** `nios2-elf-ar`
- Destination File: BSP makefile
- **Description:** Archiver command. Creates library files.
- **Restriction:** none

`hal.make.ar_post_process`

- **Identifier:** AR_POST_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed after archiver execution.
- **Restriction:** none

`hal.make.ar_pre_process`

- **Identifier:** AR_PRE_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before archiver execution.
- **Restriction:** none

**hal.make.as**

- **Identifier:** AS
- **Type:** Unquoted string
- **Default Value:** nios2-elf-gcc
- Destination File: BSP makefile
- **Description:** Assembler command. Note that CC is used for Nios II assembly language source files (**.S**).
- **Restriction:** none

hal.make.as_post_process

- **Identifier:** AS_POST_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed after each assembly file is compiled.
- **Restriction:** none

hal.make.as_pre_process

- **Identifier:** AS_PRE_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before each assembly file is compiled.
- **Restriction:** none

hal.make.bsp_arflags

- **Identifier:** BSP_ARFLAGS
- **Type:** Unquoted string
- **Default Value:** -src
- Destination File: BSP makefile
- **Description:** Custom flags only passed to the archiver. This content of this variable is directly passed to the archiver rather than the more standard ARFLAGS. The reason for this is that GNU Make assumes some default content in ARFLAGS. This setting defines the value of BSP_ARFLAGS in Makefile.
- **Restriction:** none

hal.make.bsp_asflags

- **Identifier:** BSP_ASFLAGS
- **Type:** Unquoted string
- **Default Value:** -Wa,-gdwarf2

- Destination File: BSP makefile
- **Description:** Custom flags only passed to the assembler. This setting defines the value of BSP_ASFLAGS in Makefile.
- **Restriction:** none

hal.make.bsp_cflags_debug

- **Identifier:** BSP_CFLAGS_DEBUG
- **Type:** Unquoted string
- **Default Value:** -g
- Destination File: BSP makefile
- **Description:** C/C++ compiler debug level. -g provides the default set of debug symbols typically required to debug a typical application. Omitting -g removes debug symbols from the .elf file. This setting defines the value of BSP_CFLAGS_DEBUG in Makefile.
- **Restriction:** none

hal.make.bsp_cflags_defined_symbols

- **Identifier:** BSP_CFLAGS_DEFINED_SYMBOLS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Preprocessor macros to define. A macro definition in this setting has the same effect as a #define in source code. Adding -DALT_DEBUG to this setting has the same effect as #define ALT_DEBUG in a source file. Adding -DFOO=1 to this setting is equivalent to the macro #define FOO 1 in a source file. Macros defined with this setting are applied to all .S, C source (.c), and C++ files in the BSP. This setting defines the value of BSP_CFLAGS_DEFINED_SYMBOLS in the BSP makefile.
- **Restriction:** none

hal.make.bsp_cflags_optimization

- **Identifier:** BSP_CFLAGS_OPTIMIZATION
- **Type:** Unquoted string
- **Default Value:** -O0
- Destination File: BSP makefile
- **Description:** C/C++ compiler optimization level. -O0 = no optimization, -O2 = normal optimization, etc. -O0 is recommended for code that you want to debug since compiler optimization can remove variables and produce non-sequential execution of code while debugging. This setting defines the value of BSP_CFLAGS_OPTIMIZATION in Makefile.
- **Restriction:** none



hal.make.bsp_cflags_undefined_symbols

- **Identifier:** BSP_CFLAGS_UNDEFINED_SYMBOLS
- **Type:** Unquoted string
- **Default Value:** none
- **Destination File:** BSP makefile
- **Description:** Preprocessor macros to undefine. Undefined macros are similar to defined macros, but replicate the `#undef` directive in source code. To undefine the macro `FOO` use the syntax `-u FOO` in this setting. This is equivalent to `#undef FOO` in a source file. Note: the syntax differs from macro definition (there is a space, i.e. `-u FOO` versus `-DFOO`). Macros defined with this setting are applied to all `.S`, `.c`, and C++ files in the BSP. This setting defines the value of `BSP_CFLAGS_UNDEFINED_SYMBOLS` in the BSP Makefile.
- **Restriction:** none

hal.make.bsp_cflags_user_flags

- **Identifier:** BSP_CFLAGS_USER_FLAGS
- **Type:** Unquoted string
- **Default Value:** none
- **Destination File:** BSP makefile
- **Description:** Custom flags passed to the compiler when compiling C, C++, and `.S` files. This setting defines the value of `BSP_CFLAGS_USER_FLAGS` in Makefile.
- **Restriction:** none

hal.make.bsp_cflags_warnings

- **Identifier:** BSP_CFLAGS_WARNINGS
- **Type:** Unquoted string
- **Default Value:** `-Wall`
- **Destination File:** BSP makefile
- **Description:** C/C++ compiler warning level. `-Wall` is commonly used. This setting defines the value of `BSP_CFLAGS_WARNINGS` in Makefile.
- **Restriction:** none

hal.make.bsp_cxx_flags

- **Identifier:** BSP_CXXFLAGS
- **Type:** Unquoted string
- **Default Value:** none
- **Destination File:** BSP makefile
- **Description:** Custom flags only passed to the C++ compiler. This setting defines the value of `BSP_CXXFLAGS` in Makefile.
- **Restriction:** none

hal.make.bsp_inc_dirs

- **Identifier:** BSP_INC_DIRS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Space separated list of extra include directories to scan for header files. Directories are relative to the top-level BSP directory. The -I prefix is added by the makefile, therefore you must not include it in the setting value. This setting defines the value of BSP_INC_DIRS in the makefile.
- **Restriction:** none

hal.make.build_post_process

- **Identifier:** BUILD_POST_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed after BSP built.
- **Restriction:** none

hal.make.build_pre_process

- **Identifier:** BUILD_PRE_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before BSP built.
- **Restriction:** none

hal.make.cc

- **Identifier:** CC
- **Type:** Unquoted string
- **Default Value:** nios2-elf-gcc -xc
- Destination File: BSP makefile
- **Description:** C compiler command
- **Restriction:** none

hal.make.cc_post_process

- **Identifier:** CC_POST_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed after each .c or .S file is compiled.
- **Restriction:** none



hal.make.cc_pre_process

- **Identifier:** CC_PRE_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before each .c or .S file is compiled.
- **Restriction:** none

hal.make.cxx

- **Identifier:** CXX
- **Type:** Unquoted string
- **Default Value:** nios2-elf-gcc -xc++
- Destination File: BSP makefile
- **Description:** C++ compiler command
- **Restriction:** none

hal.make.cxx_post_process

- **Identifier:** CXX_POST_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before each C++ file is compiled.
- **Restriction:** none

hal.make.cxx_pre_process

- **Identifier:** CXX_PRE_PROCESS
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: BSP makefile
- **Description:** Command executed before each C++ file is compiled.
- **Restriction:** none

hal.make.ignore_system_derived.big_endian

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0

- Destination File: `public.mk`
- **Description:** Enable BSP generation to query if SOPC system is big endian. If true ignores export of 'ALT_CFLAGS += -meb' to `public.mk` if big endian system. If true ignores export of 'ALT_CFLAGS += -mel' if little endian system. This setting is intended for big endian Nios II processor and has no effect to default little endian Nios II processor.
- **Restriction:** none

Note: The `hal.make.ignore_system_derived.big_endian` setting is only available in Nios II EDS Standard version.

`hal.make.ignore_system_derived.fpu_present`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** Enable BSP generation to query if SOPC system has FPU present. If true ignores export of 'ALT_CFLAGS += -mhard-float' to `public.mk` if FPU is found in the system. If true ignores export of 'ALT_CFLAGS += -mhard-soft' if FPU is not found in the system.
- **Restriction:** none

`hal.make.ignore_system_derived.hardware_divide_present`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** Enable BSP generation to query if SOPC system has hardware divide present. If true ignores export of 'ALT_CFLAGS += -mno-hw-div' to `public.mk` if no division is found in system. If true ignores export of 'ALT_CFLAGS += -mhw-div' if division is found in the system.
- **Restriction:** none

`hal.make.ignore_system_derived.hardware_fp_cust_inst_divider_present`

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** Enable BSP generation to query if SOPC system floating point custom instruction with a divider is present. If true ignores export of 'ALT_CFLAGS += -mcustom-fpu-cfg=60-2' and 'ALT_LDFLAGS += -mcustom-fpu-cfg=60-2' to `public.mk` if the custom instruction is found in the system.
- **Restriction:** none



hal.make.ignore_system_derived.hardware_fp_cust_inst_no_divider_present

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Enable BSP generation to query if SOPC system floating point custom instruction without a divider is present. If true ignores export of 'ALT_CFLAGS += -mcustom-fpu-cfg=60-1' and 'ALT_LDFLAGS += -mcustom-fpu-cfg=60-1' to public.mk if the custom instruction is found in the system.
- **Restriction:** none

hal.make.ignore_system_derived.sopc_simulation_enabled

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Enable BSP generation to query if SOPC system has simulation enabled. If true ignores export of 'ELF_PATCH_FLAG += --simulation_enabled' to public.mk.
- **Restriction:** none

hal.make.ignore_system_derived.debug_core_present

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Enable BSP generation to query if SOPC system has a debug core present. If true ignores export of 'CPU_HAS_DEBUG_CORE = 1' to public.mk if a debug core is found in the system. If true ignores export of 'CPU_HAS_DEBUG_CORE = 0' if no debug core is found in the system.
- **Restriction:** none

hal.make.ignore_system_derived.hardware_multiplier_present

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Enable BSP generation to query if SOPC system has multiplier present. If true ignores export of 'ALT_CFLAGS += -mno-hw-mul' to public.mk if no multiplier is found in the system. If true ignores export of 'ALT_CFLAGS += -mhw-mul' if multiplier is found in the system.
- **Restriction:** none

hal.make.ignore_system_derived.hardware_mux_present

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: public.mk
- **Description:** Enable BSP generation to query if SOPC system has hardware mux present. If true ignores export of 'ALT_CFLAGS += -mno-hw-mulx' to public.mk if no mux is found in the system. If true ignores export of 'ALT_CFLAGS += -mhw-mulx' if mux is found in the system.
- **Restriction:** none

hal.make.ignore_system_derived.sopc_system_base_address

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: public.mk
- **Description:** Enable BSP generation to query SOPC system for system ID base address. If true ignores export of 'SOPC_SYSID_FLAG += --sidp=<address>' and 'ELF_PATCH_FLAG += --sidp=<address>' to public.mk.
- **Restriction:** none

hal.make.ignore_system_derived.sopc_system_id

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: public.mk
- **Description:** Enable BSP generation to query SOPC system for system ID. If true ignores export of 'SOPC_SYSID_FLAG += --id=<sysid>' and 'ELF_PATCH_FLAG += --id=<sysid>' to public.mk.
- **Restriction:** none

hal.make.ignore_system_derived.sopc_system_timestamp

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: public.mk
- **Description:** Enable BSP generation to query SOPC system for system timestamp. If true ignores export of 'SOPC_SYSID_FLAG += --timestamp=<timestamp>' and 'ELF_PATCH_FLAG += --timestamp=<timestamp>' to public.mk.
- **Restriction:** none



hal.make.rm

- **Identifier:** RM
- **Type:** Unquoted string
- **Default Value:** rm -f
- **Destination File:** BSP makefile
- **Description:** Command used to remove files when building the clean target.
- **Restriction:** none

hal.custom_newlib_flags

- **Identifier:** CUSTOM_NEWLIB_FLAGS
- **Type:** Unquoted string
- **Default Value:** none
- **Destination File:** public.mk
- **Description:** Build a custom version of newlib with the specified space-separated compiler flags.
- **Restriction:** The custom newlib build is placed in the <bsp root>/newlib directory, and is used only for applications that utilize this BSP.

hal.enable_c_plus_plus

- **Identifier:** ALT_NO_C_PLUS_PLUS
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** public.mk
- **Description:** Enable support for a subset of the C++ language. This option increases code footprint by adding support for C++ constructors. Certain features, such as multiple inheritance and exceptions are not supported. If false, adds -DALT_NO_C_PLUS_PLUS to ALT_CPPFLAGS in public.mk, and reduces code footprint.
- **Restriction:** none

hal.enable_clean_exit

- **Identifier:** ALT_NO_CLEAN_EXIT
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** public.mk
- **Description:** When your application exits, close file descriptors, call C++ destructors, etc. Code footprint can be reduced by disabling clean exit. If disabled, adds -DALT_NO_CLEAN_EXIT to ALT_CPPFLAGS and -Wl, --defsym, exit=_exit to ALT_LDFLAGS in public.mk.
- **Restriction:** none

hal.enable_exit

- **Identifier:** ALT_NO_EXIT
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** public.mk
- **Description:** Add exit() support. This option increases code footprint if your main() routine returns or calls exit(). If false, adds -DALT_NO_EXIT to ALT_CPPFLAGS in public.mk, and reduces footprint.
- **Restriction:** none

hal.enable_gprof

- **Identifier:** ALT_PROVIDE_GMON
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Causes code to be compiled with gprof profiling enabled and the application .elf file to be linked with the GPROF library. If true, adds -DALT_PROVIDE_GMON to ALT_CPPFLAGS and -pg to ALT_CFLAGS in public.mk.
- **Restriction:** none

hal.enable_lightweight_device_driver_api

- **Identifier:** ALT_USE_DIRECT_DRIVERS
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Enables lightweight device driver API. This reduces code and data footprint by removing the HAL layer that maps device names (e.g. /dev/uart0) to file descriptors. Instead, driver routines are called directly. The open(), close(), and lseek() routines always fail if called. The read(), write(), fstat(), ioctl(), and isatty() routines only work for the stdio devices. If true, adds -DALT_USE_DIRECT_DRIVERS to ALT_CPPFLAGS in public.mk.
- **Restriction:** The Intel FPGA Host and read-only ZIP file systems cannot be used if hal.enable_lightweight_device_driver_api is true.

hal.enable_mul_div_emulation

- **Identifier:** ALT_NO_INSTRUCTION_EMULATION
- **Type:** Boolean assignment
- **Default Value:** 0



- Destination File: `public.mk`
- **Description:** Adds code to the BSP to emulate multiply and divide instructions. This code is independent of any emulation code added by the C/C++ compiler. If false, adds `-DALT_NO_INSTRUCTION_EMULATION` to `ALT_CPPFLAGS` in `public.mk`. You do not normally need to enable this option, because the C/C++ compiler detects whether the target Nios II processor core supports the multiply and divide instructions directly. If you compile for a core that lacks support for the instructions, the HAL includes the required software emulation in its run-time libraries. However, you might need to enable `hal.enable_mul_div_emulation` under the following circumstances:
 - You expect to run the Nios II software on an implementation of the Nios II processor other than the one you compiled for. The best solution is to build your program for the correct Nios II processor implementation. Resort to the `hal.enable_mul_div_emulation` if it is not possible to determine the processor implementation at compile time.
 - You have assembly language code that uses an implementation-dependent instruction.
- **Restriction:** none

`hal.enable_reduced_device_drivers`

- **Identifier:** `ALT_USE_SMALL_DRIVERS`
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** Certain drivers are compiled with reduced functionality to reduce code footprint. Not all drivers observe this setting. If true, adds `-DALT_USE_SMALL_DRIVERS` to `ALT_CPPFLAGS` in `public.mk`. Typically, drivers support this setting with a polled mode. For example, the `altera_avalon_uart` and `altera_avalon_jtag_uart` reduced drivers operate in polled mode. Several device drivers are disabled entirely in reduced drivers mode. These include the `altera_avalon_cfi_flash`, `altera_avalon_epcs_flash_controller`, and `altera_avalon_lcd_16207` drivers. As a result, certain API routines fail (HAL flash access routines). You can define a symbol provided by each driver to prevent it from being removed.
- **Restriction:** none

`hal.enable_runtime_stack_checking`

- **Identifier:** `ALT_STACK_CHECK`
- **Type:** Boolean assignment
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** Turns on HAL runtime stack checking feature. Enabling this setting causes additional code to be placed into each subroutine call to generate an exception if a stack collision occurs with the heap or statically allocated data. If true, adds `-DALT_STACK_CHECK` and `-fstack-check` to `ALT_CPPFLAGS` in `public.mk`.
- **Restriction:** none

hal.enable_sim_optimize

- **Identifier:** ALT_SIM_OPTIMIZE
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** The BSP is compiled with optimizations to speedup HDL simulation such as initializing the cache, clearing the .bss section, and skipping long delay loops. If true, adds -DALT_SIM_OPTIMIZE to ALT_CPPFLAGS in public.mk.
- **Restriction:** When this setting is true, the BSP cannot run on hardware.

hal.enable_small_c_library

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 0
- **Destination File:** public.mk
- **Description:** Causes the small newlib (C library) to be used. This reduces code and data footprint at the expense of reduced functionality. Several newlib features are removed such as floating-point support in printf(), stdin input routines, and buffered I/O. The small C library is not compatible with Micrium MicroC/OS-II. If true, adds -msmallc to ALT_LDFLAGS and adds -DSMALL_C_LIB to ALT_CPPFLAGS in public.mk.
- **Restriction:** none

hal.enable_sopc_sysid_check

- **Identifier:** none
- **Type:** Boolean assignment
- **Default Value:** 1
- **Destination File:** public.mk
- **Description:** Enables system ID check. If a System ID component is connected to the processor associated with this BSP, the system ID check is enabled in the creation of command-line arguments to download an .elf file to the target. Otherwise, system ID and timestamp values are left out of public.mk for the application makefile download-elf target definition. With the system ID check disabled, the Nios II EDS tools do not automatically ensure that the application .elf file (and BSP it is linked against) corresponds to the hardware design on the target. If false, adds --accept-bad-sysid to SOPC_SYSID_FLAG in public.mk. Intel FPGA strongly recommends leaving hal.enable_sopc_sysid_check enabled. This setting is exposed to support rare cases in which FPGA logic resources are in extremely short supply. When the system ID check is disabled, the software is unable to detect whether the software is running on the correct hardware version. This situation can lead to subtle errors that are difficult to diagnose.
- **Restriction:** none



hal.log_port

- **Identifier:** LOG_PORT
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: `system.h`
- **Description:** Slave descriptor of debug logging character-mode device. If defined, it enables extra debug messages in the HAL source. This setting is used by the Intel FPGA logging functions.

hal.log_flags

- **Identifier:** ALT_LOG_FLAGS
- **Type:** Decimal Number
- **Default Value:** 0
- Destination File: `public.mk`
- **Description:** The value is assigned to ALT_LOG_FLAGS in the generated `public.mk`. Refer to **hal.log_port** for further details. The valid range of this setting is -1 through 3.

hal.stderr

- **Identifier:** STDERR
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: `public.mk`
- **Description:** Slave descriptor of STDERR character-mode device. This setting is used by the ALT_STDERR family of defines in `system.h`.

hal.stdin

- **Identifier:** STDIN
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: `system.h`
- **Description:** Slave descriptor of STDIN character-mode device. This setting is used by the ALT_STDIN family of defines in `system.h`.

hal.stdout

- **Identifier:** STDOUT
- **Type:** Unquoted string
- **Default Value:** none
- Destination File: `system.h`
- **Description:** Slave descriptor of STDOUT character-mode device. This setting is used by the ALT_STDOUT family of defines in `system.h`.

hal.thread_stack_size

- **Identifier:** ALT_THREAD_STACK_SIZE
- **Type:** Decimal number
- **Default Value:** The default value of lwhal.thread_stack_size is selected by the default Tcl script launched when a LWHAL BSP is created. lwhal.thread_stack_size is set to 3/4 of the size of the memory region to which the .stack section is assigned, if the region is shared with other sections (the default case).
- **Destination File:** system.h
- **Description:** Defines stack size for a thread (in bytes). This setting defines the value of ALT_THREAD_STACK_SIZE in system.h.
- **Restriction:** none

16.4. Application and User Library Makefile Variables

The Nios II SBT constructs application and makefile libraries for you, inserting makefile variables appropriate to your project configuration. You can control project build characteristics by manipulating makefile variables at the time of project generation. You control a variable with the `--set` command line option, as in the following example:

```
nios2-bsp hal my_bsp --set APP_CFLAGS_WARNINGS "-Wall"
```

The following utilities and scripts support modifying makefile variables with the `--set` option:

- **nios2-app-generate-makefile**
- **nios2-lib-generate-makefile**
- **nios2-app-update-makefile**
- **nios2-lib-update-makefile**
- **nios2-bsp**

16.4.1. Application Makefile Variables

You can modify the following application makefile variables on the command line:



- **CREATE_OBJDUMP**—Assign 1 to this variable to enable creation of an object dump file (.objdump) after linking the application. The **nios2-elf-objdump** utility is called to create this file. An object dump contains information about all object files linked into the .elf file. It provides a complete view of all code linked into your application. An object dump contains a disassembly view showing each instruction and its address.
- **OBJDUMP_INCLUDE_SOURCE**—Assign 1 to this variable to include source code inline with disassembled instructions in the object dump. When enabled, this includes the --source switch when calling the object dump executable. This is useful for debugging and examination of how the preprocessor and compiler generate instructions from higher level source code (such as C) or from macros.
- **OBJDUMP_FULL_CONTENTS**—Assign 1 to this variable to include a raw display of the contents of the .text linker section. When enabled, this variable includes the --full-contents switch when calling the object dump executable.
- **CREATE_elf_DERIVED_FILES**—Setting this variable to 1 creates the HDL simulation and onchip memory initialization files when you invoke the makefile with the all target. When this variable is 0 (the default), these files are only created when you make the mem_init_generate or mem_init_install target.

Note: Creating the HDL simulation and onchip memory initialization files increases project build time.

- **CREATE_LINKER_MAP**—Assign 1 to this variable to enable creation of a link map file (.map) after linking the application. A link map file provides information including which object files are included in the executable, the path to each object file, where objects and symbols are located in memory, and how the common symbols are allocated.
- **APP_CFLAGS_DEFINED_SYMBOLS**—This variable allows you to define macros using the -D argument, for example -D <macro name>. The contents of this variable are passed to the compiler and linker without modification.
- **APP_CFLAGS_UNDEFINED_SYMBOLS**—This variable allows you to remove macro definitions using the -U argument, for example -U <macro name>. The contents of this variable are passed to the compiler and linker without modification.
- **APP_CFLAGS_OPTIMIZATION**—The C/C++ compiler optimization level. For example, -O0 provides no optimization and -O2 provides standard optimization. -O0 is recommended for debugging code, because compiler optimization can remove variables and produce non-sequential execution of code while debugging.
- **APP_CFLAGS_DEBUG_LEVEL**—The C/C++ compiler debug level. -g provides the default set of debug symbols typically required to debug an application. Omitting -g omits debug symbols from the .elf.
- **APP_CFLAGS_WARNINGS**—The C/C++ compiler warning level. -Wall is commonly used, enabling all warning messages.

- `APP_CFLAGS_USER_FLAGS`
- `APP_INCLUDE_DIRS`—Use this variable to specify paths for the preprocessor to search. These paths commonly contain C header files (.h) that application code requires. Each path name is formatted and passed to the preprocessor with the `-I` option.
You can add multiple directories by enclosing them in double quotes, for example `--set APP_INCLUDE_DIRS "../my_includes ../../other_includes"`.
- `APP_LIBRARY_DIRS`—Use this variable to specify paths for additional libraries that your application links with.

Note: When you specify a user library path with `APP_LIBRARY_DIRS`, you also need to specify the user library names with the `APP_LIBRARY_NAMES` variable.

`APP_LIBRARY_DIRS` specifies only the directory where the user library file(s) are located, not the library archive file (.a) name.

Note: Do not use this variable to specify the path to a BSP or user library created with the SBT. The paths to these libraries are specified in `public.mk` files included in the application makefile.

You can add multiple directories by enclosing them in double quotes, for example `--set APP_LIBRARY_DIRS "../my_libs ../../other_libs"`.

- `APP_LIBRARY_NAMES`—Use this variable to specify the names of additional libraries that your application must link with. Library files are .a files.

Note: You do not specify the full name of the .a file. Instead, you specify the user library name `<name>`, and the SBT constructs the filename `lib<name>.a`. For example, if you add the string "math" to `APP_LIBRARY_NAMES`, the SBT assumes that your library file is named `libmath.a`.


Each specified user library name is passed to the linker with the `-l` option. The paths to locate these libraries must be specified in the `APP_LIBRARY_DIRS` variable.

Note: You cannot use this variable to specify a BSP or user library created with the SBT. The paths to these libraries are specified in `public.mk` file included in the application makefile.

- `BUILD_PRE_PROCESS`—This variable allows you to specify a command to be executed prior to building the application, for example,
`cp *.elf ../lastbuild.`
- `BUILD_POST_PROCESS`—This variable allows you to specify a command to be executed after building the application, for example,
`cp *.elf //production/test/nios2executables.`

16.4.2. User Library Makefile Variables

You can modify the following user library makefile variables on the command line:



- `LIB_CFLAGS_DEFINED_SYMBOLS`—This variable allows you to define macros using the `-D` argument, for example `-D <macro name>`. The contents of this variable are passed to the compiler and linker without modification.
- `LIB_CFLAGS_UNDEFINED_SYMBOLS`—This variable allows you to remove macro definitions using the `-U` argument, for example `-U <macro name>`. The contents of this variable are passed to the compiler and linker without modification.
- `LIB_CFLAGS_OPTIMIZATION`—The C/C++ compiler optimization level. For example, `-O0` provides no optimization and `-O2` provides standard optimization. `-O0` is recommended for debugging code, because compiler optimization can remove variables and produce non-sequential execution of code while debugging.
- `LIB_CFLAGS_DEBUG_LEVEL`—The C/C++ compiler debug level. `-g` provides the default set of debug symbols typically required to debug an application. Omitting `-g` omits debug symbols from the `.elf`.
- `LIB_CFLAGS_WARNINGS`—The C/C++ compiler warning level. `-Wall` is commonly used, enabling all warning messages.
- `LIB_CFLAGS_USER_FLAGS`
- `LIB_INCLUDE_DIRS`—You can add multiple directories by enclosing them in double quotes, for example `--set LIB_INCLUDE_DIRS ".../my_includes .../other_includes"`

16.4.3. Standard Build Flag Variables

The SBT creates makefiles supporting the following standard makefile command-line variables:

- `CFLAGS`
- `CPPFLAGS`
- `ASFLAGS`
- `CXXFLAGS`

You can define flags in these variables on the makefile command line, or in a script that invokes the makefile. The makefile passes these flags on to the corresponding GCC tool.

16.5. Software Build Tools Tcl Commands

Tcl commands are a crucial component of the Nios II SBT. Tcl commands allow you to exercise detailed control over BSP generation, as well as to define drivers and software packages. This section describes the Tcl commands, the environments in which they run, and how the commands work together.

16.5.1. Tcl Command Environments

The Nios II SBT supports Tcl commands in the following environments:

- **BSP setting specification**—In this environment, you manipulate BSP settings to control the static characteristics of the BSP. BSP setting commands are executed before the BSP is generated.
- **BSP generation callbacks**—In this environment, you exercise further control over BSP details, managing settings that interact with one another and with the hardware design. BSP callbacks run at BSP generation time.
- **Device driver and software package definition**—In this environment, you bundle source files into a custom driver or package. This process prepares the driver or package so that a BSP developer can include it in a BSP using the SBT.

The following sections describe each Tcl environment in detail, listing the available commands.

16.5.2. Tcl Commands for BSP Settings

There are two ways to use BSP Tcl commands to manipulate project settings:

- Calling the Tcl commands by using the `--cmd` option with the utilities **nios2-bsp-create-settings**, **nios2-bsp-update-settings**, and **nios2-bsp-query-settings**
- Adding the Tcl commands in a Tcl script specified with the `--script` option

Related Information

- [Settings Managed by the Software Build Tools](#) on page 423
For more information about the settings that are available in a Nios II project and the tools that you use to specify and manipulate these settings.
- [Nios II Software Build Tools Utilities](#) on page 396
For more information about how to call Tcl commands from utilities.
- [nios2-bsp-create-settings](#) on page 400
- [nios2-bsp-update-settings](#) on page 404
- [nios2-bsp-query-settings](#) on page 403

16.5.2.1. add_memory_device

Usage

```
add_memory_device <device name> <base address> <span>
```

Options

- **<device name>**: String with the name of the memory device.
- **<base address>**: The base address of the memory device. Hexadecimal or decimal string.
- ****: The size (span) of the memory device. Hexadecimal or decimal string.

Description

This command is provided to define a user-defined external memory device, outside the hardware system. Such a device would typically be mapped through a bridge component. This command adds an external memory device to the BSP's memory map, allowing the BSP to define memory regions and section mappings for the memory as if it were part of the system. The external memory device parameters are stored in the BSP settings file.



16.5.2.2. add_memory_region

Usage

```
add_memory_region <name> <slave_desc> <offset> <span>
```

Options

- **<name>**: String with the name of the memory region to create.
- **<slave_desc>**: String with the slave descriptor of the memory device for this region.
- **<offset>**: String with the byte offset of the memory region from the memory device base address.
- ****: String with the span of the memory region in bytes.

Description

Creates a new memory region for the linker script. This memory region must not overlap with any other memory region and must be within the memory range of the associated slave descriptor. The offset and span are decimal numbers unless prefixed with 0x.

Example

```
add_memory_region onchip_ram0 onchip_ram0 0 0x100000
```

16.5.2.3. add_section_mapping

Usage

```
add_section_mapping <section_name> <memory_region_name>
```

Options

- **<section_name>**: String with the name of the linker section.
- **<memory_region_name>**: String with the name of the memory region to map.

Description

Maps the specified linker section to the specified linker memory region. If the section does not already exist, `add_section_mapping` creates it. If it already exists, `add_section_mapping` overrides the existing mapping with the new one. The linker creates the section mappings in the order in which they appear in the linker script.

Example

```
add_section_mapping .text onchip_ram0
```

16.5.2.4. are_same_resource

Usage

```
are_same_resource <slave_desc1> <slave_desc2>
```

Options

- `<slave_desc1>`: String with the first slave descriptor to compare.
- `<slave_desc2>`: String with the second slave descriptor to compare.

Description

Returns a boolean value that indicates whether the two slave descriptors are connected to the same resource. To connect to the same resource, the two slave descriptors must be associated with the same module. The module specifies whether two slaves access the same resource or different resources within that module. For example, a dual-port memory has two slaves that access the same resource (the memory). However, you could create a module that has two slaves that access two different resources such as a memory and a control port.

16.5.2.5. delete_memory_region

Usage

```
delete_memory_region <region_name>
```

Options

- `<region_name>`: String with the name of the memory region to delete.

Description

Deletes the specified memory region. The region must exist to avoid an error condition.

16.5.2.6. delete_section_mapping

Usage

```
delete_section_mapping <section_name>
```

Options

- `<section_name>`: String with the name of the section.

Description

Deletes the specified section mapping.

Example

```
delete_section_mapping .text
```

16.5.2.7. disable_sw_package

Usage

```
disable_sw_package <software_package_name>
```

Options

- `<software_package_name>`: String with the name of the software package.



Description

Disables the specified software package. Settings belonging to the package are no longer available in the BSP, and associated source files are not included in the BSP makefile. It is an error to disable a software package that is not enabled.

16.5.2.8. enable_sw_package

Usage

```
enable_sw_package <software_package_name>
```

Options

- `<software_package_name>`: String with the name of the software package, with the version number optionally appended with a ':'.

Description

Enables a software package. Adds its associated source files and settings to the BSP. Specify the desired version in the form `<software_package_name>:<version>`. If you do not specify the version, `enable_sw_package` selects the latest available version.

Examples

- Example 1: `enable_sw_package altera_hostfs:7.2`
- Example 2: `enable_sw_package my_sw_package`

16.5.2.9. get_addr_span

Usage

```
get_addr_span <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns the address span (length in bytes) of the slave descriptor as an integer decimal number.

Example

```
puts [get_addr_span onchip_ram_64_kbytes] Returns: 65536
```

16.5.2.10. get_assignment

Usage

```
get_assignment <module_name> <assignment_name>
```

Options

- `<module_name>`: Module instance name to query for assignment
- `<assignment_name>`: Module instance assignment name to query for

Description

Returns the name of the value of the assignment for a specified module instance name.

Example

```
puts [get_assignment "cpu0"  
"embeddedsb.configuration.breakSlave"] Returns: memory_0.s0
```

16.5.2.11. get_available_drivers

Usage

```
get_available_drivers <module_name>
```

Options

- <module_name>: String with the name of the module to query.

Description

Returns a list of available device driver names that are compatible with the specified module instance. The list is empty if there are no drivers available for the specified slave descriptor. The format of each entry in the list is the driver name followed by a colon and the version number (if provided).

Example

```
puts [get_available_drivers jtag_uart] Returns:  
altera_avalon_jtag_uart_driver:7.2  
altera_avalon_jtag_uart_driver:6.1
```

16.5.2.12. get_available_sw_packages

Usage

```
get_available_sw_packages
```

Options

None

Description

Returns a list of software package names that are available for the current BSP. The format of each entry in the list is a string containing the package name followed by a colon and the version number (if provided).

Example

```
puts [get_available_sw_packages] Returns: altera_hostfs:7.2  
altera_ro_zipfs:7.2
```

16.5.2.13. get_base_addr

Usage

```
get_base_addr <slave_desc>
```



Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns the base byte address of the slave descriptor as an integer decimal number.

Example

```
puts [get_base_addr jtag_uart] Returns: 67616
```

16.5.2.14. `get_break_offset`

Usage

```
get_break_offset
```

Options

None

Description

Returns the byte offset of the processor break address.

Example

```
puts [get_break_offset] Returns: 32
```

16.5.2.15. `get_break_slave_desc`

Usage

```
get_break_slave_desc
```

Options

None

Description

Returns the slave descriptor associated with the processor break address. If null, then the break device is internal to the processor (debug module).

Example

```
puts [get_break_slave_desc] Returns: onchip_ram_64_kbytes
```

16.5.2.16. `get_cpu_name`

Usage

```
get_cpu_name
```

Options

None

Description

Returns the name of the BSP specific processor.

Example

```
puts [get_cpu_name] Returns: cpu_0
```

16.5.2.17. get_current_memory_regions**Usage**

```
get_current_memory_regions
```

Options

None

Description

Returns a sorted list of records representing the existing linker script memory regions. Each record in the list represents a memory region. Each record is a list containing the region name, associated memory device slave descriptor, offset, and span, in that order.

Example

```
puts [get_current_memory_regions] Returns: {reset onchip_ram0 0 32}  
{onchip_ram0 onchip_ram0 32 1048544}
```

16.5.2.18. get_current_section_mappings**Usage**

```
get_current_section_mappings
```

Options

None

Description

Returns a list of lists for all the current section mappings. Each list represents a section mapping with the format {section_name memory_region}. The order of the section mappings matches their order in the linker script.

Example

```
puts [get_current_section_mappings] Returns: {.text onchip_ram0}  
{.rodata onchip_ram0} {.rwddata onchip_ram0} {.bss onchip_ram0}  
{.heap onchip_ram0} {.stack onchip_ram0}
```

16.5.2.19. get_default_memory_regions**Usage**

```
get_default_memory_regions
```




Options

None

Description

Returns a sorted list of records representing the default linker script memory regions. The default linker script memory regions are the best guess for memory regions based on the reset address and exception address of the processor associated with the BSP, and all other processors in the system that share memories with the processor associated with the BSP. Each record in the list represents a memory region. Each record is a list containing the region name, associated memory device slave descriptor, offset, and span, in that order.

Example

```
puts [get_default_memory_regions]
```

Returns:

```
{reset onchip_ram0 0 32} {onchip_ram0 onchip_ram0 32 1048544}
```

16.5.2.20. get_driver

Usage

```
get_driver <module_name>
```

Options

- `<module_name>`: String with the name of the module instance to query.

Description

Returns the driver name associated with the specified module instance. The format is `<driver name>` followed by a colon and the version (if provided). Returns the string "none" if there is no driver associated with the specified module instance name.

Examples

- Example 1: `puts [get_driver jtag_uart]`

Returns:

```
altera_avalon_jtag_uart_driver:7.2
```

- Example 2: `puts [get_driver onchip_ram_64_kbytes]`

Returns:

```
none
```

16.5.2.21. get_enabled_sw_packages

Usage

```
get_enabled_sw_packages
```

Options

None

Description

Returns a list of currently enabled software packages. The format of each entry in the list is the software package name followed by a colon and the version number (if provided).

Example

```
puts [get_enabled_sw_packages]
```

Returns:

```
altera_hostfs:7.2
```

16.5.2.22. get_exception_offset**Usage**

```
get_exception_offset
```

Options

None

Description

Returns the byte offset of the processor exception address.

Example

```
puts [get_exception_offset]
```

Returns:

```
32
```

16.5.2.23. get_exception_slave_desc**Usage**

```
get_exception_slave_desc
```

Options

None

Description

Returns the slave descriptor associated with the processor exception address.

Example


```
puts [get_exception_slave_desc]
```

Returns:

```
onchip_ram_64_kbytes
```

16.5.2.24. get_fast_tlb_miss_exception_offset**Usage**

```
get_fast_tlb_miss_exception_offset
```

**Options**

None

Description

Returns the byte offset of the processor fast translation lookaside buffer (TLB) miss exception address. Only a processor with an MMU has such an exception address.

Example

```
puts [get_fast_tlb_miss_exception_offset]
```

Returns:

32

16.5.2.25. get_fast_tlb_miss_exception_slave_desc**Usage**

```
get_fast_tlb_miss_exception_slave_desc
```

Options

None

Description

Returns the slave descriptor associated with the processor fast TLB miss exception address. Only a processor with an MMU has such an exception address.

Example

```
puts [get_fast_tlb_miss_exception_slave_desc]
```

Returns:

onchip_ram_64_kbytes

16.5.2.26. get_interrupt_controller_id**Usage**

```
get_interrupt_controller_id <slave_desc>
```

Options

- <slave_desc>: String with the slave descriptor to query.

Description

Returns the interrupt controller ID of the slave descriptor (-1 if not a connected interrupt controller).

16.5.2.27. get_irq_interrupt_controller_id**Usage**

```
get_irq_interrupt_controller_id <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns the interrupt controller ID connected to the IRQ associated with the slave descriptor (-1 if none).

16.5.2.28. get_irq_number**Usage**

```
get_irq_number <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns the interrupt request number of the slave descriptor, or -1 if no interrupt request number is found.

16.5.2.29. get_memory_region**Usage**

```
get_memory_region <name>
```

Options

- `<name>`: String with the name of the memory region.

Description

Returns the linker script region information for the specified region. The format of the region is a list containing the region name, associated memory device slave descriptor, offset, and span in that order.

Example

```
puts [get_memory_region reset]
```

Returns:

```
reset onchip_ram0 0 32
```

16.5.2.30. get_module_class_name**Usage**

```
get_module_class_name <module_name>
```

Options

- `<module_name>`: String with the module instance name to query.

Description

Returns the name of the module class associated with the module instance.



Example

```
puts [get_module_class_name jtag_uart0]
```

Returns:

```
altera_avalon_jtag_uart
```

16.5.2.31. get_module_name

Usage

```
get_module_name <slave_desc>
```

Options

- <slave_desc>: String with the slave descriptor to query.

Description

Returns the name of the module instance associated with the slave descriptor. If a module with one slave, or if it has multiple slaves connected to the same resource, the slave descriptor is the same as the module name. If a module has multiple slaves that do not connect to the same resource, the slave descriptor consists of the module name followed by an underscore and the slave name.

Example

```
puts [get_module_name multi_jtag_uart0_s1]
```

Returns:

```
multi_jtag_uart0
```

16.5.2.32. get_reset_offset

Usage

```
get_reset_offset
```

Options

None

Description

Returns the byte offset of the processor reset address.

Example

```
puts [get_reset_offset]
```

Returns:

```
0
```

16.5.2.33. get_reset_slave_desc

Usage

```
get_reset_slave_desc
```

Options

None

Description

Returns the slave descriptor associated with the processor reset address.

Example

```
puts [get_reset_slave_desc]
```

Returns:

```
onchip_ram_64_kbytes
```

16.5.2.34. get_section_mapping**Usage**

```
get_section_mapping <section_name>
```

Options

- `<section_name>`: String with the section name to query.

Description

Returns the name of the memory region for the specified linker section. Returns null if the linker section does not exist.

Example

```
puts [get_section_mapping .text]
```

Returns:

```
onchip_ram0
```

16.5.2.35. get_setting**Usage**

```
get_setting <name>
```

Options

- `<name>`: String with the name of the setting to get.

Description

Returns the value of the specified BSP setting. `get_setting` returns boolean settings with the value 1 or 0. If the value of the setting is an empty string, `get_setting` returns "none".

The `get_setting` command is equivalent to the `--get` command-line option.

Example

```
puts [get_setting hal.enable_gprof]
```



Returns:
0

16.5.2.36. `get_setting_desc`

Usage

`get_setting_desc <name>`

Options

- `<name>`: String with the name of the setting to get the description for.

Description

Returns a string describing the BSP setting.

Example

```
puts [get_setting_desc hal.enable_gprof]
```

Returns:

```
"This example compiles the code with gprof profiling enabled and links \
the application .elf with the GPROF library. If true, adds \
-DALT_PROVIDE_GMON to ALT_CPPFLAGS and -pg to ALT_CFLAGS in public.mk."
```

16.5.2.37. `get_slave_descs`

Usage

`get_slave_descs`

Options

None

Description

Returns a sorted list of all the slave descriptors connected to the Nios II processor.

Example

```
puts [get_slave_descs]
```

Returns:

```
jtag_uart0 onchip_ram0
```

16.5.2.38. `is_char_device`

Usage

`is_char_device <slave_desc>`

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is a character device.

Examples

- Example 1: `puts [is_char_device jtag_uart]`
Returns:
1
- Example 2: `puts [is_char_device onchip_ram_64_kbytes]`
Returns:
0

16.5.2.39. `is_connected_interrupt_controller_device`

Usage

`is_connected_interrupt_controller_device <slave_desc>`

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is an interrupt controller device that is connected to the processor so that the interrupt controller sends interrupts to the processor.

16.5.2.40. `is_connected_to_data_master`

Usage

`is_connected_to_data_master <slave_desc>`

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is connected to a data master.

16.5.2.41. `is_connected_to_instruction_master`

Usage

`is_connected_to_instruction_master <slave_desc>`

Options

- `<slave_desc>`: String with the slave descriptor to query.



Description

Returns a boolean value that indicates whether the slave descriptor is connected to an instruction master.

16.5.2.42. `is_ethernet_mac_device`

Usage

```
is_ethernet_mac_device <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is an Ethernet MAC device.

16.5.2.43. `is_flash`

Usage

```
is_flash <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is a flash memory device.

16.5.2.44. `is_memory_device`

Usage

```
is_memory_device <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is a memory device.

Examples

- Example 1:

```
puts [is_memory_device jtag_uart]
```

Returns:
0
- Example 2:

```
puts [is_memory_device onchip_ram_64_kbytes]
```

Returns:
1

16.5.2.45. `is_non_volatile_storage`

Usage

```
is_non_volatile_storage <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is a non-volatile storage device.

16.5.2.46. `is_timer_device`

Usage

```
is_timer_device <slave_desc>
```

Options

- `<slave_desc>`: String with the slave descriptor to query.

Description

Returns a boolean value that indicates whether the slave descriptor is a timer device.

16.5.2.47. `log_debug`

Usage

```
log_debug <message>
```

Options

- `<message>`: String with message to log.

Description

Displays a message to the host's `stdout` when the logging level is debug.



16.5.2.48. log_default

Usage

log_default <message>

Options

- <message>: String with message to log.

Description

Displays a message to the host's stdout when the logging level is default or higher.

Example

```
log_default "This is a default message."
```

Displays:

```
INFO: Tcl message: "This is a default message."
```

16.5.2.49. log_error

Usage

log_error <message>

Options

- <message>: String with message to log.

Description

Displays a message to the host's stderr, regardless of logging level.

16.5.2.50. log_verbose

Usage

log_verbose <message>

Options

- <message>: String with message to log.

Description

Displays a message to the host's stdout when the logging level is verbose or higher.

16.5.2.51. set_driver

Usage

set_driver <driver_name> <module_name>

Options

- <driver_name>: String with the name of the device driver to use.
- <module_name>: String with the name of the module instance to set.

Description

Selects the specified device driver for the specified module instance. The `<driver_name>` argument includes a version number, delimited by a colon (:). If you omit the version number, `set_driver` uses the latest available version of the driver that is compatible with the component specified by the `<module_name>` argument.

If `<driver_name>` is `none`, the specified module instance does not use a driver. If `<driver_name>` is not `none`, it must be the name of the associated component class.

Examples

- Example 1:`set_driver altera_avalon_jtag_uart_driver:7.2 jtag_uart`
- Example 2:`set_driver none jtag_uart`

16.5.2.52. set_ignore_file

Usage

```
set_ignore_file <software_component_name> <file_name> <ignore>
```

Options

- `<software_component_name>`: Name of the driver, software package, or operating system to which the file belongs.
- `<file_name>`: Name of the file.
- `<ignore>`: Set to `true` to ignore (not generate or copy) the file, `false` to generate or copy the file normally.

Description

You can use this command to have a specific BSP file ignored (not generated or copied) during BSP generation. This command allows you to take ownership of a specific file, modify it, and prevent the SBT from overwriting your modifications.

`<software_component_name>` can have one of the following values:

- `<driver_name>`—The name of a driver, as specified with the `create_driver` command in the `*_sw.tcl` file that defines the driver. Specifies that `<file_name>` is a copied file associated with a device driver.
- `<software_package_name>`—The name of a software package, specified with the `create_sw_package` command in the `*_sw.tcl` file that defines the package. Specifies that `<file_name>` is a copied file associated with a software package.
- `<OS_name>`—The name of an OS, specified with the `create_os` command in the `*_sw.tcl` file that defines the OS, and is used in the **nios2-bsp-create-settings** to specify the BSP type. Specifies that `<file_name>` is a copied file associated with an OS.
- `generated`—Specifies that `<file_name>` is a generated top-level BSP file. The list of generated BSP files depends on the BSP type.

Note: For a list of generated files associated with a third-party OS, refer to the OS supplier's documentation.



Related Information

[Nios II Software Build Tools](#) on page 87

For more information about a list of generated files associated with HAL and MicroC/OS-II BSP

16.5.2.53. set_setting

Usage

```
set_setting <name> <value>
```

Options

- **<name>**: String with the name of the setting.
- **<value>**: String with the value of the setting.

Description

Sets the value for the specified BSP setting. Legal values for boolean settings are true, false, 1, and 0. Use the keyword none instead of an empty string to set a string to an empty value. The set_setting command is equivalent to the --set command-line option.

Example

```
set_setting hal.enable_gprof true
```

16.5.2.54. update_memory_region

Usage

```
update_memory_region <name> <slave_desc> <offset> <span>
```

Options

- **<name>**: String with the name of the memory region to update.
- **<slave_desc>**: String with the slave descriptor of the memory device for this region.
- **<offset>**: String with the byte offset of the memory region from the memory device base address.
- ****: String with the span of the memory region in bytes.

Description

Updates an existing memory region for the linker script. This memory region must not overlap with any other memory region and must be within the memory range of the associated slave descriptor. The offset and span are decimal numbers unless prefixed with 0x.

Example

```
update_memory_region onchip_ram0 onchip_ram0 0 0x100000
```

16.5.2.55. update_section_mapping

Usage

```
update_section_mapping <section_name> <memory_region_name>
```

Options

- *<section_name>*: String with the name of the linker section.
- *<memory_region_name>*: String with the name of the memory region to map.

Description

Updates the specified linker section. The linker creates the section mappings in the order in which they appear in the linker script.

Example

```
update_section_mapping .text onchip_ram0
```

16.5.2.56. add_default_memory_regions

Usage

```
add_default_memory_regions
```

Description

Defaults the BSP to use default linker script memory regions. The default linker script memory regions are the best guess for memory regions based on the reset address and exception address of the processor associated with the BSP, and all other processors in the system that share memories with the processor associated with the BSP.

16.5.2.57. create_bsp

Usage

```
create_bsp <bspType> <bsp version> <processor name> <sopcinfo>
```

Options

- *<bspType>*: Type of BSP to create.
- *<bsp version>*: Version of BSP software element to utilize.
- *<processor name>*: Name of processor instance for BSP
- *<sopcinfo>*: .sopcinfo generated file that describes the system the BSP is for.

Description

Creates a new BSP.

16.5.2.58. generate_bsp

Usage

```
generate_bsp <bspDir>
```



Options

- `<bspDir>`: BSP directory to generate files to.

Description

Generates a new BSP.

16.5.2.59. `get_available_bsp_type_versions`

Usage

```
get_available_bsp_type_versions <bsp_type> <sopcinfolpath>
```

Options

- `<bsp_type>`: BSP type identifier (e.g. hal, ucousii).
- `<sopcinfolpath>`: SOPC Information File path. Its parent folder might include custom BSP IP software components (*_sw.tcl).

Description

Gets the available BSP type versions.

16.5.2.60. `get_available_bsp_types`

Usage

```
get_available_bsp_types <sopcinfolpath>
```

Options

- `<sopcinfolpath>`: SOPC Information File path. Its parent folder might include custom BSP IP software components (*_sw.tcl).

Description

Gets the available BSP type identifiers.

16.5.2.61. `get_available_cpu_architectures`

Usage

```
get_available_cpu_architectures
```

Description

Gets the available processor architectures.

16.5.2.62. `get_available_cpu_names`

Usage

```
get_available_cpu_names <sopcinfolpath>
```

Options

- `<sopcinfolpath>`: SOPC Information File path that contains processor instances

Description

Gets the processor names given a SOPC system.

16.5.2.63. get_available_software

Usage

```
get_available_software <bsp_type> <filter> <sopcinfolpath>
```

Options

- <bsp_type>: BSP type identifier (e.g. hal, ucousii).
- <sopcinfolpath>: SOPC Information File path. Its parent folder might include custom BSP IP software components (*_sw.tcl).
- <filter>: A filter can be applied to restrict results. The following filters are available:
 - all
 - drivers
 - sw_packages
 - os_elements

Note: Comma-separated tokens are acceptable.

Description

Gets the available software (drivers, software packages, and bsp components) for a given BSP type.

16.5.2.64. get_available_software_setting_properties

Usage

```
get_available_software_setting_properties <setting_name>  
<software_name> <software_version> <sopcinfolpath>
```

Options

- <software_name>: Name of a software component (for example, "altera_avalon_uart_driver", or "hal").
- <software_version>: Enter "default" for latest version, or a specific version number.
- <setting_name>: Name of a selected software component setting to get properties for (e.g. hal.linker.allow_code_at_reset).
- <sopcinfolpath>: SOPC Information File path. Its parent folder might include custom BSP IP software components (*_sw.tcl).

Description

Gets the available setting names for a software component.



16.5.2.65. get_available_software_settings

Usage

```
get_available_software_settings <software_name> <software_version>  
<sopcinfolpath>
```

Options

- *<software_name>*: Name of a software component (e.g. altera_avalon_uart_driver).
- *<software_version>*: Enter "default" for latest version, or a specific version number.
- *<sopcinfolpath>*: SOPC Information File path. Its parent folder can include custom BSP IP software components (*_sw.tcl).

Description

Gets the available setting names for a software component.

16.5.2.66. get_bsp_version

Usage

```
get_bsp_version
```

Description

Gets the version of the BSP operating system software element.

16.5.2.67. get_cpu_architecture

Usage

```
get_cpu_architecture <processor_name> <sopcinfolpath>
```

Options

- *<processor_name>*: processor instance name
- *<sopcinfolpath>*: SOPC Information File path that contains processor_name instance

Description

Gets the processor architecture (e.g. nios2) of a specified processor instance given a SOPC system.

16.5.2.68. get_nios2_dpx_thread_num

Usage

```
get_nios2_dpx_thread_num
```

Description

If the BSP is mastered by a Nios II DPX processor, then this function returns the number of threads the processor supports. Otherwise it returns null.

16.5.2.69. get_sopcinfo_file

Usage

```
get_sopcinfo_file
```

Description

Returns the path of the BSP specific SOPC Information File.

16.5.2.70. get_supported_bsp_types

Usage

```
get_supported_bsp_types <processor_name> <sopcinfo_path>
```

Options

- *<processor_name>*: processor instance name
- *<sopcinfo_path>*: SOPC Information File path. Its parent folder can include custom BSP IP software components (*_sw.tcl).

Description

Gets the BSP types supported for a given processor and SOPC system.

16.5.2.71. is_bsp_hal_extension

Usage

```
is_bsp_hal_extension
```

Description

Returns a boolean value that indicates whether the BSP instantiated is of a type based on Intel FPGA HAL.

16.5.2.72. is_bsp_lwhal_extension

Usage

```
is_bsp_lwhal_extension
```

Description

Returns a boolean value that indicates whether the BSP instantiated is of a type based on Intel FPGA Lightweight HAL.

16.5.2.73. open_bsp

Usage

```
open_bsp <settingsFile>
```

Options

- *<settingsFile>*: .bsp settings file to open.



Description

Opens an existing BSP.

16.5.2.74. save_bsp

Usage

```
save_bsp <settingsFile>
```

Options

- `<settingsFile>`: .bsp settings file to save BSP to.

Description

Saves a new BSP.

16.5.2.75. set_bsp_version

Usage

```
set_bsp_version <version>
```

Options

- `<version>`: Version of BSP type software element to use.

Description

Sets the version of the BSP operating system software element to a specific value. The value "default" uses the latest version available. If this call is not used, the BSP is created using the 'default' BSP software element version.

16.5.2.76. set_logging_mode

Usage

```
set_logging_mode <mode>
```

Options

- `<mode>`: Logging Mode: 'silent', 'default', 'verbose', 'debug'

Description

Sets the verbosity level of the logger. Useful to eliminate tool informative messages

16.5.3. Tcl Commands for BSP Generation Callbacks

If you are defining a device driver or a software package, you can define Tcl callback functions to run whenever a BSP is generated containing your driver or package. Tcl callback functions enable you to create settings dynamically for the driver or package. This capability is essential when the driver or package settings must be customized to the hardware configuration, or to other BSP settings.

Tcl callback scripts are defined and controlled from the `*_sw.tcl` file associated with the driver or package. In `*_sw.tcl`, you can specify where the Tcl functions come from, when function runs, and the scope of each Tcl function's operation.

When the BSP is generated with your driver or software package, the settings you define in the callback scripts are inserted in `settings.bsp`.

You specify the source of the callback functions with the `set_sw_property` command, using the `callback_source_file` property.

A Tcl callback function can run at one of the following times:

- BSP initialization
- BSP generation
- BSP validation

Note: Although you can specify a new setting's value when you create the setting at BSP initialization, the setting's value can change between initialization and generation. For example, the BSP developer might edit the setting in the BSP Editor.

A Tcl callback can function in either of the following scopes:

- Component class
- Component instance

You specify each callback function's runtime environment by using the appropriate property in the `set_sw_property` command, as shown in the table, below.

Table 69. Callback Properties

Property as specified in <code>set_sw_property</code>	Run time	Scope	Callback Arguments
<code>initialization_callback</code>	Initialization	Component instance	Component instance name
<code>validation_callback</code>	Validation	Component instance	Component instance name
<code>generation_callback</code>	Generation	Component instance	<ul style="list-style-type: none"> • Component instance name • BSP generate target directory • Driver BSP subdirectory⁽¹⁵⁾
<code>class_initialization_callback</code>	Initialization	Component class	Driver class name
<code>class_validation_callback</code>	Validation	Component class	Driver class name
<code>class_generation_callback</code>	Generation	Component class	<ul style="list-style-type: none"> • Driver class name • BSP generate target directory • Driver BSP subdirectory⁽¹⁾

Tcl callbacks have access to a specialized set of commands, described in this section. In addition, Tcl callbacks can use any read-only BSP setting Tcl command.

Note: For more information about BSP setting Tcl commands, refer to the "Tcl Commands for BSP Settings" chapter. When a Tcl callback creates a setting, it can specify the value. However, callbacks cannot change the value of a pre-existing setting.

Related Information

[Tcl Commands for BSP Settings](#) on page 466

⁽¹⁵⁾ The BSP subdirectory into which the driver or package files are copied



16.5.3.1. add_class_sw_setting

Usage

```
add_class_sw_setting <setting-name> <setting-type>
```

Options

- *<setting-name>*: Name of the setting to persist in the BSP settings file. This is prepended with the driver class name associated with this callback script
- *<setting-type>*: Type of the setting to persist in the BSP settings file.

Description

Creates a BSP setting that is associated with a particular software driver element class. The `set_class_sw_setting_property` command is required to set the values for fields pertaining to a BSP software setting definition. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
add_class_sw_setting MY_FAVORITE_SETTING String
```

16.5.3.2. add_class_systemh_line

Usage

```
add_class_systemh_line <macro-name> <macro-value>
```

Options

- *<macro-name>*: Macro to be added to the system.h file for the generated BSP
- *<macro-value>*: Value associated with the macro-name to be added to the system.h file for the generated BSP

Description

This adds a system.h assignment or macro during a driver callback execution. The BSP typically uses this during the generate phase depending on the generator. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
add_class_systemh_line MY_MACRO "Macro_Value";
```

16.5.3.3. add_module_sw_property

Usage

```
add_module_sw_property <property-name> <property-value>
```

Options

- *<property-name>*: Name of the property to add to the BSP for a module instance
- *<property-value>*: Value of the property to add to the BSP for a module instance

Description

This adds a software property to the BSP driver of this module instance. The BSP typically uses this during the generate phase depending on the generator. This command is only valid for a callback script. A callback script is set in the driver's *_sw.tcl file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
add_module_sw_setting MY_FAVORITE_SETTING String
```

16.5.3.4. add_module_sw_setting

Usage

```
add_module_sw_setting <setting-name> <setting-type>
```

Options

- *<setting-name>*: Name of the setting to persist in the BSP settings file. This is prepended with the module name associated with this callback script
- *<setting-type>*: Type of the setting to persist in the BSP settings file.

Description

Creates a BSP setting that is associated with a particular instance of hardware module in a SOPC system. The `set_module_sw_setting_property` command is required to set the values for fields pertaining to a BSP software setting definition. This command is only valid for a callback script. A callback script is set in the driver's *_sw.tcl file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
add_module_sw_setting MY_FAVORITE_SETTING String
```

16.5.3.5. add_module_systemh_line

Usage

```
add_module_systemh_line <macro-name> <macro-value>
```

Options

- *<macro-name>*: Macro to be added to the `system.h` file for the generated BSP
- *<macro-value>*: Value associated with the macro-name to be added to the `system.h` file for the generated BSP



Description

This adds a `system.h` assignment or macro during a driver callback execution. The BSP typically uses this during the generate phase depending on the generator. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
add_module_systemh_line MY_MACRO "Macro_Value";
```

16.5.3.6. add_systemh_line

Usage

```
add_systemh_line <sw> <name> <value>
```

- `<sw>`: The software (OS) that the `system.h` text is associated with
- `<name>`: Name of macro to write into `system.h` (left-hand side of `#define`)
- `<value>`: Name of value to assign to macro in `system.h` (right-hand side of `#define`)

Description

Adds a line of text to the `system.h` file. The `<sw>` argument is the name of the software type (typically an operating system name) that the `system.h` text applies to. In the context of an operating system Tcl script, the name in the `create_os <name>` command must be used. The text is a name-value pair that creates a macro (`#define` statement) in the `system.h` file.

Note: This command can only be used by Tcl scripts that are registered to run at BSP generation time by an operating system.

Example

```
add_systemh_line UCOSII OS_TICKS_PER_SEC 100
```

16.5.3.7. get_class_peripheral

Usage

```
get_class_peripheral <instance-name> <irq-number>
```

Options

- `<instance-name>`: Name of EIC module instance to find connected peripheral for.
- `<irq-number>`: IRQ number to locate connected peripheral device

Description

This command is used on an EIC instance callback to obtain a peripheral slave descriptor connected to a specific IRQ port number. This command is only valid for a callback script.

Example

```
get_class_peripheral eic_1 $irq_2;
```

16.5.3.8. get_module_assignment**Usage**

```
get_module_assignment <assignment-name>
```

Options

- *<assignment-name>*: Name of the module assignment to retrieve the value for, as defined for the module instance in the .sopcinfo file

Description

Given a module assignment key, return the assignment value of a module associated with the callback script using this command. The callback script must be set in the *_sw.tcl file using the following command:

```
set_sw_property callback_source_file <filename>
```

Example

```
puts [get_module_assignment  
embeddedsw.configuration.isMemoryDevice]
```

Returns:

```
true
```

16.5.3.9. get_module_name**Usage**

```
get_module_name
```

Options

None

Description

Returns the name of the module associated with the callback script using this command. The callback script must be set in the *_sw.tcl file using the following command:

```
set_sw_property callback_source_file <filename>
```

Example

```
puts [get_module_name]
```

Returns:

```
jtag_uart
```

16.5.3.10. get_module_peripheral**Usage**

```
get_module_peripheral <irq-number>
```




Options

- *<irq-number>*: IRQ number to locate connected peripheral device

Description

This command is used on an EIC instance callback to obtain a peripheral slave descriptor connected to a specific IRQ port number. This command is only valid for a callback script.

Example

```
get_module_peripheral 2;
```

16.5.3.11. get_module_sw_setting_value

Usage

```
get_module_sw_setting_value <setting-name>
```

Options

- *<setting-name>*: Name of the module software setting to retrieve the value for, as defined by the `add_module_sw_setting` command.

Description

Given a module software setting name, return the setting value. The callback script using this command must be set in the `*_sw.tcl` file using the following command:

```
set_sw_property callback_source_file <filename>
```

You can use this command in a generation or validation callback to retrieve the current value of a setting created in an initialization callback.

Example

```
puts [get_module_sw_setting_value MY_SETTING]
```

Returns:

```
"My setting value"
```

16.5.3.12. get_peripheral_property

Usage

```
get_peripheral_property <slave-descriptor> <property-name>
```

Options

- *<slave-descriptor>*: Slave descriptor of a connected peripheral device
- *<property-name>*: Property name to query from the connected peripheral device

Description

This command is used on an EIC instance callback to obtain a connected peripheral property value. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
get_peripheral_property jtag_uart supports_preemption;
```

16.5.3.13. remove_class_systemh_line**Usage**

```
remove_class_systemh_line <macro-name>
```

Options

- *<macro-name>*: Macro to be removed to the system.h file for the generated BSP

Description

This removes a system.h assignment or macro during a driver callback execution. The BSP typically uses this during the generate phase depending on the generator. This command is only valid for a callback script. A callback script is set in the driver's *_sw.tcl file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
remove_class_systemh_line MY_MACRO;
```

16.5.3.14. remove_module_systemh_line**Usage**

```
remove_module_systemh_line <macro-name>
```

Options

- *<macro-name>*: Macro to be removed to the system.h file for the generated BSP

Description

This removes a system.h assignment or macro during a driver callback execution. The BSP typically uses this during the generate phase depending on the generator. This command is only valid for a callback script. A callback script is set in the driver's *_sw.tcl file, using the command `set_sw_property callback_source_file <filename>`.

Example

```
remove_module_systemh_line MY_MACRO;
```

16.5.3.15. set_class_sw_setting_property**Usage**

```
set_class_sw_setting_property <setting-name> <property> <value>
```



Options

- `<setting-name>`: Name of the setting to persist in the BSP settings file associated with the driver class of this callback script
- `<property>`: Name of the setting property to update
- `<value>`: Value of the setting property to update

Description

Update a driver class software setting property. The setting must be added using the `add_class_sw_setting` command before calling this method. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

You can set the following setting properties:

- `destination`
- `identifier`
- `value`
- `default_value`
- `description`
- `restrictions`
- `group`

Example

```
set_class_sw_setting_property MY_FAVORITE_SETTING default-value  
'42'
```

16.5.3.16. `set_module_sw_setting_property`

Usage

```
set_module_sw_setting_property <setting-name> <property> <value>
```

Options

- `<setting-name>`: Name of the setting to persist in the BSP settings file associated with the SOPC module of this callback script
- `<property>`: Name of the setting property to update
- `<value>`: Value of the setting property to update

Description

Update a module's software setting property. The setting must be added using the `add_module_sw_setting` command before calling this method. This command is only valid for a callback script. A callback script is set in the driver's `*_sw.tcl` file, using the command `set_sw_property callback_source_file <filename>`.

You can set the following setting properties:

- destination
- identifier
- value
- default_value
- description
- restrictions
- group

Example

```
set_module_sw_setting_property MY_FAVORITE_SETTING default-value  
'42'
```

16.5.4. Tcl Commands for Drivers and Packages

This section describes the tools that you use to specify and manipulate the settings and characteristics of a custom software package or driver. Typically, when creating a custom software package or device driver, or importing a package or driver from another development environment, you need these more powerful tools.

For more information about how to manipulate settings on existing software packages and device drivers, refer to [“Settings Managed by the Software Build Tools” on page 15–34](#).

For more information about how to manipulate settings on existing software packages and device drivers, refer to [“Tcl Commands for BSP Settings” on page 15–76](#).

A device driver and a software package are both collections of source files added to the BSP. A device driver is associated with a particular component class (for example, `altera_avalon_jtag_uart`). A software package is not associated with any particular component class, but implements a functionality such as TCP/IP.

To define a device driver or software package, you create a Tcl script defining its characteristics. This section describes the Tcl commands available to define device drivers and software packages.

For more information about creating Tcl scripts, refer to the “Tcl Scripts for BSP Settings” in the Nios II Software Build Tools section.

The following commands are available for device driver and software package creation:

- add_sw_property
- add_sw_setting
- add_sw_setting2
- create_driver
- create_os



- `create_sw_package`
- `set_sw_property`
- `set_sw_setting_property`

Related Information

- [Settings Managed by the Software Build Tools](#) on page 423
- [Tcl Commands for BSP Settings](#) on page 466
- [add_sw_property](#) on page 501
- [add_sw_setting](#) on page 503
- [create_driver](#) on page 506
- [create_os](#) on page 506
- [create_sw_package](#) on page 507
- [set_sw_property](#) on page 507

16.5.4.1. add_sw_property

Usage

`add_sw_property <property> <value>`

Options

- `<property>`: Name of property.
- `<value>`: Value assigned, or appended to the current value.

Description

This command defines a property for a device driver or software package. A property is a list of values (for example, a list of file names). The `add_sw_property` command defines a property if it is not already defined. The command appends a new value to the list of values if the property is already defined.


In the case of a property consisting of a file name or directory name, use a relative path. Specify the path relative to the directory containing the Tcl script.

This command supports the following properties:

`asm_source`

- Adds a Nios II assembly language source file (`.s` or `.S`) to BSPs containing your package. **nios2-bsp-generate-files** copies assembly source files into a BSP and adds them to the source build list in the BSP makefile. This property is optional.
- `c_source`—Adds a C source file (`.c`) to BSPs containing your package. **nios2-bsp-generate-files** copies C source files into a BSP and adds them to the source build list in the BSP makefile. This property is optional.
- `cpp_source`—Adds a C++ source file (`.cpp`, `.cc`, or `.cxx`) to BSPs containing your package. **nios2-bsp-generate-files** copies the C++ source files into a BSP and adds them to the source build list in the BSP makefile. This property is optional.

- `include_source`—Adds an include file (typically .h) to BSPs containing your package. **nios2-bsp-generate-files** copies include files into a BSP, but does not add them to the generated makefile. This property is optional.
- `include_directory`—Adds a directory to the `ALT_INCLUDE_DIRS` variable in the BSP's `public.mk` file. Adding a directory to `ALT_INCLUDE_DIRS` allows all source files to find include files in this directory. `add_sw_property` adds the path to the generated public makefile shared by the BSP and applications or libraries referencing it. `add_sw_property` compiles all files with the include directory listed in the compiler arguments. This property is optional.
- `lib_source`—Adds a precompiled library file (typically .a) to each BSP containing the driver or package. **nios2-bsp-generate-files** copies the precompiled library file into the BSP directory and adds both the library file name and the path (required to locate the library file) into the BSP's `public.mk` file. Applications using the BSP link with the library file. The library file name must conform to the following pattern: `lib<name>.a` where `<name>` is a nonempty string. Example: `add_sw_property lib_source HAL/lib/libcomponent.a` This property is optional.
- `specific_compatible_hw_version`—Specifies that the device driver only supports the specified component hardware version. See the `version` property of the `set_sw_property` command for information about version strings. This property applies only to device drivers (see the `create_driver` command), not to software packages. If your driver supports all versions of a peripheral after a specific release, use the `set_property min_compatible_hw_version` command instead. This property is optional. This property is only available for device drivers.
- `supported_bsp_type`—Adds a specific BSP type (operating system) to the list of supported operating systems that the driver or software package supports. Specify `HAL` if the software supports the Intel FPGA HAL, or operating systems that extend it. If your software is operating system-neutral and works on multiple HAL-based operating systems, state `HAL` only. If your software or driver contains code that depends on a particular operating system, state compatibility with that operating system only, but not `HAL`.
The name of another operating system to support must match the name of the operating system exactly. This operating system name string is the same as that used to create a BSP with the `nios2-bsp-*` commands, as well as in the `.tcl` script that describes the operating system, in its `create_os` command.
When you create a BSP with an operating system that extends `HAL`, such as `UCOSII`, and the BSP tools select a driver for a particular hardware module, precedence is given to drivers which state compatibility with a that specific operating system (OS) before a more generic driver stating `HAL` compatibility. This property is only available for device drivers and software packages. This property must be set to at least one operating system.
- `alt_cppflags_addition`—Adds a line of arbitrary text to the `ALT_CPPFLAGS` variable in the BSP `public.mk` file. This technique can be useful if you wish to have a static compilation flag or definition that all BSP, application, and library files receive during software build. This property is optional.



- `excluded_hal_source`—Specifies a file to exclude from the a BSP generated with an operating system that extends HAL. The value is the path to a BSP file to exclude, with respect to the BSP root. This property is optional.
- `systemh_generation_script`—Specifies a `.tcl` script to execute during generation of the BSP `system.h` file. This script runs with the tcl commands available to other BSP settings tcl scripts, and allow you to influence the contents of the `system.h` file. This property is available only to operating systems, created with the `create_os` command. This property is optional.
- `txt_source`--Adds a text file (.txt) to BSPs. Example: `add_sw_property txt_source files.txt`.

16.5.4.2. `add_sw_setting`

Usage

```
add_sw_setting <type> <destination> <displayName> <identifier>
<value> <description>
```

Options

- `<type>`: Setting type - Boolean, QuotedString, UnquotedString.
- `<destination>`: The destination BSP file associated with the setting, or the module generator that processes this setting.
- `<displayName>`: Setting name.
- `<identifier>`: Name of the macro created for a generated destination file.
- `<value>`: Default value of the setting.
- `<description>`: Setting description.

Description

This command creates a BSP setting associated with a software package or device driver. The setting is available whenever the software package or device driver is present in the BSP. **nios2-bsp-generate-files** converts the setting and its value into either a C preprocessor macro or BSP makefile variable. `add_sw_setting` passes macro definitions to the compiler using the `-D` command-line option, or adds them to the `system.h` file as `#define` statements.

The setting only exists once even if there are multiple instances of a software package. Set or get the setting with the `--set` and `--get` command-line options of the **nios2-bsp**, **nios2-bsp-create-settings**, **nios2-bsp-query-settings**, and **nios2-bsp-update-settings** commands. You can also use the BSP Tcl commands `set_setting` and `get_setting` to set or get the setting. The value of the setting persists in the BSP settings file.

To create a setting, you must define each of the following parameters.

type—This parameter formats the setting value during BSP generation. The following supported types and usage restrictions apply:

- **boolean_define_only**—Defines a macro if the setting's value is 1 or true. Example: `#define LCD_PRESENT`. No macro is defined if the setting's value is 0 or false. This setting type supports the `system_h_define` and `public_mk_define` destinations, defined below.
- **boolean**—Defines a macro or makefile variable and sets it to 1 (if the value is 1 or true) or 0 (if the value is 0 or false). Example: `#define LCD_PRESENT 1`. This type supports all destinations.
- **character**—Defines a macro as a single character with single quotes around the character. Example: `#define DELIMITER ':'`. This type supports the `system_h_define` destination, defined below.
- **decimal_number**—Defines a macro or makefile variable and sets it with an unquoted decimal (integer) number. Example: `#define NUM_COPROCESSORS 3`. This type supports all destinations.
- **double**—Defines a macro name and sets it to a value with a decimal point. Example: `#define PI 3.1416`. This type supports the `system_h_define` destination, defined below.
- **float**—Defines a macro name and sets it to a value with a decimal point and `f` character. Example: `#define PI 3.1416f`. This type supports the `system_h_define` destination, defined below.
- **hex_number**—Defines a macro name and sets it to a value with a `0x` prepended to the value. Example: `#define LCD_SIZE 0x1000`. This type supports the `system_h_define` destination, defined below.
- **quoted_string**—Quoted strings always have the macro name and setting value added to the destination files. In the destination, the setting value is enclosed in quotation marks. Example: `#define DFLT_ERR "General error"`. If the setting value contains white space, you must place quotation marks around the value string in the Tcl script. This type supports the `system_h_define` destination, defined below.
- **unquoted_string**—Unquoted strings define a macro or makefile variable with setting name and value in the destination file. In the destination file, the setting value is not enclosed in quotation marks. Example: `#define DFLT_ERROR Error`. This type supports all destinations.



destination—The destination parameter specifies where `add_sw_setting` puts the setting in the generated BSP. `add_sw_settings` supports the following destinations:

- **system_h_define**—With this destination, `add_sw_settings` formats settings as `#define <setting name> [<setting value>]` macros in the `system.h` file
- **public_mk_define**—With this destination, `add_sw_settings` formats settings as `-D<setting name>[=<setting value>]` additions to the `ALT_CPPFLAGS` variable in the BSP `public.mk` file. `public.mk` passes the flag to the C preprocessor for each source file in the BSP, and in applications and libraries using the BSP.
- **makefile_variable**—With this destination, `add_sw_settings` formats settings as makefile variable additions to the BSP makefile. The variable name must be unique in the makefile.

displayName—The name of the setting. Settings exist in a hierarchical namespace. A period separates levels of the hierarchy. Settings created in your Tcl script are located in the hierarchy under the driver or software package name you specified in the `create_driver` or `create_sw_package` command. Example:
`my_driver.my_setting`. The Nios II SBT adds the hierarchical prefix to the setting name.

identifier—The name of the macro or makefile variable being defined. In a setting added to the `system.h` file at generation time, this parameter corresponds to the text immediately following the `#define` statement.

value—The default value associated with the setting. If you do not assign a value to the option, its value is this default value. Valid initial values are `TRUE`, `1`, `FALSE`, and `0` for boolean and `boolean_define_only` setting types, a single character for the character type, integer numbers for the `decimal_number` setting type, integer numbers with or without a `0x` prefix for the `hex_number` type, numbers with decimals for `float_number` and `double_number` types, or an arbitrary string of text for quoted and unquoted string setting types. For string types, if the value contains any white space, you must enclose it in quotation marks.

description—Descriptive text that is inserted along with the setting value and name in the `summary.html` file. You must enclose the description in quotation marks if it contains any spaces. If the description includes any special characters (such as quotation marks), you must escape them with the backslash (`\`) character. The description field is mandatory, but can be an empty string (`" "`).

16.5.4.3. add_sw_setting2

Usage

```
add_sw_setting2 <setting-name> <setting-type>
```

Options

- **<setting-name>**: Name of the setting to persist in the BSP settings file. This is prepended with BSP Type when persisted.
- **<setting-type>**: Type of the setting to persist in the BSP settings file.

Description

This command creates a BSP setting that is associated with a particular software component. The 'set_sw_setting_property' command is required to set the values for fields pertaining to a BSP software setting definition.

Example

```
add_sw_setting2 MY_FAVORITE_SETTING unquoted_string
```

16.5.4.4. create_driver

Usage

```
create_driver <name>
```

Options

- <name>: Name of device driver.

Description

This command creates a new device driver instance available for the Nios II SBT. This command must precede all others that describe the device driver in its Tcl script. You can only have one `create_driver` command in each Tcl script. If the `create_driver` command appears in the Tcl script, the `create_sw_package` and `create_os` commands cannot appear.

The name argument is usually distinct from all other device drivers and software packages that the SBT might locate. You can specify driver name identical to another driver if the driver you are describing has a unique version number assignment.

If your driver differs for different operating systems, you need to provide a unique name for each BSP type.

This command is required, unless you use the `create_sw_package` or `create_os` commands, as appropriate.

16.5.4.5. create_os

Usage

```
create_os <name>
```

Options

- <name>: Name of operating system (BSP type).

Description

This command creates a new operating system (OS) instance (also known as a BSP type) available for the Nios II BSP tools. This command must precede all others that describe the OS in its Tcl script. You can only have one `create_os` command in each Tcl script. If the `create_os` command appears in the Tcl script, the `create_driver` or `create_sw_package` commands cannot appear.



The name argument is usually distinct from all other operating systems that the SBT might locate. You can specify an OS name identical to OS if the OS you are describing has a unique version number assignment.

This command is required, unless you use the `create_driver` or `create_sw_package` commands, as appropriate.

16.5.4.6. `create_sw_package`

Usage

```
create_sw_package <name>
```

Options

- `<name>`: Name of the software package.

Description

This command creates a new software package instance available for the Nios II SBT. This command must precede all others that describe the software package in its Tcl script. You can only have one `create_sw_package` command in each Tcl script. If the `create_sw_package` command appears in the Tcl script, the `create_driver` or `create_os` commands cannot appear.

The name argument is usually distinct from all other device drivers and software packages that the SBT might locate. You can specify a name identical to another software package if the software package you are describing has a unique version number assignment.

If your software package differs for different operating systems, you need to provide a unique name for each BSP type.

This command is required, unless you use the `create_driver` or `create_os` commands, as appropriate.

16.5.4.7. `set_sw_property`

Usage

```
set_sw_property <property> <value>
```

Options

- `<property>`: Type of software property being set.
- `<value>`: Value assigned to the property.

Description

Sets the specified value to the specified property. The properties this command supports can only hold a single value. This command overwrites the existing (or default) contents of a particular property with the specified value. This command applies to device drivers and software packages.

This command supports the following properties:

- `hw_class_name`—The name of the hardware class which your device driver supports. The hardware class name is also the **Component Name** shown in the Component Editor. Example: `altera_avalon_uart`. This property is only available for device drivers. This property is required for all drivers.
- `version`—The version number of this package. `set_sw_property` uses version numbers to determine compatibility between hardware (peripherals) and their software (drivers), as well as to choose the most recent software or driver if multiple compatible versions are available. A version can be any alphanumeric string, but is usually a major and one or more minor revision integers. The dot (.) character separates major and minor revision numbers. Examples: 9.0, 5.0sp1, 3.2.11. This property is optional, but recommended. If you do not specify a version, the newest version of the package is used.
- `min_compatible_hw_version`—Specifies that the device driver supports the specified hardware version, or all greater versions. This property is only available for device drivers. If your device driver supports only one or more specific versions of a hardware class, use the `add_sw_property` `specific_compatible_hw_version` command instead. See the `version` property documentation for information about version strings. This property is optional. This property is only available for device drivers.
- `auto_initialize`—Boolean value that specifies `alt_sys_init.c` needs to initialize your package. If enabled, you must provide a header file containing `INSTANCE` and `INIT` macros.

This property is optional; if unspecified, `alt_sys_init.c` does not contain references to your driver or software. This property is only available for device drivers and software packages.
- `bsp_subdirectory`—Specifies the top-level directory where **nios2-bsp-generate-files** copies all source files for this package. This property is a path relative to the top-level BSP directory. This property is optional; if unspecified, **nios2-bsp-generate-files** copies the driver or software package into the **drivers** subdirectory of any BSP including this software.
- `alt_sys_init_priority`—This property assigns a priority to the software package or device driver. The value of this property must be a positive integer. Use this property to customize the order of macro calls in the BSP `alt_sys_init.c` file. Specifying the priority is useful if your software or driver must be initialized before or after other software in the system. For example, your driver might depend on another driver already being initialized.
This property is optional. The default priority is 1000. This property is only available for device drivers and software packages.
- `display_name`—This property is used for user interfaces and other tools that wish to show a human-readable name to identify the software being described in the `.tcl` script. `display_name` is set to a few words of text (in quotes) that name your software. For example: Intel FPGA Nios II driver.
This property is optional. If not set, tools that attempt to use the display name use the package name created with the appropriate `create_` command.



- `extends_bsp_type`—This property specifies which BSP type that an operating system (created with the `create_os` command) extends (if any). Currently, only the Intel FPGA HAL (HAL) is supported. This command is required for all operating systems that wish to use HAL-compatible generators in the Nios II BSP tools. It is also required for operating systems that require the Intel FPGA HAL, device driver, or software package source files that are HAL compatible in BSPs created with that operating system. An operating system that extends HAL is presumed to be compatible with device drivers that support HAL. This command is only available for operating systems.
- `callback_source_file`—This property specifies a Tcl source file containing callback functions.
- `initialization_callback`—This property specifies the name of a Tcl callback function which is intended to run in the following environment:
 - Run time: initialization
 - Scope: component instance
 - Function argument(s): component instance name
- `validation_callback`—This property specifies the name of a Tcl callback function which is intended to run in the following environment:
 - Run time: validation
 - Scope: component instance
 - Function argument(s): component instance name
- `generation_callback`—This property specifies the name of a callback function which is intended to run in the following environment:
 - Run time: generation
 - Scope: component instance
 - Function argument(s): component instance name, BSP generate target directory, driver BSP subdirectory
- `class_initialization_callback`—This property specifies the name of a callback function which is intended to run in the following environment:
 - Run time: initialization
 - Scope: component instance
 - Function argument(s): driver class name

- `class_validation_callback`—This property specifies the name of a callback function which is intended to run in the following environment:
 - Run time: validation
 - Scope: component instance
 - Function argument(s): driver class name
- `class_generation_callback`—This property specifies the name of a callback function which is intended to run in the following environment:
 - Run time: generation
 - Scope: component instance
 - Function argument(s): driver class name, BSP generate target directory, driver BSP subdirectory
- `supported_interrupt_apis`—Specifies the interrupt API that the device driver supports. Specify `legacy_interrupt_api` if the device driver supports the legacy API only or `enhanced_interrupt_api` if the device driver supports the enhanced API only. Specify both using a quoted list if the device driver supports both APIs.

If you do not specify which API your device driver supports, the Nios II SBT assumes that only the legacy interrupt API is supported. The Nios II SBT analyzes this property for each driver in the system to determine the appropriate API to be used in the system.

Note: This property is only available for device drivers.

- `isr_preemption_supported`—Specify true if your device driver ISR can be preempted by a higher priority ISR. If you do not specify whether ISR preemption is supported, the Nios II SBT assumes that your device driver does not support preemption. If your driver does not have an ISR, but the associated device has an interrupt port, you can set this property to true.

Note: This property is valid for operating systems and device drivers.

Related Information

[Nios II Software Build Tools](#) on page 87

For more information about the legacy and enhanced APIs, refer to "Exception Handling".

16.5.4.8. set_sw_setting_property

Usage

```
set_sw_setting_property <setting-name> <property-name> <property-value>
```

Options

- `<setting-name>`: Name of the setting to persist in the BSP settings file.
- `<property-name>`: Name of the setting property to update.
- `<property-value>`: Value of the setting property to update.



Description

Update a software components setting property. The setting must already be added using 'add_sw_setting2' command before calling this method.

Example

```
set_sw_setting_property MY_FAVORITE_SETTING default-value '42'
```

16.6. Software Build Tools Path Names

There are some restrictions on how you can specify file paths when working with the Nios II SBT. The tools are designed for the maximum possible compatibility with a variety of computing environments. By following the restrictions in this section, you can ensure that the build tools work smoothly with other tools in your tool chain.

16.6.1. Command Arguments

Many Nios II software build tool commands take file name and directory path arguments. You can provide these arguments in any of several supported cross-platform formats. The Nios II SBT supports the following path name formats:

- **Quoted Windows**—A drive letter followed by a colon, followed by directory names delimited with backslashes, surrounded by double quotes. Example of a quoted Windows absolute path: "c:\altera\72\nios2eds\examples\verilog\niosII_cyclone_1c20\standard"
Quoted Windows relative paths omit the drive letter, and begin with two periods followed by a backslash. Example:
"..\niosII_cyclone_1c20\standard"
- **Escaped Windows**—The same as quoted Windows, except that each backslash is replaced by a double backslash, and the double quotes are omitted. Examples: c:\altera\72\nios2eds\examples\verilog\niosII_cyclone_1c20\standard ..\niosII_cyclone_1c20\standard
- **Linux**—An optional forward slash, followed by directory names delimited with forward slashes. Examples: /altera/72/nios2eds/examples/verilog/niosII_cyclone_1c20/standard
Linux relative paths begin with two periods followed by a forward slash. Example: ../niosII_cyclone_1c20/standard
- **Mixed**—The same as quoted Windows, except that each backslash is replaced by a forward slash, and the double quotes are omitted. Examples: c:/altera/72/nios2eds/examples/verilog/niosII_cyclone_1c20/standard ../niosII_cyclone_1c20/standard
- **Cygwin**—An absolute Cygwin path consists of the pseudo-directory name "/cygdrive/", followed by the lower case Windows drive name, followed by directory names delimited with forward slashes. Example: /cygdrive/c/altera/72/nios2eds/examples/verilog/niosII_cyclone_1c20/standard
Cygwin relative paths are the same as Linux relative paths. Example: ../niosII_cyclone_1c20/standard

The Nios II SBT accepts both relative and absolute path names.

Table 70. Path Name Format Support for Nios II SBT utilities and makefiles

Context	Formats supported on Linux ⁽¹⁶⁾	Formats supported on Windows with Cygwin
Utilities and scripts	Linux	<ul style="list-style-type: none"> Quoted Windows ⁽¹⁷⁾ Mixed Escaped Windows Cygwin
Makefiles	Linux	<ul style="list-style-type: none"> Mixed⁽¹⁸⁾ Cygwin

16.6.2. Object File Directory Tree

The makefile created by the Nios II SBT creates a new directory tree for generated object files. To the extent possible, the object file directory tree retains the structure of the corresponding source directory.

For example, if you specify the path to a source file as
`src/util/special/tools.c`

the makefile places the corresponding object code in
`obj/util/special/tools.o`

The makefile does not create object directories outside the project directory root. If the source file path you specify is a relative path beginning with ". . .", the Nios II SBT flattens the path name prior to creating the object directory structure.

For example, if you specify the path to a source file as
`../special/tools.c`

the makefile places the corresponding object code in
`obj/tools.o`

If you specify an absolute path to source files under Cygwin, the Nios II SBT creates the `obj` directory structure as if you had used the Cygwin form of the path name. For example, if you specify the path to a source file as
`c:/dev/app/special/tools.c`

the Nios II SBT places the corresponding object code in
`obj/cygdrive/c/dev/app/special/tools.o`

Related Information

[Nios II Embedded Software Projects](#) on page 90

For more information about the object file directory structure.

⁽¹⁶⁾ These rules apply to any Unix-like platform.

⁽¹⁷⁾ These rules apply to other Unix-like shells running on Windows. The Nios II Command Shell, provided with the Nios II EDS, is based on Cygwin. Examples in this chapter are designed for the Nios II Command Shell.

⁽¹⁸⁾ The build tools automatically convert path names to Cygwin format.