

2017/1/13

Category	Chapter	Command	Function	All	Execute		Query	
					PAN	TILT	PAN	TILT
Position Control	4.1	Position (absolute)			PP<position><delim>	TP<position><delim>	PP<delim>	TP<delim>
	4.2	Offset Position (relative offset)			PO<position><delim>	TO<position><delim>	PO<delim>	TO<delim>
	4.3	Resolution per Position					PR<delim>	TR<delim>
	4.4	Limit Position Queries	minimum maximum				PN<delim>	TN<delim>
	4.5	Position Limit Enforcement	enable disable	LE<delim> LD<delim>			PX<delim>	TX<delim>
	4.6	Immediate Position Execution Mode		I<delim>				
		Slaved Position Execution Mode		S<delim>				
	4.7	Await Position Command Completion		A<delim>				
	4.8	Halt Command		H<delim>	HP<delim>	HT<delim>		
	4.9	Monitor (Autoscan) Command	pan only	M<pan pos 1><pan pos 2><delim>				
			both axis	M<pan pos 1><pan pos 2><tilt pos 1><tilt pos 2><delim>				
	4.10		enable disable status	ME<delim> MD<delim>			MQ<delim> MS<delim>	
	4.11	Position Presets	set preset go to preset clear preset	XS<index><delim> XG<index><delim> XC<index><delim>				
	4.12	PTU Speed/Position		B<pan pos><tilt pos><pan speed><tilt speed><delim>				
Speed Control	5.1	Speed (absolute)			PS<positions/sec><delim>	TS<positions/sec><delim>	PS<delim>	TS<delim>
	5.2	Delta Speed (relative offset)			PD<positions/sec><delim>	TD<positions/sec><delim>	PD<delim>	TD<delim>
	5.3	Acceleration			PA<positions/sec2><delim>	TA<positions/sec2><delim>	PA<delim>	TA<delim>
	5.4	Base (Start-Up) Speed			PB<positions/sec><delim>	TB<positions/sec><delim>	PB<delim>	TB<delim>
	5.5	Speed Bounds	upper lower query	PU<positions/sec><delim> PL<positions/sec><delim> C<delim>		TL<positions/sec><delim>	PU<delim>	TU<delim>
	5.6	Speed Control Modes	independent pure velocity	CI<delim> CV<delim>				
Continuous Axis Rotation	6.1	Stationary Power Mode	enable disable	PCE<delim> PCD<delim>			PC<delim>	
User-Defined Limits	7.1	Position Limit Queries	execute disable minimum maximum user minimum user maximum	R<delim> RD<delim>			PN<delim> PX<delim> PNU<value><delim> PXU<value><delim>	TN<delim> TX<delim> TNU<value><delim> TXU<value><delim>
			enable factory limits enable user defined disable	LE<delim> LU<delim> LD<delim>				
			execute disable enable save restore	R<delim> RD<delim> RE<delim> DS<delim> DR<delim>	RP<delim>	RT<delim>		
			factory defaults	DF<delim>				
	7.2	Position Limit Enforcement	query enable disable	EE<delim> ED<delim>				
Unit Commands	8.1	Reset Pan-Tilt Unit	query enable disable enable save restore	EE<delim> ED<delim> RE<delim> DS<delim> DR<delim>				
	8.2	Default Save/Restore	factory defaults	DF<delim>				
	8.3	Echo Query/Enable/Disable	query enable disable	EE<delim> ED<delim>				
	8.4	Feedback Verbose/Terse/Off	query verbose terse	FV<delim> FT<delim>				
	8.5	Query PTU Firmware Version						
		Query PTU Short Firmware Version						
		Query PTU model number						
		Query PTU serial number						
	8.6	Supply Voltage and Temperature						
Power Control	9.1	Stationary Power Mode	regular low off	PHR<delim> PHL<delim> PHO<delim>	THR<delim> THL<delim> THO<delim>		PH<delim>	TH<delim>
			high	PMH<delim>	TMH<delim>			
			regular low	PMR<delim> PML<delim>	TMR<delim> TML<delim>		PM<delim>	TM<delim>
	9.2	In-Motion Power Mode						
Host Serial Port	10.1	Configuring Host Serial Port		@<baud><byte delay in msec><startup default><delim>				
Expanded I/O	11.1	Establish communications	PortA PortB	@A<delim> @B<delim>				
	11.2	Resume communications with the PTU		@<delim>				
ASCII TTL Control	11.3	Establish communications	PortA PortB	@A<baud><data bits><parity><handshaking><delim> @B<baud><data bits><parity><handshaking><delim>				
			TTL high TTL low	OOH<n><delim> OOL<n><delim>				
Step Modes	12.1	Configuring Step Mode			WP<resolution><delim>	WT<resolution><delim>	WP<delim>	WT<delim>
PTU Serial Network	13.1	Set PTU to interactive mode		U0<delim>				
	13.2	Set PTU network unit ID		U<Unit ID><delim>				
	13.2	Unit Select/Deselect	Unit Select Broadcast to all network	<unit ID><delim> 0<delim>				
IP Network	14.1	MAC Address		NA<mac address><delim>			NA<delim>	
	14.2	IP Address		NI<ip address><delim>			NI<delim>	
	14.3	Network Mode	Dinamic network mode Static network mode	NMD<delim> NMS<delim>				
	14.4	Redirect Port	TCP UDP	NRT80<newport><delim> NRU4000<newport><delim>			NRT80<delim> NRU4000<delim>	
	14.5	Network Gateway		NG<ip address><delim>			NG<delim>	
	14.6	Network Host Name		NN<hostname><delim>			NN<delim>	
	14.7	Network Mask		NS<subnet><delim>			NS<delim>	
Control Modes	15.1	Control Modes	Query current control mode Set open loop Set encoder correction					
			Query the number of corrections					
							GPEC<delim>	CTEC<delim>
Geo Pointing	17	See Command Reference Manual						
Pelco-D	18.1	Pelco-D Configuration	Query Pelco-D parsing Enable Pelco-D parsing Disable Pelco-D parsing Pelco-D Address					
				QPE<delim> QPD<delim> QPA<n><delim>				