

## \*How to use

### Digital Panel



1. To activate the Timer in a Digital panel



2. Place Main Switch in position 1, press and hold Deck ON/OFF button until the green lamp is turned on

### Classic Panel



1. To activate the Timer in a Classic panel



2. Place the Main Switch in A position

\*Note: The Timer is not configured from factory. You need to follow "Timer Set Up" and "Program Set Up" steps before first use.

## Tip/Example

1. Before starting to program, write down your Start and Stop Times

2. START: Set the start 45 minutes before opening

3. STOP: Set the stop 15 minutes after closing

4. Example: Observe the example below

Weekday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
Open Hours	11.00 - 21.00	11.00 - 21.00	11.00 - 21.00	11.00 - 22.00	11.00 - 22.00	12.00 - 22.00	12.00 - 20.00
Suggested Start / Stop Times	10:15 - 21.15	10:15 - 21.15	10:15 - 21.15	10:15 - 22.15	10:15 - 22.15	11:15 - 22.15	11:15 - 20.15



MODULAR ELECTRIC PIZZA OVENS



FULL SIZE, versatile and high efficient – stone hearth ovens

## PIZZAMASTER TIMER SET UP

### Oven Status:

- **ON** : Oven Operating
- **OFF** : Oven Inoperating

Date Display



### Current Weekday:

- 1= Monday, 2= Tuesday;
- .....; 7= Sunday

Menu



1. Select language by pressing or and confirm with OK



2. Press OK to configure Form Date



3. Select Date format by pressing or and confirm with OK



4. Select Year by pressing or and confirm with OK



5. Select Month by pressing or and confirm with OK



6. Select Day by pressing or and confirm with OK



7. Press OK to configure Form Time



8. Select Time display format by pressing or and confirm with OK



9. Configure hour by pressing or and confirm with OK



10. Configure minute by pressing or and confirm with OK



11. Configure **Summer** or **Winter** time by pressing or and confirm with OK



Now your timer is configured



MODULAR ELECTRIC PIZZA OVENS



FULL SIZE, versatile and high efficient – stone hearth ovens

## PROGRAM SET UP



1. Press **MENU** Menu to program ON-OFF time, confirm with **OK**



2. Press **OK** OK to configure new program



3. Press **←** or **→** to program ON or OFF times and confirm with **OK** OK



4. Select ON Hour by pressing **←** or **→** and confirm with **OK** OK



5. Select ON minutes by pressing **←** or **→** and confirm with **OK** OK



6. Select day by pressing **←** or **→** and confirm with **OK** OK



7. Press **OK** OK to Copy to another day(s). Press **←** or **→** to Save. Repeat steps 2 to 7 for individual day times



8. Select days with **←** or **→** and confirm with **OK** OK



9. Press **OK** OK to Save



10. Press **OK** OK to configure new program



11. Press **←** or **→** to program ON or OFF times and confirm with **OK** OK



12. Select OFF Hour by pressing **←** or **→** and confirm with **OK** OK



13. Select OFF minutes by pressing **←** or **→** and confirm with **OK** OK



14. Select day by pressing **←** or **→** and confirm with **OK** OK



15. Press **OK** OK to Copy to another day(s). Press **←** or **→** to Save. Repeat steps 10 to 15 for individual day times



16. Select days with **←** or **→** and confirm with **OK** OK. Save after pressing **OK** OK



MODULAR ELECTRIC PIZZA OVENS



FULL SIZE, versatile and high efficient – stone hearth ovens



## CLEAR PROGRAMS



1. \*Press **MENU** Menu to start



2. Press **◀** or **▶** until you find Delete and confirm with **OK** OK



3. Press **◀** or **▶** to select Single or Delete All (Step 5). Press **OK** OK to delete Single program



4. Press **◀** or **▶** to select Single program. Press **OK** OK to delete it



5. Select Delete All by pressing **◀** or **▶** and confirm with **OK** OK



6. Press **OK** OK to delete all the programs



7. Deleted confirmation is showed



8. Press **ESC** ESC one time to go to Program menu, or two times to Exit

**\*Note:** Use "Clear Programs" to remove one or all the ON or OFF programs. You need to follow steps "Program Set Up" after this.

## FACTORY RESET



1. \*Press **MENU** Menu, press **◀** or **▶** until you find Op-tions menu and confirm with **OK** OK



2. Press **◀** or **▶** until you find Factory Settings and confirm with **OK** OK



3. Press **OK** OK to reset completly the timer



4. Go to **TIMER SET UP** steps to configure the timer

**\*Note:** Use "Factory reset" to remove all the data. You need to follow steps "Timer Set Up" and "Program Set Up" after this.



PizzaMaster® Stone Hearth Deck Ovens are manufactured by Svenska BakePartner AB

Customer Support: Tel: +46 33 230-025 | E-mail: info@pizzamaster.com

Website: www.pizzamaster.com or www.bakepartner.com | HQ: Svenska BakePartner AB, Ödegårdsgatan 5, SE 504 64 Borås Sweden