

**Appliance displays temperatures which are too low,
child lock symbol shines****Models:**

Models	Index	Version
GKv 4310	20 to 20A	001
	20A	741
GKv 4360	10	137
	20 to 20A	001
	20A	441
GKv 5710	10 to 10G	137
	20 to 20J	001, 006, 085, 599, 647
	20 to 21B	890, 925
	20D to 20J	465, 479
GKv 5760	10 to 10C	137
	20 to 20J	001, 085, 599, 647, 986
	20 to 21B	441, 890
	20G to 20J	479
GKv 5730/5790	20 to 20E	001, 085, 455
GKv 6410	10 to 10B	137
	20 to 20L	001, 006, 085, 925
	20 to 21B	890
	20H to 20L	924
	20J to 20L	214
	20H to 20L	136
GKv 6460	10 to 10B	137
	20 to 20F	441
	20 to 20J	001, 085
	20 to 21B	890
	20F to 20J	136
	20J	D07
JKv 6410	20A to 20D	925
JKv 6460	20 to 20B	441

Fault profile: Appliance displays temperatures below zero, although the temperature in the appliance is in order.
The child lock symbol shines and cannot be deactivated.

Cause: LED defect. Other LEDs may shine erroneously as a result

To correct: Install new electronic. The substitutions are shown in Liparts.

Electronic until now	New electronic
6113 119, 6114 661	6114 493
6113 185, 6114 663	6114 491
6113 321, 6114 667	6114 489
6114 627	6114 495
6114 545	6114 497
6113 279	6114 483
6113 191, 6114 665	6114 481

Note: The former electronics may no longer be used.