

Appliance Documentation

GGv 5010/5060 from Index 40

GGv 5810/5860 from Index 40


Commercial freezer, ventilated with automatic defrosting



Contents

1.0	Operating and control elements	3
2.0	Functions at a glance	3
3.0	Description of appliance	4
3.1	Sensor positions, schematic diagrams	4
4.0	Main components and their functions	5
4.1	Electrical components and functions	5
4.2	Refrigeration components and functions	7
4.3	Miscellaneous	9
4.3.1	Door closing mechanism	9
4.3.2	Pressure compensating valve	9
4.3.3	Height-adjustable feet	9
5.0	Assembly instructions / replacement of parts	10
5.1	Electronic control system	10
5.2	Remove evaporator module	12
5.3	Sensor replacement	14
5.4	Interior fan	15
5.5	Safety temperature limiter (STL)	16
5.6	Solenoid valve	16
5.7	Condenser fan	17
6.0	Technical data	18
7.0	Hidden functions	19
7.1	Manual activation of the defrosting phase (customer menu)	19
7.2	Service menu	20
7.2.1	Demo mode	20
7.2.2	Service mode	21
7.2.3	Sensor menu	22
8.0	Table of error codes	22

1.0 Operating and control elements



- 1 : Temperature adjustment buttons
- 2 : Temperature display
- 3 : Display for activated child lock
- 3 : Display for activated defrosting
- 4 : ON/OFF button
- 5 : Alarm OFF button

2.0 Functions at a glance


Control:	Electronics
Temperature display:	Actual value
Temperature range:	-14°C to -28°C
Temperature alarm:	Visual and audible
Door alarm:	Audible
Fan:	Present
Defrosting:	Automatic (hot gas)
Interior light:	Not present
Service menu:	Present
Compressor:	Standard
Solenoid valve refrigeration circuit:	Featured (for defrosting)

3.0 Description of appliance

The GGv models are dynamically cooled upright freezers with automatic hot gas defrosting and a series 6 control system with actual value display.

The appliance has a lamellar evaporator with fan and solenoid valve for hot gas defrosting. Two sensors, an air sensor and an evaporator sensor, see to the control and automatic defrosting. A safety temperature limiter protects the appliance against excessively high temperatures during the defrosting phase.

3.1 Sensor positions, schematic diagrams



4.0 Main components and their functions

4.1 Electrical components and functions

Electronics	
Type:	Series 6 electronic control system
Components:	Control and power PCB
Setting range:	-14°C to -28°C
Display range:	-50°C to -1°C
Functions	
Temperature alarm:	<p>When: Set value: -14°C to -24°C Alarm value: 4K warmer than set value. Set value: -25° C to -28 °C Alarm value: -20°C</p> <p>Audible: 4 beeps (suppressed during start-up)</p> <p>Visual: Flashing temperature display</p> <p>Alarm is output with a 30-minute delay when the air sensor has reached the alarm value (e.g. set value: -18° C, actual value at -14° C for 30 minutes → alarm).</p> <p>On start-up the temperature display flashes until the switch-off value is reached, the audible alarm is suppressed.</p>
Door alarm:	<p>When: door open for longer than 3 minutes.</p> <p>Audible: 3 beeps</p>
Defrosting:	<p>Activation: - During start-up after 3 hours cumulative compressor running time. - After a cumulative compressor running time of 3 to 9 hours maximum, depending on the number/duration of the door openings. - Manually via the customer menu.</p> <p>Function: Hot gas defrosting (see chap. 4.2.1.2.). The defrost water is collected in the evaporator basin and channelled into the evaporation tray on the compressor.</p> <p>End: The defrosting phase is ended thermally as a rule (+10°C). The compressor will start up after a drip-off time of 10 minutes. The evaporator fan will start up as soon as the evaporator is at least as cold as the air temperature. If no thermal ending takes places, the defrosting phase is terminated after 120 minutes and the error message "Ad" displayed.</p> <p>Display: The defrost symbol is illuminated during the defrosting phase. During the defrosting phase, the value last displayed before defrosting started is retained for 45 minutes.</p>
Child lock:	<p>Activated by the customer menu (see operating instructions).</p> <p>When the child lock is activated, the ON/OFF button and the temperature adjuster buttons are inactive. The remaining functions are available for unrestricted use.</p>

Sensors

Air sensor: Position: at the rear left on the underside of the evaporator module.
 Function: - Switches the compressor ON/OFF.
 - Generates the display value.

Evaporator sensor: Position: Inserted into lamellar evaporator.
 Function: - Ends the defrosting phase.
 - Together with the air sensor after defrosting signals the enable for fan ON.

Switch

Door switch: Position: In front panel.
 Type: Reed PCB
 Contact type: Make contact
 Function: Activation via magnet on the door, magnet is replaceable.

Switching signal when:

door closed: Door alarm OFF

door open: Door alarm ON

Temperature fuse: Position: on the left side of the evaporator.
 Type: safety fuse
 Function: serves purely as a safety device!
 Triggers and thus interrupts voltage supply to the compressor when the evaporator heats up to over +84°C.

Loads

Compressor: Function: **ON:** Air sensor switch-on value.
OFF: Air sensor switch-off value.
Special features: On-delay time (8 minutes) must have elapsed.

Solenoid valve: Position: in the evaporator module.
 Type: 2/1 valve
 Function: opens when the defrosting phase starts and channels the hot gas directly to the evaporator

Fan: Position: in the evaporator module, at the rear centre
 Function:

Sensors	Set value	Compresso	Door	Fan
Switch-on value	-14 to -21°C	OFF	CLOSED	OFF
Switch-on value	-22 to -28°C	OFF	CLOSED	ON
Switch-on value	-14 to -28°C	ON	CLOSED	ON
Switch-on value	-14 to -28°C	ON	OPEN	OFF
Switch-off value	-14 to -28°C	OFF/ON	CLOSED/OPEN	OFF

Condenser fan: Position: beside the condenser
 Function: cools the condenser and runs parallel to the compressor


4.2 Refrigeration components and functions

Compressor:	1 standard compressor	
Evaporator:	Type:	lamellar evaporator.
	Type of installation:	as module under the appliance lid
	Injection point:	rear
	Flow sequence:	back to front
Frame heater:	Position:	foamed-in in the region of the frame.
	Type:	hot gas heater
Condenser:	Type:	wire tube condenser
	Type of installation:	suspended freely at the rear
Auxiliary condenser:	Type:	coil condenser
	Type of installation:	in the compressor recess
Solenoid valve:	2/1 valve	
Refrigerant	R290	

4.2.1 Function principle

4.2.1.1 Refrigeration

The solenoid valve is closed. The refrigerant runs through the customary circuit.



4.2.1.2 Hot gas defrosting

Defrosting of the evaporator is by hot gas.

When the defrosting phase is started, the compressor runs on and the solenoid valve opens. Hot gas flows over the bypass into the evaporator basin heater and evaporator. The refrigerant is then cooled down briefly by the ice-encrusted evaporator and is thus liquefied and then subsequently evaporated in the evaporator capsule by the heat of the latter. The gaseous refrigerant which is heated by the dissipated heat from the compressor is then pumped through the circuit.





Fig. 4.2.1.2/ 1




Fig. 4.2.1.2/ 2

4.3 Miscellaneous

4.3.1 Door closing mechanism

At an opening angle of between 0 and 30° the hinge bushing slips over the inclined hinge pin so that the door closes automatically. At an opening angle of more than 30° the door remains open.


Fig. 4.3.1/ 1 Opening angle > 30°



Fig. 4.3.1/ 2 Opening angle < 30°



Fig. 4.3.1/ 3 Opening angle = 0°



4.3.2 Pressure compensating valve

The pressure compensating valve is combined with the defrost water drain




Fig. 4.3.2 / 1

4.3.3 Height-adjustable feet

The height-adjustable feet are screwed on from underneath with a socket head screw. To increase the stability of the two rear height-adjustable feet, reinforcement brackets are also screwed in there.



Fig. 4.3.3/ 1




Fig. 4.3.3/ 2

5.0 Assembly instructions / replacement of parts

5.1 Electronic control system

Covers:

- unclip the covers on the underside of the front housing and remove the fastening screws.

Note: The cover on the door side is easier to remove if the door is taken off first (remove fastening screw, slide the door out of the turn hinge at the side and remove in a downward direction).




Fig. 5.1/ 1



Fig. 5.1/ 2




Fig. 5.1 /3

Front casing:

- Draw the front housing forwards and raise it.
- Unplug the connector from the power PCB and remove the front housing.




Fig. 5.1/ 4

PCBs:

- remove the marked locks, take off the PCB edge connectors and remove the PCB carrier
- Unclip the control PCB carrier from the front housing.




Fig. 5.1/ 5




Fig. 5.1/ 6

5.2 Remove evaporator module

Air guide

Undo bayonet screws and remove from air guide plate.




Fig. 5.2/ 1



Fig. 5.2/ 2

Front panel:

- remove stoppers and fastening screws.
- Unclip front panel (pull down and out to the front).



Fig. 5.2/ 3



Fig. 5.2/ 4

Catches:

- remove the left and right catches (push down at the front with a screwdriver until the locating lug unclips – then simply take off in an inward direction).




Fig. 5.2/ 5



Fig. 5.2/ 6




Fig. 5.2/ 7

Module

- Pull module forwards, fold downwards and place on grid.
- Remove adhesive strips (they are no longer required for re-assembly).
- Pull the evaporator sensor out of the groove or feedthrough.
First lift polystyrene part at the front and then draw it off.




Fig. 5.2/ 8




Fig. 5.2/ 9

Connector strip

- Unhook locating lug from the connector strip and pull up the strip.
- Electrical consumers are then easier to unplug.




Fig. 5.2/ 10




Fig. 5.2/ 11




Fig. 5.2/ 12


5.3 Sensor replacement

Air sensor:

- Clip sensor out of the holder and thread it through the opening.
 - Then pull sensor out through the rear wall and replace with universal sensor.
- Note: The universal sensor connector must be positioned on the appliance rear – not in the interior!

**Fig. 5.3/ 1****Fig. 5.3/ 2****Evaporator sensor:**

- Pull sensor out through the rear wall and replace with universal sensor.
- Note: The universal sensor connector must be positioned on the appliance rear – not in the interior!

**Fig. 5.2/ 3****Fig. 5.2/ 4**

5.4 Interior fan

Connector

- Unplug fan on the connector strip.
- Unhook fan and mount and remove towards the rear.




Fig. 5.4/ 1




Fig. 5.4/ 2

Fan mount:

- Remove blades.
- Pull off rubber rings and unclip the fan holder part of the fan.



Fig. 5.4/ 3




Fig. 5.4/ 4

Recess for mount:

- Place the rear of the mount into the recess and hook the mount in.




Fig. 5.4/ 5



Fig. 5.4/ 6

5.5 Safety temperature limiter (STL)

STL

- Unplug STL on the connector strip.
- Remove fastening screws and then take out STL.




Fig. 5.5/ 1

5.6 Solenoid valve

Solenoid valve:

- Unplug solenoid valve on the connector strip.
- Lift out the coil casing




Fig. 5.6/ 1



Fig. 5.6/ 2

5.7 Condenser fan

- Cover:**
- remove fastening screws and cover.
 - Pull out holder




Fig. 5.7/ 1




Fig. 5.7/ 2

- Fan:**
- Draw out locking pins.
 - Remove fan and mount.




Fig. 5.7/ 3



Fig. 5.7/ 4

6.0 Technical data

Solenoid valve	Wattage:	12 watts
	Voltage:	220 - 240 V

Evaporator fan:	Wattage:	6 W
	Speed:	1350 rpm.
	Voltage:	220 – 240 V

Condenser fan:	Wattage:	35 W
	Speed:	1300 rpm.
	Voltage:	220 – 240 V


Temperature limiter:	Trigger temp.:	84°C
-----------------------------	----------------	------

Sensor values:

Temperature °C	Resistance value kOhm
+35	3.1
+30	3.8
+25	4.7
+20	5.9
+15	7.3
+10	9.3
+5	11.9
0	15.3
-5	19.8
-10	25.9
-15	34.1
-20	45.3
-25	60.8
-30	82.3
-35	112.8

7.0 Hidden functions


7.1 Manual activation of the defrosting phase (customer menu)



Step	Display	Operation	Display following operation	INFO
1	Actual value	Hold down "Alarm" for 3 seconds	"c" flashes	Customer menu activation
2	"c" flashes	Press "Up" once	"H" flashes	Activate defrosting
3	"H" flashes	Press "Alarm"	"A" flashes + defrost symbol	Defrosting activated (stops automatically)

7.2 Service menu

The service menu may be used by service technicians only.



7.2.1 Demo mode

Step	Display	Operation	Display following operation	Testing option / Info
Activating demo mode				
1a	Actual value	Press "Alarm" and "ON/OFF" simultaneously for 3 seconds	"d1" flashes	Service menu activation
2a	"d1" flashes	Press "Alarm"	Set value	Demo mode ON
Deactivating demo mode (demo mode can be deactivated only using the service menu, not by OFF/ON.)				
1B	Set value	Press "Alarm" and "ON/OFF" simultaneously for 3 seconds	"d0" flashes	Service menu activation
2b	"d0" flashes	Press "Alarm"	Current actual value	Demo mode OFF
Operation is switched to the mode wanted, demo mode or normal, as soon as "Alarm" has been actuated.				

7.2.2 Service mode

Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				
1	OFF	Press "Alarm" and "ON/OFF" simultaneously for 3 seconds	"d1" flashes	Service menu activation
Customer service mode -- Check display LED, buttons, door contact				
1	"d1" flashes	Press "Up" once	"L" flashes	Service mode selected
2	"L" flashes	Press "Alarm"	"rd" flashes	Service mode activated
3	"rd" flashes	Door open and closed	All LEDs and the display (88) light up	Door contact, LEDs
4	All LEDs and the display (88) light up *	Press all the buttons	2 seconds audible alarm "L0" lights up	Buttons
Service mode -- testing electric loads--				
5 -> 8	"L0" lights up		"L0" lights up	All OFF
6	"L0" lights up	Press "Up"	"L1" lights up	Compressor + condenser fan ON
7	"L1" lights up	Press "Up"	"L3" lights up	Compressor fan ON
5 <- 8	"L3" lights up	Press "Up"	"L4" lights up	Solenoid valve
Return to step 5 by pressing the "Up" button again.				
End		Press "ON/OFF"		

7.2.3 Sensor menu

Step	Display	Operation	Display following operation	Testing option / Info
Service menu start				
1	OFF	Hold down "Alarm" and simultaneously press "ON/OFF"	"d1" flashes	Service menu activation
2	"d1" flashes	Press "Up" twice	"E" flashes	Sensor selection
3	"E" flashes	Press "Up"	E3 in alternation with the respective temperature	Air sensor
4	E3 in alternation with the respective temperature	Press "Up"	E4 in alternation with the respective temperature	Evaporator sensor
5	E4 in alternation with the respective temperature	Press "Up"	E8 in alternation with the respective door condition (1= open, 2 = closed)	Reed contact
Return to step 5 by pressing the "Up" button again.				
End		Press "ON/OFF"		

8.0 Table of error codes

Error code	Defective component	Emergency mode
"F3" flashes	Air sensor	Continuous operation
"F4" flashes	Evaporator sensor	Continuous operation
"Ad" flashes	Maximum defrost duration exceeded	Normal operation
"HE" flashes	Excess evaporator temperature	All consumers are switched off

In order to acknowledge the "HE" signal, the appliance must be switched off and then unplugged. To put back into operation, repeat steps in reverse order