



MKS SERV042D/57D_RS485 V1.0.5


USER MANUAL

| MKS SERV042D/57D_RS485 Manual Release | | | |
|---------------------------------------|---|----------|----------|
| manual | discription | firmware | date |
| V1.0.0 | First release | V1.0.0 | Mar-2023 |
| V1.0.1 | 1.Added SR_OPEN, SR_CLOSE control mode. | V1.0.1 | Apr-2023 |
| | 2.It can set any working current. | | |
| | 3.Redefined speed and acceleration for serial Mode. | | |
| | 4. Add the "92" command , It can set the current position to 0 point. | | |
| | 5. Add the "8D" command, It can set the group address. | | |
| V1.0.2 | 1.Add long data package. | V1.0.2 | May-2023 |
| | 2.Support for Modbus-RTU communication protocol. | | |
| | 3.Slave does not answer if broadcast address or group address or long data package is used. | | |
| | 4. OUT_1 port output stall indication. | | |
| V1.0.3 | 1. Add the "9A" command, It can set the parameter of 0_Mode. | V1.0.3 | Jul-2023 |
| | 2. Add the "8F" command, It can locked the key. | | |
| | 3. Add the "34" command, It can read the IO Ports status. | | |
| | 4. the number of slave addresses can be set by menu is change to 16. | | |
| | 5. add left and right endstop limit function. | | |
| V1.0.4 | 1. Added menu or command (9BH) to set holding current percentage function. | V1.0.4 | Sep-2023 |
| | 2. Added absolute motion by pulses(FEH). | | |
| | 3. Modify the 8CH command and add the option of active. | | |
| | 4. Add emergency stop command(F7H). | | |
| | 5. Add limit port remap command (9EH). | | |
| | | | |
| V1.0.5 | 1. Support no limit switch for "go home" function. | V1.0.5 | May-2024 |
| | 2. Added menu options: "Hm_Mode" and "Hm_Ma". | | |
| | 3. Add the "94" command. | | |
| | 4. Fix the bug of command "F4H" and "F5H". | | |
| | 5. The command"F5H"supports real-time data update. | | |
| | 6. Add the restart motor command(41H). | | |

Part1. Feature


1.1 Interface

1. SERV042D_RS485 Interface



Note: EVCC/EGND is powered by SERVO42D 5V(20mA)

2. SERV057D_RS485 Interface



1.2 Key Operation

| Key | Function |
|-------|-----------------------------------|
| Next | move down |
| Enter | Confirm |
| Menu | Enter/exit parameter setting menu |

3. How to View parameter

Press the “Menu” key to Enter the Menu
press the “Next” key to move to the sub-option
press the “Enter” key, then it show the value.

4. How to setting Parameter:

Press the “Menu” key to Enter the Menu
press the “Next” key to move to sub-option
press the “Enter” key, it show the value.
press the “Next” key to move to the value
press the “Enter” key to set the value.

1.3 Parameter description

- 0.0° - the angle of the motor shaft. (unit degree).
(Note : It calculated based on the read encoder value, dynamically displayed)
- 0.00err - the err of the motor shaft angle.
- 0clk - the pulses have been received.



1.4 Work mode

| | Work Mode | | MAX RPM | Work Current |
|-------|------------------|----------|---------|--------------------------------------|
| OPEN | pulse interface | CR_OPEN | 400RPM | Fix, the work current is Ma |
| | serial interface | SR_OPEN | | |
| CLOSE | pulse interface | CR_CLOSE | 1500RPM | Fix, the work current is Ma |
| | serial interface | SR_CLSOE | | |
| vFOC | pulse interface | CR_vFOC | 3000RPM | self-adaption, the Max current is Ma |
| | serial interface | SR_vFOC | | |

Notel: The default work mode is CR_vFOC.


Note2: It can work without encoder in “OPEN” work mode.

Part2. Wire


2.1 Motor wire

Note: The motor internal resistance should be less than 10 ohms.


1. SERV042D_RS485 motor wire



2. SERV057D_RS485 motor wire



2.2 Pulse interface wire




Note: if the (STP/DIR/EN) signal high level is 3.3V, the COM must be 3.3V
 if the (STP/DIR/EN) signal high level is 5.0V, the COM must be 5.0V
 ...
 and so on.

2.3 RS485 wire


Note: Tip: In order to reduce bus interference, the host-gnd and the motor-gnd must connected together, and RS485 signals are transmitted using shielded twisted pairs.

1. SERV042D_RS485 Single-slave




Note: Single slave communication does not need 120Ω Terminal.

2. SERV057D_RS485 Single-slave




Note: Single slave communication does not need 120Ω Terminal.

3. Multiple-slave




2.4 End stop wire

1. SERV042D_CAN end stop wire



Note: EVCC/EGND is powered by SERV042D 5V(20mA)

2. SERV057D_CAN end stop wire



| SW1 | | |
|-----|---|---|
| PIN | ON | OFF |
| 3 | EVCC/EGND is powered by SERV057D 5V(20mA) | EVCC/EGND is powered by externally power.(3.3V-24V) |
| 2 | | |
| 1 | RS485 120Ω Terminal | NULL |

Note: The mechanical switch only needs to be connected the "EGND, IN_1", and the SW1 pin2 must be in the ON state.



2.5 IO Port Description

| PORT | Function | 57D | 42D |
|-------|--|-----|-----|
| IN_1 | home or left-limit | √ | √ |
| IN_2 | right-limit | √ | X |
| OUT_1 | stall indication: 0-protected; 1-unprotected | √ | X |
| OUT_2 | reserved | √ | X |

Note: After enabling the limit remapping function, IN_1 maps to En, IN_2 maps to Dir.

2.6 EndStop-limit Description

1. The EndStop-limit function needs to be turned on:
(Menu -> EndLimit or serial command "90")
2. When first time to using the limit function or changing the limit parameters, it is necessary to go home;
(Menu -> GoHome or serial command "91")
3. After the left-endstop is triggered, the motor will no longer run to the left;
4. After the right-endstop is triggered, the motor will no longer run to the right; (only for 57D)
5. Limit remapping function can be turned on (serial mode only)
Left limit -> En port
Right limit -> Dir port
The Com port must be connected to the corresponding high level



Part3. Menu description

1. **CAL** : Calibrate the motor.

2. **Mode** : Work mode selection.

CR_OPEN : pulse interface Open mode, the motor run without encoder

CR_CLOSE : pulse interface Close mode, the motor run with encoder.

CR_vFOC : pulse interface FOC mode, the motor run with encoder.

SR_OPEN : serial interface Open mode, the motor run without encoder

SR_CLOSE : serial interface Close mode, the motor run with encoder.

SR_vFOC : serial interface FOC mode, the motor run with encoder.

(Default: CR_vFOC)

| | Mode | | MAX RPM | Work Current |
|-------|------------------|----------|---------|--------------------------------------|
| OPEN | pulse interface | CR_OPEN | 400RPM | Fix, the work current is Ma |
| | serial interface | SR_OPEN | | |
| CLOSE | pulse interface | CR_CLOSE | 1500RPM | Fix, the work current is Ma |
| | serial interface | SR_CLOSE | | |
| vFOC | pulse interface | CR_vFOC | 3000RPM | self-adaption, the Max current is Ma |
| | serial interface | SR_vFOC | | |

Note: CR_CLOSE is better than CR_vFOC for 3D printing.

3. **Ma** : Set the working current.

SERV042D: 0, 200, 400..., 3000(mA) (default 1600mA)

SERV057D: 0, 400, 800..., 5200(mA) (default 3200mA)

SERV028D: 0, 200, 400..., 3000(mA) (default 600mA)

SERV035D: 0, 200, 400..., 3000(mA) (default 800mA)

Other Current such as 123mA need to be set by serial command .It will be added to the last options.

4. **HoldMa** : Set holding current percentage.

10%, 20%,, 90%

(Default: 50%, the holding current at half the working current)

Note: Only for OPEN mode and CLOSE mode, vFOC mode is invalid.

5. **MStep** : Set subdivisions.

Supports subdivision from 1 to 256.

(Default: 16)

subdivisions 1,2,4,8,16,32,64,128, and 256 can be set by Menu.

Other subdivisions such as 67 subdivisions need to be set by serial command . It will be added to the last options.



6. **En** : Set the effective level of EN pin.
H : High level is valid.
L : Low level is effective.
Hold : the driver board is always enabled.
(Default: L)
7. **Dir** : Set the positive direction of motor rotation.
CW : Clockwise rotation is positive
CCW : Counterclockwise rotation is positive
(Default: CW)
Note: only for pulse interface, the direction of serial interface is set by command.
8. **AutoSDD** : Set auto turn off the OLED screen.
Disable : disable auto turn off the OLED
Enable : enable auto turn off the OLED
(Default: Disable)
If set to Enable, the screen will automatically turn off after about 15 seconds, and any button can wake up the screen again.
9. **Protect** : Set the motor shaft locked-rotor protection function.
Disable: disable protection
Enable: enable protection
(Default: Disable)
After this option is enabled, the protection will be triggered when it is detected to be locked-rotor, and the motor will be release.
Note: you can release the protection status by pressing the Enter button or the serial port command.
10. **MPlyer** : Set internal 256 subdivision.
(Default: Enable)
Note: After this option is Enabled, it automatically enable internal 256 subdivision, it can reduce the vibration and noise when the motor at low speed.
11. **UartBaud** : Set the baud rate of serial.
9600/19200/25000/38400/57600/115200/256000.
(Default: 38400)



12. **UartAddr** : Set the the slave address of seria.
01
...
15
16
(Default: 01)
Note: The addresses greater than 16 need to be set by serial command. After it is set, it will be added to this option.
13. **UartRSP** : Choose whether the slave respond in speed/positon mode.
Disable: disable respond
Enable: enable respond
(Default: Enable)
Note: If disable respond, It can query the running status of the motor by command "F1".
14. **Mb_RTU** : Choose whether to use MODBUS-RTU communication protocol.
Disable: disable MODBUS-RTU communication protocol
Enable: enable MODBUS-RTU communication protocol
(Default: Disable)
15. **O_Mode** : The motor will go back to zero when power on.
Disable : do not go back to zero.
DirMode : go back to zero with direction of CW or CCW (the direction is set in O_Dir menu).
NearMode : go back to zero with minimum angle.
(Default: Disable)
16. **Set 0** : Set the zero point for go back when power on.
(O_Mode must not be Disable)
17. **O_Speed** : Set the speed of go back to zero point.
0 : slowest.
...
4 : fastest.
18. **O_Dir** : Set the direction of go back to zero point.
CW : Clockwise.
CCW : Counterclockwise.
(Default: CW)
19. **Hm_Trig** : Set the effective level of the end stop.
Low : Low level is effective
High : High level is valid
(Default: Low)



20. **Hm_Dir** : Set the direction of go home.
CW : Clockwise rotation is positive
CCW : Counterclockwise rotation is positive
(Default: CW)
21. **Hm_Speed** : Set the speed (RPM) of go home.
30
60
90
120
150
180
Other speed such as 600(RPM) need to be set by serial command .
It will be added to the last options.
22. **Hm_Mode** : Set the method of go home.
Limited : used Limit switch for go home(default)
noLimit : no Limit switch for go home
When “noLimit” for go home, the motor will runs with a fixed torque (Hm_Ma setting) until it stops when it encounters an obstacle, and then runs in reverse for a certain distance (94H command setting) and then stops. The stopping point is the zero point.
23. **Hm_Ma** : Set the current of “noLimit” go home.
SERVO42D: 0, 200, 400..., 3000(mA) (default 800mA)
SERVO57D: 0, 400, 800..., 5200(mA) (default 400mA)
SERVO28D: 0, 200, 400..., 3000(mA) (default 200mA)
SERVO35D: 0, 200, 400..., 3000(mA) (default 200mA)
Note: The “Hm_Ma” is only valid during “noLimit” go home operation. It should be set to a smaller current as much as possible to avoid damaging the motor.
24. **EndLimit** : Set the endstop-limit function.
Disable: disable endstop-limit
Enable: enable endstop-limit
(Default: Disable)
Note1: When first time to using the limit function or changing the limit parameters, it is necessary to go home;
(Menu -> GoHome or serial command “91”)
Note 2: When EndLimit=Enable, when the motor goHome touches the left limit switch, the motor will unlocked the shaft.
If you want to locked the axis after goHome, you should set EndLimit=Disable.



25. **GoHome:** Go home

Notel: It need an “end stop”. The motor will keep running until it hits the limit switch.

Note2: If the limit switch is already closed, the motor will rotate in the opposite direction to homeDir until the limit switch is opened, and then go home.

26. **Restore :** Reload the default parameters.

After restored the default parameters, it needs to Calibrate the motor.

Note: Press the “Next” key first, then power on, it can quickly restore the default parameters.

27. **About :** Show version parameters.

28. **Exit :**Exit the parameter setting menu.

Part4. Serial data format

Note: For MODBUS-RTU protocol commands, see Part 8.

| Downlink package(PC → SERV042D/57D) | | | | | |
|-------------------------------------|------------|----------|------|--|------------|
| Head | Slave addr | Function | Data | | Check code |
| FA | addr | code | | | CRC |
| | | | | | |
| Uplink package (PC ← SERV042D/57D) | | | | | |
| Head | Slave addr | Function | Data | | Check code |
| FB | addr | code | | | CRC |

- Downlink package Head is “FA”, uplink package Head is “FB”.
- The slave address(addr) range is 00~255. (default is 01).
00 is the broadcast address;
01~10 can be set in the UartAddr option of the display menu;
greater than 10 need to be set by serial commands.
- The function code (code) executes the corresponding command.
for example, 0x80 executes the calibration command.
- The Check code is CHECKSUM 8bit
For example: command “FA 01 80 00 CRC”

$$\text{CRC} = (0xFA + 0x01 + 0x80 + 0x00) \& 0xFF = 0x17B \& 0xFF = 0x7B$$

Note: Slave does not answer if broadcast address is used.

Part5. Serial command description

Note1: Please set the serial slave address first. (default:01)

The default address for the following chapters is 01.

Note2: For MODBUS-RTU protocol commands, see Part 8.

5.1 Read parameter command

1. command1 : FA 01 30 CRC

read the encoder value(carry).

| Uplink package (PC ← SERV042D/57D) | | | | | |
|------------------------------------|------------|----------|---------|----------|-----|
| Head | Slave addr | Function | Data | | CRC |
| FB | 01 | 30 | carry | value | CRC |
| | | | int32_t | uint16_t | |

carry: the carry vaule of the encoder.

value: the current vaule of the encoder. (range 0~0x3FFF)

When value is greater than 0x3FFF, carry +=1.

When Value is less than 0, carry -=1.

For example:

If the current carry|value is 0x3FF0, After one turn CCW, the carry|value (+0x4000) is 0x13FF0.

If the current carry|value is 0x3FF0, After one turn CW, the carry|value (-0x4000) is 0xFFFFFFFF3FF0.

Note: The encoder value is updated regardless of whether the motor is enabled or not.

2. Command2 : FA 01 31 CRC

read the encoder value(addition).

| Uplink package (PC ← SERV042D/57D) | | | | | |
|------------------------------------|------------|----------|-----------|--|-----|
| Head | Slave addr | Function | value | | CRC |
| FB | 01 | 31 | (int48_t) | | CRC |

After one turn clockwise, the value += 0x4000;

After one turn CCW, the value -= 0x4000;

For example:

If the current value is 0x3FF0, After one turn CCW, the value(+0x4000) is 0x7FF0.

If the current value is 0x3FF0, After one turn CW, the value(-0x4000) is 0xFFFFFFFFFF0.



3. Command3 : FA 01 32 CRC

Read the real-time speed of the motor. (RPM)

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|----------------|-----|
| Head | Slave addr | Function | value | CRC |
| FB | 01 | 31 | speed(int16_t) | CRC |

Note : if it run CCW, the speed > 0 (RPM)
if it run CW, the speed < 0 (RPM)

4. Command4 : FA 01 33 CRC

Read the number of pulses received.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 33 | pulses(int32_t) | CRC |

5. Command6 : FA 01 34 CRC

read the IO Ports status.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 34 | status(uint8_t) | CRC |

| status | | | | | | | |
|----------|------|------|------|-------|-------|------|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| reserved | | | | OUT_2 | OUT_1 | IN_2 | IN_1 |

Note: After enabling the limit remapping function, IN_1 maps to En,
IN_2 maps to Dir.

6. Command5 : FA 01 39 CRC

read the error of the motor shaft angle.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 39 | error(int32_t) | CRC |

The error is the difference between the angle you want to control minus the real-time angle of the motor, 0~51200 corresponds to 0~360° .

for example, when the angle error is 1° , the return error is 51200/360= 142.222, and so on.

**7. Command6 : FA 01 3A CRC**

read the En pins status.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 3A | enable(uint8_t) | CRC |

enable =1 Enabled

enable =0 Disabled

8. Command7 : FA 01 3B CRC

Read the go back to zero status when power on.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 3B | status(uint8_t) | CRC |

status =0 going to zero.

status =1 go back to zero success.

status =2 go back to zero fail.

9. Command8 : FA 01 3D CRC

Release the motor shaft locked-rotor protection state.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 3D | status(uint8_t) | CRC |

status =1 release success.

status =0 release fail.

10. Command9 : FA 01 3E CRC

Read the motor shaft protection state.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 3E | status(uint8_t) | CRC |

status =1 protected.

status =0 no protected.

5.2 Set parameters command

1. Calibrate the encoder

(Same as the "Cal" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 80 | 00 | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 80 | status(uint8_t) | CRC |

status =0 Calibrating...

status =1 Calibrated success.

status =2 Calibrating fail.

Note : The motor must be unloaded.

2. Set the work mode

(Same as the "Mode" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 82 | mode (0~5) | CRC |

mode = 0 CR_OPEN

mode = 1 CR_CLOSE

mode = 2 CR_vFOC

mode = 3 SR_OPEN

mode = 4 SR_CLOSE

mode = 5 SR_vFOC

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 82 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

| | Mode | | MAX RPM | Work Current |
|-------|------------------|----------|---------|---|
| OPEN | pulse interface | CR_OPEN | 400RPM | Fix, the work current is the Ma |
| | serial interface | SR_OPEN | | |
| CLOSE | pulse interface | CR_CLOSE | 1500RPM | Fix, the work current is the Ma |
| | serial interface | SR_CLOSE | | |
| vFOC | pulse interface | CR_vFOC | 3000RPM | self-adaption, the Max current is the Ma |
| | serial interface | SR_vFOC | | |



3. Set the working current

(Same as the "Ma" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|-------------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 83 | Current(uint16_t) | CRC |

Note: the new current will show in the screen of Ma option.

SERV042D/28D/35D: Maximum Current =3000mA

SERV057D: Maximum Current =5200mA

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 83 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

4. Set the holding current percentage

(Same as the "HoldMa" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 9B | holdMa(01~08) | CRC |

hold = 00 10%.

hold = 01 20%.

...

hold = 08 90%.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 9B | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

Note: Only for OPEN mode and CLOSE mode, vFOC mode is invalid.

5. Set subdivision

(Same as the "MStep" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 84 | micstep(00~FF) | CRC |

Note: the new micstep will show in the screen of MStep option.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 84 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

6. Set the active of the En pin

(Same as the "En" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 85 | enable(00~02) | CRC |

enable = 00 active low (L)

enable = 01 active high (H)

enable = 02 active always (Hold)

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 85 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

7. Set the direction of motor rotation

(Same as the "Dir" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 86 | dir(00~01) | CRC |

dir = 00 CW

dir = 01 CCW

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 86 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

8. Set auto turn off the screen function

(Same as the "AutoSDD" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 87 | enable(00~01) | CRC |

enable = 01 enabled

enable = 00 disabled

If set to Enable, the screen will automatically turn off after about 15 seconds, and any button can wake up the screen again.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 87 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

9. Set the motor shaft locked-rotor protection function

(Same as the "Protect" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 88 | enable(00~01) | CRC |

enable = 01 enabled protection

enable = 00 disabled protection

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 88 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

Note: you can release the protection status by pressing the Enter button or the serial command.

10. Set the subdivision interpolation function

(Same as the "Mplyer" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 89 | enable(00~01) | CRC |

enable = 01 enabled interpolation function.

enable = 00 disabled interpolation function.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 89 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.



11. Set the baud rate

(Same as the "UartBaud" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|-------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 8A | baud(01~07) | CRC |

baud = 01 9600.
baud = 02 19200.
baud = 03 25000.
baud = 04 38400.
baud = 05 57600.
baud = 06 115200.
baud = 07 256000.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8A | status(uint8_t) | CRC |

status =1 Set success.
status =0 Set fail.

12. Set the slave address

(Same as the "UautAddr" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|-------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 8B | addr(00~FF) | CRC |

Note1: the new address will show in the screen of UartAddr option.

Note2: 0 is the broadcast address

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8B | status(uint8_t) | CRC |

status =1 Set success.
status =0 Set fail.



13. Set the slave respond and active

| Downlink package (PC → SERV042D/57D) | | | | | |
|--------------------------------------|------------|----------|---------------|---------------|-----|
| Head | Slave addr | Function | Data | Data | CRC |
| FA | 01 | 8C | respon(00~01) | active(00-01) | CRC |

respon = 01 enabled respond (default)

respon = 00 disabled respond

active = 01 enabled active (default)

active = 00 disabled active

Note: If disable respond, It can query the running status of the motor by command “F1”.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8C | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

The difference between respond and active

Take position control mode 1 as an example:

Host sends FA 01 FD 02 80 02 00 00 FA 00 76

a. In no response mode (respon =0, active = xx)

The slave does not return any information.

b. In the mode of not actively initiating data (respon =1, active =0)

Slave returns immediately Position control starts 01 or fails 00.

c. In default mode (respon =1, active =1)

Slave returns immediately Position control starts 01 or fails 00.

Return 02 or 03 after the motor finishes running or touches the limit stop.

14. Set MODBUS-RTU communication protocol

(Same as the “MB_RTU” option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 8E | enable(00~01) | CRC |

enable = 01 enabled Modbus-RTU

enable = 00 disabled Modbus-RTU

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8E | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.



15. Set the key lock or unlock

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 8F | enable(00~01) | CRC |

enable = 01 lock the key

enable = 00 unlock the key

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8F | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

16. Set the group address

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|-------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 8D | addr(01~FF) | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 8D | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

For example, there are 6 motors with the settings address:

| | Broadcast addr | Slave addr | Group addr |
|---------|----------------|------------|------------|
| motor 1 | 0 | 1 | 0x50 |
| motor 2 | 0 | 2 | 0x50 |
| motor 3 | 0 | 3 | 0x50 |
| motor 4 | 0 | 4 | 0x51 |
| motor 5 | 0 | 5 | 0x51 |
| motor 6 | 0 | 6 | 0x51 |

send FA 01 FD 01 2C 64 00 00 0C 80 15, motor 1 will rotate a turn

send FA 00 FD 01 2C 64 00 00 0C 80 14, motor1-6 will rotate a turn

send FA 50 FD 01 2C 64 00 00 0C 80 64, motor1-3 will rotate a turn

send FA 51 FD 01 2C 64 00 00 0C 80 65, motor4-6 will rotate a turn

Note: Slave does not answer if group address is used.



5.3 Set Home command

1. Set the parameter of home

(Same as the “HmTrig、HmDir、HmSpeed、EndLimit” option on screen)

| Downlink package (PC → SERV042D/57D) | | | | | | | |
|--------------------------------------|------------|----------|--------|--------|----------|----------|--------|
| byte1 | byte2 | byte3 | byte 4 | byte 5 | byte 6-7 | byte 8 | byte 9 |
| Head | Slave addr | Function | level | dir | speed | enable | Check |
| FA | 01 | 90 | HmTrig | HmDir | HmSpeed | EndLimit | CRC |

HmTrig the effective level of the end stop

0: Low 1: High

HmDir the direction of go home

0: CW 1: CCW

HmSpeed the speed of go home

0~3000 (RPM)

EndLimit

0: disable endstop-limit

1: enable endstop-limit

Note : The speed description can be found in Chapter 6.1.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 90 | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.

Note1:When first time to using the “EndLimit” function or changing the limit parameters, it is necessary to go home;

(Menu → GoHome or serial command “91”)

Note 2: When EndLimit=1, when the motor goHome touches the left limit switch, the motor will unlocked the shaft.

If you want to locked the axis after goHome, you should set EndLimit=0.

2. Go home

(Same as the “GoHome” option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 91 | NULL | CRC |

Note: If the limit switch is already closed, the motor will rotate in the opposite direction to homeDir until the limit switch is opened, and then go home.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 91 | status(uint8_t) | CRC |



status =0 go home fail.
status =1 go home start.
status =2 go home sucess.

3. Set Currnet Axis to zero

It can set the current Axis to Zero. Just as “GoHome” without run the motor.

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 92 | NULL | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 92 | status(uint8_t) | CRC |

status =0 set fail.
status =1 set success.

4. Set the parameter of “noLimit” go home

| Downlink package (PC → SERV042D/57D) | | | | | | |
|--------------------------------------|------------|----------|---------------|---------|-----------|---------|
| byte1 | byte2 | byte3 | byte 4-7 | byte 8 | byte 9-10 | byte 11 |
| Head | Slave addr | Function | Reverse Angle | hm-Mode | Hm_ma | Check |
| FA | 01 | 94 | retValue | mode | ma | CRC |

mode 0: used Limit switch for go home

1: no Limit switch for go home

ma the current of “noLimit”go home

retValue: 0~0xFFFFFFFF

for example:

retValue = 0x4000 (it will return 360 degree)

retValue = 0x2000 (it will return 180 degree) (default)

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 94 | status(uint8_t) | CRC |

status =0 set fail.

status =1 set success.

Note1: Reference the menu of “Hm_Mode” and “Hm_Ma”.

Note2: Reference the Command 90/91.



5. Set limit port remap

(only for serial control mode)

The 28/35/42D motor has only a left limit port. In serial control mode, limit port remapping can be enabled to add a right limit port.

For the 57D motor, limit port remapping can also be enabled if required to facilitate wiring.

Left limit -> En port

Right limit -> Dir port

The Com port must be connected to the corresponding high level.

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|---------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 9E | enable(00~01) | CRC |

enable = 01 enable remap limit port

enable = 00 disable remap limit port

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 9E | status(uint8_t) | CRC |

status =1 Set success.

status =0 Set fail.



5.4 Set 0_Mode command

In 0_Mode, the motor can automatically return to the 0 point position when power on. The maximum angle is 359 degrees.

1. Set the parameter of 0_Mode

(Same as the “0_Mode、Set 0、0_Speed、0_Dir” option on screen)

| Downlink package (PC → SERV042D/57D) | | | | | | | |
|--------------------------------------|------------|----------|--------|--------|---------|--------|--------|
| byte1 | byte2 | byte3 | byte 4 | byte 5 | byte 6 | byte 7 | byte 8 |
| Head | Slave addr | Function | 0_Mode | Set 0 | 0_Speed | 0_Dir | Check |
| FA | 01 | 9A | mode | enable | speed | dir | CRC |

mode:

- 0: Disable do not go back to zero
- 1: DirMode go back to zero with direction
- 2: NearMode go back to zero with minimum angle

enable:

- 0: clean zero
- 1: set zero

speed:

- 0 ~ 4 (0:slowest 4:fastest)

dir:

- 0: CW
- 1: CCW

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 9A | status(uint8_t) | CRC |

status =0 set fail.

status =1 set success.



5.5 Restore the default parameter

(Same as the "Restore" option on screen)

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 3F | NULL | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 3F | status(uint8_t) | CRC |

status =1 restore success.

status =0 restore fail.

Note1: After restored the parameters, It will reboot again, and need to calibrate the motor.

Note2: Press the "Next" key, and power on the motor, the default parameter will be restored.

5.6 Restart the motor

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | 41 | NULL | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | 41 | status(uint8_t) | CRC |

status =1 restart success.

status =0 restart fail.



5.7 Long Data Package

Long data packets, that is, a packet of data contains up to 5 commands, and the slave judges which command to execute based on the address.

Long data packets format:

| Head | 0xFC | | | | 1byte |
|-----------|-------------|--------|-----|---------|---------|
| | byte 1 | byte 2 | ... | byte 10 | |
| command 1 | slaveAddr1 | code | ... | | 10 byte |
| command 2 | slaveAddr 2 | code | ... | | 10 byte |
| command 3 | slaveAddr 3 | code | ... | | 10 byte |
| command 4 | slaveAddr 4 | code | ... | | 10 byte |
| command 5 | slaveAddr 5 | code | ... | | 10 byte |
| checksum | CRC | | | | 1 byte |

Note:

- 1.The length of the long data packet is 52 bytes in total.
- 2.The length of each command X is 10 bytes, when it is less than 10 bytes, add 0 to supplement.
- 3.Command X is the corresponding ordinary command, remove the frame header (FA) and checksum.
- 4.If the slave addresses of command X and command Y ($X < Y$) are the same, only command X is executed.
- 5.Slave does not answer.

For example, sending the following long data packet can control 5 motors to perform different actions (16 subdivisions)

FC

```
01 F6 00 32 0A 00 00 00 00 00
02 F6 80 64 20 00 00 00 00 00
03 FD 01 2C 02 00 04 E2 00 00
04 F4 02 58 64 00 19 00 00 00
05 F5 04 B0 C8 00 0C 80 00 00
```

11

```
[2023-04-30 22:40:55.899]# SEND HEX>
```

```
FC 01 F6 00 32 0A 00 00 00 00 02 F6 80 64 20 00 00 00 00 03 FD 01 2C 02
00 04 E2 00 00 04 F4 02 58 64 00 19 00 00 00 05 F5 04 B0 C8 00 0C 80 00 00 11
```

Motor 1 rotates forward continuously in speed mode (speed=0x32, acc=0x0A)

Motor 2 reverses continuously in speed mode (speed=0x64, acc=0x20)

Motor 3 rotates forward 100 times in position mode 1 (speed=0x12C, acc=0x02)

Motor 4 rotates forward 100 times in position mode 2 (speed=0x258, acc=0x64)

Motor 5 runs to coordinate 0xC8000 in position mode 3 (speed=0x4B0, acc=0xC8)



Part6. Run the motor by serial command

Note1: This chapter needs to set the working mode to serial mode.
(SR_OPEN/SR_CLOSE/SR_VFOC)

Note2: For MODBUS-RTU protocol commands, see Part 8.

6.1 Description the parameters of speed and acceleration

1. speed

The speed parameter ranges from 0 to 3000. The larger the value, the faster the motor rotates.

When speed = 0, the motor stops rotating.

The maximum speed of the control mode is as follows:

| | Control mode | | Max speed |
|------------|------------------|----------|-----------|
| Open mode | Pulse interface | CR_OPEN | 400(RPM) |
| | Serial interface | SR_OPEN | |
| Close mode | Pulse interface | CR_CLOSE | 1500(RPM) |
| | Serial interface | SR_CLOSE | |
| FOC mode | Pulse interface | CR_vFOC | 3000(RPM) |
| | Serial interface | SR_vFOC | |

If the set speed is greater than the maximum speed of the control mode, the motor runs at the maximum speed of the control mode.

Note: The speed value is calibrated based on 16/32/64 subdivisions, and the speeds of other subdivisions need to be calculated based on 16 subdivisions.

For example, setting speed=1200

At 8 subdivisions, the speed is 2400 (RPM)

At 16/32/64 subdivisions, the speed is 1200 (RPM)

At 128 subdivisions, the speed is 150 (RPM)

2. acceleration

The value of the acceleration(acc) ranges from 0 to 255. The larger the value, the faster the motor accelerates/decelerates.

If acc=0, the motor runs without acceleration or deceleration, and runs directly at the set speed.

① accelerates

Suppose at time t_1 , the current speed is V_{t1} ($V_{t1} < \text{speed}$)

at time t_2 , the current speed is V_{t2}

$$t_2 - t_1 = (256 - \text{acc}) * 50 \text{ (uS)}$$

The relationship between the current speed V_{ti} , acc, and speed is as follows:

$$V_{t2} = V_{t1} + 1 \text{ (} V_{t2} \leq \text{speed)}$$

For example: acc = 236, speed = 3000

| T(ms) | speed (RPM) | T(ms) | speed (RPM) |
|-------|-------------|-------|-------------|
| 0 | 0 | ... | ... |
| 1 | 1 | ... | ... |
| 2 | 2 | 2998 | 2998 |
| 3 | 3 | 2999 | 2999 |
| ... | ... | 3000 | 3000 |

② decelerates

Suppose at time t_1 , the current speed is V_{t1} ($V_{t1} > \text{speed}$)

at time t_2 , the current speed is V_{t2}

$$t_2 - t_1 = (256 - \text{acc}) * 50 \text{ (uS)}$$

The relationship between the current speed V_{ti} , acc, and speed is as follows:

$$V_{t2} = V_{t1} - 1 \text{ (} V_{t2} \geq \text{speed)}$$

6.2 Query/Enable the motor command

1. Query the motor status

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | F1 | — | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F1 | status(uint8_t) | CRC |

status = 0 query fail.
 status = 1 motor stop
 status = 2 motor speed up
 status = 3 motor speed down
 status = 4 motor full speed
 status = 5 motor is homing
 status = 5 motor is Cal...

2. Enable the motor

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | F3 | en (00~01) | CRC |

en = 00 disable.
 en = 01 enable.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F3 | status(uint8_t) | CRC |

status = 1 set success.
 status = 0 set fail.

6.3 Emergency stop the motor

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | F7 | — | CRC |

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F7 | status(uint8_t) | CRC |

status = 0 stop fail.

status = 1 stop success.

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

6.4 About Multiple Motors Control

1. Broadcast address, all motors execute the same command.
2. Group address, group A motors execute command a, group B motors execute command b.
3. Long data packets, motors can execute different commands.



6.5 Speed mode command

In speed mode, the motor can be run with a fixed acceleration and speed.

1. Run the motor in speed mode

| Downlink package (PC → SERV042D/57D) | | | | | | | |
|--------------------------------------|------------|----------|-------|-------|-------|-------|-------|
| BYTE1 | BYTE2 | BYTE3 | BYTE4 | | BYTE5 | BYTE6 | BYTE7 |
| Head | Slave addr | Function | dir | Rev | speed | acc | CRC |
| FA | addr | F6 | b7 | b6-b4 | b3-b0 | acc | CRC |
| | | | dir | -- | speed | | |

Byte 4: The highest bit indicates the direction, the lower 4 bits and byte 5 together indicate the speed

Byte 5: The lower 4 bits of byte 5 and byte 4 together indicate speed

The parameter description is as follows:

addr: slave address, the value range is 0-255

dir: the value range is 0/1 (CCW/CW)

speed: the speed, the value range is 0-3000

acc: the acceleration, the value range is 0-255

for example:

Send “FA 01 F6 01 40 02 34” ,

the motor rotates forward at acc=2, speed=320RPM

Send “FA 01 F6 81 40 02 B4” ,

the motor reverses at acc=2, speed=320RPM

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F6 | status(uint8_t) | CRC |

status = 1 run success.

status = 0 run fail.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .



2. Stop the motor in speed mode

| Downlink package (PC → SERVO42D/57D) | | | | | | | | |
|--------------------------------------|---------------|----------|-------|-------|-------|-------|-------|-------|
| BYTE1 | BYTE2 | BYTE3 | BYTE4 | | BYTE5 | | BYTE6 | BYTE7 |
| Head | Slave addr | Function | dir | Rev | speed | | acc | CRC |
| FA | addr | F6 | b7 | b6-b4 | b3-b0 | b7-b0 | acc | CRC |
| | | | 0 | 0 | 0 | | | |

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

① Deceleration and stop the motor slowly ($acc \neq 0$)
for example:

Send FA 01 F6 00 00 02 F3

Stop the motor with deceleration $acc=2$

② Immediate stop command ($acc = 0$)
for example:

Send FA 01 F6 00 00 00 F1

Stop the motor immediately

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F6 | status(uint8_t) | CRC |

status = 0 stop the motor fail.

status = 1 start to stop the motor.

status = 2 stop the motor success.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .



3. Save/Clean the parameter in speed mode

| Downlink package (PC → SERV042D/57D) | | | | |
|--------------------------------------|------------|----------|-------|-----|
| Head | Slave addr | Function | Data | CRC |
| FA | 01 | FF | state | CRC |

state = C8 Save.

state = CA Clean.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | FF | status(uint8_t) | CRC |

status = 1 start.

status = 0 fail.

status = 2 success.

Note: The motor can rotate clockwise or counterclockwise at a constant speed when powered on.



6.6 Position model: relative motion by pulses

In the position control mode, the motor can be run to the specified position with the set acceleration and speed.

1. Run the motor in position model

| Downlink package (PC → SERVO42D/57D) | | | | | | | | | |
|--------------------------------------|------------|----------|-------|-------|-------|-------|-------|----------|--------|
| BYTE1 | BYTE2 | BYTE3 | BYTE4 | | | BYTE5 | BYTE6 | BYTE7-10 | BYTE11 |
| Head | Slave addr | Function | dir | Rev | speed | | acc | pulses | CRC |
| FA | addr | FD | b7 | b6-b4 | b3-b0 | b7-b0 | acc | pulses | CRC |
| | | | dir | -- | speed | | | | |

Byte 4: The highest bit indicates the direction, the lower 4 bits and byte 5 together indicate the speed

Byte 5: The lower 4 bits of byte 5 and byte 4 together indicate speed

The parameter description is as follows:

addr: slave address, the value range is 0-255

dir: the value range is 0/1 (CCW/CW)

speed: the speed, the value range is 0-3000 (RPM)

acc: the acceleration, the value range is 0-255

pulses: the motor run steps, the value range is 0 - 0xFFFFFFFF

for example:

Send FA 01 FD 01 40 02 00 00 FA 00 35,

the motor rotates 20 times in the forward direction with acc=2, speed=320RPM (16 subdivisions);

Send FA 01 FD 81 40 02 00 00 FA 00 b5,

the motor rotates 20 times in the reverse direction with acc=2, speed=320RPM (16 subdivisions);

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | FD | status(uint8_t) | CRC |

status = 0 run fail.

status = 1 run starting...

status = 2 run complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .



2. Stop the motor in position model

| Downlink package (PC → SERVO42D/57D) | | | | | | | | | |
|--------------------------------------|------------|----------|-------|-------|-------|-------|-------|----------|--------|
| BYTE1 | BYTE2 | BYTE3 | BYTE4 | | BYTE5 | | BYTE6 | BYTE7-10 | BYTE11 |
| Head | Slave addr | Function | dir | Rev | speed | | acc | pulses | CRC |
| FA | addr | FD | b7 | b6-b4 | b3-b0 | b7-b0 | acc | 0 | CRC |
| | | | 0 | 0 | 0 | | | | |

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

① Deceleration and stop the motor slowly ($acc \neq 0$)

for example:

Send FA 01 FD 00 00 02 00 00 00 00 FA

Stop the motor with deceleration $acc=2$

② Immediate stop command ($acc = 0$)

for example:

Send FA 01 FD 00 00 00 00 00 00 00 F8

Stop the motor immediately

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | FD | status(uint8_t) | CRC |

status = 0 stop the motor fail.

status = 1 stop the motor starting....

status = 2 stop the motor complete.

Note1: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .

6.7 Position mode2: absolute motion by pulses

In the position control mode2, the motor can be run to the specified pulses position with the set acceleration and speed.

1. Run the motor in position mode2

| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|---------------|---------|
| Head | Slave addr | Function | speed | acc | absolute axis | Check |
| FA | addr | FE | speed | acc | absPulses | CRC |

The parameter description is as follows:

speed: the speed, the value range is 0-3000(RPM)

acc: the acceleration, the value range is 0-255

absPulses: the absolute pulses, int32_t

For example:

If the current axis is any value

Send FA 01 FE 02 58 02 00 00 40 00 95

The motor will move to 0x4000 (speed = 600(RPM), acc =2)

After move the pulses is 0x4000.

If the current axis is any value

Send FA 01 FE 02 58 02 FF FF C0 00 13

The motor will move to -0x4000 (speed = 600(RPM), acc =2)

After move the pulses is -0x4000.

| Uplink package (PC ← SERVO42D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | FE | status(uint8_t) | CRC |

status = 0 run fail.

status = 1 run starting...

status = 2 run complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .



2. Stop the motor in position mode2

| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|-----------|---------|
| Head | Slave addr | Function | speed | acc | absPulses | Check |
| FA | addr | FE | 0 | acc | 0 | CRC |

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

① Deceleration and stop the motor slowly ($acc \neq 0$)

for example:

Send FA 01 FE 00 00 04 00 00 00 00 FD

Stop the motor with deceleration $acc=4$

② Immediate stop command ($acc = 0$)

for example:

Send FA 01 FE 00 00 00 00 00 00 00 F9

Stop the motor immediately

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | FE | status(uint8_t) | CRC |

status = 0 stop fail.

status = 1 stop starting...

status = 2 stop complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disabled by Menu “UartRSP” or Command “8C”.

6.8 Position mode3: relative motion by axis

In the position control mode3, the motor can be run to the specified axis with the set acceleration and speed.

Notel: the axis is the encoder value(addition).It can be read by command “31” .

1. Run the motor in position mode2

| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|---------------|---------|
| Head | Slave addr | Function | speed | acc | Relative axis | Check |
| FA | addr | F4 | speed | acc | relAxis | CRC |

The parameter description is as follows:

speed: the speed, the value range is 0-3000(RPM)

acc: the acceleration, the value range is 0-255

relAxis: the relative axis, int32_t

For example:

If the current axis is 0x8000. (read by code “31”)

Send FA 01 F4 02 58 02 00 00 40 00 8B

The motor will relative move 0x4000 (speed = 600(RPM), acc =2)

After move the axis is 0xC000. (0x8000+0x4000=0xC000)

If the current axis is 0x8000. (read by code “31”)

Send FA 01 F4 02 58 02 FF FF C0 00 03

The motor will relative move -0x4000 (speed = 600(RPM), acc =2)

After move the axis is 0x4000. (0x8000-0x4000=0x4000)

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F4 | status(uint8_t) | CRC |

status = 0 run fail.

status = 1 run starting...

status = 2 run complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C” .

2. Stop the motor in position mode3



| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|---------------|---------|
| Head | Slave addr | Function | speed | acc | Relative axis | Check |
| FA | addr | F4 | 0 | acc | 0 | CRC |

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

① Deceleration and stop the motor slowly ($acc \neq 0$)

for example:

Send FA 01 F4 00 00 04 00 00 00 00 F3

Stop the motor with deceleration $acc=4$

② Immediate stop command ($acc = 0$)

for example:

Send FA 01 F4 00 00 00 00 00 00 00 EF

Stop the motor immediately

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F4 | status(uint8_t) | CRC |

status = 0 stop fail.

status = 1 stop starting...

status = 2 stop complete.

status = 3 end limit stoped.

Note: the "Uplink package" can be disable by Menu "UartRSP" or Command "8C".

6.9 Position mode4: absolute motion by axis

In the position control mode4, the motor can be run to the specified axis with the set acceleration and speed.

Note1: the axis is the encoder value(addition). It can be read by command “31”.

Note2: Support real-time updates of speed and coordinates, that is, new commands can be issued to change speed and coordinates when the previous command is running

1. Run the motor in position mode4

| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|---------------|---------|
| Head | Slave addr | Function | speed | acc | absolute axis | Check |
| FA | addr | F5 | speed | acc | absAxis | CRC |

The parameter description is as follows:

speed: the speed, the value range is 0-3000(RPM)

acc: the acceleration, the value range is 0-255

relAxis: the absolute axis, int32_t

For example:

If the current axis is any value

Send FA 01 F5 02 58 02 00 00 40 00 8C

The motor will move to 0x4000 (speed = 600(RPM), acc =2)

After move the axis is 0x4000.

If the current axis is any value

Send FA 01 F5 02 58 02 FF FF C0 00 0A

The motor will move to -0x4000 (speed = 600(RPM), acc =2)

After move the axis is -0x4000.

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F5 | status(uint8_t) | CRC |

status = 0 run fail.

status = 1 run starting...

status = 2 run complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disable by Menu “UartRSP” or Command “8C”.



2. Stop the motor in position mode4

| byte1 | byte2 | byte3 | byte 4-5 | byte 6 | byte 7-10 | byte 11 |
|-------|------------|----------|----------|--------|---------------|---------|
| Head | Slave addr | Function | speed | acc | absolute axis | Check |
| FA | addr | F5 | 0 | acc | 0 | CRC |

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

① Deceleration and stop the motor slowly ($acc \neq 0$)

for example:

Send FA 01 F5 00 00 04 00 00 00 00 F4

Stop the motor with deceleration $acc=4$

② Immediate stop command ($acc = 0$)

for example:

Send FA 01 F5 00 00 00 00 00 00 00 F0

Stop the motor immediately

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

| Uplink package (PC ← SERV042D/57D) | | | | |
|------------------------------------|------------|----------|-----------------|-----|
| Head | Slave addr | Function | Data | CRC |
| FB | 01 | F5 | status(uint8_t) | CRC |

status = 0 stop fail.

status = 1 stop starting...

status = 2 stop complete.

status = 3 end limit stoped.

Note: the “Uplink package” can be disabled by Menu “UartRSP” or Command “8C”.

Part7. Serial example


Note: For MODBUS-RTU example, see Part 8.

7.1 Config the SERV042D/57D

1. Menu → Mode → SR_vFOC.
2. Menu → UartBaud → 38400.
3. Menu → UartAddr → 01.

7.2 Config the Uart Assistant


1. Select the Channel; (such as COM5).
 2. Select the Baudrate; (such as 38400, Must be equal to motor baudrate).
 3. Recv Options: select “HEX”.
 4. Send Options: select “HEX”.
 5. Append checkcode: select “CHECKSUM-8”.
- Such as below:



7.3 Read the encoder value

send "FA 01 30 2B"

return "FB 01 30 FF FF FF FF 22 69 B3"



7.4 Run the motor in speed mode

Note : Please configure the working mode to “SR_vFOC”.

Menu-> Mode -> SR_vFOC

1. Send `FA 01 F6 01 40 02` , the motor will rotate at "speed = 320RPM, acc=2";

Return `FB 01 F6 01 F3`, the motor run in speed mode successful;

2. Send `FA 01 FF C8` to save the speed mode parameters;


Return `FB 01 FF 01 FC`, save successful;

3. Send `FA 01 F6 00 00 02` to stop the motor;

Return `FB 01 F6 01 F3`, the motor stops successfully;

After power-on again, the motor will run according to the save speed mode parameters.

The example command of speed mode is shown in the following figure:



7.5 Run the motor in position model

Note : Please configure the working mode to “SR_vFOC”.

Menu-> Mode -> SR_vFOC

1. Send `FA 01 FD 02 80 05 00 09 C4 00`, the motor will rotate forward 200 circles (16 subdivisions) with “speed = 640RPM, acc = 5”;

Return `FB 01 FD 01 FA`, the motor starts to run;

Return `FB 01 FD 02 FB`, the motor is run completed;

2. Send `FA 01 FD 82 80 08 00 30 D4 00`, the motor to reverse 1000 circles with “speed = 640RPM, acc = 8” (16 subdivisions);

Return `FB 01 FD 01 FA`, the motor starts to run;


While the motor is running:

Send `FA 01 FD 00 00 08 00 00 00 00`, the motor to stop with acc=8;

Return `FB 01 FD 01 FA`, the motor starting to stop;

Return `FB 01 FD 02 FB`, the motor has stopped;

The example command of position control mode is shown in the following figure:



Part8. MODBUS-RTU command description

Note: It need to enable MODBUS-RTU by menu or serial command.

8.1 Read parameter command

1. Read the encoder value(carry)

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 30H | 00H | 03H | B0H | 04H |

| Response | | | | | | |
|-----------|----------|-------|---------|----------|-------|----|
| SlaveAddr | Function | Bytes | DATA | | CRC16 | |
| | | | carry | value | Hi | Lo |
| 01H | 04H | 06H | int32_t | uint16_t | | |

carry: the carry vaule of the encoder.

value: the current vaule of the encoder. (range 0~0x3FFF)

When value is greater than 0x3FFF, carry +=1.

When Value is less than 0, carry -=1.

For example:

If the current carry|value is 0x3FF0, After one turn CCW, the carry|value (+0x4000) is 0x13FF0.

If the current carry|value is 0x3FF0, After one turn CW, the carry|value (-0x4000) is 0xFFFFFFFF3FF0.

Note: The encoder value is updated regardless of whether the motor is enabled or not.

See “00_F4(30)read encoder value (carry).mbp” for example.

2. Read the encoder value(addition)

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 31H | 00H | 03H | E1H | C4H |

| Response | | | | | | |
|-----------|----------|-------|-----------|--|-------|----|
| SlaveAddr | Function | Bytes | value | | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 06H | (int48_t) | | | |

After one turn clockwise, the value += 0x4000;

After one turn CCW, the value -= 0x4000;

For example:



If the current value is 0x3FF0, After one turn CCW, the value(+0x4000) is 0x7FF0.

If the current value is 0x3FF0, After one turn CW, the value(-0x4000) is 0xFFFFFFFFFF0.

See “01_F4(31)read encoder value(addition).mbp” for example.

3. Read the real-time speed of the motor

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 32H | 00H | 01H | E1H | C4H |

| Response | | | | | |
|-----------|----------|-------|-----------|-------|----|
| SlaveAddr | Function | Bytes | speed | CRC16 | |
| | | | | Hi | Lo |
| 01H | 04H | 02H | (int16_t) | | |

Note : if it run CCW, the speed > 0 (RPM)

if it run CW, the speed < 0 (RPM)

See “02_F4(32)Read the real-time speed.mbp” for example.

4. Read the number of pulses

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 33H | 00H | 02H | 81H | C4H |

| Response | | | | | |
|-----------|----------|-------|------------|-------|----|
| SlaveAddr | Function | Bytes | pulses | CRC16 | |
| | | | | Hi | Lo |
| 01H | 04H | 04H | (uint32_t) | | |

See “03_F4(33)Read the number of pulses.mbp” for example.



5. Read the IO Ports status

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 34H | 00H | 01H | 70H | 04H |

| Response | | | | | | |
|-----------|----------|-------|----------|-----------|-------|----|
| SlaveAddr | Function | Bytes | Reserved | status | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 02H | 00H | (uint8_t) | | |

| status | | | | | | | |
|----------|-----|-----|------|-------|-------|------|------|
| Bit7 | ... | ... | bit4 | bit3 | bit2 | bit1 | bit0 |
| reserved | | | | OUT_2 | OUT_1 | IN_2 | IN_1 |

Note: After enabling the limit remapping function, IN_1 maps to En, IN_2 maps to Dir.

6. Read the error of angle

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 39H | 00H | 02H | A1H | C6H |

| Response | | | | | |
|-----------|----------|-------|-----------|-------|----|
| SlaveAddr | Function | Bytes | errors | CRC16 | |
| | | | | Hi | Lo |
| 01H | 04H | 04H | (int32_t) | | |

The error is the difference between the angle you want to control minus the real-time angle of the motor, 0~51200 corresponds to 0~360° .

for example, when the angle error is 1° , the return error is 51200/360= 142.222, and so on.

See “04_F4(39)Read the error of angle.mbp” for example.



7. Read the En pins status

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 3AH | 00H | 01H | 11H | C7H |

| Response | | | | | | |
|-----------|----------|-------|----------|-----------|-------|----|
| SlaveAddr | Function | Bytes | Reserved | enable | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 02H | 00H | (uint8_t) | | |

enable =1 Enabled

enable =0 Disabled

See “05_F4(3A)Read the En pins status.mbp” for example.

8. Read the go back to zero status

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 3BH | 00H | 01H | 40H | 07H |

| Response | | | | | | |
|-----------|----------|-------|----------|-----------|-------|----|
| SlaveAddr | Function | Bytes | Reserved | status | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 02H | 00H | (uint8_t) | | |

status =0 going to zero.

status =1 go back to zero success.

status =2 go back to zero fail.

See “06_F4(3B)Read the go back to zero status.mbp” for example.

9. Read the motor shaft protection status

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | 3EH | 00H | 01H | 50H | 06H |

| Response | | | | | | |
|-----------|----------|-------|----------|-----------|-------|----|
| SlaveAddr | Function | Bytes | Reserved | status | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 02H | 00H | (uint8_t) | | |

status =1 protected.

status =0 no protected.

See “07_F4(3E)Read the motor shaft protection status.mbp” for example.



10. Read the motor status

| Request | | | | | | | |
|-----------|----------|------------------|-----|-----------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Reg | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 04H | 00H | F1H | 00H | 01H | 60H | 39H |

| Response | | | | | | |
|-----------|----------|-------|----------|-----------|-------|----|
| SlaveAddr | Function | Bytes | Reserved | status | CRC16 | |
| | | | | | Hi | Lo |
| 01H | 04H | 02H | 00H | (uint8_t) | | |

status = 0 read fail.

status = 1 motor stop

status = 2 motor speed up

status = 3 motor speed down

status = 4 motor full speed

status = 5 motor is homing

status = 6 motor is Cal...

See "09_F4(F1)Read the motor status.mbp" for example.

8.2 Write parameter command

1. Release the motor shaft locked-rotor protection status

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 3DH | 00H | 01H | D9H | C6H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 3DH | 00H | 01H | D9H | C6H |

See "09_F4(F1)Read the motor status.mbp" for example.

2. Restore the default parameter

(Same as the "Restore" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 3FH | 00H | 01H | 78H | 06H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 3FH | 00H | 01H | 78H | 06H |



See “11_F6(3F)Restore the default parameter.mbp” for example.

3. Restart the motor

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 41H | 00H | 01H | 18H | 1EH |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 41H | 00H | 01H | 18H | 1EH |

4. Calibrate the motor

(Same as the “Cal” option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 80H | 00H | 01H | 49H | E2H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 80H | 00H | 01H | 49H | E2H |

See “12_F6(80)Calibrate the motor.mbp” for example.

Note : The motor must be unloaded.

5. Set the work mode

(Same as the “Mode” option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 82H | 00H | mode | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 82H | 00H | mode | | |

mode = 0 CR_OPEN
mode = 1 CR_CLOSE
mode = 2 CR_vFOC
mode = 3 SR_OPEN



mode = 4 SR_CLOSE

mode = 5 SR_vFOC

See “13_F6(82)Set the work mode.mbp” for example.

6. Set the work current

(Same as the “Ma” option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 83H | Current | | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 83H | Current | | | |

Note: the new current will show in the screen of Ma option.

SERV042D/28D/35D: Maximum Current =3000mA

SERV057D: Maximum Current =5200mA

See “14_F6(83)Set the work current.mbp” for example.

7. Set the holding current percentage

(Same as the “HoldMa” option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 9BH | 00H | holdMa | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 9BH | 00H | holdMa | | |

holdMa = 00 10%

holdMa = 01 20%

...

holdMa = 08 90%

Note: Only for OPEN mode and CLOSE mode, vFOC mode is invalid.



8. Set subdivision

(Same as the "MStep" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 84H | micstep | | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 84H | micstep | | | |

See "15_F6(84)Set subdivision.mbp" for example.

9. Set the active of the En pin

(Same as the "En" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 85H | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 85H | 00H | enable | | |

enable = 00 active low (L)

enable = 01 active high (H)

enable = 02 active always (Hold)

See "16_F6(85)Set the active of the En pin.mbp" for example.

10. Set the direction of motor rotation

(Same as the "Dir" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 86H | 00H | dir | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 86H | 00H | dir | | |

dir = 00 CW

dir = 01 CCW

See "17_F6(86)Set the direction of motor rotation.mbp" for example.

Note: only for pulse interface, the direction of serial interface is set by command.

11. Set auto turn off the screen function

(Same as the " AutoSDD " option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 87H | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 87H | 00H | enable | | |

enable = 01 enabled

enable = 00 disabled

If set to Enable, the screen will automatically turn off after about 15 seconds, and any button can wake up the screen again.

See "18_F6(87)Set auto turn off the screen.mbp" for example.

12. Set the motor shaft locked-rotor protection

(Same as the " Protect " option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 88H | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 88H | 00H | enable | | |

enable = 01 enabled protection

enable = 00 disabled protection

Note: you can release the protection status by pressing the Enter button or the serial command.

See "19_F6(88)Set the motor locked-rotor protection.mbp" for example.

13. Set the subdivision interpolation function

(Same as the "MPlyer" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 89H | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 89H | 00H | enable | | |

enable = 01 enabled interpolation function.

enable = 00 disabled interpolation function.

See "20_F6(89)Set the subdivision interpolation.mbp" for example.

14. Set the baud rate

(Same as the "UartBaud" option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8AH | 00H | baud | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8AH | 00H | baud | | |

baud = 01 9600.

baud = 02 19200.

baud = 03 25000.

baud = 04 38400.

baud = 05 57600.

baud = 06 115200.

baud = 07 256000.

See "21_F6(8A)Set the baud rate.mbp" for example.



15. Set the slave address

(Same as the " UartAddr " option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8BH | 00H | addr | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8BH | 00H | addr | | |

Note1: the new address will show in the screen of UartAddr option.

Note2: 0 is the broadcast address

See "22_F6(8B)Set the slave address.mbp" for example.

16. Set MODBUS-RTU communication protocol

(Same as the " MB_RTU " option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8EH | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8EH | 00H | enable | | |

enable = 01 enabled MODBUS-RTU communication protocol.

enable = 00 disabled MODBUS-RTU communication protocol.

See "23_F6(8E)Set MODBUS-RTU.mbp" for example.

17. Set the key locked or unlocked

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8FH | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 8FH | 00H | enable | | |

enable = 01 locked the key.

enable = 00 unlocked the key.



18. Set Currnet Axis to zero

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 92H | 00H | 01H | E9H | E7H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 92H | 00H | 01H | E9H | E7H |

It can set the current Axis to Zero. Just as “GoHome” without run the motor.

See “25_F6(92) Set Currnet Axis to zero.mbp” for example.

19. Set serial mode motor enable

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | F3H | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | F3H | 00H | enable | | |

enable = 01 enabled the motor.

enable = 00 disabled the motor.

See “26_F6(F3)Set serial mode motor enable.mbp” for example.

Note : This command is only for “SR_OPEN/SR_CLOSE/SR_VFOC” mode



20. Set the parameter of home

(Same as the “HmTrig、HmDir、HmSpeed、EndLimit” option on screen)

| Request | | | | | | | | | | | | | |
|---------------|--------------|---------------------|-----|--------------------------|-----|-------|---------------|-------------|---------------|----|----------|-------|----|
| Slave addr | Func tion | Starting Address | | Quantity of Registers | | Bytes | Trig level | Home dir | Home speed | | enable | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | Hi | Lo | | Hi | Lo |
| 01H | 10H | 00H | 90H | 00H | 03H | 05H | hmTrig | hmDir | HmSpeed | | EndLimit | | |

hmTrig the effective level of the end stop

0: Low

1: High

hmDir the direction of go home

0: CW

1: CCW

hmSpeed the speed of go home

0~3000 (RPM)

EndLimit

0: disable endstop-limit

1: enable endstop-limit

Note : The speed description can be found in Chapter 6.1.

| Response | | | | | | | |
|------------|----------|------------------|-----|-----------------------|-----|-------|-----|
| Slave addr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | 90H | 00H | 03H | 80H | 25H |

See “28_F16(90)Set the parameter of home.mbp” for example.

Note1:When first time to using the “EndLimit” function or changing the limit parameters, it is necessary to go home;
(Menu -> GoHome or serial command “91”)

Note 2: When EndLimit=1, when the motor goHome touches the left limit switch, the motor will unlocked the shaft.

If you want to locked the axis after goHome, you should set EndLimit=0.

21. Set limit port remap

(only for serial control mode)

The 28/35/42D motor has only a left limit port. In serial control mode, limit port remapping can be enabled to add a right limit port.

For the 57D motor, limit port remapping can also be enabled if required to facilitate wiring.

Left limit -> En port

Right limit -> Dir port

The Com port must be connected to the corresponding high level.

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 9EH | 00H | enable | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|--------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 9EH | 00H | enable | | |

enable = 01 enable remap limit port

enable = 00 disable remap limit port

22. Set the parameter of 0_Mode

In 0_Mode, the motor can automatically return to the 0 point position when power on. The maximum angle is 359 degrees.

(Same as the “0_Mode、Set 0、0_Speed、0_Dir” option on screen)

| Request | | | | | | | | | | | | |
|---------------|--------------|---------------------|-----|--------------------------|-----|-------|--------|--------|---------|-------|-------|----|
| Slave addr | Func tion | Starting Address | | Quantity of Registers | | Bytes | 0_Mode | Set 0 | 0_Speed | 0_Dir | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | | Hi | Lo |
| 01H | 10 H | 00H | 9AH | 00H | 02H | 04H | mode | enable | speed | dir | | |

mode:

- 0: Disable do not go back to zero
- 1: DirMode go back to zero with direction
- 2: NearMode go back to zero with minimum angle

enable:

- 0: clean zero
- 1: set zero

speed:

- 0 ~ 4 (0:slowest 4:fastest)

dir:

- 0: CW
- 1: CCW

| Response | | | | | | | |
|------------|----------|------------------|-----|-----------------------|-----|-------|-----|
| Slave addr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | 9AH | 00H | 02H | 61H | E7H |



8.3 Motor running command

Note : The acceleration and speed description can be found in Chapter 6.1.

8.3.1 Emergency stop the motor

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | F7H | 00H | 01H | F9H | F8H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | F7H | 00H | 01H | F9H | F8H |

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

8.3.2 Go home

(Same as the “GoHome” option on screen)

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 91H | 00H | 01H | 19H | E7H |

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|-----|-------|-----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | 91H | 00H | 01H | 19H | E7H |

See “24_F6(91) Go Home.mbp” for example.

Note: If the limit switch is already closed, the motor will rotate in the opposite direction to homeDir until the limit switch is opened, and then go home.



8.3.3 Speed mode command

Note: It needs to set the working mode to serial mode.

(SR_OPEN/SR_CLOSE/SR_VFOC)

In speed mode, the motor can be run with a fixed acceleration and speed.

1. Run the motor in speed mode

| Request | | | | | | | | | | | | |
|------------|-----------|------------------|-----|-----------------------|-----|-------|------------|---------------|-------|----|-------|----|
| Slave Addr | Func tion | Starting Address | | Quantity of Registers | | Bytes | direc tion | accelera tion | speed | | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F6H | 00H | 02H | 04H | dir | acc | speed | | | |

dir: the value range is 0/1 (CCW/CW)

acc: the acceleration, the value range is 0-255

speed: the speed, the value range is 0-3000

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F6H | 00H | 02H | A1H | FAH |

See “29_F16(F6) Run the motor in speed mode.mbp” for example.

2. Stop the motor in speed mode

The stop command can stop the motor slowly, or stop the motor immediately.

When setting $acc \neq 0$, the motor decelerates and stops slowly

When setting $acc = 0$, the motor stops immediately

| Request | | | | | | | | | | | | |
|------------|-----------|------------------|-----|-----------------------|-----|-------|------------|----------------|-------|----|-------|----|
| Slave Addr | Func tion | Starting Address | | Quantity of Registers | | Bytes | direc tion | acce le ration | speed | | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F6H | 00H | 02H | 04H | 00H | acc | 00H | | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F6H | 00H | 02H | A1H | FAH |

See “29_F16(F6) Run the motor in speed mode.mbp” for example.

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!



3. Save/Clean the parameter in speed mode

| Request | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | FFH | 00H | flag | | |

flag = C8H save the parameter

flag = CAH clean the parameter

| Response | | | | | | | |
|-----------|----------|------------------|-----|------------|------|-------|----|
| SlaveAddr | Function | Register Address | | Write Data | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 06H | 00H | FFH | 00H | flag | | |

See “27_F6(FF) Save or Clean the parameter in speed mode.mbp”
for example.

Note: The motor can rotates clockwise or counterclockwise at a constant speed when powered on.



8.3.4 Position model: relative motion by pulses

Note: It needs to set the working mode to serial mode.

(SR_OPEN/SR_CLOSE/SR_VFOC)

1. Run the motor in position model

| Request | | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----------|--------------|-------|--------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | direction | acceleration | speed | pulses | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | | Hi | Lo |
| 01H | 10H | 00H | FDH | 00H | 04H | 08H | dir | acc | speed | pulses | | |

dir (uint8_t) the value range is 0/1 (CCW/CW)

acc (uint8_t) the acceleration, the value range is 0 - 255

speed (uint16_t) the speed, the value range is 0 - 3000 (RPM)

pulses (uint32_t) the steps, the value range is 0 - 0xFFFFFFFF

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | FDH | 00H | 04H | 50H | 3AH |

See “30_F16(FD) Position model relative motion by pulses.mbp” for example.

2. Stop the motor in position model

The stop command can stop the motor slowly, or stop the motor immediately.

When setting acc \neq 0, the motor decelerates and stops slowly

When setting acc = 0, the motor stops immediately

| Request | | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----------|--------------|-------|--------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | direction | acceleration | speed | pulses | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | | Hi | Lo |
| 01H | 10H | 00H | FDH | 00H | 04H | 08H | 00H | acc | 00H | 00H | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | FDH | 00H | 04H | 50H | 3AH |

See “30_F16(FD) Position model relative motion by pulses.mbp” for example.

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!

8.3.5 Position mode2: absolute motion by pulses

Notel: It needs to set the working mode to serial mode.

(SR_OPEN/SR_CLOSE/SR_VFOC)

In the position control mode2, the motor can be run to the specified pulses position with the set acceleration and speed.

1. Run the motor in position mode2

| Request | | | | | | | | | | | |
|---------------|--------------|---------------------|-----|--------------------------|-----|-------|--------------|-------|------------------|-------|----|
| SlaveA ddr | Func tion | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | absolute axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | FEH | 00H | 04H | 08H | acc | speed | absPulses | | |

acc (uint16_t) the acceleration, the value range is 0 - 255

speed (uint16_t) the speed, the value range is 0 - 3000 (RPM)

absPulses(int32_t) the Pulses, int32_t

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | FEH | 00H | 04H | | |

2. Stop the motor in position mode2

The stop command can stop the motor slowly, or stop the motor immediately.

When setting acc \neq 0, the motor decelerates and stops slowly

When setting acc = 0, the motor stops immediately

| Request | | | | | | | | | | | |
|---------------|--------------|---------------------|-----|--------------------------|-----|-------|--------------|-------|------------------|-------|----|
| SlaveA ddr | Func tion | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | absolute axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | FEH | 00H | 04H | 08H | acc | 00H | 00H | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | FEH | 00H | 04H | | |

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!



8.3.6 Position mode3: relative motion by axis

Note1: It needs to set the working mode to serial mode.

(SR_OPEN/SR_CLOSE/SR_VFOC)

Note2: the axis is the encoder value(addition).It can be read by command “31”.

In the position control mode3, the motor can be run to the specified axis with the set acceleration and speed.

1. Run the motor in position mode3

| Request | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|--------------|-------|---------------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | Relative axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | F4H | 00H | 04H | 08H | acc | speed | relAxis | | |

acc (uint16_t) the acceleration, the value range is 0 - 255

speed (uint16_t) the speed, the value range is 0 - 3000 (RPM)

relAxis(int32_t) the steps, int32_t

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F4H | 00H | 04H | 80H | 38H |

See “31_F16(F4) Position mode2 relative motion by axis.mbp” for example.

2. Stop the motor in position mode3

The stop command can stop the motor slowly, or stop the motor immediately.

When setting acc \neq 0, the motor decelerates and stops slowly

When setting acc = 0, the motor stops immediately

| Request | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|--------------|-------|---------------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | Relative axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | F4H | 00H | 04H | 08H | acc | 00H | 00H | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F4H | 00H | 04H | 80H | 38H |

See “31_F16(F4) Position mode2 relative motion by axis.mbp” for example.

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!



8.3.7 Position mode4: absolute motion by axis

Note1: It needs to set the working mode to serial mode.

(SR_OPEN/SR_CLOSE/SR_VFOC)

Note2: the axis is the encoder value(addition). It can be read by command “31”.

Note3: Support real-time updates of speed and coordinates, that is, new commands can be issued to change speed and coordinates when the previous command is running

1. Run the motor in position mode4

| Request | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|--------------|-------|---------------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | absolute axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | F5H | 00H | 04H | 08H | acc | speed | absAxis | | |

acc (uint16_t) the acceleration, the value range is 0 - 255

speed (uint16_t) the speed, the value range is 0 - 3000 (RPM)

absAxis(int32_t) the steps, int32_t

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F5H | 00H | 04H | D1H | F8H |

See “32_F16(F5) Position mode3 absolute motion by axis.mbp” for example.

2. Stop the motor in position mode4

The stop command can stop the motor slowly, or stop the motor immediately.

When setting acc \neq 0, the motor decelerates and stops slowly

When setting acc = 0, the motor stops immediately

| Request | | | | | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|--------------|-------|---------------|-------|----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | Bytes | acceleration | speed | absolute axis | CRC16 | |
| | | Hi | Lo | Hi | Lo | | | | | Hi | Lo |
| 01H | 10H | 00H | F5H | 00H | 04H | 08H | acc | 00H | 00H | | |

| Response | | | | | | | |
|-----------|----------|------------------|-----|-----------------------|-----|-------|-----|
| SlaveAddr | Function | Starting Address | | Quantity of Registers | | CRC16 | |
| | | Hi | Lo | Hi | Lo | Hi | Lo |
| 01H | 10H | 00H | F5H | 00H | 04H | D1H | F8H |

See “32_F16(F5) Position mode3 absolute motion by axis.mbp” for example.

Note: If the motor rotating more than 1000RPM, it is not a good idea to stop the motor immediately!



Part9. FAQ

9.1 NOTE

1. Power input voltage is 12V-24V.
2. Don't hot plug motor cable and data cable.
3. When the motor is calibrating, do not carry a load.
4. After installed the motor, or changed the motor wiring sequence, you need to re-calibrate the motor again.
5. The default work mode is CR_vFOC(EN/STP/DIR interface).
6. Press the "Next" key first, then power on, it can quickly restore the default parameters.
7. If "Phase Line Error!" is displayed before calibration:
 - b) Check the motor connection line sequence;
 - c) Check the power supply voltage and output power (24V/1A, 12V/2A);;
 - d) If the power supply is connected to the motherboard through the MKS APT module, try to connect the MKS APT module to ports such as X, Y, Z, E, etc., and then restart again.
 - e) Do not use the MKS APT module for power supply before calibration, and the power supply is directly connected to V+ and Gnd.

9.2 FAQ

| No | Question | Solution |
|----|-------------------------|--|
| 1 | Not Cal | Calibrate the motor. |
| 2 | Reverse Lookup Error! | Calibrate Fail, Check magnet and motor shaft |
| 3 | Magnet Loss! | Not install the magnet. |
| 4 | Magnet Strong! | the magnet too near. |
| 5 | Magnet Weak! | the magnet too far. |
| 6 | Encoder Error! | Check magnet and motor shaft |
| 7 | Offset Current Error! | Reference voltage error |
| 8 | Phase Line Error! | The motor line sequence is wrong or the power supply is not enough |
| 9 | Wrong Protect! | Locked-rotor protection |
| 10 | Coming Back to Origin.. | Going back to zero. |
| 11 | Reboot Again | The motor need to be restart. |
| 12 | Press Next Key To Fixed | Press Next Key, until it reboot. |
| | | |



Part10. Schematic

Please download 《MKS SERV042D/57D V1.0 Schematic.pdf》 in
<https://github.com/makerbase-motor/MKS-SERV042D>
<https://github.com/makerbase-motor/MKS-SERV057D>

Part11. contact us

<https://makerbase.aliexpress.com/>
<https://www.youtube.com/channel/UC2i5I1tc0XRJ2ZJiRxwpCUQ>
<https://github.com/makerbase-motor>