

## How to bind the serial port baud rate screen V1.0

category	content
Key words	Serial port baud rate summary screen



revise history

version	date	the reason	prepared by	Examine
V1.0	2018/05/15	Create documents	Xie upheld as	



## Sales and Service

**Guangzhou color Optoelectronics Technology Co., Ltd.**

phone: 020-82186683

fax: 020-82187676

Email : hmi@gz-dc.com (Public Service) website: [www.gz-dc.com](http://www.gz-dc.com)

Ground Address: Guangzhou High-tech Industrial Development Zone, Yushu Industrial Park, Beverly West 8 number

C Building 303 Housing official website Taobao retail shop: <https://gz-dc.taobao.com>



## table of Contents

1. Scope .....	1
2. Development Environment version .....	2
3. Binding serial port baud rate screen method .....	3
3.1 Binding instructions baud rate .....	3
3.2 Project Configuration Lock Baud Rate .....	4



## 1. Scope

Documentation for budget, basic, were linked, 86 box series serial-screen products.

## 2. Development Environment version

1 , VisualTFT Software version: V3.0.0.732 And above; versions View: Open VisualTFT Click Help -> About VisualTFT You can view the current software version number; the latest version can be found at [www.gz-dc.com](http://www.gz-dc.com) Download



2 , Serial screen hardware version: V2.22.959.XXX And above. View version :( 1) Check

the version number sticker on the back screen.

(2) VisualTFT After the success of the online screen, the version number displayed in the lower right corner.


### 3. Binding serial port baud rate screen method

The method of binding the serial baud rate screen two ways: First, the baud rate is achieved by sending a binding to a serial instruction screen; the second is disposed inside the engineering properties of the corresponding baud rate property, can be downloaded directly Engineering .

#### 3.1 Binding instructions baud rate


The baud rate can be bound by the serial instruction screen, the following steps:

1. Assistant opening command, select the "device configuration", as shown in 3-1 Fig.




Map 3-1 Device Configuration

2. Send "Release System Configuration lock" instruction, as shown in 3-2 Fig.



Map 3-2 System configuration lock is released

3. Select the appropriate baud rate, transmit "set" baud rate command, as shown in 3-3 Fig.



Map 3-3 Set the baud rate

### 3.2 Project Configuration Lock Baud Rate

The baud rate is set in the project properties through Project Configuration Lock Baud Rate mainly good, then compiled, you can re-download the project, the appropriate action as follows:

1. Open the menu bar "Tools", select the "Project Configuration", as 3-4 Fig.



Map 3-4 Project Configuration

2. Compile the project, the project can be re-downloaded.

Note: Download this step will make the project screen communication is communication at the baud rate, if the instruction is bound to another baud rate, and that the screen will be locked in another baud rate; when the screen works re-download, it will bind to the baud rate of the project configuration.