

# EftTerminalStatus messages

In this page we present all the Status Codes which can be sent on the EftTerminalStatus messages.

We support 4 different types of Terminal Status messages:

- [Display status messages](#)
- [Card Status Messages](#)
- [Power Status Messages](#)
- [Information Status Codes](#)

## Display status messages

These messages are sent when a display is shown on terminal. They are marked as status type “D” (Display).

Screen	Status Code
ACCOUNT_TYPE_SELECTION	1122
ACTIVATION_IN_PROGRESS	1182
AMOUNT_CONFIRMATION	118
AMOUNT_ENTRY	120
AMOUNT_GRATUITY_ENTRY	116
AMOUNT_OUT_OF_CEILING_LIMITS	1177
AMOUNT_TOO_HIGH	1137
APN_ENTRY	1200
APPLICATION_SELECTION	1041
APPLICATION_SELECTION_CARDHOLDER_OVERRIDE	1285
APPROVED	107
APPROVED_WARN	1142
AUTHORIZATION_IN_PROGRESS	110
AUTH_CODE_ENTRY	1048
AUTH_SERVERS_MENU	1227
AUTH_SERVERS_SELECTION	1228
BATTERY_LOW	1248
BLUETOOTH_DEVICE_SELECTION	1160
BLUETOOTH_MENU	1159
BLUETOOTH_MENU_CONFIG	1190
BLUETOOTH_PAIRING_FAILURE	1162
BLUETOOTH_PAIRING_SUCCESS	1161
BLUETOOTH_PIN	1163
BLUETOOTH_TETHERING	1164
BLUETOOTH_TETHERING_CONNECT	1165
CARD_ACCEPTED	1008
CARD_BLOCKED	1009
CARD_CVV_ENTRY	1273
CARD_DATE_EXPIRY_ENTRY	104
CARD_DATE_INVALID	1249

CARD_DATE_START_ENTRY	1042
CARD_EXPIRED	1011
CARD_ISSUE_NUMBER	105
CARD_NOT_ACCEPTED	113
CARD_NUMBER_ENTRY	103
CARD_ONLY_ONE	1066
CARD_RECONITION_IN_PROGRESS	1030
CASH_OUT_IN_PROGRESS	1254
CFG_USB	1158
CHECK_BALANCE_IN_PROGRESS	1184
COMMUNICATION_ERROR	1152
COMPLETION_IN_PROGRESS	1027
CONFIG_APPMODE	1246
CONFIG_INSTALLMENT_MENU	1290
CONFIG_KEYBOARD	1275
CONFIG_LOCK_MODE	1263
CONFIG_LOG_LEVEL_MENU	1234
CONFIG_LOG_MENU	1233
CONFIG_LOG_TARGET_MENU	1272
CONFIG_LOYALTY_MENU	1291
CONFIG_MENU	1070
CONFIG_NETWORK_AUTHENTICATION_MENU	1243
CONFIG_NETWORK_MODE_MENU	1239
CONFIG_NETWORK_PPP_PASSWORD_ENTRY	1242
CONFIG_NETWORK_PPP_USERNAME_ENTRY	1241
CONFIG_NETWORK_PROVIDER_MENU	1240
CONFIG_PAX_CUSTOMIZATION	1260
CONFIG_SERVERS_SELECTION	1237
CONFIG_SETTINGS_BOOLEAN	1298
CONFIG_SETTINGS_MENU	1297
CONFIG_STORE_RESET_FAILURE	1094
CONFIG_STORE_RESET_IN_PROGRESS	1096
CONFIG_STORE_RESET_MENU	1093
CONFIG_STORE_RESET_SUCCESSFUL	1095
CONFIG_SYSTEM_MENU	1156
CONFIG_SYSTEM_UI	1296
CONFIG_UPDATE_MENU	1155
CONFIRM_INTERFACE_CHANGE	1185
CONNECT_DEVICE_BASESTATION	1255
DCC_CHOICE	112
DCC_DISCLAIMER_PROVIDER	1229

DECLINED	108
DEVICE_NOT_REGISTERED	1287
DIAGNOSTICS_BACKGROUND_MENU	1226
DIAGNOSTICS_BACKGROUND_START_FAILURE	1225
DIAGNOSTICS_BACKGROUND_START_SUCCESS	1208
DIAGNOSTICS_BACKGROUND_STOP_FAILURE	1209
DIAGNOSTICS_BACKGROUND_STOP_SUCCESS	1210
DIAGNOSTICS_BATTERY	1211
DIAGNOSTICS_BATTERY_MENU	1212
DIAGNOSTICS_CONNECTIVITY	1213
DIAGNOSTICS_FAILED	1214
DIAGNOSTICS_MANUAL_PRINT_QUESTION	1215
DIAGNOSTICS_MENU	1216
DIAGNOSTICS_PING	1217
DIAGNOSTICS_PING_MENU	1218
DIAGNOSTICS_PLEASE_WAIT	1219
DIAGNOSTICS_SUCCESSFUL	1220
DIAGNOSTICS_TIME_ENTRY	1221
DIAGNOSTICS_WIFI	1232
DIAGNOSTICS_WIFI_GENERAL_INFORMATION	1222
DIAGNOSTICS_WIFI_MENU	1224
DIAGNOSTICS_WIFI_SPECIFIC_INFORMATION	1223
DONATION_QUESTION	1202
DOWNLOAD_CONFIG_CANCELED	1074
DOWNLOAD_CONFIG_FAILED	1071
DOWNLOAD_CONFIG_NOT_AVAILABLE	1075
DOWNLOAD_CONFIG_PLEASE_WAIT	1073
DOWNLOAD_CONFIG_SUCCESS	1072
DOWNLOAD_FIRMWARE_CANCELLED	1080
DOWNLOAD_FIRMWARE_FAILED	1079
DOWNLOAD_FIRMWARE_FAILED_ACCESS	1147
DOWNLOAD_FIRMWARE_FAILED_COM	1146
DOWNLOAD_FIRMWARE_FAILED_MAC_IN_USE	1150
DOWNLOAD_FIRMWARE_FAILED_MAC_UN	1148
DOWNLOAD_FIRMWARE_FAILED_TID_IN_USE	1151
DOWNLOAD_FIRMWARE_FAILED_TID_UN	1149
DOWNLOAD_FIRMWARE_PLEASE_WAIT	1077
DOWNLOAD_FIRMWARE_SUCCESS	1078
EMV_LANGUAGE_SELECTION	1039
ERROR_OTHER_CARD	1067
EVENT_UPLOAD_FAILED	1118

EVENT_UPLOAD_PLEASE_WAIT	1116
EVENT_UPLOAD_SUCCESS	1117
EXPORT_TO_USB_FAILED	1235
EXPORT_TO_USB_SUCCESSFUL	1236
FILE_COPY_FAIL	1269
FILE_COPY_SUCCESS	1270
FIRMWARE_UPDATE_FAILED	1083
FIRMWARE_UPDATE_INSTALL	1081
FIRMWARE_UPDATE_NOT_AVAILABLE	1084
FIRMWARE_UPDATE_SUCCESS	1082
GIFT_CARD_MENU_SAVVY	1262
GIFT_CARD_MENU_SVS	1181
GIFT_CARD_TYPE_SELECTION	1261
GPRS_MENU	1201
GRATUITY_MENU	115
GRATUITY_QUESTION	115
GRATUITY_TOO_HIGH	1018
GUEST_COUNT_ENTRY	1231
HOST_UNAVAILABLE	1037
HOST_WARNING	109
INSERT_CARD	101
INSERT_PRESENT_CARD	1110
INSERT_SWIPE_CARD	1109
INSERT_SWIPE_PRESENT_CARD	1113
INSERT_USB	1264
INSTALLMENT_OFFER	1292
INSTANCE_TID_ENTRY	1092
INTEGRATOR_SERVER_SELECTION	1247
INVALID_INPUT	1276
KEY_INITIAL_ERROR	1167
KEY_LOADING_FAILED	1168
LANGUAGE_SELECTION	1038
LAN_MENU	1186
LOYALTY_QUESTION	1293
MAIN_MENU	1059
MISSING_STORE_NUMBER	1289
NETWORK_DEFAULT_GATEWAY_ENTRY	1055
NETWORK_DHCP_MENU	1057
NETWORK_DNS_1_ENTRY	1056
NETWORK_DNS_2_ENTRY	1056
NETWORK_INFO	1064

NETWORK_IP_ENTRY	1053
NETWORK_MENU	1065
NETWORK_NO_ADAPTER	1063
NETWORK_SUBNETMASK_ENTRY	1054
NEW_SIM_CARD_DETECTED	1244
NFC_TRY_AGAIN	1069
NO_APP_FOUND	1032
NO_ENTRY_FOUND	1128
NO_RECEIPT_AVAILABLE	1207
NO_WLAN_AVAILABLE	1135
OPERATION_CANCELED	1187
OPERATION_FAILED	1188
OPERATION_NOT_ALLOWED	1245
OPERATION_SUCCESSFUL	1279
PARTIAL_APPROVAL_QUESTION	1173
PASSWORD_ENTRY	1119
PAYMENT_MEAN_SELECTION	1191
PAYMENT_SELECTION	1049
PAYMENT_SELECTION_DYNAMIC	1049
PAY_AT_BAR_MENU	1206
PAY_AT_TABLE_AMOUNT_CONFIRMATION	1138
PAY_AT_TABLE_CHECK_ALREADY_PAID	1169
PAY_AT_TABLE_CHECK_ID_ENTRY	1125
PAY_AT_TABLE_CHECK_SEQ_ID_ENTRY	1145
PAY_AT_TABLE_PAYMENT_SELECTION	1136
PAY_AT_TABLE_REFUND_CASH	1139
PAY_AT_TABLE_REVENUE_CENTER_SELECTION	1174
PAY_AT_TABLE_SCENARIO_SELECTION	1123
PAY_AT_TABLE_TABLE_ID_ENTRY	1126
PAY_AT_TABLE_WAITER_ID_ENTRY	1124
PAY_AT_TABLE_WAITER_ID_UNKNOWN	1127
PIN_ENTRY	106
PIN_ENTRY_BYPASS	1020
PIN_ENTRY_BYPASS_LAST_TRIAL	1021
PIN_ENTRY_LAST_TRIAL	1019
PIN_REENTRY	1129
PIN_REENTRY_BYPASS	1131
PIN_REENTRY_BYPASS_LAST_TRIAL	1132
PIN_REENTRY_LAST_TRIAL	1130
PLEASE_WAIT	1017
PRESENT_CARD	1108

PRESENT_DEVICE_AGAIN	1294
PRESENT_MEMBERSHIP_CARD	1230
PRINTER_ERROR	1170
PRINTER_MENU	1178
PRINTER_PRINT_QUEUE	1171
PRINTER_QUEUE_FULL	1172
PROCESSING_PLEASE_WAIT	1022
PROCESS_NOT_POSSIBLE	1175
QR_SCAN_ALIPAY_PLUS	1300
QR_SCAN_IMAGE_BEFORE	1301
QR_SCAN_TEXT_AFTER	1192
QR_SCAN_TEXT_BEFORE	1295
REACTIVATION_DATA	1101
REACTIVATION_MENU	1102
REACTIVATION_PINPAD_ENTRY	1098
REACTIVATION_PINPAD_FAILURE	1104
REACTIVATION_PINPAD_SUCCESS	1103
REACTIVATION_READER_ENTRY	1099
REACTIVATION_READER_FAILURE	1106
REACTIVATION_READER_SUCCESS	1105
RECEIPT_COPY	1141
RECEIPT_INFO_PRINT	1144
RECEIPT_NEXT	1120
RECEIPT_QUESTION_CARDHOLDER	1203
RECEIPT_QUESTION_FINAL_INVOICE	1204
RECEIPT_QUESTION_MERCHANT	1205
RECEIPT_TO_PRINT_SELECTION	1179
RECONNECTING_WIFI_PLEASE_WAIT	1278
REDEMPTION_IN_PROGRESS	1183
REFERENCE_NUMBER_ENTRY	1277
REFUND_IN_PROGRESS	1029
REINSERT_CARD	1015
REINSERT_PRESENT_CARD	1112
RELOAD_IN_PROGRESS	1185
REMOTE_SYSTEM_ERROR	1288
REMOVE_CARD	121
REPRESENT_CARD	1121
REVERSAL_APPROVED	1035
REVERSAL_DECLINED	1036
REVERSAL_IN_PROGRESS	1025
SALE_IN_PROGRESS	1028

SCREEN_SAVER	1250
SEE_PHONE	1068
SELECTED_APPLICATION	1034
SETTINGS_LIST	1299
SETTLEMENT_REVERSAL_IN_PROGRESS	1026
SHIFT_SELECTION	1040
SIGNATURE_CONFIRMATION_CARDHOLDER	114
SIGNATURE_CONFIRMATION_MERCHANT	114
SIM_PIN_ENTRY	1195
SIM_PUK_ENTRY	1198
SSH_MENU	1157
SWIPE_CARD	102
SWIPE_PRESENT_CARD	1111
TAXFREE_CHECK	1257
TAXFREE_OFFER	1258
TAX_REFUND_ELIGIBILITY_OFFER	1280
TAX_REFUND_GET_FROM_OPERATOR_AND_STAMP	1281
TAX_REFUND_LIST	1282
TAX_REFUND_OTHER_OPTIONS_AVAILABLE	1283
TAX_REFUND_SINGLE_OPTION_OFFER	1284
TERMINAL_DEACTIVATED	1006
TERMINAL_INFO	1051
TERMINAL_NOT_OPERATIONAL	1052
TERMINAL_OUT_OF_ORDER	1100
TERMINAL_READY	123
TERMINAL_REBOOT	1060
TERMINAL_REBOOT_MANUAL	1061
TIME_CONFIG_ENTRY	1085
TIME_CONFIG_FAILURE	1087
TIME_CONFIG_IN_PROGRESS	1086
TIME_CONFIG_SUCCESS	1088
TIME_MENU	1166
TIP_NOT_SUPPORTED	1176
TMS_FILES_UPDATE_FAILED	1251
TMS_FILES_UPDATE_NO_NEW_FILE	1252
TMS_FILES_UPDATE_SUCCESSFUL	1253
TMS_IP_ENTRY	1091
TMS_PORT_ENTRY	1090
TMS_SERVERS_SELECTION	1238
TMS_TID_ENTRY	1089
TOPUP_IN_PROGRESS	1256

TRANSACTION_CANCELED	124
TRANS_DETAILS_CONFIRM	1153
TRANS_REF_NUM_ENTRY	1043
TRY_ANOTHER_INTERFACE	1274
VALIDATION_IN_PROGRESS	1023
VALIDATION_ONLINE_IN_PROGRESS	1024
WELCOME	119
WLAN_AUTHENTICATION_SELECTION	1265
WLAN_AVAILABLE_NETWORKS	1133
WLAN_ENCRYPTION_SELECTION	1046
WLAN_IDENTITY_ENTRY	1266
WLAN_KEY_ENTRY	1047
WLAN_MENU	1189
WLAN_NO_CERTIFICATES_AVAILABLE	1267
WLAN_NO_CREDENTIALS_AVAILABLE	1268
WLAN_PRIV_KEY_PWD_ENTRY	1271
WLAN_PROTOCOL_SELECTION	1045
WLAN_SELECTION_MODE	1134
WLAN_SSID_ENTRY	1044
WRONG_PASSWORD	1286
UNKNOWN	125

## Card Status Messages

These messages are sent when the card status changes on terminal. They are marked as status type “C” (Card).

Status Type	Status Code
Card inserted	200
Card removed	201
Card swiped	202
Card not present	203
Card manually entered	204
Card data accepted	205
Card data not accepted	206
Card data error	207
Card cancelled	208
Card timeout	209
Card reading started	210
Card presented	211

## Power Status Messages

These messages are sent when the integrator requests the power information to the terminal. They are marked as status type “P” (Power).



Woken Up message is sent when the terminal awakes after being in sleep mode.

Description	Status Code
Power on	300
Power off	301
Woken up	302

## Information Status Codes

These messages are sent when the terminal starts or the integrator requests the terminal information (400), or when the terminal languages gets changed (401), these are always sent as status type "I" (Info).

Description	Status Code
Terminal information	400
Language changed	401