

URSQRTE

Unsigned Reciprocal Square Root Estimate. This instruction reads each vector element from the source SIMD&FP register, calculates an approximate inverse square root for each value, places the result into a vector, and writes the vector to the destination SIMD&FP register. All the values in this instruction are unsigned integer values.

Depending on the settings in the [CPACR_EL1](#), [CPTR_EL2](#), and [CPTR_EL3](#) registers, and the current Security state and Exception level, an attempt to execute the instruction might be trapped.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	Q	1	0	1	1	1	0	1	sz	1	0	0	0	0	1	1	1	0	0	1	0	Rn						Rd			

URSQRTE <Vd>.<T>, <Vn>.<T>

```
integer d = UInt(Rd);
integer n = UInt(Rn);

if sz == '1' then UNDEFINED;
constant integer esize = 32;
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;
```

Assembler Symbols

<Vd> Is the name of the SIMD&FP destination register, encoded in the "Rd" field.

<T> Is an arrangement specifier, encoded in "sz:Q":

sz	Q	<T>
0	0	2S
0	1	4S
1	x	RESERVED

<Vn> Is the name of the SIMD&FP source register, encoded in the "Rn" field.

Operation

```
CheckFPAdvSIMDEnabled64();
bits(datasize) operand = V[n, datasize];
bits(datasize) result;
bits(32) element;

for e = 0 to elements-1
    element = Elem[operand, e, 32];
    Elem[result, e, 32] = UnsignedRSqrtEstimate(element);
```

```
V[d, datasize] = result;
```

[Base
Instructions](#)

[SIMD&FP
Instructions](#)

[SVE
Instructions](#)

[SME
Instructions](#)

[Index by
Encoding](#)

[Sh
Pseu](#)

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode
no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56

Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This
document is Non-Confidential.