

RDSVL

Read multiple of Streaming SVE vector register size to scalar register

Multiply the Streaming SVE vector register size in bytes by an immediate in the range -32 to 31 and place the result in the 64-bit destination general-purpose register.

This instruction does not require the PE to be in Streaming SVE mode.

SME

(FEAT_SME)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	1	0	0	1	0	1	1	1	1	1	1	0	1	0	1	1	imm6						Rd				

RDSVL <Xd>, #<imm>

```
if !HaveSME() then UNDEFINED;
integer d = UInt(Rd);
integer imm = SInt(imm6);
```

Assembler Symbols

- <Xd> Is the 64-bit name of the destination general-purpose register, encoded in the "Rd" field.
- <imm> Is the signed immediate operand, in the range -32 to 31, encoded in the "imm6" field.

Operation

```
CheckSMEEnabled();
constant integer SVL = CurrentSVL;
integer len = imm * (SVL DIV 8);
X[d, 64] = len<63:0>;
```

Operational information

If PSTATE.DIT is 1:

- The execution time of this instruction is independent of:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.
- The response of this instruction to asynchronous exceptions does not vary based on:
 - The values of the data supplied in any of its registers.
 - The values of the NZCV flags.

[Base
Instructions](#)

[SIMD&FP
Instructions](#)

[SVE
Instructions](#)

[SME
Instructions](#)

[Index by
Encoding](#)

[Sh
Pseu](#)

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode
no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56

Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This
document is Non-Confidential.