

## FEXPA

Floating-point exponential accelerator

The FEXPA instruction accelerates the polynomial series calculation of the  $\exp(x)$  function.

The double-precision variant copies the low 52 bits of an entry from a hard-wired table of 64-bit coefficients, indexed by the low 6 bits of each element of the source vector, and prepends to that the next 11 bits of the source element ( $\text{src}<16:6>$ ), setting the sign bit to zero.

The single-precision variant copies the low 23 bits of an entry from hard-wired table of 32-bit coefficients, indexed by the low 6 bits of each element of the source vector, and prepends to that the next 8 bits of the source element ( $\text{src}<13:6>$ ), setting the sign bit to zero.

The half-precision variant copies the low 10 bits of an entry from hard-wired table of 16-bit coefficients, indexed by the low 5 bits of each element of the source vector, and prepends to that the next 5 bits of the source element ( $\text{src}<9:5>$ ), setting the sign bit to zero.

A coefficient table entry with index  $m$  holds the floating-point value  $2^{(m/64)}$ , or for the half-precision variant  $2^{(m/32)}$ . This instruction is unpredicated. This instruction is illegal when executed in Streaming SVE mode, unless FEAT\_SME\_FA64 is implemented and enabled.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	1	0	0	size	1	0	0	0	0	0	1	0	1	1	1	0	Zn				Zd						

**FEXPA** **<Zd>.<T>**, **<Zn>.<T>**

```
if !HaveSVE() then UNDEFINED;
if size == '00' then UNDEFINED;
constant integer esize = 8 << UInt(size);
integer n = UInt(Zn);
integer d = UInt(Zd);
```

## Assembler Symbols

**<Zd>** Is the name of the destination scalable vector register, encoded in the "Zd" field.

**<T>** Is the size specifier, encoded in "size":

size	<T>
00	RESERVED
01	H
10	S
11	D

<Zn> Is the name of the source scalable vector register, encoded in the "Zn" field.

## Operation

```
CheckNonStreamingSVEEnabled();
constant integer VL = CurrentVL;
constant integer PL = VL DIV 8;
constant integer elements = VL DIV esize;
bits(VL) operand = Z[n, VL];
bits(VL) result;

for e = 0 to elements-1
    bits(esize) element = Elem[operand, e, esize];
    Elem[result, e, esize] = FPExpA(element);

Z[d, VL] = result;
```

---

[Base  
Instructions](#)

[SIMD&FP  
Instructions](#)

[SVE  
Instructions](#)

[SME  
Instructions](#)

[Index by  
Encoding](#)

[Sh  
Pseud](#)

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode  
no\_diffs\_2023\_09\_RC2, sve v2023-06\_rel ; Build timestamp: 2023-09-18T17:56

Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This  
document is Non-Confidential.