

BFMUL (vectors, unpredicated)

BFloat16 floating-point multiply vectors (unpredicated)

Multiply all BFloat16 elements of the second source vector to corresponding elements of the first source vector and place the results in the corresponding elements of the destination vector.

This instruction follows SVE2.1 non-widening BFloat16 numerical behaviors.

This instruction is unpredicated.

ID_AA64ZFR0_EL1.B16B16 indicates whether this instruction is implemented.

SVE2

(FEAT_SVE_B16B16)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	1	1	0	0	1	0	1	0	0	0	0	Zm	0	0	0	0	1	0	Zn	Zd											
								size<1>		size<0>																					

BFMUL <Zd>.H, <Zn>.H, <Zm>.H

```
if (!HaveSVE2() && !HaveSME2()) || !IsFeatureImplemented(FEAT_SVE_B16B16)
integer n = UInt(Zn);
integer m = UInt(Zm);
integer d = UInt(Zd);
```

Assembler Symbols

- <Zd> Is the name of the destination scalable vector register, encoded in the "Zd" field.
- <Zn> Is the name of the first source scalable vector register, encoded in the "Zn" field.
- <Zm> Is the name of the second source scalable vector register, encoded in the "Zm" field.

Operation

```
CheckSVEEnabled();
constant integer VL = CurrentVL;
constant integer elements = VL DIV 16;
bits(VL) operand1 = Z[n, VL];
bits(VL) operand2 = Z[m, VL];
bits(VL) result;

for e = 0 to elements-1
    bits(16) element1 = Elem[operand1, e, 16];
    bits(16) element2 = Elem[operand2, e, 16];
    Elem[result, e, 16] = BFMul(element1, element2, FPCR[]);
```

```
Z[d, VL] = result;
```

[Base
Instructions](#)

[SIMD&FP
Instructions](#)

[SVE
Instructions](#)

[SME
Instructions](#)

[Index by
Encoding](#)

[Sh
Pseu](#)

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode
no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56
Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This
document is Non-Confidential.