

DCPS2

Debug Change PE State to EL2, when executed in Debug state:

- If executed at EL0 or EL1 changes the current Exception level and SP to EL2 using SP_EL2.
- Otherwise, if executed at ELx, selects SP_ELx.

The target exception level of a DCPS2 instruction is:

- EL2 if the instruction is executed at an exception level that is not EL3.
- EL3 if the instruction is executed at EL3.

When the target Exception level of a DCPS2 instruction is ELx, on executing this instruction:

- **ELR_ELx** becomes unknown.
- **SPSR_ELx** becomes unknown.
- **ESR_ELx** becomes unknown.
- **DLR_EL0** and **DSPSR_EL0** become unknown.
- The endianness is set according to **SCTLR_ELx.EE**.

This instruction is undefined at the following exception levels:

- All exception levels if EL2 is not implemented.
- At EL0 and EL1 if EL2 is disabled in the current Security state.

This instruction is always undefined in Non-debug state.

For more information on the operation of the DCPS<n> instructions, see [DCPS](#).

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	1	0	1	0	1	0	0	1	0	1	imm16										0 0 0			1	0						
LL																															

DCPS2 {#<imm>}

```
if !Halted() then UNDEFINED;
```

Assembler Symbols

<imm> Is an optional 16-bit unsigned immediate, in the range 0 to 65535, defaulting to 0 and encoded in the "imm16" field.

Operation

```
DCPSInstruction(LL);
```

[Base
Instructions](#)

[SIMD&FP
Instructions](#)

[SVE
Instructions](#)

[SME
Instructions](#)

[Index by
Encoding](#)

[Sh
Pseudocode](#)

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode
no_diffs_2023_09_RC2, sve v2023-06_rel ; Build timestamp: 2023-09-18T17:56

Copyright Â© 2010-2023 Arm Limited or its affiliates. All rights reserved. This
document is Non-Confidential.