

# Vehicle Driver Operation Manual

## Starting the Vehicle

### 1. Press the Start Button:

- Locate and press the Start button on the dashboard to begin the vehicle startup sequence.



### 1. Use RFID Tag to Unlock the Vehicle:

- While pressing the brake pedal, use the RFID tag to unlock the vehicle.



- You can see all the information on the cluster



### 1. Release the Hand Brake:

- Disengage the hand brake by pulling the lever or pressing the button, depending on your vehicle's configuration.



#### 1. **Activate Motor Controller Unit (MCU):**

- Press the brake pedal.
- Press the Park Enable button to activate the Motor Controller Unit (MCU).



## Driving Modes

- **Eco Mode:**

- Press the Eco button to move the vehicle in Eco mode, optimizing for fuel efficiency.



- **Power Mode:**

- Press the Power button to move the vehicle in Power mode, providing more performance.



- **Reverse Mode (Rev):**

- Press the Rev button to move the vehicle in reverse.



## Parking the Vehicle

- **Set to Park Mode:**
  - Press the Park button again to disable the MCU and set the vehicle to Park mode.

## Turning Off the Vehicle

1. **Release the Start Button:**
  - To turn off the vehicle, release the Start button.



## Charging the Vehicle

1. **Connect the Charger:**
  - Connect the charger to the vehicle's charging socket.



1. **Display State of Charge (SOC):**
  - Once connected, the vehicle's cluster will show only the State of Charge (SOC).



1. **Vehicle Inoperable During Charging:**

- The vehicle will not start while it is connected to the charger.

By following these steps, you can efficiently operate and charge your vehicle. Make sure to follow all safety procedures and refer to this manual whenever needed.