

Deluxe Espresso Maker 3000 - User Manual

Congratulations on your purchase!

Getting Started

Your Deluxe Espresso Maker 3000 is designed to deliver barista-quality coffee at home. Before first use, rinse all removable parts with warm water.

Parts Overview

1. Water reservoir (1.8L capacity)
2. Bean hopper with grind selector
3. Drip tray with level indicator
4. Steam wand for milk frothing
5. Cup warmer on top
6. Control panel with LCD display

Making Espresso

1. Fill water reservoir with fresh cold water
2. Add coffee beans to hopper
3. Select grind size (fine for espresso)
4. Place cup under spout
5. Press espresso button
6. Wait 25-30 seconds for extraction

Milk Frothing

1. Fill pitcher with cold milk (½ full)

2. Insert steam wand just below milk surface
3. Turn steam knob to ON position
4. Move pitcher in circular motion
5. Stop when milk reaches 65°C (150°F)
6. Tap pitcher to remove large bubbles

Cleaning and Maintenance

Daily: Empty drip tray and rinse portafilter

Weekly: Clean steam wand and run cleaning cycle

Monthly: Descale machine using provided tablets

Replace water filter every 2 months

Troubleshooting

- No water flow: Check reservoir is filled and seated properly
- Weak coffee: Adjust grind size to finer setting
- Machine not heating: Check power connection
- Loud grinding noise: Beans may contain foreign objects

Warranty: 2 years parts and labor

Customer Support: 1-800-COFFEE-3000

Website: www.espressomaker3000.com