



**GET
SAT**

BE UNSTOPPABLE



GetSAT Version Upgrade Manual

Upgrade Manual from Versions Above 4.0 to 4.6

Document # MN-181223 version 4.6

January 20, 2020

Proprietary Notice

The information and ideas contained herein are proprietary to GetSAT communications Ltd. and shall not be duplicated or disclosed outside the receiving organization or the receiving organization's potential customer without prior written approval from GetSAT communications LTD., nor used by the receiving organization or any of its subsidiaries or affiliates, for any purpose other than evaluation of the ideas and work contained herein

any data contained in this document shall not be: (i) used for purposes other than the purposes explicitly agreed under the agreement addressing the provisions of this documents; (ii) copied or duplicated; (iii) reverse engineered or de-compiled, modified or revised; or (iv) used in any illegal manner or in any way that infringes any right of any third party including the rights in connection with privacy and intellectual property rights. (v) used to copy, modify, or create derivative works or improvements of the documents or products related thereto; (vi) used to access or use the products related thereto for purposes of competitive analysis of such product, the development, provision or use of a competing software service or product or any other purpose that is to Get Sat's detriment or commercial disadvantage; (vii) any trademarks, specifications, documentation, warranties or disclaimers, or any copyright, trademark, patent or other intellectual property or proprietary rights notices shall not be removed, deleted, altered or obscured from any document, product related thereto or deliverable or any part thereof or any other materials provided by Get Sat, including any copy thereof. (viii) any export control rule, law or regulation applicable to the documents or products related thereto shall not be infringed or breached.

CONTENTS

1.	ABSTRACT.....	3
1.1	Revision History	3
2.	VERSION UPGRADE STEPS.....	4
2.1	General upgrade process steps	4
2.2	Detailed upgrade process steps	4

List of Tables

Table 1:	Revision history	3
----------	------------------------	---

1. ABSTRACT

This document describes the Milli/Micro/Nano SAT version upgrade procedure from version 4.0 and above to version 4.6 If you are upgrading from an older version, please contact GetSAT support at support@getsat.com For Help.

1.1 Revision History

Release	Date	Author	Description
Ver 4.0.0.0	July 01, 2019	Shai Hakim	Update to 4.0.0
Ver 4.5	May 03, 2020	Mark Borohov	Update to 4.5
Ver 4.5.2	June 2, 2020	Mark Borohov	Patch to 4.5
Ver 4.5.3	June 16, 2020	Mark Borohov	Patch to 4.5
Ver 4.5.5	September 15, 2020	Mark Borohov	Patch to 4.5
Ver 4.6.0	December 24, 2020	Mark Borohov	Update to 4.5
Ver 4.6.1	January 20, 2020	Mark Borohov	Patch to 4.6

Table 1: Revision history

2. VERSION UPGRADE STEPS

2.1 General upgrade process steps

1. Save the system configuration from the current version, General and Terminal
2. Upgrade the Factory default bundle with version 4.6
3. Restore the system configuration
4. Upgrade the Bundle 1 with version 4.6
5. Restore the system configuration

2.2 Detailed upgrade process steps

1. Log in to the system with WEB UI using an Admin account and navigate to Settings -> Packages.
2. Make sure that active bundle is not factory default bundle, if yes switch active bundle to operational and wait until terminal will boot once again.
3. You **MUST** save the system configuration file (you will need it after the version upgrade), under Settings -> Packages download "general" configuration and "Terminal" configuration.
4. Upgrade (Settings->Packages) the Golden firmware of factory default bundle to newest version 4.6 and wait until it will finish the upgrade.
5. Activate the Factory Default bundle and wait until terminal is booted and login as admin.
6. Navigate to Settings -> Packages, factory default bundle version should show the version that has just been updated to, if not repeat stage 4 to fix broken version number, power cycle after finishing stage 4.
7. Upload the Terminal.xml configuration on Settings->Packages via upload "Terminal" configuration. Make sure that LNB LOs and BUC LOs are in Mhz (**Note:** below 4.5.0 versions, LOs are in Ghz).
8. When upgrading from 4.0-4.2 upload the saved configuration on Settings->Packages via upload "General" configuration.
9. Power cycle the terminal.
10. Login to the terminal as admin go to Settings -> Packages, and upgrade bundle 1 to 4.6. version and wait until it will finish the upgrade.

11. After Operational firmware burn has completed successfully activate bundle 1 and wait until it will be loaded.
12. Repeat stage 8.
13. Power cycle the terminal.

Note!

Make sure that all configuration was uploaded successfully, make sure that system type, serial number, MAC address, DC remove of the spectrum and encoders calibrations are correct.