

The Icom M411 radio controls



There should be no need to use any other controls
unless a Distress Message is received

Operating the Icom M411 radio

1. Use the top right hand button to turn on.
A tone will sound for a couple of seconds to allow you to set the volume.
2. A single light press of the '**SCAN**' button will start or stop a programmed scan that reviews channels 0, 12, 16, and channel 86.
3. To select any other channel first stop the scan and use the up and down arrows to select your desired channel.

DSC Distress Function

1. Should a DSC digital emergency call be sent out a loud alarm will sound on the radio.
2. To silence the alarm press **ANY** button once.
3. The radio will now re-tune itself to Channel 16.
NOTE – if the scrolling display says '**ALL SHIPS**' it will not automatically re-tune to Ch 16. Either press '**ENT**' or use the up and down arrows to go to Channel 16.
4. Have a paper and pen available to write down any message that is sent.
5. Turn on the tape recorder so you can review the message sent later.

How to display the DSC message

The alarm has sounded and you have now noted the verbal message that followed, or, no verbal message has been received.

1. **RCV DISTRESS** will be scrolling top right in the display.
2. Press the button marked **'MENU'**.
3. Use the 'up' and 'down' arrows to select **'DSC LOG'**.
4. Press button marked **'ENT'**.
5. Press up and down arrows to display **'DISTRESS'**.
6. Press **'ENT'** again.
7. There can be up to 20 messages, use the up and down arrows to find the one with * against it.
8. Press **'ENT'** and read the message.
9. When finished press **'CLR'**.