

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	1 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

# TECHNICAL MANUAL

---

## PYCO

### Pyramid control

#### SUMMARY

---

This document describes the procedures for programming/updating the microcontroller firmware and the system configuration of the PYCO pyramid controller.

---

This document is copyright of B:ENG. All Rights Reserved. No part of this document, in whole or in part, may be used, reproduced, stored in a retrieval system or transmitted, in any form, or by any means, electronic or otherwise, including photocopying, reprinting, or recording, for any purpose, without the express written permission of B:ENG.



	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	2 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

Change history

Rev	Date	Changes	Page	From
A	2016-11-22	First edition	-	MB

Referenced documents

#	Doc.#	Rev	Type	Publisher	Title
1					

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	3 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

## Table of contents

<b>1</b>	<b>Acronyms.....</b>	<b>5</b>
<b>2</b>	<b>Introduction.....</b>	<b>6</b>
2.1	System overview .....	6
2.2	Functional scope .....	8
2.2.1	Real-time and temperature measurement .....	8
2.2.2	Music playback .....	9
2.2.3	Motion detection.....	9
2.2.4	230VAC actuator control .....	9
2.2.5	File system management .....	9
2.2.6	Display indication .....	9
2.2.7	System configuration.....	9
2.2.8	Tasks Processing .....	9
<b>3</b>	<b>System configuration .....</b>	<b>9</b>
3.1	Communication .....	9
3.2	Configuration.....	10
3.2.1	Task management .....	10
3.2.1.1	Show tasks .....	10
3.2.1.2	Add task.....	10
3.2.1.3	Remove task.....	10
3.2.1.4	Edit task .....	11
3.2.2	System parameters .....	11
3.2.2.1	Display system parameters.....	11
3.2.2.2	Edit system parameters .....	11
3.2.3	Audio.....	12
3.2.3.1	Start audio playback .....	12
3.2.3.2	Pause audio playback.....	12
3.2.3.3	Stop audio playback .....	12
3.2.3.4	Set volume.....	12
3.2.3.5	Show volume .....	12
3.2.3.6	Hide volume.....	12
3.2.4	File system.....	13
3.2.4.1	List the contents of the storage medium .....	13
3.2.4.2	Change directory .....	13
3.2.4.3	Working directory .....	13
3.2.4.4	Read file content.....	13
3.2.4.5	Delete file / folder.....	13
3.2.4.6	Index data .....	13
3.2.5	Real-time clock .....	14

	<div> <div>TECHNICAL MANUAL</div> <div>PYCO pyramid control</div> </div>	PAGE	4 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	DRAFT

3.2.5.1

Edit date and time

14

3.2.6

Display

14

3.2.6.1

Contrast

14

3.2.6.2

Brightness

14

3.2.7

Actuator

14

3.2.7.1

Activate

15

3.2.7.2

Deactivate

15

3.2.7.3

Enable All

15

3.2.7.4

Disable All

15

3.2.8

Other

15

3.2.8.1

All commands

15

3.2.8.2

Delete console content

15

3.2.8.3

Saves task list

15

3.2.8.4

Saves system parameters

16

3.2.8.5

Load task and system parameters

16

4

Firmware programming

16

List of figures

No entries for a list of figures could be found.

List of tables

No entries for a list of figures could be found.

List of open points

ToDo 1: Stuff that has to be done..... Error! Bookmark not defined.

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	5 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

## 1 Acronyms

The following acronyms have been used in this document:

Acronyms	Meaning
DC	Direct Current
ESD	Electro-Static Discharge
IC	Integrated Circuit
SMD	Surface Mounted Device
HD-SDI	High Definition - Serial Digital Interface
mS	Milli-Second
PCB	Printed Circuit Board
PoSDI	Power over SDI
PWM	Pulse Width Modulation
RS-232	Single-Ended Serial Communication Protocol
RS-422	Differential Serial Communication Protocol
RS-485	Differential Serial Multipoint Communication Protocol
SDI	Serial Digital Interface
TBD	To Be Determined
uC	Micro-Controller
uS	Micro-Second
V	Volts
CANBus	Controller Area Network
VGA	Video Graphics Array
DVI	Digital Visual Interface
PCB	Printed Circuit Board

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	6 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

## 2 Introduction

### 2.1 System overview

The system described here is a digital control system consisting of the following components (see Fig. 1):

1. 80 MHz ARM Cortex-M4 microprocessor
2. Two-line dot-matrix display NHD-0216K3Z-NSW-BBW-V3
3. Endless rotary push encoder
4. UART-RF radio module HM-TRP
5. SD card slot
6. USB2.0 interface
7. Sound card with VS1003 audio codec
8. Real-time clock (incl. temperature sensor) DS3231
9. EEPROM 32KByte
10. 8-channel relay board (230VAC 10A)
11. Infrared motion sensor HCSR501




Fig. 1 - Overall system overview







	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	9 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

- 2.2.2 Music playback
- 2.2.3 Motion detection
- 2.2.4 230VAC actuator control
- 2.2.5 File system management
- 2.2.6 Display indication
- 2.2.7 System configuration
- 2.2.8 Tasks Processing

```
> aa
```

AUFGABENLISTE													
Nr.	Id	Startzeit	Stopzeit	Aktivzeit	Bewegung	Audio	Aktor	Ch 1	Ch 2	Ch 3	Ch 4	Ch 5	Ch 6
01	01	20:58	23:08	05:30	X	X	X	X	X	-	-	-	-
02	02	23:08	23:09	05:00	-	X	X	-	-	-	X	-	-
03	03	23:10	23:12	05:00	-	X	X	-	-	X	-	X	-

Fig. 7 - Task list

## 3 System configuration

### 3.1 Communication

The system configuration is done using the supplied USB wireless adapter. This, when used on a Windows system, emulates a serial interface (COM port) and can be used in conjunction with a console programme (Putty, hTerm, ...) to configure the system at hand. The following parameters are set for communication:

**Baud rate** : 9600  
**Stopbit** : 1  
**Parity** : none  
**CTS** : none

The parameters to be set are exemplified by the hTerm programme in Fig. 8.

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	10 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>




Fig. 8 - Example of communication parameters in HTerm

3.2 Configuration

3.2.1 Task management

Task management can be controlled with the following four commands:

3.2.1.1 Show tasks

Lists all existing tasks in a table.

aa<No parameters>

3.2.1.2 Add task

Adds a task and then lists all existing tasks in a table.

ah<No parameters>

3.2.1.3 Remove task

Deletes an existing task and then lists all existing tasks in a table.

ae<Tasks Id>                      Task number                      1 - 25

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	11 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

### 3.2.1.4 Edit task

Processes an existing task with the functions listed below and then lists all existing tasks in a table.

ab -a <tasks Id>	Task number	1 - 15
-sah <starting hours>	Starting hour	0 - 23
-sam <start minute>	Start minute	0 - 59
-soh <stop hour>	Stop hour	0 - 23
-som <stop minute>	Stop minute	0 - 59
-akm <Active minute>	Active minute	0 - 59
-aks <active second>	Active second	0 - 59
-b <switch>	Motion sensor	0: Off, 1: On
-au <switch>	Audio playback	0: Off, 1: On
-act <switch>	Actuator usage	0: Off, 1: On
-ak <channel>	Actuator channel	1 - 8

### 3.2.2 System parameters

The editing of the system parameters can be controlled with the following 2 commands:

#### 3.2.2.1 Display system parameters

Lists all system parameters in a table.

sa<No parameters>

#### 3.2.2.2 Edit system parameters

Edits the system parameters with the functions listed below and then lists all parameters in a table.

from -m <switch>	Mode	0: Auto, 1: Manuel
-v <volume>	Standard volume	0 - 100
-ebz <time>	Standard fade-in/fade-out time	0 - 60 s
-dc <contrast>	Standard display contrast	1 - 50
-db <brightness>	Standard display brightness	1 - 8
-atm <time>	Standard active second	0 - 59
-ats <time>	Standard active minute	0 - 59
-bvz <time>	Standard motion delay	0: Off, 1: On

		PAGE	12 (17)
		DATE	2016-11-22

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

### 3.2.3 Audio

Audio playback can be controlled with the following 6 commands:

#### 3.2.3.1 *Start audio playback*

Starts audio playback by specifying a file path (absolute path) to a valid audio file (.wav, .mp3). If the current playback was paused by the command `pause`, it can be continued by executing `play`. In this case, **no** parameter is necessary.

```
play <audioteipath>
```

#### 3.2.3.2 *Pause audio playback*

Pauses the current audio playback.

```
pause <No parameters>
```

#### 3.2.3.3 *Stop audio playback*

Stops the current audio playback.

```
stop <No parameters>
```

#### 3.2.3.4 *Set volume*

Adjusts the playback volume.

```
lst <volume> Playback volume 0 - 100
```

#### 3.2.3.5 *Show volume*

Fades in the volume of the current audio playback. The fade-in ends when the current volume is reached.

```
einlb <time> Fade-in time (seconds) 0 - 60
```

#### 3.2.3.6 *Hide volume*

Hides the volume of the current audio playback.

```
offlb <time> Fade out time (seconds) 0 - 60
```

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	13 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

### 3.2.4 File system

The file system can be controlled with the following 6 commands:

#### 3.2.4.1 *List the contents of the storage medium*

Lists the entire content of the storage medium. This includes the name, properties and size of the respective file.

```
ls<No parameter>
```

#### 3.2.4.2 *Change directory*

Switches to the specified directory.

```
cd    <directory>          To directory to be changed
cd .. <No parameters>      Switches to the previous directory
```

#### 3.2.4.3 *Working directory*

Shows the current working directory

```
pwd<No parameter>
```

#### 3.2.4.4 *Read file content*

Reads the content of the specified file and outputs it.

```
cat    <file>              File to be read
```

#### 3.2.4.5 *Delete file / folder*

Deletes the specified file / folder(s).

```
rm     <file/folder>       File / folder to be deleted
```

#### 3.2.4.6 *Index data*

Indexes all existing data on the data carrier (max. number: 150). Order, hidden and system files are ignored.

```
Index <No parameters>
```

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	14 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

### 3.2.5 Real-time clock

The real-time clock can be controlled with the following command:

#### 3.2.5.1 *Edit date and time*

Edits the date / time and displays the result afterwards.

z	-?	Displays all real-time clock commands	
	-a	Shows the current date, Time and temperature on	
	-wt <day of the week>	Sets the day of the week	Mon, Tue, Wed, Thu, Fri, Sat, Sun
	-dd <tag>	Sets the day	1 - 31
	-mm <month>	Sets the month	1 - 12
	-yy <year>	Sets the year	0 - 99
	-h <hour>	Sets the hour	0 - 23
	-m <minute>	Sets the minute	0 - 59
	-s <second>	Sets the second	0 - 59

### 3.2.6 Display

The display can be controlled with the following commands:

#### 3.2.6.1 *Contrast*

Changes the display contrast

disp -c	<contrast>	Contrast value	1 - 50
---------	------------	----------------	--------

#### 3.2.6.2 *Brightness*

Changes the display brightness

disp -b	<brightness>	Brightness value	1 - 8
---------	--------------	------------------	-------

### 3.2.7 Actuator

	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	15 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

#### 3.2.7.1 *Activate*

Activates the specified actuator channel.

```
rly -at <channel> Actuator channel1 - 8
```

#### 3.2.7.2 *Deactivate*

Deactivates the specified actuator channel.

```
rly -from <channel> Actuator channel1 - 8
```

#### 3.2.7.3 *Enable All*

Activates all actuator channels.

```
rly -allan<no parameter>
```

#### 3.2.7.4 *Disable All*

Deactivates all actuator channels.

```
rly -alloff<no parameter>
```

### 3.2.8 Other

#### 3.2.8.1 *All commands*

Shows a list of all commands.

```
? <No parameters>
```

#### 3.2.8.2 *Delete console content*

Deletes the entire content of the console / terminal.

```
cls<No parameters>
```

#### 3.2.8.3 *Saves task list*

Saves the current task list in the file `task.cfg`



	<b>TECHNICAL MANUAL</b> <i>PYCO pyramid control</i>	PAGE	16 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

spa<No parameters>

#### 3.2.8.4 Saves system parameters

Saves the current system parameters in file `system.cfg`


sps<no parameters>

#### 3.2.8.5 Loading task and system parameters

Loads task and system parameters from the `system.cfg` and `task.cfg` files.

lad<No parameters>.

## 4 Firmware programming



	<h1>TECHNICAL MANUAL</h1> <p><i>PYCO pyramid control</i></p>	PAGE	17 (17)
		DATE	2016-11-22
		AUTHOR	MB
		DOK.#	
		REV	A
		STATUS	<b>DRAFT</b>

