

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

Initial Setup

Change your laptop's IP Address to match the drive, so they can communicate and the laptop can be used to configure the drive.

The Olympus Lexium MDrive LMDCE573 is shipped with a factory default IP Address as follows.

- IP Address: 192.168.33.1
- Subnet Mask: 255.255.0.0

1. Connect 48 VDC power to the Lexium MDrive.
2. Connect Ethernet cable from your laptop to the Lexium MDrive.
3. Change your laptop's LAN IP address to 192.168.33.220, and the subnet mask to 255.255.255.0 by doing the following:

- a. Open Network and Sharing Center.
- b. In the System Tray, right-click the network icon.




Figure PH018-12 – System Tray, Network Icon

Network Connections opens.

- c. Click "Open Network and Sharing Center".



Figure PH018-13 – Network Connections

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

Network and Sharing Center opens.

d. Click “Local Area Connection”.




Figure PH018-14 – Network and Sharing Center

Local Area Connection Status opens.

e. Click “Properties”.




Figure PH018-15 – Local Area Connection Status

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

The Local Area Connection Properties window opens.

- f. Select “Internet Protocol Version 4 (TCP/IPv4)” and click “Properties”.




Figure PH018-16 – Local Area Connection Properties

The Internet Protocol Version 4 (TCP/IPv4) Properties window opens.




Figure PH018-17 – Change IP Address and Subnet Mask

- g. Change the IP address to 192.168.33.220 and the subnet mask to 255.255.255.0.
The window should look exactly like Figure PH018-17.

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

- h. Click OK, twice, and then close the Local Area Network Status and the Network and Sharing Center.
4. On the desktop, double-click the Lexium MDrive Software Suite icon.



Figure PH018-18 – Lexium MDrive Software Suite Desktop Icon

5. When the program opens, click “Launch Lexium MDrive Ethernet Interface.”




Figure PH0 18-19 – Lexium MDrive Software

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

6. The Lexium MDrive Ethernet TCP/IP Configuration Utility opens.




Figure PH018-20 – TCP/IP Configuration Utility

7. Make sure the Connection box shows 192.168.33.1 as the IP Address.
8. Click "Connect".
9. Select the Config tab.
10. Click "Read All".

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

The window populates (see Figure PH018-21).

Note: Connection information is at the bottom of the screen.

11. Verify or change the IP address and/or subnet mask. They should be 192.168.33.1 for the IP address and 255.255.255.0 for the subnet mask.
12. Make sure the Application Protocol is EtherNet/IP.

The screenshot shows a software interface with several tabs: Manual, SEM Port, MODBUS, Config, and E.I.P. The Config tab is active. The interface is divided into several sections. A red rectangle highlights the 'IP Address /Subnet Mask/Alt.SEM Port: IOK' section, which contains input fields for IP (192, 168, 33, 1), Subnet Mask (255, 255, 255, 0), and Gateway IP (192, 168, 1, 200), each with a 'Write' button. Below this is the 'Application Protocol' section with a dropdown menu set to 'EtherNet/IP' and a 'Set' button. To the right of the red box is the 'Tftp Server IP' section with input fields and 'Write', 'Read', and 'Get local IP' buttons. Below that is the 'Ethernet Upgrade File Name' section with a text input field and 'Browse & set file name', 'Write', and 'Read' buttons. At the bottom of the main area is the 'Broadcast (Retrieve IP and serial no. of units on the network)' section with a 'UDP Broadcast' button, a 'Clear' button, and a 'Broadcast Address' field containing '255.255.255.255'. On the far right is the 'TCP/IP App Ver.' section with a 'Read' button. A status bar at the very bottom of the window displays the text: '192.168.33.220:50132 is connected to: 192.168.33.1:503'.

Figure PH018-21 – Config. Window

Make sure your screen looks exactly like Figure PH018-21.

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

13. Select the E.I.P. tab.
14. Configure the input devices to look **exactly** like Figure PH018-22.

The screenshot shows a software window titled "E.I.P." with tabs for "Manual", "SEM Port", "MODBUS", "Config", and "E.I.P.". The "E.I.P." tab is active. Inside the window, there is a section titled "Assembly Object (0x04) : fOK" and a sub-section "Valid for E.I.P. Devices Only". This section contains two main panels: "Instance 100 - Input (T->O)" and "Instance 112 - Output (O->T)".

Instance 100 - Input (T->O)

Device	Value
EF	BOOL
LR	BOOL
IN	USINT
C1	DINT
C2	DINT
ER	DINT

Instance 112 - Output (O->T)

Device	Value
C1	DINT
C2	DINT
MA	DINT
ER	DINT
RC	USINT
HC	USINT
OT	USINT
SL	DINT
LG	DINT
VM	DINT
AS	USINT
CF	USINT

Below these panels are "Get" and "Set" buttons. At the bottom of the window, there is a section "I/O Implicit connection test" with a dropdown menu set to "On" and "Get" and "Set" buttons. A status bar at the very bottom indicates "192.168.33.220:50132 is connected to: 192.168.33.1:503".

Figure PH018-22 – E.I.P Tab

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

15. Select the SEM Port tab.

To read the Lexium MDrive status parameter type “PR” + “Parameter Name”.

(i.e. PR A => parameter read acceleration setpoint.)

To set Acceleration = 1,000,000 type the following in the command line.

- A = 1,000,000 <Enter>

16. Manually set the following parameters as listed below:

- A = 1000000 <Enter> (Acceleration)
- D = 2000000 <Enter> (Deceleration)
- LD = 5000 <Enter> (Rotor Lead Limit)
- LG = 5000 <Enter> (Rotor Lag Limit)
- VM = 2000000 <Enter> (Maximum Velocity)
- AS = 2 <Enter> (Hybrid Mode => Variable Current)
- HC = 5 <Enter> (Hold Current)
- RC = 25 <Enter> (Run Current)
- S <Enter> (To Save parameter setting to Non-Volatile Memory)



Figure PH018-23 – SEM Port Tab

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

17. Test the Lexium MDrive.

To jog the Lexium MDrive for testing, type in “MR” + “Motor Counts”.

(i.e. MR 500000 => Move Relative position 500000 motor counts)

To jog clockwise 500,000 counts type in the following.

MR = 500000 <Enter>

To jog counter-clockwise 500,000 counts type in the following.

MR = -500000 <Enter>




Figure PH018-24 – Testing

18. The Lexium MDrive is now ready for Ethernet control.

Troubleshooting

The following are the meanings of the indicator lights on the Motor and the Gateway.

Motor Indicator Lights

Status indicators The Lexium MDrive has two LEDs for status indication.

- LED 1: Status of the power supply
- LED 2: Status indication. Indication functions programmed using the Lexium MDrive Pulse/direction Configuration Utility advanced mode. See Lexium MDrive Software Suite manual.

LED 1

Color	Status
Off	No Power
Green	Power supply in range
Red	Power supply out of range

LED 2

See the Pulse/direction Configuration Utility section of the Lexium MDrive Software Suite manual for available attention states.

Color	Status
Off	Not configured
Green	No attention state exists
Red	Preset attention state exists

Figure PH018-25 – Meaning of Motor Indicator LEDs

Location of LEDs on the Motor.




Figure PH018-26 – Motor LEDs

TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR SETUP AND WIRING FOR REVOLUTION GATES

Heat and Control Product Handling Systems

Gateway Indicator Lights

EtherNet/IP		
NS (Network Status - LED 1)		
Off		No power, no Ethernet connection
Red	Solid	Unrecoverable fault
	Flashing	Recoverable fault or I/O connection timed out
Green	Solid	Normal runtime operation (I/O connection allocated)
	Flashing	Device is idle or not allocated to a client (PLC)
Red+Green	Alternating	Power-up self test in progress
MS (Module Status - LED 2)		
Off		No power
Red	Solid	Unrecoverable fault
	Flashing	Minor, recoverable fault
Green	Solid	I/O connection established
	Flashing	Standby, no I/O connection established
Red+Green	Alternating	Power-up self test in progress

Location of LEDs on the Gateway.




Figure PH018-27 – Gateway LEDs

**TECHNICAL PUBLICATION PH018 – OLYMPUS LEXIUM SERVO MOTOR
SETUP AND WIRING FOR REVOLUTION GATES**

Heat and Control Product Handling Systems

Revision Record

Revision Level	Date	By	Description
Rev 00	09/13/16	Devin Riley & Arlene Mason	<ul style="list-style-type: none">Initial Release