

WARRANTY

This Canopy is covered by a 12 month warranty. The Company undertakes to replace or repair, free of charge, any defect which the Company considers to be due to faulty workmanship or material within 12 months of the purchase date, except for:

- Defects arising from neglect, misuse or unauthorised modifications.
- Damage caused by storm, abuse, misuse, dropping or other similar damage caused by or as a result of failure to follow storage or erection instructions.
- Unauthorised alterations, additions or repairs.
- Transportation or shipment costs to and from the Manufacturer or their recognised agents, for repair or assessment against a warranty claim.
- Damage caused due to UV degradation.
- Materials and/or labour costs to renew, repair or replace components due to fair wear and tear or condensation.
- Tents used on permanent sites or displays.

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.

The Manufacturer and/or their recognised agents, directors, employees or insurers will not be held liable for consequential or other damages, losses or expenses in connection with or by reason of or the inability to use the tent for any purpose.

NOTE; Any claim(s) arising due to missing parts or faulty goods MUST be made before use. The manufacturer will not be responsible for any claims regarding missing parts or faulty items where the product has not been checked by the user prior to use.



SunnCamp

FRONT FITTING CANOPIES

Covering: Family Vario & Omni Canopies


Thank you for purchasing this canopy from SunnCamp.

Before attaching the canopy to your canopy, carefully read and understand these instructions. If there is anything you do not understand, contact your retailer for advice.

By following the instructions on erecting, dismantling, packing and storing the canopy you will enjoy many years of trouble free camping.

FAMILY VARIO CANOPY

This Canopy can be fitted to the Family Vario 400, 600 and 600 Plus produced from 2007 onward.



PARTS LISTING

The Family Vario Canopy consists of the following items and you should check everything is present before setting off.

Canopy Flysheet	1
Curved Alloy Pole	1
Peg Bag	1
Carry-Bag	1

It is a requirement of the warranty that you unpack and erect this canopy at home prior to proper use. This will enable you to familiarise yourself with the canopy and check all parts are present and in good condition.

If you find any part missing or a fault with your canopy, contact the retailer before returning or using it.

GETTING STARTED

Unpack the canopy and place the carry-bag somewhere safe. Separate all components and check that everything is present.


POLES

Take the curved alloy pole and slot together.

The Poles are folded down to aid storage. When fitting the pole sections together, make sure that the pole tubes are firmly slotted together.

CANOPY FABRIC


Insert the pole into the sleeve on the front of the canopy.



Each pole end is held captive by a pin and ring which in turn are both attached to an adjustable strap running from the canopy canvas and to a spacing strap.

The spacing strap runs between both legs to ensure correct spacing.

The other end of the canopy has a tensioning strap sewn in to its edge and this should be positioned over the first upright front shock loaded pole's sleeve, not the angled built-in canopy pole. Each end of the strap should then be guided down the edge of the tent to the bottom corner and secured with tent pegs.




Adjust the strap to bring it under tension, to hold the canopy secure.

Finally, use tent pegs to secure the front pole, spacing strap and all guy ropes supplied to hold the assembly in place.

OMNI CANOPY

This Canopy can be fitted to the Ventura 400, Invader 600, Trail 400, Nirvana 500, Sunrise 400 Plus and the Family Vario models produced 2007 or earlier.



PARTS LISTING

The Omni Canopy consists of the following items and you should check everything is present before setting off.

Canopy Flysheet	1
Black Shock Corded Pole	1
Peg Bag	1
Carry-Bag	1


It is a requirement of the warranty that you unpack and erect this canopy at home prior to proper use. This will enable you to familiarise yourself with the canopy and check all parts are present and in good condition.

If you find any part missing or a fault with your canopy, contact the retailer before returning or using it.

GETTING STARTED

Unpack the canopy and place the carry-bag somewhere safe. Separate all components and check that everything is present.

POLES




Take the shock corded pole and slot together.

The Poles are folded down to aid storage. When fitting the pole sections together, make sure that the pole body is fully inserted into its adjoining ferrule.

CANOPY FABRIC

Insert the pole into the sleeve on the front of the canopy.




Each pole end is held captive by a pin and ring which in turn are both attached to an adjustable strap running from the canopy canvas and to a spacing strap.

The spacing strap runs between both legs to ensure

correct spacing. The spacing strap may become a trip hazard when erection is complete and should be ‘pinned down’ along its length using tent pegs.

Starting at one end, insert the ring pin into the end of the pole. Next, go to the other end of the pole and insert the ring pin to bring the pole under tension. The front two corners should now be secured with tent pegs.



The other end of the canopy has a tensioning strap sewn in to its edge and this should be positioned over the tent’s front shock loaded pole’s sleeve. Each end of the strap should then be guided down the edge of the tent and may be either secured to a pegging ‘O’ ring using the fitted plastic hook or alternatively secured with a tent peg.

Finally, use tent pegs to secure the front pole, spacing strap and all guy ropes supplied to hold the assembly in place.

WHICHEVER CANOPY YOU HAVE...

SAFETY

It is advisable to have a ‘Fire’ bucket filled with water, placed outside the tent. Hopefully it will never be needed, but if it is, you will be glad you made the effort.

The canopy’s fabric is fire retardant, NOT fire proof and therefore you must not smoke or use a naked flame in or near the canopy. This includes the traditional ‘camp fire’.

Guy ropes can cause a trip hazard and should be marked so that passers by can see them.

Tent pegs are also a trip hazard and should not be left ‘half in’.

CLEANING, STORING AND REPAIRS

Cleaning...

Both inside and outside of the canopy should only be cleaned using fresh clean water and a damp cloth. Do not use detergents or chemical cleaners.

Storing...

The canopy is best stored in its original carry-bag, however, if the canopy is dismantled when wet, you MUST not leave it stored until it has been thoroughly dried. After a wet pack-up, erect the canopy as soon as possible and allow to fully dry naturally before repacking in the carry-bag.

If stored when wet, the canopy will suffer from mildew and will become unusable.

Repairs...

Repairs to the canopy should only be made by the manufacturer’s recommended agents. Repairs made by an unauthorised party will make the manufacturers warranty void.

STORM AND WEATHER SUITABILITY

This canopy is designed for light use in normal weather conditions. It is not suitable for storms, gales, sub zero or tropical conditions.

UV DETERIORATION

Prolonged exposure to direct sunlight can weaken the fabric of the canopy. To avoid the risk of UV Deterioration, site the canopy in a shaded area, where it will be protected from exposure to strong sunlight.

MOISTURE

Moisture collecting on the inside of the canopy fabric is condensation caused by the occupier. It is NOT a sign of leakage.

Note that condensation, or damage caused by it, is NOT covered by the manufacturer’s warranty.

DISMANTLING

To dismantle the canopy, simply reverse the erection procedure. All poles must be dismantled and the canopy should be carefully rolled prior to placing back in the carry-bag.