

BODY CONTROL SYSTEM DTC TROUBLESHOOTING

NOTE:

- Before starting the troubleshooting, check for loose or poor contact in the BCU related circuit.
-

1. [**DTC B1 IGNITION POWER FAILURE**](#)
2. [**DTC B3 BACK-UP 1 FAILURE**](#)
3. [**DTC B11 HEADLIGHT DIMMER/PASSING LIGHT CONTROL SWITCH FAILURE**](#)
4. [**DTC B12 TURN SIGNAL SWITCH FAILURE**](#)
5. [**DTC B17 HORN SWITCH/FAVORITE SWITCH FAILURE**](#)
6. [**DTC B21/B22/B23/B24 TURN SIGNAL LIGHT FAILURE**](#)
7. [**DTC B35 HORN RELAY LOAD FAILURE**](#)
8. [**DTC B83 SEL LEFT SWITCH/BACK SWITCH/SEL UP SWITCH/SEL DOWN SWITCH FAILURE**](#)
9. [**DTC B91 \(101-2\) BCU EEPROM MALFUNCTION**](#)