

Screen History PILLION STEP > REMOVAL/INSTALL... ▼

S2MLF000A020027S2MLF000B020041



REMOVAL/INSTALLATION

Remove the pillion step bracket bolts [1] and pillion step assembly [2].

Installation is in the reverse order of removal.

TORQUE:

Pillion step bracket bolt:
32 N·m (3.3 kgf·m, 24 lbf·ft)

NOTE:

- Apply grease to the pillion step joint pin sliding area.

Left side shown:

