

IGNITION COIL TRAY DISASSEMBLY/ASSEMBLY

[Remove the ignition coil tray assembly.](#)

Release the wire clip [1].

Remove the bolts [2].

Disconnect the following:

- No. 1-1 ignition coil connectors [3]
- No. 1-2 ignition coil connectors [4]
- No. 2-1 ignition coil connectors [5]
- No. 2-2 ignition coil connectors [6]

Remove the following parts from the ignition tray [7]:

- No. 1-1 ignition coil [8]
- No. 1-2 ignition coil [9]
- No. 2-1 ignition coil [10]
- No. 2-2 ignition coil [11]
- Ignition sub harness [12]

Installation is in the reverse order of removal.

NOTE:

- [Route the wire harness properly.](#)



