

PRIOR DIAGNOSIS

Before processing the DTC troubleshooting, check as follows:

- Check for loose or poor contact on the DTC related connectors (each sensor, solenoid, unit etc.), then recheck the DTC.
- [Erase the DTC](#) and recheck it.
- Refer to probable cause of each detected DTC and check the listed items first. If possible, correct the abnormally.

NOTE:

- Always turn the ignition switch OFF when checking the continuity of the circuit and before disconnecting the connectors.
- Some DTCs have a recheck function, so that the priority DTC is detected when the ignition switch is switched from OFF to ON. Wait for 10 seconds and check the DTC again.