

ABBREVIATION

Throughout this manual, the following abbreviations are used to identify the respective parts or systems.

Abbrev. term	Full term
ABS	Anti-lock Brake System
A/F sensor	Air/Fuel sensor
APS	Accelerator Position Sensor
BCU	Body Control Unit
CAN	Controller Area Network
CKP sensor	Crankshaft Position sensor
DCT	Dual Clutch Transmission
DLC	Data Link Connector
DRL	Daytime running light
DTC	Diagnostic Trouble Code
ECM	Engine Control Module
ECT sensor	Engine Coolant Temperature sensor
EOP sensor	Engine Oil Pressure sensor
EOP switch	Engine Oil Pressure switch
EOT sensor	Engine Oil Temperature sensor
ESS	Emergency Stop Signal
EVAP	Evaporative Emission
GP sensor	Gear Position sensor
GST	Generic Scan Tool
HSTC	Honda Selectable Torque Control
HISS	Honda Ignition Security System
IAT sensor	Intake Air Temperature sensor
MAP sensor	Manifold Absolute Pressure sensor
MCS	Motorcycle Communication System
MID	Multi Information Display
MIL	Malfunction Indicator Lamp
MT	Manual Transmission
OBD	On-Board Diagnostic
PAIR	Pulse Secondary Air Injection
PGM-FI	Programmed Fuel Injection
SCS	Service Check Signal
TBW	Throttle By Wire
TCM	Transmission Control Module
TP sensor	Throttle Position sensor
TR sensor	Transmission Range sensor
VS sensor	Vehicle Speed sensor