

## FUEL FLOW INSPECTION

[Disconnect the quick connect fitting from the fuel rail.](#)

Place the end of the fuel feed hose [1] into an approved fuel container.

**NOTE:**

- Clean up any spilled fuel.

Temporarily connect the battery negative (–) cable and fuel pump unit 5P (Black) connector.

Turn the ignition switch ON.

Measure the amount of fuel flow.

**NOTE:**

- The fuel pump operates for 2 seconds.  
Repeat this procedure 5 times to meet the total measuring time.
- Return fuel to the fuel tank when the measurement is completed.

Amount of fuel flow:
<b>319 cm<sup>3</sup> (10.8 US oz, 11.2 Imp oz) minimum/ 10 seconds at 12 V</b>

If the fuel flow is less than specified, inspect the following:

- Pinched or clogged fuel hose or fuel tank breather hose
- [Fuel pump unit](#)

[Connect the quick connect fitting.](#)



