

REMOVAL/INSTALLATION

[Remove the right rear side cowl.](#)

Release the starter relay [1] from the stay.

Disconnect the relay connector [2] and remove the starter relay.

Installation is in the reverse order of removal.

- [For relay inspection](#)

