

REMOVAL/INSTALLATION

Remove the thermostat.

Disconnect the ECT sensor 2P (Black) connector [1].

Remove the ECT sensor [2] and O-ring [3].

Installation is in the reverse order of removal.

TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)

NOTE:

- Do not apply oil to the O-ring.
- Check the O-ring and replace if necessary as a ECT sensor assembly.

