

REMOVAL/INSTALLATION

Remove the Fuel tank.

Remove the front cross plate bolts [1] and front cross plate [2].

Installation is in the reverse order of removal.

TORQUE:

Front cross plate bolt:

12 N·m (1.2 kgf·m, 9 lbf·ft)

