

## REMOVAL/INSTALLATION

### Remove the main seat.

Remove the power box cover and fuel relay [1].  
Installation is in the reverse order of removal.

- For relay inspection

