

REMOVAL/INSTALLATION

[Remove the main seat.](#)

Remove the power box cover and fan relay [1].
Installation is in the reverse order of removal.

- [For relay inspection](#)

