

## REMOVAL/INSTALLATION

Remove the following:

- [Shock absorber](#)
- Radiator reserve tank mounting bolt [1]
- Spring [2]

Remove the radiator reserve tank [3] by releasing the boss [4] from the frame.

Disconnect the siphon hose [5] and drain the coolant.

Installation is in the reverse order of removal.

**NOTE:**

- [Route the radiator reserve tank drain hose \[6\] properly](#).

